



Steering System Maintenance Guidelines



Hazard Warning Definitions

 WARNING	A warning describes hazards or unsafe practices which could result in severe personal injury or death.
 CAUTION	A caution describes hazards or unsafe practices which could result in personal injury or product or property damage.
NOTE	A note gives key information to make following a procedure easier or quicker.

Notice

This guide was prepared for the purpose of providing general advice concerning the diagnosis and correction of commercial vehicle steering related problems. This guide is intended for the use of properly trained, professional mechanics, NOT “Do-it-Yourselfers”. Also, this guide should be used in conjunction with service manuals provided by both the vehicle and component manufacturers. Diagnosis and correction of commercial vehicle steering related problems should only be handled by properly trained, professional mechanics who have the proper equipment, tools, instructions and know-how to perform the work properly and safely.

Power Steering System Analyzer (PSSA) Gauge


Some of the tests in this manual require the use of a PSSA. This device is a combination flow meter, shut-off valve, and pressure gauge. This tool will allow you to measure flow and pressure, and provide a load on the pump through the hydraulic lines of the steering system. This tool is required to correctly analyze a steering system. TRW recommends that you **DO NOT BEGIN TROUBLESHOOTING A STEERING SYSTEM WITHOUT THE USE OF A PSSA**. If you are not sure how to use a PSSA, you may refer to the video available through our website at: www.trucksteering.com. This video compliments the tests in this book which require the use of the PSSA.

 WARNING	Throughout this troubleshooting guide, test procedures are recommended to help locate the cause of each complaint. While performing these tests, TRW advises that you TAKE NECESSARY PRECAUTIONS when working with internal vehicle components and hot hydraulic fluids.
--	---

Table of Contents

Preventative Maintenance Guidelines	5
Approved Fluids and Grease	6
Input Shaft Seal Replacement	7
Seal Removal	8
Seal Inspection	9
Sector Shaft Adjustment	10
Poppets	11
Resetting Criteria	11
System Identification	12
Initial Poppet Setting Procedure	12
Poppet Resetting Single Gear System	13
Poppet Resetting Mirror System	15
Poppet Resetting Reverse System	17
Main Gear Adjustment	18
Rotary Cylinder Adjustment	18
Air Bleeding the Steering System	19
Visual Identification	19
Auto Bleed Gears	19
Manual Bleed Gears	20
Flushing the Steering System	21
Power Steering System Analyzer (PSSA) Application and Use ..	23
Installing the PSSA	23
Power Steering Pump Test	25
Poppet Trip Pressure Test	26
Test Result Charts	28
PSSA Installations (Various Gear Configurations)	29
Linkage Inspection, Maintenance, Replacement, and Adjustment	30
Maintenance Checklist	30
Tie Rod End Replacement	31
Draglink - One End Adjustable	32
Draglink - Two end Adjustable	33
Tie Rod Tube Assembly - One End Adjustable	34
Tie Rod Tube Assembly - TwoEnd Adjustable	35
Drop Center Tie Rod Tube Assembly - One End Adjustable	36

Preventive Maintenance Guidelines



⚠ CAUTION

Never high pressure wash or steam clean a power steering gear while on or off the vehicle. This will force contaminants into the gear, especially through the side cover vent plug hole, input shaft seal, and output shaft seal areas. These contaminants could destroy seals, bushings, and bearings. Resulting in a reduction of steering gear performance.

Approved Hydraulic Fluids

The type of fluid used in the power steering system is vital to extend both the life of the components and its seals. It is necessary to utilize a steering system fluid that is specified and approved by the vehicle manufacturer and also complies with TRW Commercial Steering Systems' recommendation.

It is recommended that any fluid specification, outside of the compliant lubricant listed, be reviewed by TRW to ensure the compatibility between the component and fluid type being used.

TRW recommends using one of the following fluids in the power steering system.

Automatic Transmission Fluid

- Dexron II
- Dexron III
- Ford Mercon

NOTE

The steering system should be kept filled with one of the above fluids.

⚠ CAUTION

Completely flush the steering system when changing to another fluid. Replace the reservoir filter after flushing the system. Fill the system with one of the recommended fluids above, only. Do not mix fluid types. Any mixture or any unapproved oil could lead to seal deterioration and leaks. A leak could ultimately cause the loss of fluid, which could result in a loss of power steering assist.

Be sure to bleed the air out of the system before putting the vehicle back into service.

Approved Grease

#2 NLGI extreme pressure, lithium based, moly filled, heavy duty grease.
Mobil SHC100 for use on greasable intermediate column slip joint

NOTE

More specific procedures and intervals can be found in the vehicle manufacturers service manual. These procedures are TRW's general guidelines for steering related preventive maintenance. Service manuals and technical bulletins are also available through our website.

Input Shaft Seal Replacement

Detecting Input Shaft Seal Leakage

TRW power steering gears incorporate an “Umbrella” style external dirt seal between the steering shaft U-joint and the housing of the steering gear. The cavity under this seal is filled by TRW at assembly with a special grease to inhibit corrosion of the input shaft near the input shaft seal. Since this “Umbrella” does not positively interfere with the main housing, some amount of the grease under it can migrate to the external housing surfaces. Over time, especially under elevated operating temperatures, some of the base oil in the grease can separate from the carrier. This thin film of oil can spread over the upper part of the gear, attract dust and dirt, causing the appearance that the input shaft seal is leaking power steering fluid.

Initial inspection criteria to determine if the input shaft seal is leaking:

- If the dust/dirt in this area is “dry” (not saturated or not dripping fluid) the input shaft seal is operating properly.
- If it has not been necessary to replenish the reservoir fluid level frequently, the input shaft seal is operating properly.
- If the dust /dirt is “Wet” or appears as “caked mud” then a closer look is required.

Additionally, the following are other causes that may present false indications of input shaft seal leakage.

- Look for signs of over-greasing the U-joint yoke (which can spread to the input shaft seal of the steering gear over time, creating an appearance of leakage), leaking power steering hoses (they are usually covered with a “wet mud” when the rubber part starts to fail).
- Oil leaks can occur at the hose fittings which give a false indication of a steering gear input shaft seal leak.
- On many vehicles, the reservoir is located directly over the steering gear. Overfilled or leaking reservoirs can drip onto the steering gear resulting in a false indication of an input shaft seal leak.

In order to determine if the input shaft seal is leaking, do the following:

1. Wipe down the area of the steering gear around the input shaft seal and hose connections.

⚠ CAUTION

Never high pressure wash or steam clean a power steering gear while on or off the vehicle. This will force contaminants into the gear, especially through the side cover vent plug hole, input shaft seal, and output shaft seal areas. These contaminants could destroy seals, bushings, and bearings. Resulting in a reduction of steering gear performance.

2. With the vehicle parked and a temperature gauge inserted in the reservoir, observe the input shaft seal area and hose connections while running the engine and steering the vehicle for 5-10 minutes. The oil temperature should be 130° - 160° F when observing seal area and hose connections.

⚠ CAUTION

Do not let oil temperature exceed 250° F while performing this maneuver.

Conclusions:

- If fluid leakage is noted from the reservoir, hose, fittings, or other plumbing connections, repair the problem and retest.
- If no fluid leakage is observed, then the appearance of leakage is likely a migration of grease not a seal failure.

Seal Removal

This procedure uses the vehicle's power steering pump to force out the input shaft seal. To use this procedure, the power steering pump should have a minimum of 1,500 psi available.

1. Place a drip pan on the floor to catch the oil.
2. Disconnect return line (Figure 1) from the steering gear. Plug the return line and cap the return port of the gear with high pressure fittings
3. Disconnect the intermediate column from the steering gear's input shaft. Clean the input shaft end of the steering gear.
4. Remove the dirt and water seal from the steering gear.
5. Wipe out the grease from behind the dirt and water seal.
6. Insert a small screwdriver into the notch formed in the end of the spiral retaining ring (Figure 2). Remove the retaining ring. Be careful not to scratch the bore with the screwdriver.
7. Slip the intermediate column back onto the input shaft with the pinch bolt installed, but not tightened.
8. Tie a clean shop towel (Figure 3) around the input shaft area to reduce oil spatter.
9. Check the reservoir, and add fluid if necessary, until the level is at the "full" mark on the dipstick. Do not mix fluid types.
- ⚠ CAUTION**
Any mixture of fluid types, or use of any unapproved fluid could lead to seal deterioration and leaks. A leak could ultimately cause the loss of fluid, which could result in a loss of power steering assist.
10. With the vehicle in neutral, momentarily turn the starter (quickly turn off the engine if it starts).
11. Remove the shop towel. Disconnect the intermediate column (Figure 4), and remove the input shaft seal (Figure 5).



Figure 1




Figure 2



Figure 3




Figure 4



Figure 5




Figure 6




Figure 7



Figure 8



Figure 9




Figure 10

Seal Inspection

1. Check the seal area of the valve housing for any seal fragments. Remove all debris.
2. Check the seal for heat damage. If the seal is stiff and brittle, and not pliable like the new seal (Figure 6), it is probably heat damaged. Determine and fix the cause of excessive heat in the steering system.

Seal Installation

1. Put clean grease (provided in the kit) on the inside diameter of the new input shaft seal, and place it over the input shaft.
2. Place small diameter-end of the seal installer tool (J37073) over the input shaft and against the seal (Figure 7). Tap the seal installer tool until the tool shoulder is square against the valve housing. Remove any seal material that may have sheared off in the seal bore or retaining ring groove.

⚠ CAUTION

Do not use a socket to install this seal because you will not be able to control seal installation depth, possibly causing a leak.

3. Insert new retaining ring into the groove (Figure 8).
4. Pack the end of the valve housing bore around the input shaft with grease (provided in the kit). Choose the correct size of the new dirt & water seal by comparing it to the old seal, or by measuring the major diameter of the input shaft serrations (see chart below). Apply more grease to the back-side of the new dirt & water seal and install it over the input shaft (Figure 9). Seat it in the groove behind the serrations and against the valve housing.

Seal Part Number	Serration Size	Major Serration Diameter
478044	13/16" x 36	0.807 / 0.799
478060	7/8 x 36	0.866 / 0.857
478050	1" x 36	0.987 / 0.977
478050	1" x 79	1.008 / 1.000

5. Reconnect the intermediate column (Figure 10) to the input shaft and tighten the pinch bolt to torque level specified by the vehicle manufacturer.
6. Reconnect the return line to the steering gear return port. Then, refill the reservoir if necessary.
7. Air bleed the system using the procedure outlined by TRW.

Sector Shaft Adjustment

The sector shaft adjustment procedure can only be completed on the vehicle if the adjusting screw and jam nut are accessible. This nut is located on the side cover.

1. With the engine on, rotate the steering wheel until the wheels are straight ahead and the timing mark on the sector shaft (Figure 1) lines up with the mark on the housing. The line on the sector shaft should be at a 90° angle from the input shaft. The sector shaft is now centered and prepared for the adjustment.
2. Turn the vehicle off.
3. Remove the draglink from the pitman arm.
4. To avoid resetting the poppets, do not rotate the input shaft more than 1 1/2 turns from the “centered” position while the draglink is disconnected.
5. While in the “centered” position, grasp the pitman arm (Figure 2) and gently try to rotate it back and forth. If looseness or lash is felt at this point, the sector shaft is out of adjustment.
6. Loosen the jam nut.
7. If no lash was detected in Step 4, turn the shaft adjusting screw (Figure 3) counterclockwise until you feel lash at the output shaft.
8. Slowly turn the sector shaft adjusting screw clockwise until you feel no lash using only slight pressure on the pitman arm, about 10 ft•lb of torque.
9. Hold the adjusting screw in place, and tighten the jam nut. Torque the jam nut to 43 ft•lb (58 N•m).
10. Turn the steering wheel 1/4 turn each side of center, then back to center and recheck the pitman arm for lash. If you still feel lash, repeat the procedure.
11. Reconnect the draglink to the pitman arm. Torque the nut to approved vehicle manufacturer’s specifications and reinsert cotter pin.
12. Maintain grease in the sector shaft bearing through the grease fitting (Figure 4) in the housing using only a hand operated grease gun. Add grease until it begins to purge past the dirt and water seal.

⚠ CAUTION

Do not use a power grease gun because it will supply grease too fast; this could adversely affect the high pressure seal and contaminate the hydraulic fluid.



Figure 1




Figure 2




Figure 3




Figure 4

Poppets

What are Poppets?

Poppets are pressure unloading valves, inside the rack piston, that “relieve” *just before* a full turn is made in each direction. When poppets are set or reset correctly, system pressure will be reduced before the axle stop bolt contacts the axle stop in both directions.



Poppet Resetting Criteria

Poppets on TRW steering gears do not have to be reset, unless the vehicle has been modified in such a way that wheelcut for the vehicle is decreased.

If the gear has a fixed stop bolt and you are decreasing the vehicle’s wheelcut, you will need a new poppet adjusting screw and jam nut. If wheelcut is being increased, the poppets will reset automatically. In this case, refer to the Poppet Setting procedure.

Examples of modifications that require poppet resetting include:

- Changing to larger tires
- Reducing wheelcut for any reason
- Steer axle U-bolts were bent or broken
- If the pitman arm was mistimed and was retimed
- Axle stop bolts were damaged and have been replaced
- Or when the steering gear has been mounted on a different vehicle.

NOTE

Use the POPPET RESETTING PROCEDURES only if you made a modification to the vehicle as outlined in the list above.

System Identification

Before resetting poppets on a steering gear, you must identify the type of system with which you are working.


For single gear and a gear with linear assist cylinders, use the Single Gear Poppet Resetting procedure.

On a dual gear system, you must determine whether the system has either mirror image gears or reversed image gears. The procedures are slightly different for each type of system, so use the following criteria to identify which method applies to your application.


1. Park the vehicle with the wheels turned all the way to the axle stop in either direction. Turn the vehicle off.
2. Look at the output shaft timing mark nearest the housing piston bore on the main gear. Is this mark pointing toward the poppet screw or away from it?
3. Now check the output shaft timing mark nearest the housing piston bore on the rotary cylinder. Does it point toward the poppet screw or away from it?

Use the MIRROR SYSTEM procedure if the timing marks point to opposite ends of the gears.

Use the REVERSE SYSTEM procedure if both timing marks point toward the poppet screws or both point toward the end opposite the poppet screws.



Mirror System



Reverse System

Initial Poppet Setting Procedure

For this procedure to work correctly, you must have 1) A new or remanufactured gear received from TRW or your vehicle manufacturer's aftermarket system, or 2) a used gear on which poppet seats have been replaced or reset during gear disassembly and assembly procedures. Also, a fixed stop bolt or a poppet adjusting screw must be part of the steering gear assembly.

To set the poppets on a new or remanufactured steering gear, follow these simple steps.

1. Make sure the axle stop bolts are set to vehicle manufacturer's wheelcut or clearance specifications.
2. Raise the front end so the steer axle tires are off the ground.
3. Start the engine and let it idle.
4. Steer the vehicle in in one direction, until you contact the axle stop. Pull hard on the steering wheel.
5. Now, steer the vehicle in the opposite direction until you contact the axle stop. Again, pull hard on the steering wheel.
6. Turn the vehicle off.




Figure 1



Figure 2




Figure 3




Figure 4



Figure 5

Single Gear Poppet Resetting Procedure

1. Set the axle stops to vehicle manufacturer's wheelcut or clearance specifications.
2. Make sure the engine is off and the road wheels are in the straight ahead position.
3. Remove and discard the poppet fixed stop bolt and washer (Figure 1, if equipped) from the lower end of the housing. If the gear has a poppet adjusting screw and jam nut that need to be replaced, remove and discard them at this point also.
4. If a new poppet adjusting screw and nut are being used, turn the screw into the non-sealing end of the jam nut until the Allen drive end of the screw is flush with the nut (Figure 2).

⚠ CAUTION

Be sure the Allen drive end of the screw is not below the face of the nut. Failing to keep it flush with the face of the nut will cause the poppet seat flange to break later on during this procedure.

5. If the adjusting screw is already part of the steering gear (Figure 3), back the nut off of the adjusting screw until it is flush with the Allen drive end of the adjusting screw.
6. Turn the new adjusting screw and jam nut into the housing until the nut is firmly against the housing using an Allen wrench. Tighten the jam nut against the housing.
7. Refill the system reservoir with approved hydraulic fluid.

⚠ CAUTION

Do not mix fluid types. Mixing of transmission fluid, motor oil, or other hydraulic fluids will cause seals to deteriorate faster.

8. Place a jack under the center of the front axle and raise the front end of the vehicle so the steer axle tires are off the ground.
9. Start the engine and let it run at idle speed.
10. Note which output shaft timing mark is nearest the housing piston bore.
11. Turn the steering wheel in the direction that makes this timing mark move toward the adjusting screw you just installed (Figure 4). Turn in this direction until axle stop contact is made.
12. Pull hard (Figure 5) on the steering wheel (put up to 40 lb rim pull on a 20" dia. steering wheel) after the axle stop is contacted.

⚠ CAUTION

Do not hold the steering wheel at full turn for more than 10 seconds at a time; the heat build-up at pump relief pressure may damage system components.

13. Turn the steering wheel in the opposite direction (end of timing mark away from adjusting screw, Figure 6) until the other axle stop is contacted.
14. Pull hard on the steering wheel.
15. Release the steering wheel and shut off the engine.
16. Loosen the jam nut and back out the adjusting screw until 1" is past the nut (Figure 7). Tighten the jam nut against the housing.
17. Start the engine and let it idle.
18. Turn the steering wheel, so that the timing mark on the output shaft points toward the adjusting screw, until axle stop contact is made.
19. Pull hard on the steering wheel and hold it in this position for no more than 10 seconds at a time, then release to allow the system to cool.
20. Repeat this hold and release process while completing steps 21-22.
21. Loosen the jam nut and hold it in place with a wrench so it will not contact the housing.
22. With steering wheel held at full turn, turn the adjusting screw in (clockwise) using finger-pressure only (do not use a ratchet), until the Allen wrench stops (Figure 8). At this point, the adjusting screw has contacted the poppet seat. Do not attempt to turn it in farther.

NOTE

Pause the turning-in process each time the driver releases the steering wheel; continue turning the adjusting screw in only while the wheel is held at full turn.

23. Back off the adjusting screw $3\frac{1}{4}$ turns and tighten the jam nut. Torque the jam nut to 35 ft•lbs.

The poppets have now been reset. Lower the vehicle and remove the jack.

Be sure to check the reservoir and fill if required.

NOTE

Do not remove the adjusting screw, it is now part of the steering gear assembly.

NOTE

The length of the poppet adjusting screw beyond the nut may be different for each vehicle, but must be no more than $1\frac{1}{16}$ " for proper thread engagement (Figure 9).




Figure 6



Figure 7




Figure 8



Figure 9

Poppet Resetting - Mirror System

This resetting procedure will work in most cases with at least $1\frac{3}{4}$ hand-wheel-turns from each side of center. If you're making a large reduction in wheelcut and this procedure does not work, you may have to replace or internally reset the poppets using the procedure described in the appropriate gear service manual.

1. Set the axle stops to vehicle manufacturer's wheelcut or clearance specifications.
2. Make sure the engine is off and the road wheels are in straight ahead position.
3. Remove and discard the poppet fixed stop bolt and washer (if equipped) from the lower end of the housing on both the main gear and the rotary cylinder. If either unit has a poppet adjusting screw and jam nut that need to be replaced, remove and discard them at this point also.

If a new poppet adjusting screw and nut are being used, turn the screws into the non-sealing end of the jam nuts until the Allen drive end of the screw is flush with the nut.

⚠ CAUTION

Be sure the Allen drive end of the screw is not below the face of the nut. Failing to keep it flush with the face of the nut will cause the poppet seat flange to break later on during this procedure.

4. If the adjusting screw is already part of the main gear or rotary cylinder, back the nut off of the adjusting screw until it is flush with the Allen drive end of the adjusting screw.
5. Turn the new adjusting screw and jam nut (without rotating the jam nut on the screw) into the housing until the jam nut is firmly against the housing, on both the main gear and the rotary cylinder, using an Allen wrench. Tighten the jam nut against the housing.
6. Refill the system reservoir with approved hydraulic fluid.

⚠ CAUTION

Do not mix fluid types. Mixing of transmission fluid, motor oil, or other hydraulic fluids will cause seals to deteriorate faster.

7. Place a jack under the center of the front axle and raise the front end of the vehicle so the steer axle tires are off the ground.
8. Start the engine and let it run at idle speed.
9. Note which output shaft timing mark is nearest the housing piston bore.
10. Turn the steering wheel in the direction that makes this timing mark move toward the adjusting screw you just installed on the main gear. Turn in this direction until axle stop contact is made.
11. Pull hard on the steering wheel (put 40 lbs. rim pull on a 20" dia. steering wheel) after the axle stop is contacted.

⚠ CAUTION

Do not hold the steering wheel at full turn for more than 10 seconds at a time; the heat build-up at pump relief pressure may damage system components.

12. Turn the steering wheel in the opposite direction (end of timing mark points away from adjusting screw on the main gear) until the other axle stop is contacted.
13. Pull hard on the steering wheel.

14. Release the steering wheel and shut off the engine.
15. Loosen the jam nut and back out the adjusting screw, on both the main gear and the rotary cylinder, until 1" is past the nut. Tighten the jam nuts against the housings.
16. Start the engine and let it idle.
17. Turn the steering wheel, so that the timing mark on the main gear output shaft points toward the adjusting screw, until axle stop contact is made.
18. Pull hard on the steering wheel and hold it in this position for no more than 10 seconds at a time, then release to allow the system to cool.
19. Repeat this hold and release process while completing the following steps for both the main gear and rotary cylinder adjustments.

NOTE

Pause the turning-in process each time the driver releases the steering wheel; continue turning the adjusting screw in only while the wheel is held at full turn.

Main Gear Adjustment

1. With steering wheel held at full turn, loosen the jam nut on the main gear, and hold it in place with a wrench so it will not contact the housing.
2. Turn the adjusting screw in (clockwise) using finger-pressure only (do not use a ratchet), until the Allen wrench stops. At this point, the adjusting screw has contacted the poppet seat. Do not attempt to turn it in farther.
3. Back off the adjusting screw $3\frac{1}{4}$ turns and tighten the jam nut. Torque the jam nut to 35 ft•lbs.

Rotary Cylinder Adjustment

1. Turn the steering wheel in the opposite direction, so that the timing mark on the main gear output shaft points away from the adjusting screw, until axle stop contact is made.
2. With steering wheel held at full turn, loosen the jam nut on the rotary cylinder and hold it in place with a wrench so it will not contact the housing.
3. Turn the adjusting screw in (clockwise) using finger-pressure only (do not use a ratchet), until the Allen wrench stops. At this point, the adjusting screw has contacted the poppet seat. Do not attempt to turn it in farther.
4. Back off the adjusting screw $3\frac{1}{4}$ turns and tighten the jam nut. Torque the jam nut to 35 ft•lbs.
5. The poppets on both the main gear and rotary cylinder have now been reset. Lower the vehicle. Check the fluid level in the reservoir and fill if required.

NOTE

Do not remove the poppet adjusting screws, they are now part of the main gear and rotary cylinder assemblies.

NOTE

The length of the poppet adjusting screw beyond the nut may be different for each vehicle, but must be no more than $1\frac{1}{16}$ " for proper thread engagement.

Poppet Resetting - Reverse System

This resetting procedure will work in most cases with at least $1\frac{3}{4}$ hand-wheel-turns from each side of center. If you're making a large reduction in wheelcut and this procedure does not work, you may have to replace or internally reset the poppets using the procedure described in the appropriate gear service manual.

1. Set the axle stops to vehicle manufacturer's wheelcut or clearance specifications.
2. Make sure the engine is off and the road wheels are in straight ahead position.
3. Remove and discard the poppet fixed stop bolt and washer (if equipped) from the lower end of the housing on both the main gear and the rotary cylinder. If either unit has a poppet adjusting screw and jam nut that need to be replaced, remove and discard them at this point also.

If a new poppet adjusting screw and nut are being used, turn the screws into the non-sealing end of the jam nuts until the Allen drive end of the screw is flush with the nut.

⚠ CAUTION

Be sure the Allen drive end of the screw is not below the face of the nut. Failing to keep it flush with the face of the nut will cause the poppet seat flange to break later on during this procedure.

4. If the adjusting screw is already part of the main gear or rotary cylinder, back the nut off of the adjusting screw until it is flush with the Allen drive end of the adjusting screw.
5. Turn the new adjusting screw and jam nut (without rotating the jam nut on the screw) into the housing until the jam nut is firmly against the housing, on both the main gear and the rotary cylinder, using an Allen wrench. Tighten the jam nut against the housing.
6. Refill the system reservoir with approved hydraulic fluid.

⚠ CAUTION

Do not mix fluid types. Mixing of transmission fluid, motor oil, or other hydraulic fluids will cause seals to deteriorate faster.

7. Place a jack under the center of the front axle and raise the front end of the vehicle so the steer axle tires are off the ground.
8. Start the engine and let it run at idle speed.
9. Note which output shaft timing mark is nearest the housing piston bore.
10. Turn the steering wheel in the direction that makes this timing mark move toward the adjusting screws you just installed on both the main gear and the rotary cylinder. Turn in this direction until axle stop contact is made.
11. Pull hard on the steering wheel (put 40 lbs. rim pull on a 20" dia. steering wheel) after the axle stop is contacted.

⚠ CAUTION

Do not hold the steering wheel at full turn for more than 10 seconds at a time; the heat build-up at pump relief pressure may damage system components.

12. Turn the steering wheel in the opposite direction (end of timing mark points away from adjusting screw) until the other axle stop is contacted.
13. Pull hard on the steering wheel.

14. Release the steering wheel and shut off the engine.
15. Loosen the jam nut and back out the adjusting screw until 1" is past the nut on both the main gear and the rotary cylinder. Tighten the jam nut against both housings.
16. Start the engine and let it idle.
17. Turn the steering wheel, so that the timing mark on the output shaft points toward the adjusting screw, until axle stop contact is made.
18. Pull hard on the steering wheel and hold it in this position for no more than 10 seconds at a time, then release to allow the system to cool.
19. Repeat this hold and release process while completing the following steps. First on the main gear, then on the rotary cylinder.

NOTE

Pause the turning-in process each time the driver releases the steering wheel; continue turning the adjusting screw in only while the wheel is held at full turn.

Main Gear Adjustment

1. With steering wheel held at full turn, loosen the jam nut on the main gear, and hold it in place with a wrench so it will not contact the housing.
2. Turn the adjusting screw in (clockwise) using finger-pressure only (do not use a ratchet), until the Allen wrench stops. At this point, the adjusting screw has contacted the poppet seat. Do not attempt to turn it in farther.
3. Back off the adjusting screw 3¼ turns and tighten the jam nut. Torque the jam nut to 35 ft•lbs.

Rotary Cylinder Adjustment

1. With steering wheel held at full turn, loosen the jam nut on the rotary cylinder and hold it in place with a wrench so it will not contact the housing.
2. Turn the adjusting screw in (clockwise) using finger-pressure only (do not use a ratchet), until the Allen wrench stops. At this point, the adjusting screw has contacted the poppet seat. Do not attempt to turn it in farther.
3. Back off the adjusting screw 3¼ turns and tighten the jam nut. Torque the jam nut to 35 ft•lbs.
4. The poppets on both the main gear and rotary cylinder have now been reset. Lower the vehicle. Check the fluid level in the reservoir and fill if required.

NOTE

Do not remove the poppet adjusting screws, they are now part of the main gear and rotary cylinder assemblies.

NOTE

The length of the poppet adjusting screw beyond the nut may be different for each vehicle, but must be no more than 1⅞" for proper thread engagement.

Air Bleeding the Steering System

Visual Identification

When you air bleed a steering system, you are simply allowing air trapped in the cavities of the steering gear to escape. As a general rule, if your steering gear is a “standard mount”, you should use the Automatic Bleed method. If your gear is an “inverted mount”, you will need to use the Manual Bleed method to purge the trapped air from the gear.





Automatic Bleed Gears

1. Fill the reservoir.
2. Start the engine, let it run for 10 seconds - without steering, then shut it off.
3. Check the reservoir, and refill if the fluid level has dropped.
4. Repeat at least three times, checking and refilling the reservoir each time if necessary.

NOTE

Do not allow the fluid level to drop significantly or run out of the reservoir. This may induce air into the system.

5. Start the engine and let it idle for 2 minutes - without steering. Shut off the engine and check the fluid level in the reservoir. Refill if required.
6. Start the engine again. Steer the vehicle from full left to full right several times. Automatic bleed systems should now be free from trapped air.
7. Finally, be sure to check the fluid level in the reservoir. Refill if necessary before returning the vehicle to service.



Manual Bleed Gears

1. Fill the reservoir.
2. Start the engine, let it run for 10 seconds - without steering, then shut it off.
3. Check the reservoir, and refill if the fluid level has dropped.
4. Repeat this process at least three times, checking and refilling the reservoir each time if necessary.


NOTE

Do not allow the fluid level to drop significantly or run out of the reservoir. This may induce air into the system.

5. Start the engine and let it idle for 2 minutes - without steering. Shut off the engine and check the fluid level in the reservoir. Refill if required.
6. Start the engine again. Steer the vehicle from full left to full right several times.
7. Again, check the fluid level in the reservoir.
8. With the engine idling, steer from full left turn to full right turn several times. Stop steering with the wheels pointed straight ahead and loosen the manual bleed screw 2-3 turns.
9. Allow air and aerated fluid to "bleed out" until fluid appears without bubbles.
10. Close the bleed screw, refill the reservoir if required.
11. Repeat this process three or four times until all the air is discharged. Torque manual bleed screw to 45 in•lb.

⚠ CAUTION

Do not turn steering wheel with bleed screw loosened.



Manual Bleed Screw Location



Figure 1




Figure 1



Manual Bleed Screw Style

Flushing the Steering System

The steering system must be flushed every time a gear, pump, or reservoir gets replaced, regardless if the components are new or are remanufactured.

1. Set parking brake on vehicle and block rear wheels.
2. Raise the front end off the ground.
3. Take vehicle out of gear and put into neutral position.
4. Raise hood and wipe down area around the steering gear and the hydraulic lines related to the steering system.
5. Place a drip pan under the steering gear to catch the oil.
6. Remove both the pressure and return lines (Figure 1) from the steering gear and allow the oil to drain into the empty container.
7. Remove filter (Figure 2) from the power steering fluid reservoir and discard. Disconnect the supply line from the reservoir.
8. Rinse and clean the inside of the reservoir with an approved solvent, then air dry. Do not use a shop rag to wipe the inside of the reservoir and make sure that none of the solvent enters the rest of the steering system. If the reservoir is made from plastic inspect for cracks and damage. Replace if necessary.
9. Turn steering wheel from full left to full right 3-4 times. Collect the drained oil in the same container as in Step 6. This will purge the oil from the steering gear.
10. Reconnect pressure and return lines to the steering gear. Connect the supply line to the reservoir and then tighten all fittings.
11. Install new filter element into the reservoir.
12. Clean reservoir filler cap with an approved solvent. Inspect gasket and replace if necessary.
13. Inspect all hydraulic hoses (Figure 3) for cracks, soft or sweat spots and signs of local collapse (remove all covers/corrugated tubing from hoses to do this) and replace any that are found to be defective.
14. Check any fittings and connectors for blockage. Clear any blockages using an appropriate method.



Figure 1




Figure 2



Figure 3

15. Fill reservoir with approved replacement fluid and reinstall the filler cap (Figure 5).
16. Start engine for 10 seconds, stop, and check reservoir fluid level and top off if necessary. You may need to repeat this procedure 3 or 4 times.
17. Upon completion of filling the reservoir, start the engine and let it idle. At engine idle, steer full right and full left (Figure 6) once and return to straight ahead. Stop engine and check power steering reservoir level and top off if required.

⚠ CAUTION

Do not hold steering wheel at full turn for longer than 10 seconds as this will cause system to overheat.

18. Restart engine and steer full turns each direction 3 or 4 times.
19. Stop engine and recheck reservoir fluid level and adjust to correct level, if needed.
20. Inspect system for leaks and correct if necessary.
21. Bleed air from the system, if required.
22. Remove drip pan and lower vehicle. Remove blocks from wheels and return vehicle for normal service.



Figure 5



Figure 6

Power Steering System Analyzer (PSSA) Application and Use

Introduction

This booklet is intended to give the you, the technician, a better understanding of the power steering system analyzer. Primarily, how it works and how to properly use it to diagnose hydraulic power steering related issues. You should also know that the use of the power steering system analyzer is required when completing many of the diagnostic tests found in our Chart Your Way to Easy Steering - Diagnostics Service Manual. The test procedures were developed using TRW power steering components. However, the operating principles of the power steering system analyzer can be applied to all commercial power steering systems.

The goal of this booklet is to take you step-by-step through each of the test procedures which require the use of the power steering system analyzer. This will then assist you in locating the root cause of any hydraulic steering related complaint and provide you with necessary test results when calling TRW.

⚠ WARNING

While performing these tests, TRW advises that you take necessary precautions when working with internal vehicle components and hot hydraulic fluid. Be sure to take special care to protect yourself, and those around you, while performing a diagnostic test.

⚠ CAUTION

Do not attempt to diagnose a hydraulic steering related problem without using a power steering system analyzer. You will not be able to properly determine the correct information needed to analyze and diagnose the steering system.

This booklet will show you how to properly install the power steering system analyzer into the power steering system and use it to get measured results for the following tests; Power Steering Pump, Pump Flow Control Response, Poppet Trip Pressure, and Internal Leakage.

Be sure to record your results in the tables (Page 6) and be prepared to provide this information when calling to talk with your TRW Technical Service Representatives.


Installing the Power Steering System Analyzer

Some Chart Your Way diagnostic test procedures require a power steering system analyzer which is a combination flow meter, pressure gauge and load valve all in one. The system analyzer lets you measure flow and pressure and apply a load to the pump through the steering systems hydraulic lines.

Depending on the model of gauge being used, you may see an arrow showing the direction of the oil flow. This will assist you in making sure the flow meter is properly installed in the system. A load valve, located near the gauge, is used to either restrict or open the flow of oil to the system.

The gauge has a SAE/Metric scale to read the flow of oil in either GPM (U.S. gallons per minute) or LPM (liters per minute). The system pressure is measured in either PSI (U.S. pounds per square inch) or kg /cm² (kilograms per centimeter squared).

The power steering system analyzer is installed between the power steering pump and the steering gear. Connect the valve end of the power steering system analyzer to the steering gear's pressure port and the other end to the pump's pressure port.



Power Steering Pump Test

This section will instruct you on how to measure pump flow and system pressure. Be sure to follow the lines to make sure that they are hooked up correctly before attempting to perform any tests.

Verify engine idle speed per original equipment manufacturers specifications.

1. Install the power steering system analyzer in the pressure line with load valve fully open. Recheck and adjust the fluid level, if required. Install a temperature gauge in the reservoir and begin the test with the fluid temperature between 125-135° F (52-57° C).
2. Run the engine at idle. Measure and record the flow and pressure readings (Table A).

⚠ CAUTION

When closing the power steering system analyzer load valve, do so slowly and keep an eye on the pressure gauge. Do not allow the system to exceed 3000 psi or (207 bar) for safety of personnel and to prevent damage to the vehicle.

⚠ CAUTION

Do not keep the load valve closed for more than 5 seconds at a time because damage to the system may result from excessive heat build-up.

3. With the engine at idle, adjust the load valve to show 1000 PSI on the gauge. Measure and record the flow and pressure readings (Table A).
4. Now with the load valve fully open, increase the engine speed to 1500 RPM, measure and record the flow and pressure readings (Table A).
5. With the engine speed at 1500 RPM, adjust the load valve to show 1000 PSI on the gauge. Measure and record the flow and pressure readings (Table A).
6. Determine the recommended flow range and maximum allowable system pressure for the steering system being used by referring to your Original Equipment Manufacturer's service manual for your application.
7. Compare the minimum and maximum flows, and the relief pressure you measured, to gear and pump specifications as shown in your service manuals
8. If the minimum measured pump flow is less than the minimum recommended flow for the steering gear used; the pump may not be putting out enough flow for an adequate steering speed. If the maximum system pressure is lower than that specified for the pump, it may not be developing enough pressure to steer the vehicle. If either case exists, the pump may need to be repaired or replaced.

NOTE

When hydraulic tests are completed and hoses are reconnected, check the fluid level and bleed the air from the hydraulic system using the procedures outlined in the appropriate steering gear service manual.

Pump Flow Control Response Test

This section will instruct you on how to determine proper pump flow control response. Be sure to follow the lines to make sure that they are hooked up correctly before attempting to perform any tests.

1. Install the power steering system analyzer in the pressure line with load valve fully open. Recheck and adjust the fluid level, if required. Install a temperature gauge in the reservoir and begin the test with the fluid temperature between 125-135° F (52-57° C).

▲ CAUTION

If the system temperature goes over 250° F (121° C), or 150° F (66° C) above the surrounding temperature at any time during the test, stop the test. This temperature level is considered extreme and steering system performance and life will be seriously affected. Damage to hoses, seals, and other components may result if operated at extreme temperature. If the steering system is operating above the recommended temperatures, the heat problem may be the root cause of the complaint.

▲ CAUTION

When closing the power steering system analyzer load valve, do so slowly and keep an eye on the pressure gauge. Do not allow the system to exceed 3000 psi or (207 bar) for safety of personnel and to prevent damage to the vehicle.

▲ CAUTION

Do not keep the load valve closed for more than 5 seconds at a time because damage to the system may result from excessive heat build-up.

2. With the engine at idle, note the flow rate. Fully close the load valve until the flow drops to zero. Quickly open the load valve observing the flow meter. The flow rate must instantly return to the reading you have already noted.
3. With the load valve open run the engine to 1500 RPM and note the flow rate. Fully close the load valve until the flow drops to zero. Quickly open the load valve observing the flow meter. The flow rate must instantly return to the reading you have already noted.
4. Conduct this pump response test three times at idle and three times at 1500 RPM. Record your results (Table B). If the flow rate does not return immediately, the pump is malfunctioning, which can result in a momentary loss of power assist.

NOTE

When hydraulic tests are completed and hoses are reconnected, check the fluid level and bleed the air from the hydraulic system using the procedures outlined in the appropriate steering gear service manual.

Poppet Trip Pressure Test

This section will instruct you on how to verify poppet trip pressure. Be sure to follow the lines to make sure that they are hooked up correctly before attempting to perform any tests.

1. Install the power steering system analyzer in the pressure line with load valve fully open. Recheck and adjust the fluid level, if required. Install a temperature gauge in the reservoir and begin the test with the fluid temperature between 125-135° F (52-57° C).
2. Increase engine speed to 1500 RPM.
3. Steer the vehicle into a full right turn. Then, record the poppet trip pressure (Table C) shown on the power steering system analyzer pressure gauge.
4. Now, steer the vehicle into a full left turn, and again, record the poppet trip pressure (Table C) shown on the power steering system analyzer pressure gauge.

Each recorded value should be at least 200-400 PSI below pump relief test value previously noted in Table A. If you do not meet this criteria, poppets should be reset, using the procedure outlined in the appropriate steering gear manual. When complete, make sure to recheck the vehicle to make sure it is operating properly.

NOTE

When hydraulic tests are completed and hoses are reconnected, check the fluid level and bleed the air from the hydraulic system using the procedures outlined in the appropriate steering gear service manual.

Internal Leakage Test

Finally, you will be instructed on how to measure internal leakage for both a single gear and dual gear system. Be sure to follow the lines to make sure that they are hooked up correctly before attempting perform any tests.

⚠ WARNING

This test can be dangerous if not performed correctly. Keep your fingers clear of the axle stops and spacer block during this test. Make sure that the spacer block contacts the axle stop squarely. Contact that is not square could break the axle stops or dangerously throw or eject the spacer block.

1. Install the power steering system analyzer in the pressure line with load valve fully open. Recheck and adjust the fluid level, if required. Install a temperature gauge in the reservoir and begin the test with the fluid temperature between 125-135° F (52-57° C).
2. To test the steering gear for internal leakage, you must first prevent operation of the gear's internal unloading (poppet) valves or relief valve (or both, in some gears). This will allow full pump relief pressure to develop. To prevent operation of the poppets, place an unhardened steel spacer block, at least one inch thick and long enough to keep your fingers clear, between the axle stop at one wheel. If the steering gear is equipped with a relief valve, remove the relief valve cap, o-ring, and two piece relief valve from the steering gear valve housing. Install the relief valve plug, special tool number J37130, in its place to prevent operation of the steering gear relief valve.

NOTE

Be sure you reinstall the relief valve and valve cap with new o-ring, back into the gear after this test.

⚠ CAUTION

When running this test, do not hold the steering wheel in the full turn position for longer than 5 to 10 seconds at a time to avoid damaging the pump.

3. Turn the steering wheel until the axle stops bottom on the spacer block.
4. Apply 20 pounds of force to the rim of the steering wheel during this test to be sure that the steering gear control valve is fully closed. The pressure gauge should now read pump relief pressure (see Table A). Record the steering gear internal leakage (Table D) on the flow meter.
5. Repeat this test for the opposite direction of turn.
6. If internal leakage is greater than 1 gallon per minute (3.8 liters per minute) and there is no auxiliary hydraulic linear or rotary cylinder in the system, repair or replace the gear.

If the internal leakage is greater than 2 gallons per minute (7.6 liters per minute), and there is an auxiliary hydraulic linear or hydraulic rotary cylinder in the system, controlled by the gear, isolate the auxiliary cylinder from the system by disconnecting the auxiliary cylinder hydraulic lines at the steering gear auxiliary ports. Plug the steering gear ports with suitable steel or high pressure plugs or caps.

In the event that a rotary cylinder is used in the system, connect the disconnected lines together with a suitable union fitting. In the case of a linear cylinder, first plug the disconnected lines and then disconnect the cylinder from steering linkage, making sure it will clear the steered axle

Repeat the internal leakage test and record your results in Table D. If the internal leakage is less than 1 gallon per minute (3.8 liters per minute), repair or replace the auxiliary cylinder. If the internal leakage is greater than 1 gallon per minute (3.8 liters per minute), repair or replace the gear.

NOTE

When hydraulic tests are completed and hoses are reconnected, check the fluid level and bleed the air from the hydraulic system using the procedures outlined in the appropriate steering gear service manual.

Test Results

Table A

Relief Pressure _____ PSI/BAR

Engine (RPM)	GPM or LPM at:	
	No Load	1000 PSI
Idle		
1500		

Table B

	PSI or BAR
Pump Relief #1 (Idle)	
Pump Relief #2 (Idle)	
Pump Relief #3 (Idle)	

	PSI or BAR
Pump Relief #1 (1500 RPM)	
Pump Relief #2 (1500 RPM)	
Pump Relief #3 (1500 RPM)	

Table C

	PSI or BAR
Full right hand turn	
Full left hand turn	

Table D


Single Gear System

	GPM or LPM
Full right hand turn	
Full left hand turn	

Dual Gear System

	GPM or LPM
Full right hand turn	
Full left hand turn	

PSSA Installations



Legend

- | | | | |
|------------------|---------------------|---------------------|---------------------|
| 1. Thermometer | 5. Steering Gear | 9. Load Valve | 13. Auxilliary Line |
| 2. Supply Line | 6. Return Line | 10. Flow Meter | 14. Assist Cylinder |
| 3. Pump | 7. Reservoir Filter | 11. Pressure Gauge | Linear or Rotary |
| 4. Pressure Line | 8. Reservoir | 12. Auxilliary Line | |

Linkage Inspection, Maintenance, Replacement, and Adjustment

Inspection Criteria

First by lightly rocking the steering wheel, observe any looseness in the two mating tapers, or any movement of the stud nut. Looseness in either place requires further inspection.

If either of the mating tapered parts show distortion or wear, both parts must be replaced.

Second, make sure the wheels are straight ahead, the truck engine is turned off, and no force is being exerted on the linkage by the steering gear. To check the soundness of the joint, just use your hand to push and pull the tie rod end in and out in the direction of the ball stud axis (see illustration).

For inspection purposes, the link must be held without twisting, and with hand-pressure only (approximately 100 lbs), measured with a scale for in and out motion on the ball stud axis. If the in and out motion on the stud's axis measures over 1/8" or 3 mm with hand pressure only, then the vehicle should be taken out of service.

If it moves, but measures less than 1/8" (3 mm) it should be replaced at the nearest practical service center. Any movement less than 1/8" (3 mm) is strictly a maintenance issue for the vehicle.


Do not use a wrench or other object to obtain more leverage. Applying leverage to any linkage can cause movement regardless of whether or not the linkage needs to be replaced. Applying leverage can also damage the linkage

Don't apply steering gear power to the joint to test for a worn tie rod end; that produces normal movement, and that movement is not an indicator of wear.

Maintenance Checklist

Each time the tie rod ends are lubricated you should also visually inspect for:

- Cracks, breaks or bends in the linkage components.
- Check for broken clamps and gouges on tubes from rubbing parts.
- Check for missing or damaged grease fittings. Some tie rod ends are not equipped with grease fittings from the factory. But if one is supposed to be there and it is not, the missing fitting must be replaced.
- Check for any form of tearing or improper sealing on the seal. Also check for wear on the socket throat.
- Check all tie rod end connections for missing cotter pins.



Tie Rod End - Section View

Tie Rod End Replacement

If the lash is originating from the tie rod end, it will need to be replaced. If the lash is in the tapered stud connection between the tie rod end and its mating part, both the tie rod end and the mating part must be replaced to recreate a proper fit between the two.

1. Loosen the clamp or jam nut on the tie rod end (Figure 1).
2. Disconnect the tie rod end from the mating component.
3. Unscrew the tie rod end from the tube (Figure 2). Use a pipe wrench if necessary, being careful not to deform the tube.
4. Screw the new tie rod end into the tube (Figure 3). Tie rod end threads must be visible the entire length of the cross tube slot. The tie rod end is to be engaged at least one thread deeper than the end of the cross tube slot.
5. Refer to the adjustment and centering procedures, for the type of assembly you are working on, covered in this document.
6. Torque the clamp nut or jam nut (Figure 5) to the vehicle manufacturer's specifications.




Figure 1




Figure 2



Figure 3




Figure 4




Figure 5




Figure 1



Figure 2




Figure 3



Figure 4



Figure 5

Draglink– One End Adjustable

1. Position the road wheels straight ahead.
2. Disconnect the draglink at the pitman arm using the appropriate tool.
3. Make sure the steering gear is on center by aligning the timing marks on the housing and output shaft.
4. Loosen the clamp on the draglink.
5. Adjust the draglink length to fit the holes on the pitman arm and the axle steer arm.
6. Grasp the long side of the draglink with both hands (Figure 1). Rotate it away from you as far as it will go, then toward you as far as it will go. Center between these two points.
7. Hold the long side in place. Grasp the tie rod end (Figure 2) and rotate it toward you and away from you as far as you. Center the tie rod end between these two points.
8. With both ends centered, tighten the clamp, and torque (Figure 3) to vehicle manufacturer's specifications.

⚠ WARNING

If the clamp is tack-welded (Figure 4), don't remove the tack weld. If removed, clamping force will not be enough to keep the tie rod end threads stationary. Loss of steering control will result. If the tack welded end requires replacement, the entire assembly needs to be replaced.

NOTE

If the clamp is free-to-rotate (Figure 5) it can be tightened in any position properly, as long as there is enough clearance from other parts.

9. Lubricate both tie rod ends (unless they are non-greaseable ends) until you can see clean grease purging out of the seal. Use #2 NLGI Grease.

NOTE

A hand operated grease gun must be used when lubricating linkage. Power grease guns generate excessive force that will damage the boot seal.

NOTE

This purge is necessary to ensure contaminants are removed from socket assemblies.

Draglink– Two End Adjustable

1. Position the road wheels straight ahead.
2. Loosen the clamps on the both ends of the draglink.
3. Rotate the center tube of the draglink (Figure 1) until the steering gear is on center (housing and output shaft timing marks aligned).
4. Tighten the clamps and torque (Figure 2) to manufacturer's specifications.

⚠ WARNING

If the clamp is tack-welded (Figure 3), don't remove the tack weld. If removed, clamping force will not be enough to keep the tie rod end threads stationary. Loss of steering control will result. If the tack welded end requires replacement, the entire assembly needs to be replaced.

NOTE

If the clamp is free-to-rotate (Figure 4) it can be tightened in any position properly, as long as there is enough clearance from other parts.

5. Lubricate both tie rod ends (unless they are non-greaseable ends) until you can see clean grease purging out of the seal. Use #2 NLGI Grease.

NOTE

A hand operated grease gun must be used when lubricating linkage. Power grease guns generate excessive force that will damage the boot seal.

NOTE

This purge is necessary to ensure contaminants are removed from socket assemblies.




Figure 1




Figure 2



Figure 3



Figure 4




Figure 1



Figure 2




Figure 3



Figure 4



Figure 5

Tie Rod Tube Assembly– One End Adjustable

1. Position the road wheels straight ahead.
2. Raise the front end of the vehicle so the steer axle tires are off the ground.
3. Loosen the clamp on the tie rod tube.
4. Turn the hex adjuster until the toe is correct.

⚠ WARNING

Do not adjust the tie rod end to a position where you can see the end of the tie rod end threads through the slot in the tube. If the socket threaded end is visible, corrosion may occur in the tube and weaken the components.

5. Grasp the long side of the tie rod with both hands (Figure 1). Rotate it away from you as far as it will go, then toward you as far as it will go. Center the tie rod between these two points.
6. Hold the long side in place. Grasp the tie rod end (Figure 2) and rotate it toward you and away from you as far as you can. Center the tie rod end between these two points.
7. With both ends centered, tighten the clamp, and torque (Figure 3) to vehicle manufacturer's specifications.

⚠ WARNING

If the clamp is tack-welded (Figure 4), don't remove the tack weld. If removed, clamping force will not be enough to keep the tie rod end threads stationary. Loss of steering control will result. If the tack welded end requires replacement, the entire assembly needs to be replaced.

NOTE

If the clamp is free-to-rotate (Figure 5) it can be tightened in any position properly, as long as there is enough clearance from other parts.

9. Lubricate both tie rod ends (unless they are non-greaseable ends) until you can see clean grease purging out of the seal. Use #2 NLGI Grease.

NOTE

A hand operated grease gun must be used when lubricating linkage. Power grease guns generate excessive force that will damage the boot seal.

NOTE

This purge is necessary to ensure contaminants are removed from socket assemblies.

Tie Rod Tube Assembly– Two End Adjustable

1. Position road wheels straight ahead.
2. Loosen the clamps on both ends of the tie rod tube.
3. Rotate the center tube of the tie rod (Figure 1) until achieve proper toe-in measurements on the front wheels.
4. Tighten the clamps and torque (Figure 2) to manufacturer's specifications.

⚠ WARNING

If the clamp is tack-welded (Figure 3), don't remove the tack weld. If removed, clamping force will not be enough to keep the tie rod end threads stationary. Loss of steering control will result. If the tack welded end requires replacement, the entire assembly needs to be replaced.

NOTE

If the clamp is free-to-rotate (Figure 4) it can be tightened in any position properly, as long as there is enough clearance from other parts.

9. Lubricate both tie rod ends (unless they are non-greaseable ends) until you can see clean grease purging out of the seal. Use #2 NLGI Grease.

NOTE

A hand operated grease gun must be used when lubricating linkage. Power grease guns generate excessive force that will damage the boot seal.

NOTE

This purge is necessary to ensure contaminants are removed from socket assemblies.




Figure 1




Figure 2



Figure 3



Figure 4




Figure 1




Figure 2



Figure 3



Figure 4



Figure 5

Drop Center Tie Rod Tube Assembly– One End Adjustable

1. Position road wheels straight ahead.
2. Place a jack under the center of the front axle. Raise up the front end of the vehicle so the steer axle tires are off the ground.
3. Loosen the clamp on the tie rod tube.

Disconnect the tie rod from the tie rod arm at the adjustable end.
4. Adjust the socket in one-full-turn increments (Figure 1). Reinstall the socket end, tighten (do not torque) the fastener after each full turn.
5. Check the toe-in measurement after each full turn adjustment. Repeat as necessary until the toe is correct.
6. Grasp the long side of the tie rod with both hands (Figure 2). Rotate it away from you as far as it will go, then toward you as far as it will go. Center the tie rod between these two points.
7. Hold the long side in place. Grasp the tie rod end (Figure 3) and rotate it toward you and away from you as far as you can. Center the tie rod end between these two points.
8. With both ends centered, tighten the clamp, and torque to vehicle manufacturer's specifications.

⚠ WARNING

If the clamp is tack-welded (Figure 4), don't remove the tack weld. If removed, clamping force will not be enough to keep the tie rod end threads stationary. Loss of steering control will result. If the tack welded end requires replacement, the entire assembly needs to be replaced.

NOTE

If the clamp is free-to-rotate (Figure 5) it can be tightened in any position properly, as long as there is enough clearance from other parts.

9. Lubricate both tie rod ends (unless they are non-greaseable ends) until you can see clean grease purging out of the seal. Use #2 NLGI Grease.

NOTE

A hand operated grease gun must be used when lubricating linkage. Power grease guns generate excessive force that will damage the boot seal.

NOTE

This purge is necessary to ensure contaminants are removed from socket assemblies.



TRW Automotive
Commercial Steering Systems
800 Heath Street
Lafayette, IN 47904
Tel 765.423.5377
Fax 765.429.1868
www.trucksteering.com

© TRW Inc. 2008

TRW800

Rev. 4/08