



## ASA-5 AUTOMATIC SLACK ADJUSTER

### DESCRIPTION

The Bendix ASA-5 sure stroke automatic slack adjuster is designed for use on cam actuated drum brakes of the type in use on most highway vehicles. Like a manual slack adjuster, the ASA-5 multiplies and transforms the linear force of the air actuator into a rotational force or torque which is used to apply the foundation brake. Additionally, the ASA-5 automatically adjusts the clearance between the brake lining and drum to compensate for wear.

A variety of ASA-5 configurations are offered including both straight arm and 5/8" yoke offset models. The ASA-5 is offered in arm lengths of 5, 5-1/2 and 6 inches and worm gear splines to accommodate the standard 1-1/4" and 1-1/2" SAE 10C as well as the Rockwell 24 and 28 tooth and Propar 37 tooth splines.

Either of two yoke designs (easy-on and quick connect) in combination with an external manual adjuster hex provides convenient installation and maintenance of the ASA-5.

### OPERATION

#### GENERAL

The automatic adjustment provided by the Bendix ASA-5 results in consistent brake lining to drum clearance and brake actuator stroke. The key to its operation is the ability to complete the brake adjustment during the early part of each Brake Application and to cease adjusting as resistance to brake cam rotation begins to build. This aspect of the adjuster mechanism's operation prevents overadjustment due to: lining compression, actuator bracket deflection, drum and foundation brake component distortion, or brake component wear.

The ASA-5 incorporates a clutch-type adjuster mechanism that continuously adjusts in very small increments as lining and drum wear occurs. The adjustments made by the ASA-5 are, therefore, not in specific increments relative to actuator stroke.

#### APPLICATION

When the brakes are applied, the linear travel of the brake actuator's push rod causes the ASA-5 to rotate the foundation brake camshaft which in turn begins to force the




FIGURE 1 - ASA-5 AUTOMATIC SLACK ADJUSTER

brake shoes into contact with the drum. When the ASA-5 rotates, the yoke assembly pivots on the yoke pin causing the link to be pulled upward.

The "teeth" on the link mesh with the adjuster mechanism pinion and as the link is pulled it travels first through its free play and then the pinion is rotated. Rotation of the pinion is transmitted through the clutch spring to the worm and shaft. Worm and shaft rotation results in worm gear rotation which in turn adjusts (or repositions) the brake camshaft.

When the foundation brake shoes contact the drum, the camshaft begins to resist rotation and friction between the worm gear and worm builds, preventing further rotation of the worm. Brake adjustment ceases at this point and further rotation of the ASA-5 will cause the pinion




FIGURE 2 - SECTIONAL VIEW OF PROFILE AND END

and clutch spring to slip. The “free play” between the link teeth and pinion results in a predetermined lining to drum clearance.

## RELEASE

When the brake application is released, the brake actuator push rod returns the ASA-5 to the released position. During release, the ASA-5 rotates back toward the actuator causing the brake camshaft to again rotate, but in the opposite direction, and the brake shoes begin to move away from the drum. As the ASA-5 rotates back to the release position the yoke again pivots causing the link to be pushed downward into the slack adjuster body. The “free play” between the link teeth and pinion is taken up during the initial part of the release. Continued movement of the ASA-5 toward the released position causes the link to rotate the pinion. The anti-reverse spring prevents counterclockwise rotation of the shaft and worm causing the pinion and clutch spring to slip. The gripping action of the anti-reverse spring and slippage of the clutch spring during release is due to the direction of the coil windings of each.

## YOKE DESIGNS

ASA-5 slack adjusters may be equipped with either of two yoke designs. Both are designed to permit installation or removal of the slack adjuster along with its yoke body and its attached adjusting linkage.

The brake actuator push rod must thread into the adapter a minimum of 1/2 inch and must not extend more than 7/64 inch beyond the other end of the adapter. The yoke adapters (quick connect & easy-on) have either a 1 or 1-1/4 inch hex to allow tightening of the brake actuator push rod jam nut.

## EASY-ON YOKE (REFER TO FIGURE 3)

The easy-on yoke assembly consists of an adapter which is threaded internally to match the push rod threads and externally to match female threads in the yoke. A special extended yoke adapter is also available as a separate service item. The extended adapter is 1/2 inch longer than the standard and is primarily intended for use when the existing brake actuator push rod is too short.




FIGURE 3 - EASY-ON YOKE ASSEMBLY

### QUICK-CONNECT YOKE

The adapter bushing in this case is threaded internally to match the push rod, but is designed to slide into the yoke. A retainer ring is used to secure the adapter bushing in the yoke. (Refer to Figure 4)




FIGURE 4 - QUICK-CONNECT YOKE ASSEMBLY

### IMPORTANT! PLEASE READ:

When working on or around a vehicle, the following general precautions should be observed:

1. Park the vehicle on a level surface, apply the parking brakes, and always block the wheels.
2. Stop the engine when working around the vehicle.
3. If the vehicle is equipped with air brakes, make certain to drain the air pressure from all reservoirs before beginning ANY work on the vehicle.

4. Following the vehicle manufacturer's recommended procedures, deactivate the electrical system in a manner that removes all electrical power from the vehicle.
5. When working in the engine compartment the engine should be shut off. Where circumstances require that the engine be in operation, **EXTREME CAUTION** should be used to prevent personal injury resulting from contact with moving, rotating, leaking, heated, or electrically charged components.
6. Never connect or disconnect a hose or line containing pressure; it may whip. Never remove a component or plug unless you are certain all system pressure has been depleted.
7. Never exceed recommended pressures and always wear safety glasses.
8. Do not attempt to install, remove, disassemble or assemble a component until you have read and thoroughly understand the recommended procedures. Use only the proper tools and observe all precautions pertaining to use of those tools.
9. Use only genuine Bendix replacement parts, components, and kits. Replacement hardware, tubing, hose, fittings, etc. should be of equivalent size, type, and strength as original equipment and be designed specifically for such applications and systems.
10. Components with stripped threads or damaged parts should be replaced rather than repaired. Repairs requiring machining or welding should not be attempted unless specifically approved and stated by the vehicle or component manufacturer.
11. Prior to returning the vehicle to service, make certain all components and systems are restored to their proper operating condition.

### INITIAL INSTALLATION PREPARATION

1. If necessary, remove the manual or automatic slack adjuster currently installed, including the brake chamber yoke assembly.
2. Before mounting the ASA-5 on the camshaft, check the brake chamber push rod length to determine whether shortening or replacement is required. To accomplish this:
  - A. With the brake chamber in the released position, place a square (or equivalent object) so that one edge is parallel to the actuator push rod while the other edge bisects the brake camshaft. Measure the distance from the push rod end to the vertical

edge of the square and compare it to the values in Figure 5.

- B. If the measurement is less than the minimum shown in Figure 5, the brake actuator push rod must be shortened. If the measurement is greater than the maximum values, the brake actuator push rod may require replacement. The extended adapter, available as a separate service part (5/18-18 pc. no. 297700 and 1/2-20 pc. no. 297701) may avoid the need to replace the brake actuator push rod. The extended adapter is available for the easy-on yoke assembly only.
3. Inspect the foundation brake, brake chamber and related components. Make certain the camshaft bushings and seals are not excessively worn. Lubricate the camshaft bushings. Check the brake chamber bracket for cracks and excessive corrosion. The brake actuator push rod should not be loose or bent and the return spring should be firm. Replace parts that are suspect.
4. Wire brush the foundation brake camshaft to loosen contamination and wipe clean. Depending on environmental conditions, an application of antiseize compound to both the camshaft and worm gear spline may facilitate later slack removal.




FIGURE 5 - MEASURING THE BRAKE ACTUATOR PUSH ROD

## INSTALLATION

1. Select the proper ASA-5.
2. Install the ASA-5 on the brake camshaft.
3. If the ASA-5 has the easy-on yoke (see Figure 3), position the brake actuator push rod jam nut approximately 1-5/16 inches from the end of the brake actuator push rod. Thread the easy-on yoke adapter on the brake actuator push rod until it is approximately 3/8 inch from the end of the brake actuator push rod end. Turn the ASA-5 manual adjustment hex clockwise until the adapter extends into the threaded bore of the yoke approximately 1/8 inch. Thread the adapter into the yoke and tighten to 10 foot pounds.
4. If the ASA-5 has the quick connect yoke (see Figure 4), position the brake actuator push rod jam nut approximately 1 inch from the end of the brake actuator push rod. Thread the quick connect adapter bushing on the brake actuator push rod until it is flush with the end of the brake actuator push rod. Install the retaining ring on the adapter bushing, making certain it is in the adapter bushing groove. Turn the ASA-5 manual adjustment hex clockwise until the adapter bushing begins to enter the yoke. Fully compress the retaining ring "legs" and continue turning the ASA-5 manual adjustment hex until the adapter bushing is completely in the yoke.

Allow the retaining ring to expand into the corresponding groove in the yoke. Make certain the retaining ring is seated in both the yoke and the adapter bushing groove by manually pulling the ASA-5 arm, attempting to separate the adapter bushing and yoke.

5. Run the brake actuator push rod jam nut down against the adapter or adapter bushing. Hold the adapter or adapter bushing hex with a wrench and tighten the jam nut to 300-400 inch pounds for the 1/2"-20 thread and 400-600 inch pounds for the 5/8"-18 thread.
6. Manually adjust the brakes.

**Note:** The vehicle brakes should be adjusted using the vehicle or brake manufacturer's recommendation. If they are not available, the following procedure can be used:

## BRAKE ADJUSTMENT

Rotate the manual adjustment hex clockwise until the linings are snug against the drum. Turn the adjustment hex counterclockwise 1/4 turn. Pull the actuator push rod to confirm that approximately 1/2 inch of push rod free stroke exists. Apply 85 psi and check that the push rod stroke is below the readjustment Limit. If the stroke exceeds the readjustment limit, check the condition of the foundation brake. Refer to *Brake Maintenance Inspection*.

7. Manually uncage the spring brakes before returning the vehicle to service.
8. With the ASA-5 installed, check to ensure clearance requirements with the brake fully released and at the actuator's maximum stroke. Also consider clearances with the vehicle suspension springs depressed to the jounce bumpers, as well as in rebound.

## PREVENTIVE MAINTENANCE

**Important:** Review the warranty policy before performing any intrusive maintenance procedures. An extended warranty may be voided if intrusive maintenance is performed during this period.

Because no two vehicles operate under identical conditions, maintenance and maintenance intervals will vary. Experience is a valuable guide in determining the best maintenance interval for any one particular operation.

Visually check for physical damage such as broken air lines and broken or missing parts.

Every 25,000 miles, or 3 months, or 500 operating hours or at the time of routine vehicle chassis lubrication, whichever occurs first, the following steps should be followed (Also observe any shorter brake adjustment inspections or maintenance intervals specified by the vehicle manufacturer):

1. Lubricate the automatic slack adjuster through the lube fitting with a quality multipurpose chassis lubricant (N.L.G.I. Grade 1 or 2).  
Lubricate the slack adjuster until clean lubricant flows from the grease relief opening in the boot.
2. Perform the *In Service Inspection* described in this manual.

## IN SERVICE INSPECTION

1. Apply and release the vehicle brakes several times while observing the ASA-5. The ASA-5 and brake actuator should move freely without binding or interference and should return to the full released position. Observe the looseness that exists between the yoke and adapter bushing and the yoke and link pins and their mating parts (yoke, body, link). Replace these parts if looseness appears excessive. Make certain the brake actuator push rod jam nut is tight against the yoke adapter.
2. Inspect the ASA-5 for physical damage paying particular attention to the link, boot and yoke. Inspect for bent, broken, loose or misaligned brake actuator push rods and cracked or damaged brake actuator brackets. Repair or replace any components found to be damaged.

3. Measure the brake actuator push rod stroke while making an 80-90 psi service brake application. Actuator push rod strokes should not exceed the values shown in the following actuator stroke table. The correct pressure for this test can be achieved as follows. Build the system pressure up to 100 psi reading on the vehicle gage. Shut the engine off. Fan the brakes to attain a 90-95 psi reading. Make and hold a full brake application while the strokes are checked.

## ACTUATOR STROKE TABLE

Brake Actuator Size	Recommended Maximum Operating Stroke
30	2"
24	1-3/4"
20	1-3/4"
16	1-3/4"
12	1-3/8"

If the actuator stroke exceeds those shown, inspection of the foundation brake and/or the automatic slack should be completed. Maintenance of the foundation brake may be a factor in the long stroke conditions. Inspecting the foundation brake per the *Brake Maintenance Inspection* presented in this manual should determine how much of the long stroke condition is caused by the condition of the foundation brake. The ASA-5 can be tested using the instructions presented in this manual under *Testing the ASA-5 Adjuster Mechanism*.

## TESTING THE ASA-5 ADJUSTER MECHANISM

The following test can be made to determine if the ASA-5 adjuster mechanism is functioning properly.

1. With the brakes released and the vehicle wheels blocked, de-adjust the brakes by rotating the manual adjustment hex counterclockwise approximately 1/2 to 1 revolution.

**Note:** Considerable torque is required to rotate the manual adjustment hex counterclockwise and should be considered normal. The required torque may be as high as 70 foot pounds.

2. Using a straight edge, scribe a line across the manual adjustment hex head and slack adjuster body. (Refer to Figure 6).
3. Apply and COMPLETELY RELEASE the service brakes several times while observing the manual adjustment hex and the scribed line. The ASA-5 manual adjustment hex should rotate clockwise during the application and remain stationary during release. No counterclockwise rotation of the hex should be observed. The amount of clockwise rotation (adjustment) will decrease progressively as the brake nears proper




FIGURE 6 - TESTING ADJUSTER MECHANISM

adjustment. If the ASA-5 fails to perform as described, it will be necessary to repair or replace it.

4. Manually readjust the ASA-5 being tested before returning the vehicle to service. (See section *Installation*, Step 6)

**Note:** While it is possible to use the automatic adjustment feature of the ASA-5 to bring the brake back into adjustment, it will require numerous applications and COMPLETE RELEASES (the number of applications depends on how much the slack was de-adjusted).

## BRAKE MAINTENANCE INSPECTION

The following test can be used to inspect the maintenance condition of the foundation brake and to determine how much of the chamber stroke is caused by the condition of the foundation brake.

1. Chock wheels to keep vehicle from moving.
2. Raise axle so wheel can be rotated.
3. Adjust slack adjuster to produce light brake drag with wheel rotation.
4. Apply brake to 80-90 psi and measure stroke (See Item 3 of *In Service Inspection* for pressure tips).
5. If stroke significantly exceeds the values shown in the chart, the brake may be out of the norm and brake maintenance may be required.

AL Factor	15"x4" Front Brake	16.5"x7" Tractor, Truck or Bus Brake	16.5"x7" Trailer Brake
12 X 5.0"	1/2"	N/A	N/A
12 X 5.5"	1/2"	N/A	N/A
16 X 5.0"	5/8"	1/2"	N/A
16 X 5.5"	3/4"	1/2"	N/A
16 X 6.0"	7/8"	5/8"	N/A
20 X 5.0"	5/8"	1/2"	3/8"
20 X 5.5"	3/4"	5/8"	1/2"
20 X 6.0"	7/8"	3/4"	5/8"
24 X 5.0"	N/A	5/8"	1/2"
24 X 5.5"	N/A	5/8"	5/8"
24 X 6.0"	N/A	3/4"	5/8"
30 X 5.0"	N/A	3/4"	5/8"
30 X 5.5"	N/A	7/8"	3/4"
30 X 6.0"	N/A	1"	7/8"

## ASA-5 REMOVAL

**Note:** Make certain the vehicle has been prepared according to the instructions under the heading **IMPORTANT! PLEASE READ.**

1. If the ASA-5 is equipped with the easy-on yoke assembly illustrated in Figure 3:
  - A. Loosen the brake actuator push rod jam nut and run it back on the brake actuator push rod approximately 5/8 inch.
  - B. Loosen the easy-on yoke adapter and run it back on the brake actuator push rod until it is free of the yoke.
  - C. Rotate the manual adjustment hex counterclockwise until the ASA-5 is clear of the brake actuator push rod.

**Note:** Considerably more torque is required to rotate the manual adjustment hex counterclockwise than is necessary to rotate it clockwise. The torque may be as high as 70 foot pounds.

2. If the ASA-5 is equipped with the quick-connect yoke assembly illustrated in Figure 4:
  - A. Rotate the ASA-5 manual adjustment hex counterclockwise until the brake actuator push rod just begins to move out of the actuator.
  - B. Pinch the legs of the retaining ring together and pull the ASA-5 away from the brake actuator push rod until the adapter bushing is free of the yoke. Remove the retaining ring from the adapter bushing.
  - C. Rotate the manual adjustment hex counter clockwise until the ASA-5 is clear of the brake actuator push rod.




FIGURE 7 - ASA SERVICEABLE PARTS

3. Remove the ASA-5 slack adjuster from the camshaft of the foundation brake by removing the retaining clip and any spacers or washers that may be present.

## DISASSEMBLY

### GENERAL

A reasonable level of cleanliness should be observed when working on the ASA-5. Clean the exterior before disassembly.

The following disassembly and assembly procedure is presented for reference purposes and presupposes that a rebuild or repair of the ASA-5 is being undertaken. Several replacement parts and maintenance kits are available which do not require full disassembly. The instructions provided with these parts and kits should be followed in lieu of the instructions presented here.

1. Clamp the ASA-5 ARM in a bench vise. Do not clamp across the portion of the body that contains the adjuster assembly or worm gear. Using a wire brush, thoroughly clean the exterior of the slack adjuster paying particular attention to the area around the manual adjustment hex and its retaining ring. Wipe all loose contaminants away before proceeding.
2. Remove the cotter pins and washers from the yoke pin and link pin.
3. Remove the yoke pin and link pin and separate the yoke from the ASA-5.
4. If the ASA-5 has a yoke pin bushing, press it out of the slack adjuster arm.
5. Remove the boot from the retaining boss on the body. Rotate the manual adjustment hex clockwise until the link and boot can be pulled free of the ASA-5 body. Separate the boot from the link.
6. Remove the adjuster assembly retainer ring and the shims, if present, beneath it.
7. Rotate the manual adjustment hex counterclockwise. The entire assembly should screw out of the body as the manual adjustment hex is rotated. If the adjuster assembly does not screw out of the body, it will be necessary to prevent rotation of the worm gear as the adjuster hex is rotated.
8. Remove the thrust washer.
9. Carefully insert a 3/8 inch drift punch into the adjuster assembly bore in the body and drive out the spring retainer and anti-reverse spring.
10. Do not remove the lube fitting in the ASA-5 body unless damage is noted. Rotate the fitting counterclockwise. If it loosens, it is threaded. If it doesn't loosen it is unthreaded and can be pulled out of the body. When

removing an angled fitting, note its position relative to the body before removal.

11. No further disassembly of the ASA-5 is permitted.

## CLEANING AND INSPECTION

1. Wipe the excess grease out of the adjuster assembly and spring retainer bores in the body without the use of solvents. Do not use solvents or soap and water for cleaning.
2. Inspect the bores for corrosion, pitting and galling. If deep pitting or galling is noted, the ASA-5 should be replaced.
3. Look into the adjuster assembly bore and while rotating the gear, check for damaged or missing worm gear teeth. Replace the ASA-5 if this is noted.
4. Inspect the worm gear camshaft splines for damage. If damaged, replace the ASA-5.
5. Clean and inspect the yoke pin and link pin holes in the yoke, adjuster link and slack adjuster body. The holes should be visually round with no perceptible "egg shaping." A new yoke pin and link pin can be used to make this inspection. If this condition is noted, the affected part must be replaced.
6. Clean out the retaining ring grooves in the ASA-5 body and yoke.

## REASSEMBLY

1. If an unthreaded lube fitting was removed for replacement, use a mallet and appropriate insertion tool to drive in the replacement. If a threaded fitting was removed, use the appropriate wrench to install the replacement. Make certain to relocate the angled fitting in the same position noted during disassembly.
2. If the ASA-5 uses a yoke pin bushing, press it into the slack adjuster arm.
3. Clamp the ASA-5 ARM in a bench vise in a manner that will allow the adjuster assembly to be inserted downward into the body.
4. Lightly lubricate the adjuster assembly and thrust washer. Install the thrust washer on the shaft assembly and insert the assembly into the ASA-5 body. Rotate the adjuster hex clockwise until the adjuster is completely in place in the body.
5. Install the appropriate retaining ring and shims (if required, to achieve .010 inch of clearance).
  - A. If a C-type retaining ring was removed, add the combination of shims necessary to fill the clearance between both the installed shaft assembly and retaining ring.

If addition of .010 inch or less of shims was necessary, remove all the shims and reinstall the C-type retaining ring.

If addition of .015 inch or more of shims was necessary, adjust the combination of shims to reduce the shim stack thickness by .010 inch and reinstall the C-type retaining ring. Ensure entire ring is seated in the groove.

- B. If a wave-type retaining ring was removed, shimming is not required and **no** shims should be added. Install the wave-type retaining ring. Ensure entire ring is seated in the groove.

After installation of the retaining ring, make certain the manual adjustment hex is free to rotate.

6. Make certain the anti-reverse spring is fully installed in the spring retainer as illustrated in Figure 7. Using an arbor press, press the spring retainer and anti-reverse spring in the ASA-5 body. Support the manual adjustment hex head during installation of the spring retainer. Press the spring retainer in until it bottoms against the shaft. (See Figure 2.)
7. Install the boot on the adjuster link making certain the lip of the boot is seated in the groove on the link.
8. Insert the link and boot into the slack adjuster body. To engage the link teeth with the pinion (refer to Figure 2), apply a slight amount of pressure pushing the link into the slack adjuster body, then gently rotating the manual adjustment hex counterclockwise to draw the link into the body. Secure the large diameter of the boot over the cast boss on the slack adjuster body.
9. Depending on environmental conditions an application of anti-seize compound to both the yoke and link pins may facilitate later removal. Install the yoke and secure it to the ASA-5 body and link using the yoke pin and link pin. **Note:** Install the yoke and link pins from the direction as shown in Figure 7. Install washers and cotter pins in the yoke pin and link pin, and secure each. Bend each leg of the cotter pins to a minimum




FIGURE 8 - WORM GEAR LUBRICATION



of 25 degrees, creating an included angle of at least 50 degrees between the legs.

10. Lubricate the automatic slack adjuster through the lube fitting with a quality multipurpose chassis lubricant (N.L.G.I. Grade 1 or 2). Lubricate the slack adjuster until clean lubricant flows from the grease relief opening in the boot.

**Note:** This pre-installation lubrication on those ASA-5's equipped with a lubrication groove cut in the splines of the worm gear requires the temporary insertion of a "dummy camshaft spline" in the worm gear, or the lubrication of these units must be performed with the slack adjuster installed on the brake camshaft. (Refer to Figure 8.)

## RETROFITTING THE ASA-5

### PREPARATION

The Bendix ASA-5 automatic slack adjuster can replace a manual slack or competitive automatic slack adjuster provided some considerations are kept in mind:

1. Excessive duty cycles, high application pressures and brake force compounding can result in reduced slack adjuster durability.

2. Determine that the AL factor of the vehicle to be retrofitted is 195 or less. To determine the AL factor multiply the slack adjuster arm length (from the center of the cam spline to the center of the yoke pin hole in use) times the brake chamber size. Example: a type 30 brake chamber connected to a 6 inch arm slack adjuster,  $A = 30$  square inches,  $L = 6$  inches; therefore,  $30 \times 6 = 180$ , AL factor.
3. Make sure the foundation brake components are in good condition. Excessive drum out-of roundness will result in excessive lining wear. See the *In Service Inspection* section contained in this manual.
4. In order to select the proper slack adjuster, choose an ASA-5 with the same arm length, spline size, push rod thread size and offset as the slack adjuster it is replacing.
5. When retrofitting the Bendix ASA-5, make certain to read the instructions packaged with all service replacement ASA-5 slack adjusters (BWS582/ASA-5).

## ASA-5 TROUBLESHOOTING CHART

SYMPTOMS	CAUSE	REMEDY
1. Brake Actuator stroke is too long.	A. Loose actuator push rod jam nut.	A. Reposition components and torque to specification.
	B. Excessive clearance between adapter/ adapter bushing and yoke due to wear.	B. Replace damaged or worn parts.
	C. Excessive clearance between components: yoke pin—yoke link pin—link yoke pin—body.	C. Replace worn parts.
	D. Damaged (worn) splines on slack or camshaft.	D. Replace damaged parts.
	E. Weak or broken brake actuator return springs. Weak or broken brake shoe return spring.	E. Replace weak or broken springs.
	F. Worn or broken foundation brake components, including camshaft bushings, brake chamber bracket, etc.	F. Repair or replace as required per <i>In Service Inspection</i> .
	G. ASA-5 adjuster mechanism not functioning.	G. Lubricate, test adjuster mechanism, conduct in service inspection, repair components as necessary, replace.
	H. Brake drum—worn, excessively machined, bell-mouthed, excessive thermal expansion.	H. Replace or repair as required.
	I. Damaged ASA-5.	I. Replace component(s) or slack adjuster.
	J. ASA-5 improperly installed.	J. Correct installation position.

## ASA-5 TROUBLESHOOTING CHART (Continued)

SYMPTOMS	CAUSE	REMEDY
2. Brakes dragging— apparent overadjustment of brakes.	A. ASA-5 improperly installed. Too close to actuator: brakes can't fully release.	A. Correct the ASA-5 installation.
	B. Loose actuator push rod jam nut.	B. Reposition components and torque to specification.
	C. Spring brakes not fully retracting.	C. Check spring brake release air pressure and repair or replace air valving as necessary. Repair or replace spring brake.
	D. Broken foundation brake components, including camshaft bushings.	D. Repair or replace as required per <i>In Service Inspection</i> .
	E. Vehicle brake torque imbalance. (More work done by some brakes than others, thermal expansion of drums).	E. Check other brakes to insure they are working. Check air pressure balance and threshold pres- sure (refer to Bendix publication BW-1555). Check driver braking habits, e.g. use of trailer control valve. Use same friction material on all axles.
	F. Brake drum out-of-round, excessive thermal expansion.	F. Replace or repair as required.
	G. Air system malfunction, not exhausting completely.	G. Inspect and correct.
	H. New lining swells during break-in.	H. Back-off adjustment until brakes are free.

