

# Bendix® Wheel Speed Sensor Warranty Eligibility Checklist

## Eligible Returns Only Accepted with Completed Checklist



### Preparation

Note: Follow all standard safety precautions - see back page. Park the vehicle, chock the wheels and drain air system. Turn the ignition off. Use ABS diagnostics to find the suspected sensor.

### A. Inspect Physical Condition

Inspect the sensor cable for cuts, or evidence of crimping or pinching - these conditions are ineligible for Bendix warranty. If found, replace the sensor, clear the trouble code according to the ECU Service Data directions. Re-check system before returning vehicle to service.

### B. Test Resistance and Voltage

The vehicle must be at ambient temperature (0-100 degrees F, -18 to 38 degrees C) for an accurate reading, so be sure that the wheel end area is not hot. Based on the ABS ECU diagnostic code, disconnect the suspected sensor harness. At the extreme top of the temperature range, the sensor resistance can vary from 1200-2700 Ohms and still be within the operable range.

1. Inspect the connectors and terminals for corrosion, physical damage or loose connections. If possible, repair and/or clean the connectors. Damage of this type after the OE installation is not warrantable.
2. Use a Volt-Ohm meter to measure resistance across the connector pins:

- check one → ☐ OK - between 1200 and 2700 ohms.  
☐ Not OK - less than 1200 or more than 2700 ohms.

**If not OK, replace the sensor\*. End test.**


3. Confirm that chocks are in place on vehicle. For the wheel speed sensor needing testing, raise the wheel off the ground.
4. Release the parking brakes.
5. While having the wheel rotated by hand slowly at a rate of at least ½ revolution per second, test using an **AC** voltage meter at the ECU the output across the connectors.

- check one → ☐ OK - Output voltage is 0.25 Volt AC minimum  
☐ Not OK - Output voltage is less than 0.25 Volt **AC**.

If voltage is not OK, reposition sensor by gently pushing it closer toward the wheel until it touches the exciter ring. Repeat the voltage measurement.

**If still not OK, replace sensor\*. End test.**

7. If the Ohm and voltage readings are OK, the sensor itself is not the cause of the failure. Reconnect the sensor and examine the wiring harness and ECU connector for causes of failure, such as pinched wires, loose pins, etc.



### \* WHEN REPLACING A SENSOR UNDER WARRANTY

**NOTE: DO NOT CUT THE SENSOR CABLE WHEN REMOVING SENSOR - if the cable is cut, the warranty claim will automatically be denied.**

- A. Use the new corresponding Bendix sensor service kit that contains the sensor and clamping sleeve.
- B. Clear the trouble code using the ECU Service Data instructions.
- C. Include this checklist when returning a sensor. Please fill out all applicable fields on this checklist and:

ECU Model \_\_\_\_\_

VIN or Repair Order # \_\_\_\_\_

- D. Attach the checklist to the warranty claim form.

## SAFE MAINTENANCE PRACTICES

When working on or around a vehicle, the following general precautions should be observed at all times.

1. Park the vehicle on a level surface, apply the parking brakes, and always block the wheels. Always wear safety glasses.
2. Stop the engine and remove ignition key when working under or around the vehicle. When working in the engine compartment, the engine should be shut off and the ignition key should be removed. Where circumstances require that the engine be in operation, EXTREME CAUTION should be used to prevent personal injury resulting from contact with moving, rotating, leaking, heated or electrically charged components.
3. Do not attempt to install, remove, disassemble or assemble a component until you have read and thoroughly understand the recommended procedures. Use only the proper tools and observe all precautions pertaining to use of those tools.
4. If the work is being performed on the vehicle's air brake system, or any auxiliary pressurized air systems, make certain to drain the air pressure from all reservoirs before beginning ANY work on the vehicle. If the vehicle is equipped with an AD-IS™ air dryer system or a dryer reservoir module, be sure to drain the purge reservoir.
5. Following the vehicle manufacturer's recommended procedures, deactivate the electrical system in a manner that safely removes all electrical power from the vehicle.
6. Never exceed manufacturer's recommended pressures.
7. Never connect or disconnect a hose or line containing pressure; it may whip. Never remove a component or plug unless you are certain all system pressure has been depleted.
8. Use only genuine Bendix® replacement parts, components and kits. Replacement hardware, tubing, hose, fittings, etc. must be of equivalent size, type and strength as original equipment and be designed specifically for such applications and systems.
9. Components with stripped threads or damaged parts should be replaced rather than repaired. Do not attempt repairs requiring machining or welding unless specifically stated and approved by the vehicle and component manufacturer.
10. Prior to returning the vehicle to service, make certain all components and systems are restored to their proper operating condition.
11. For vehicles with Antilock Traction Control (ATC), the ATC function must be disabled (ATC indicator lamp should be ON) prior to performing any vehicle maintenance where one or more wheels on a drive axle are lifted off the ground and moving.