

2013 PACCAR MX-13

Diagnostic Service Manual

EPA2013


(P062A to P1223)






Index


[P062A](#) [P062B](#) [P062D](#) [P0640](#) [P0650](#) [P0666](#) [P0668](#) [P0669](#) [P0691](#) [P0692](#) [P0698](#) [P0699](#) [P0703](#) [P081C](#)
[P0833](#) [P0865](#) [P101E](#) [P101F](#) [P1020](#) [P1021](#) [P1022](#) [P1023](#) [P1024](#) [P1025](#) [P1026](#) [P1029](#) [P102A](#) [P102B](#)
[P102C](#) [P102D](#) [P102E](#) [P102F](#) [P1030](#) [P1032](#) [P1039](#) [P103C](#) [P1040](#) [P1042](#) [P104B](#) [P104C](#) [P104D](#) [P1050](#)
[P1057](#) [P1086](#) [P1087](#) [P1088](#) [P1089](#) [P1090](#) [P1091](#) [P109C](#) [P109D](#) [P1110](#) [P1115](#) [P1122](#) [P1127](#) [P1128](#)
[P1133](#) [P1134](#) [P1135](#) [P1136](#) [P1137](#) [P1138](#) [P1139](#) [P113A](#) [P113B](#) [P1158](#) [P1159](#) [P1160](#) [P1161](#) [P1163](#)
[P1167](#) [P1168](#) [P1180](#) [P1191](#) [P1194](#) [P1195](#) [P1196](#) [P1201](#) [P1202](#) [P1203](#) [P1204](#) [P1205](#) [P1206](#) [P1207](#)
[P1208](#) [P1209](#) [P1210](#) [P1211](#) [P1212](#) [P1213](#) [P1214](#) [P1215](#) [P1216](#) [P1217](#) [P1218](#) [P1219](#) [P1220](#) [P1221](#)
[P1222](#) [P1223](#)

P062A

Code number	P062A
Fault code description	Common rail pump unit control-Too short at a certain rail pressure "Pressure below lowest allowable pressure at commanded pressure."
Fault code information	1 trip MIL 3 drive cycle recovery Readiness group – None Freeze frame type - Fuel
Description of component(s)	<p>Common rail pump units 1 and 2 supply fuel to the common rail.</p>  <ol style="list-style-type: none"> 1. Outlet port 2. Solenoid connector 3. Sealing ring fuel supply gallery - outside 4. Sealing ring fuel supply gallery - fuel return gallery 5. Sealing ring fuel return gallery - crankcase 6. Spring 7. Roller lifter 8. Common rail pump unit cam 9. Fuel return port 10. Fuel supply port <p>Operation The internal plunger is actuated via a roller lifter on the camshaft. Each pump has three pump events every two crankshaft revolutions. Fuel from the fuel gallery can enter the pump plunger area via an internal valve. A pump event starts when the plunger travels up, the PCI ECU activates the solenoid briefly, and the internal valve closes the opening to the fuel gallery. The internal valve</p>

	<p>is kept closed hydraulically, and the fuel is pumped to the rail via a check valve in the outlet bore of the pump unit.</p> <p>The pump event stops when the roller lifter passes the top of the camshaft lobe, causing the plunger to travel downward again. Due to this, the pressure above the plunger decreases and the internal valve opens the opening to the fuel gallery. The check valve in the outlet bore closes and prevents fuel from flowing back from the rail to the plunger area.</p> <p>Control</p> <p>The amount of fuel pumped to the rail depends on the duration of the pump event. The earlier the solenoid is activated by the PCI ECU in the up stroke of the pump plunger, the more (mg/stroke) fuel is pumped to the rail.</p> <p>Effect on the system:</p> <ul style="list-style-type: none"> • Rail pressure control. The rail pressure is closed-loop controlled. A comparison is made between the actual rail pressure and rail pressure demands determined by the ECU. The rail pressure is adjusted by pumping more or less fuel to the rail with the common rail pump
<p>Location of component(s)</p>	<p style="text-align: center;">L092</p> 

	<p style="text-align: right;">L093</p> 
Diagnostic condition	This diagnostic runs when the rail pressure control state is: Pump unit only.
Set condition of fault code	The PCI ECU (D420) detects that the common rail pump unit activation duration is lower than expected for a particular rail pressure for more than 4 seconds.
Reset condition of fault code	This DTC changes to inactive when the fault is no longer detected.
Electrical diagram(s)	



D420	L092	L093	Function
A25	2		Signal low, common rail pump unit 1
A26	1		Signal high, common rail pump unit 1
A27		1	Signal high, common rail pump unit 2
A28		2	Signal low, common rail pump unit 2

Technical data

Component check, common rail pump unit 1 (L092)

Preparation

- Key off the ignition
- Disconnect connector L092
- Measure on component connector L092

Pin (+ probe)	Pin (- probe)	Value	Condition
1	2	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]

Component check, common rail pump unit 2 (L093)

Preparation

- Key off the ignition
- Disconnect connector L093
- Measure on component connector L093

Pin (+ probe)	Pin (- probe)	Value	Condition
1	2	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]

Possible causes

- common rail pressure sensor deviation
- common rail pump unit failure

Additional information

- The common rail pump units (L092 and L093) supply fuel to the common rail. The amount of fuel pumped to the rail (rail pressure) depends on the activation duration of the pump event.
- The common rail pump unit control is closed-loop controlled. A comparison is made between the expected and the actual common rail pump unit activation duration.
- Engine torque is reduced

Diagnostic Step-by-Step



Perform the troubleshooting steps below using the breakout harness, if necessary, to check electrical components, such as sensors, electrical control units, and harnesses. Back probing is not recommended, as it could damage the harness. The ignition should always be in the OFF position when connecting or disconnecting electrical components in order to reduce the likelihood of damage to electrical components.





- Disconnecting the EAS connectors during the troubleshooting process will result in multiple errors.
- For specific electrical component information and pinout locations, always refer to the technical data.
- It is necessary to exit the fault code menu in DAVIE and run the diagnostic test again to identify a change in errors.
- Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive fault codes. Refer to the 'possible causes' section.

Step 1	Step ID 062A-a	SRT
<p>Visually inspect the associated component connections and wiring for any of the following:</p> <ul style="list-style-type: none"> • Signs of fuel leaks • Fuel component parts not installed correctly • Bent or broken fuel lines • Electrical connections are not secure <p>Was there evidence of any of the above?</p> <ul style="list-style-type: none"> • No: Continue to the next step in the troubleshooting process. • Yes: Clean, adjust, repair, or replace affected components for any issues identified. <p>Use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none"> • If this related fault is no longer active, then this issue has been resolved. • If this related fault is still active, continue to the next step in the troubleshooting process. 		

Step 2	Step ID 062A-b	SRT
<p>DAVIE Direct: Monitor EGR and related temperature sensors</p> <p>Use DAVIE to monitor the following temperatures:</p> <ul style="list-style-type: none"> • EGR Temperature • Ambient Temperature • Intercooler Temperature • Before Turbine Temperature • Coolant Temperature <p>Idle the engine for a minimum of 10 minutes to allow temperatures to stabilize. While monitoring, temperature values from sensor to sensor should not vary more than $\pm 30^{\circ}\text{F}$.</p> <p>Do any monitored values vary by more than $\pm 30^{\circ}\text{F}$?</p> <ul style="list-style-type: none"> • No: Continue to the next step in the troubleshooting process. • Yes: Clean adjust, repair or replace affected components for any issues identified. <p>Use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none"> • If this related fault is no longer active, then this issue has been resolved. 		



	<ul style="list-style-type: none">• If this related fault is still active, continue to the next step in the troubleshooting process.			
	<table><tr><td>Step 3</td><td>Step ID 062A-c</td><td>SRT</td></tr></table> <p>DAVIE Direct Test: Pressure Control Valve Run the prescribed DAVIE Direct test to determine if the high pressure valve is working correctly. Does the test fail to complete or result in a failed state?</p> <ul style="list-style-type: none">• No: Continue to the next step in the troubleshooting process.• Yes: Make the appropriate repairs or component replacements. <p>Use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">• If this related fault is no longer active, then this issue has been resolved.• If this related fault is still active, continue to the next step in the troubleshooting process.	Step 3	Step ID 062A-c	SRT
	Step 3	Step ID 062A-c	SRT	
	<table><tr><td>Step 4</td><td>Step ID 062A-d</td><td>SRT</td></tr></table> <p>Replace: Electronic Unit pump Replace the faulty Electronic Unit Pump.</p> <p>Use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">• If this related fault is no longer active, then this issue has been resolved.• If this related fault is still active, continue to the next step in the troubleshooting process	Step 4	Step ID 062A-d	SRT
Step 4	Step ID 062A-d	SRT		
<table><tr><td>Step 5</td><td>Step ID 062A-e</td><td>SRT</td></tr></table> <p>For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the Engine Support Call Center at 1-800-477-0251.</p>	Step 5	Step ID 062A-e	SRT	
Step 5	Step ID 062A-e	SRT		
Verification Drive Cycle	To validate repair, drive the vehicle until the coolant temperature is at least 70°C [158°F]. Once the minimum target temperature has been reached, proceed at a minimum speed of 80 km/h [50 mph] in the highest gear possible with the engine speed between 1100 and 1500 rpm and set the cruise control. This test is best performed with a loaded vehicle/trailer, but if load is unavailable, turn as many engine power consumers on to produce engine load. Perform this test for roughly 5 to 8 km [3 to 5 miles] or in 3 separate 1.5 km [1 mile] increments if a steady 5 to 8 km [3 to 5 miles] is unachievable. Use a flat road, if possible.			
	Back to Index			

P062B

Code number	P062B																				
Fault code description	Internal ECU injector power generation-Voltage too high																				
Fault code information	1 trip MIL 3 drive cycle recovery Readiness group – None Freeze frame type – Comprehensive																				
Description of component(s)	Not Applicable																				
Location of component(s)	Not Applicable																				
Diagnostic condition	This diagnostic runs Continuously when the ignition is on.																				
Set condition of fault code	The internal ECU injector power supply voltage is too high.																				
Reset condition of fault code	This DTC changes to inactive when the fault is no longer detected.																				
Electrical diagram(s)	Not Applicable																				
Technical data	Not Applicable																				
Possible causes	Clear the fault with DAVIE. If the fault reoccurs after ignition on, replace the ECU.																				
Additional information	<ul style="list-style-type: none">Numerous OBD monitors will not run anymore.Humidity calculation and correction switched off.																				
Diagnostic Step-by-Step	<div><div></div><div><p>Perform the troubleshooting steps below using the breakout harness, if necessary, to check electrical components, such as sensors, electrical control units, and harnesses. Back probing is not recommended, as it could damage the harness. The ignition should always be in the OFF position when connecting or disconnecting electrical components in order to reduce the likelihood of damage to electrical components.</p><div><div></div><ul style="list-style-type: none">Disconnecting the EAS connectors during the troubleshooting process will result in multiple errors.For specific electrical component information and pinout locations, always refer to the technical data.It is necessary to exit the fault code menu in DAVIE and run the diagnostic test again to identify a change in errors.Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive fault codes. Refer to the 'possible causes' section.</div></div></div> <table><tr><td>Step 1</td><td>Step ID 062B-a</td><td>SRT</td></tr><tr><td colspan="3">Visual inspection - Visually inspect all applicable connectors and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.</td></tr></table> <table><tr><td>Step 2</td><td>Step ID 062B-b</td><td>SRT</td></tr><tr><td colspan="3">Verify that there are no other fault codes in DAVIE.<ul style="list-style-type: none">If no other codes exist, proceed to step 3If there are other fault codes, correct them before proceeding.</td></tr></table> <table><tr><td>Step 3</td><td>Step ID 062B-c</td><td>SRT</td></tr><tr><td colspan="3">With key OFF, disconnect the engine harness from the PCI. Verify that there is 12-volt battery power and that grounds are good.<ul style="list-style-type: none">If 12 V is present - Proceed to step 4.If there is a problem – Refer to Rapido for repair.</td></tr></table>			Step 1	Step ID 062B-a	SRT	Visual inspection - Visually inspect all applicable connectors and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.			Step 2	Step ID 062B-b	SRT	Verify that there are no other fault codes in DAVIE. <ul style="list-style-type: none">If no other codes exist, proceed to step 3If there are other fault codes, correct them before proceeding.			Step 3	Step ID 062B-c	SRT	With key OFF, disconnect the engine harness from the PCI. Verify that there is 12-volt battery power and that grounds are good. <ul style="list-style-type: none">If 12 V is present - Proceed to step 4.If there is a problem – Refer to Rapido for repair.		
Step 1	Step ID 062B-a	SRT																			
Visual inspection - Visually inspect all applicable connectors and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.																					
Step 2	Step ID 062B-b	SRT																			
Verify that there are no other fault codes in DAVIE. <ul style="list-style-type: none">If no other codes exist, proceed to step 3If there are other fault codes, correct them before proceeding.																					
Step 3	Step ID 062B-c	SRT																			
With key OFF, disconnect the engine harness from the PCI. Verify that there is 12-volt battery power and that grounds are good. <ul style="list-style-type: none">If 12 V is present - Proceed to step 4.If there is a problem – Refer to Rapido for repair.																					

	Step 4	Step ID 062B-d	SRT
	Turn the key ON, and verify that there is 12-volt ignition power to the PCI: <ul style="list-style-type: none"> If 12 V is present - Proceed to step 5. If there is a problem – Refer to Rapido for repair. 		
	Step 5	Step ID 062B-e	SRT
	Possible PCI failure – Contact the Engine Support Center for further instructions on replacement of the PCI.		
Verification Drive Cycle	To validate repair, with DAVIE connected and key ON, clear the errors. Start the engine and let it idle to verify with DAVIE that the errors do not recur.		
	Back to Index		


P062D

Code number	P062D								
Fault code description	Internal ECU injector power generation – Voltage too low								
Fault code information	1 trip MIL 3 drive cycle recovery Readiness group – None Freeze frame type - Comprehensive								
Description of component(s)	This information not required since this is an internal PCI issue								
Location of component(s)	This information not required since this is an internal PCI issue								
Diagnostic condition	This diagnostic runs continuously when the ignition is on.								
Set condition of fault code	The internal ECU injector power supply voltage is too low.								
Reset condition of fault code	This DTC changes to inactive when the fault is no longer detected.								
Electrical diagram(s)	This information not required since this is an internal PCI issue								
Technical data	This information not required since this is an internal PCI issue								
Possible causes	Clear the fault with DAVIE. If the fault reoccurs after ignition on, replace the ECU.								
Additional information	<ul style="list-style-type: none">Numerous OBD monitors will not run anymore.Humidity calculation and correction switched off.								
Diagnostic Step-by-Step	<div> Perform the troubleshooting steps below using the breakout harness, if necessary, to check electrical components, such as sensors, electrical control units, and harnesses. Back probing is not recommended, as it could damage the harness. The ignition should always be in the OFF position when connecting or disconnecting electrical components in order to reduce the likelihood of damage to electrical components.</div> <div><ul style="list-style-type: none">Disconnecting the EAS connectors during the troubleshooting process will result in multiple errors.For specific electrical component information and pinout locations, always refer to the technical data.It is necessary to exit the fault code menu in DAVIE and run the diagnostic test again to identify a change in errors.Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive fault codes. Refer to the 'possible causes' section.</div> <table><tr><td>Step 1</td><td>Step ID 062D-a</td><td>SRT</td></tr><tr><td colspan="3"><p>Visual Inspection</p><p>Visually inspect the associated component connections and wiring for any of the following:</p><ul style="list-style-type: none">Loose, bent or broken connectorBent, broken, corroded, or pushed back pinsMoisture or dirt inside the connectorDamage to the wire harness or insulationECU connections are damaged or disconnectedBatteries are not okay, contacts are not secure<p>Was there evidence of any of the above?</p><ul style="list-style-type: none">No: Continue to step 2 in the troubleshooting process.Yes: Clean, adjust, repair, or replace affected components for any issues identified. Proceed to step 3<p>Use DAVIE to re-check for the presence of active faults.</p></td></tr></table>			Step 1	Step ID 062D-a	SRT	<p>Visual Inspection</p> <p>Visually inspect the associated component connections and wiring for any of the following:</p> <ul style="list-style-type: none">Loose, bent or broken connectorBent, broken, corroded, or pushed back pinsMoisture or dirt inside the connectorDamage to the wire harness or insulationECU connections are damaged or disconnectedBatteries are not okay, contacts are not secure <p>Was there evidence of any of the above?</p> <ul style="list-style-type: none">No: Continue to step 2 in the troubleshooting process.Yes: Clean, adjust, repair, or replace affected components for any issues identified. Proceed to step 3 <p>Use DAVIE to re-check for the presence of active faults.</p>		
Step 1	Step ID 062D-a	SRT							
<p>Visual Inspection</p> <p>Visually inspect the associated component connections and wiring for any of the following:</p> <ul style="list-style-type: none">Loose, bent or broken connectorBent, broken, corroded, or pushed back pinsMoisture or dirt inside the connectorDamage to the wire harness or insulationECU connections are damaged or disconnectedBatteries are not okay, contacts are not secure <p>Was there evidence of any of the above?</p> <ul style="list-style-type: none">No: Continue to step 2 in the troubleshooting process.Yes: Clean, adjust, repair, or replace affected components for any issues identified. Proceed to step 3 <p>Use DAVIE to re-check for the presence of active faults.</p>									


	<ul style="list-style-type: none"> • If this related fault is no longer active, then this issue has been resolved. • If this related fault is still active, continue to the next step in the troubleshooting process. 		
	Step 2	Step ID 062D-b	SRT
	<p>Electrical Checks (D420) For all electrical checks and diagrams, refer to the Engine Service Rapido electrical schematic viewer (ESV) for detailed schematics, connector pin locations, and corresponding signal values.</p> <ul style="list-style-type: none"> • Enter the Engine number • Select the ESV icon • Click the Search button • Select the "Component Code" within the Electrical Diagram Search pop-up window • In the component code box select D420 then Search. <p>Follow ESV through to find any electrical related problems. Based on the fault message provided, confirm that the following electrical values are within specified ranges or limits: Ensure that the ignition key/switch has been set to OFF before disconnecting related cables.</p> <ul style="list-style-type: none"> • Supply and signal voltages. • Cable continuity (no opens or shorts). <p>Are measured electrical values outside of expected range or limits?</p> <ul style="list-style-type: none"> • No: Continue to the next step in the troubleshooting process. • Yes: Make the appropriate repairs or component replacements. Proceed to Step 3 <p>Use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none"> • If this related fault is no longer active, then this issue has been resolved. • If this related fault is still active, continue to the next step in the troubleshooting process. 		
	Step 3	Step ID 062D-c	SRT
	<p>Replace: Engine Controller Unit (ECU) Replace the identified faulty component. Contact the PACCAR Engine Support Call Center to confirm replacement of the ECU. Use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none"> • If this related fault is no longer active, then this issue has been resolved. • If this related fault is still active, continue to the next step in the troubleshooting process. 		
	Step 4	Step ID 062D-d	SRT
	<p>Contact the PACCAR Engine Support Call Center</p> <ul style="list-style-type: none"> • For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center at 1-800-477-0251. 		
	<p>Verification Drive Cycle</p> <p>To validate repair, with the brakes set, turn the key to the ON position with the engine off, and allow 10 seconds for the system to initialize and run diagnostics.</p>		

	Back to Index
--	-------------------------------


P0640


Code number	P0640
Fault code description	Grid heater relay - Voltage too high or short circuit to supply
Fault code information	3 drive cycle recovery Readiness group – None Freeze frame type – Comprehensive
Description of component(s)	<div>  <p>For further assistance: Contact the PACCAR Engine Support Call Center 1-800-477-0251</p> </div> <p>Please contact the Engine Support Center</p>
Location of component(s)	
Diagnostic condition	
Set condition of fault code	
Reset condition of fault code	
Electrical diagram(s)	
Technical data	
Possible causes	
Additional information	
Diagnostic Step-by-Step	Please refer to chassis wiring information.
Verification Drive Cycle	N/A
	Back to Index

P0650

Code number	P0650
Fault code description	Malfunction Indicator Lamp (MIL) - Current too low or open circuit on ECU D420 pin B23
Fault code information	3 drive cycle recovery Readiness group – None Freeze frame type – Comprehensive
Description of component(s)	<div>  <div> For further assistance: Contact the PACCAR Engine Support Call Center 1-800-477-0251 </div> </div> <p>Please contact the Engine Support Center</p>
Location of component(s)	
Diagnostic condition	
Set condition of fault code	
Reset condition of fault code	
Electrical diagram(s)	
Technical data	
Possible causes	
Additional information	
Diagnostic Step-by-Step	Please refer to chassis wiring information.
Verification Drive Cycle	N/A
	Back to Index

P0666

Code number	P0666
Fault code description	Internal ECU temperature – Data erratic, intermittent, or incorrect at ignition on
Fault code information	1 trip MIL 3 drive cycle recovery Readiness group – None Freeze frame type - Comprehensive
Description of component(s)	 <p>PCI ECU (D420)</p> <p>Besides a microprocessor and the electronics to sense the inputs and control the outputs, two sensors can be found in the electronic control unit:</p> <ul style="list-style-type: none"> • Atmospheric pressure sensor • Temperature sensor <p>ECU atmospheric pressure sensor</p> <p>The PCI ECU has an internal atmospheric pressure sensor in the housing. Air can enter the ECU housing via the air vent (1).</p> <p>Effect on the system:</p> <ul style="list-style-type: none"> • Reduces the maximum engine torque when driving at high altitudes (low air pressure). <p>ECU temperature sensor</p> <p>The PCI ECU has an internal temperature sensor on the printed circuit board.</p> <p>Effect on the system:</p> <ul style="list-style-type: none"> • Monitors the temperature of the electronic control unit. <p>Injector codes</p> <p>Every fuel injector is calibrated during production to compensate for any production tolerances. An injector calibration code is present on the housing and connector of the injector. These injector codes must be (re)programmed with DAVIE if one or more injectors have been replaced or fitted in another position, or if the PCI ECU is replaced.</p> <p>Not programming or incorrectly programmed injector codes can result in reduced</p>

	engine performance or a warning to the driver.
Location of component(s)	<p style="text-align: center;">D420</p> 
Diagnostic condition	<p>This diagnostic runs:</p> <ul style="list-style-type: none"> • when the ignition has been keyed off continuously for at least 8 hours; • difference between the coolant temperature and ambient temperature is less than 15°C [59°F] • ambient temperature is more than -20°C [-4°F]
Set condition of fault code	<ul style="list-style-type: none"> • The PCI ECU (D420) detects that the measured internal ECU temperature differs by more than 3°C [37°F] from the average of other temperature sensors on the engine for more than 5 seconds (after the ignition has been keyed off for at least 8 hours).
Reset condition of fault code	<p>The 8-hour ignition off diagnostics consists of three separate steps:</p> <ol style="list-style-type: none"> 1. The vehicle ignition may NOT be switched on or engine started for 8-10 consecutive hours (ideal situation would be overnight). 2. Once the 8 to 10 consecutive hours have been reached, key on the ignition (NO engine start) and wait for 10 seconds to allow the system to power up and the diagnostics to run. 3. Start the engine and let it idle for 2 minutes. <p>This DTC changes to inactive when the fault is no longer detected.</p>
Electrical diagram(s)	This information not required since this is an internal PCI issue
Technical data	This information not required since this is an internal PCI issue
Possible causes	Faulty ECU
Additional information	For this diagnostic, the internal PCI ECU temperature sensor reading is compared with an average of other temperature sensors on the engine after the ignition has been switched off for at least 8 hours.

Diagnostic Step-by-Step



Perform the troubleshooting steps below using the breakout harness, if necessary, to check electrical components, such as sensors, electrical control units, and harnesses. Back probing is not recommended, as it could damage the harness. The ignition should always be in the OFF position when connecting or disconnecting electrical components in order to reduce the likelihood of damage to electrical components.




- Disconnecting the EAS connectors during the troubleshooting process will result in multiple errors.
- For specific electrical component information and pinout locations, always refer to the technical data.
- It is necessary to exit the fault code menu in DAVIE and run the diagnostic test again to identify a change in errors.
- Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive fault codes. Refer to the 'possible causes' section.

Step 1	Step ID 0666a	SRT
Visual Inspection Visually inspect the associated component connections and wiring for any of the following: <ul style="list-style-type: none"> • Loose, bent or broken connector • Bent, broken, corroded, or pushed back pins • Moisture or dirt inside the connector • Damage to the wire harness or insulation • ECU connections are damaged or disconnected • Batteries are not okay, contacts are not secure <p>Was there evidence of any of the above?</p> <ul style="list-style-type: none"> • No: Continue to the step 2 in the troubleshooting process. • Yes: Clean, adjust, repair, or replace affected components for any issues identified. Proceed to step 3 <p>Use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none"> • If this related fault is no longer active, then this issue has been resolved. • If this related fault is still active, continue to the next step in the troubleshooting process. 		


Step 2	Step ID 0666b	SRT
Electrical Checks (D420) For all electrical checks and diagrams, refer to the Engine Service Rapido electrical schematic viewer (ESV) for detailed schematics, connector pin locations, and corresponding signal values. <ul style="list-style-type: none"> • Enter the Engine number • Select the ESV icon • Click the Search button • Select the "Component Code" within the Electrical Diagram Search pop-up window • In the component code box select D420 then Search. 		

	<p>Follow ESV through to find any electrical related problems. Based on the fault message provided, confirm that the following electrical values are within specified ranges or limits: Ensure that the ignition key/switch has been set to OFF before disconnecting related cables.</p> <ul style="list-style-type: none">• Supply and signal voltages.• Cable continuity (no opens or shorts). <p>Are measured electrical values outside of expected range or limits?</p> <ul style="list-style-type: none">• No: Continue to the next step in the troubleshooting process.• Yes: Make the appropriate repairs or component replacements. <p>Use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">• If this related fault is no longer active, then this issue has been resolved.• If this related fault is still active, continue to the next step in the troubleshooting process.						
	<table><tr><td>Step 3</td><td>Step ID 0666c</td><td>SRT</td></tr><tr><td colspan="3"><p>Replace: Engine Controller Unit (ECU) Replace the identified faulty component. Contact the PACCAR Engine Support Call Center to confirm replacement of the ECU. Use DAVIE to re-check for the presence of active faults.</p><ul style="list-style-type: none">• If this related fault is no longer active, then this issue has been resolved.• If this related fault is still active, continue to the next step in the troubleshooting process.</td></tr></table>	Step 3	Step ID 0666c	SRT	<p>Replace: Engine Controller Unit (ECU) Replace the identified faulty component. Contact the PACCAR Engine Support Call Center to confirm replacement of the ECU. Use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">• If this related fault is no longer active, then this issue has been resolved.• If this related fault is still active, continue to the next step in the troubleshooting process.		
Step 3	Step ID 0666c	SRT					
<p>Replace: Engine Controller Unit (ECU) Replace the identified faulty component. Contact the PACCAR Engine Support Call Center to confirm replacement of the ECU. Use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">• If this related fault is no longer active, then this issue has been resolved.• If this related fault is still active, continue to the next step in the troubleshooting process.							
	<table><tr><td>Step 4</td><td>Step ID 0666d</td><td>SRT</td></tr><tr><td colspan="3"><p>Contact the PACCAR Engine Support Call Center For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center at 1-800-477-0251.</p></td></tr></table>	Step 4	Step ID 0666d	SRT	<p>Contact the PACCAR Engine Support Call Center For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center at 1-800-477-0251.</p>		
Step 4	Step ID 0666d	SRT					
<p>Contact the PACCAR Engine Support Call Center For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center at 1-800-477-0251.</p>							
Verification Drive Cycle	To validate repair, with the brakes set, turn the key to the ON position with the engine off, and allow 10 seconds for the system to initialize and run diagnostics.						
	<div>Back to Index</div>						


P0668

Code number	P0668
Fault code description	Internal ECU temperature – Internal error
Fault code information	<div>  <p>For further assistance: Contact the PACCAR Engine Support Call Center 1-800-477-0251</p> </div> <p>Please Contact the Engine Support Center</p>
Description of component(s)	
Location of component(s)	
Diagnostic condition	
Set condition of fault code	
Reset condition of fault code	
Electrical diagram(s)	
Technical data	
Possible causes	
Additional information	
Diagnostic Step-by-Step	
Verification Drive Cycle	
	Back to Index


P0669

Code number	P0669
Fault code description	Internal ECU temperature – Internal error
Fault code information	<div>  <div> For further assistance: Contact the PACCAR Engine Support Call Center 1-800-477-0251 </div> </div> <p>Please Contact the Engine Support Center</p>
Description of component(s)	
Location of component(s)	
Diagnostic condition	
Set condition of fault code	
Reset condition of fault code	
Electrical diagram(s)	
Technical data	
Possible causes	
Additional information	
Diagnostic Step-by-Step	
Verification Drive Cycle	
	Back to Index

P0691

Code number	P0691
Fault code description	Electronic controlled fan - Voltage too low or short circuit to ground on ECU D420 pin C74
Fault code information	3 drive cycle recovery Readiness group – None Freeze frame type – Comprehensive
Description of component(s)	<div>  <div> For further assistance: Contact the PACCAR Engine Support Call Center 1-800-477-0251 </div> </div> <p>Please contact the Engine Support Center</p>
Location of component(s)	
Diagnostic condition	
Set condition of fault code	
Reset condition of fault code	
Electrical diagram(s)	
Technical data	
Possible causes	
Additional information	
Diagnostic Step-by-Step	Please refer to chassis wiring information.
Verification Drive Cycle	N/A
	Back to Index

P0692

Code number	P0692
Fault code description	Electronic controlled fan - Voltage too high or short circuit to supply on ECU D420 pin C74
Fault code information	3 drive cycle recovery Readiness group – None Freeze frame type – Comprehensive
Description of component(s)	<div>  <div> For further assistance: Contact the PACCAR Engine Support Call Center 1-800-477-0251 </div> </div> <p>Please contact the Engine Support Center</p>
Location of component(s)	
Diagnostic condition	
Set condition of fault code	
Reset condition of fault code	
Electrical diagram(s)	
Technical data	
Possible causes	
Additional information	
Diagnostic Step-by-Step	Please refer to chassis wiring information.
Verification Drive Cycle	N/A
	Back to Index

P0698

Code number	P0698
Fault code description	ECU PCI 5V sensor supply – Voltage too low or short circuit to ground
Fault code information	1 trip MIL 3 drive cycle recovery Readiness group – None Freeze frame type - Comprehensive
Description of component(s)	This information not required since this is an internal PCI issue
Location of component(s)	This information not required since this is an internal PCI issue
Diagnostic condition	This diagnostic runs continuously when the ignition is on.
Set condition of fault code	The internal ECU reference sensor power supply voltage is too low.
Reset condition of fault code	This DTC changes to inactive when the fault is no longer detected.
Electrical diagram(s)	This information not required since this is an internal PCI issue
Technical data	This information not required since this is an internal PCI issue
Possible causes	Broken reference sensor, internally in ECU.
Additional information	<ul style="list-style-type: none"> Numerous OBD monitors will not run anymore. Engine torque is reduced.
Diagnostic Step-by-Step	
Verification Drive Cycle	
	Back to Index


P0699

Code number	P0699
Fault code description	ECU PCI 5V sensor supply – Voltage too high or short circuit to supply
Fault code information	1 trip MIL 3 drive cycle recovery Readiness group – None Freeze frame type - Comprehensive
Description of component(s)	This information not required since this is an internal PCI issue
Location of component(s)	This information not required since this is an internal PCI issue
Diagnostic condition	This diagnostic runs continuously when the ignition is on.
Set condition of fault code	The internal ECU reference sensor power supply voltage is too high.
Reset condition of fault code	This DTC changes to inactive when the fault is no longer detected.
Electrical diagram(s)	This information not required since this is an internal PCI issue
Technical data	This information not required since this is an internal PCI issue
Possible causes	Broken reference sensor, internally in ECU.
Additional information	<ul style="list-style-type: none"> • Numerous OBD monitors will not run anymore. • Engine torque is reduced.
Diagnostic Step-by-Step	This information not required since this is an internal PCI issue
Verification Drive Cycle	
	Back to Index


P0703

Code number	P0703
Fault code description	CAN communication - Message (EBC1) out of range - EBS brake switch from brake system
Fault code information	3 drive cycle recovery Readiness group – None Freeze frame type – Generic
Description of component(s)	This code relates to a communication issue and not to a specific component.
Location of component(s)	This code relates to a communication issue and not to a specific component.
Diagnostic condition	This diagnostic runs continuously when the ignition is on.
Set condition of fault code	
Reset condition of fault code	This DTC changes to inactive as soon as the error is no longer detected.


Electrical diagram(s)




NAMUX 4 Architecture (Phase 1): T680



NAMUX 3 Architecture



NAMUX 4 Architecture



Technical data

This code relates to a communication issue and not to a specific component.

Possible causes

Check the cabin ECU for fault codes

Additional information

No additional information available

Diagnostic Step-by-Step



Perform the troubleshooting steps below using the breakout harness, if necessary, to check electrical components, such as sensors, electrical control units, and harnesses. Back probing is not recommended, as it could damage the harness. The ignition should always be in the OFF position when connecting or disconnecting electrical components in order to reduce the likelihood of damage to electrical components.



- Disconnecting the EAS connectors during the troubleshooting process will result in multiple errors.
- For specific electrical component information and pinout locations, always refer to the technical data.
- It is necessary to exit the fault code menu in DAVIE and run the diagnostic test again to identify a change in errors.
- Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive fault codes. Refer to the 'possible causes' section.


Step 1	Step ID 0703a	SRT
<p>Visual Inspection</p> <p>OFF the ignition key, disconnect the connector from component and ECU. Visually inspect all applicable connectors (bent, broken, corroded or loose pins) damage to wire harness, sign of exhaust leaks during each step of the diagnostic procedure.</p> <p>Was there evidence of any of the above?</p>		

	<ul style="list-style-type: none">No: Proceed to step 2.Yes: Make the appropriate repairs or component replacements. <p>Use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">If this related fault is no longer active, then this issue has been resolved.If this related fault is still active, Proceed to step 2			
	<table><tr><td>Step 2</td><td>Step ID 0703b</td><td>SRT</td></tr></table> <p>Data check</p> <ul style="list-style-type: none">Lookup the technical data of the specific systemPerform the checking data test of the specific component <p>Is test pass?</p> <ul style="list-style-type: none">No: Proceed to step 3Yes : Proceed to step4	Step 2	Step ID 0703b	SRT
	Step 2	Step ID 0703b	SRT	
	<table><tr><td>Step 3</td><td>Step ID 0703c</td><td>SRT</td></tr></table> <p>Repair or replace component</p> <ul style="list-style-type: none">Repair or replace the component, also check for electrical connection and wiring harness.Reconnect the connectorON the ignition key <p>Use DAVIE to re-check for the presence of active faults:</p> <ul style="list-style-type: none">Is DTC fault active: Proceed to step 4Is DTC fault inactive: Issue resolved. Clear inactive fault.	Step 3	Step ID 0703c	SRT
	Step 3	Step ID 0703c	SRT	
<table><tr><td>Step 4</td><td>Step ID 0703d</td><td>SRT</td></tr></table> <p>For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the Engine Support Call Center at 1-800-477-0251.</p>	Step 4	Step ID 0703d	SRT	
Step 4	Step ID 0703d	SRT		
Verification Drive Cycle	<p>To verify the repair:</p> <p>With the brakes set, turn the key to the ON position with the engine off, and allow 10 seconds for the system to initialize and run diagnostics.</p> <p>With the brakes set, start the engine and allow it to run at idle for 2 minutes.</p>			
	<div>Back to Index</div>			


P081C

Code number	P081C
Fault code description	CAN communication - message (CCVS_VIC) out of range - park brake switch from vehicle controller.
Fault code information	3 drive cycle recovery Readiness group – None Freeze frame type – Generic
Description of component(s)	This code relates to a communication issue and not to a specific component.
Location of component(s)	This code relates to a communication issue and not to a specific component.
Diagnostic condition	This diagnostic runs continuously when the ignition is on.
Set condition of fault code	
Reset condition of fault code	This DTC changes to inactive as soon as the error is no longer detected.
Electrical diagram(s)	<p style="text-align: center;">NAMUX 3 Architecture: 2010 B-Cab</p> <p>The diagram illustrates the NAMUX 3 Architecture for a 2010 B-Cab. The central component is the CECU 3 (Central Electronic Control Unit 3). It is connected to several key systems and components:</p> <ul style="list-style-type: none"> Steering Wheel: Connected via Cab CAN. Cluster: Connected via Instrumentation CAN. MCS (Master Control Switch): Connected via Cab CAN. Diagnostic CAN: Connected via Diagnostic Connector. ABS (Anti-lock Braking System): Connected via Vehicle CAN. PACCAR Display: Connected via Vehicle CAN. Engine: Connected via Engine CAN. Aftertreatment CAN: Connected via After-treatment DCU. Chassis Node: Connected via Frame CAN. This node manages various sensors and actuators: <ul style="list-style-type: none"> VOLTAGE SENSORS, FUEL SENDERS, CURRENT SENSOR, PRESSURE SENSORS, VACUUM SENSOR, and TEMP SENSORS. FRONT LAMPS and TAIL / TRAILER LAMPS. Other Connections: The CECU 3 also interfaces with SWITCHES, SPARE INPUTS, and the CVSG BUS (connected to ELECTRONIC CVSG's). <p>Firewalls are indicated between the Diagnostic CAN and the Vehicle CAN, and between the Vehicle CAN and the Chassis Node.</p>


NAMUX 4 Architecture (Phase 1): T680



NAMUX 3 Architecture



NAMUX 4 Architecture



Technical data

This code relates to a communication issue and not to a specific component.

Possible causes

Check cabin ECU for faults

Additional information

No additional information available

Diagnostic Step-by-Step



Perform the troubleshooting steps below using the breakout harness, if necessary, to check electrical components, such as sensors, electrical control units, and harnesses. Back probing is not recommended, as it could damage the harness. The ignition should always be in the OFF position when connecting or disconnecting electrical components in order to reduce the likelihood of damage to electrical components.



- Disconnecting the EAS connectors during the troubleshooting process will result in multiple errors.
- For specific electrical component information and pinout locations, always refer to the technical data.
- It is necessary to exit the fault code menu in DAVIE and run the diagnostic test again to identify a change in errors.
- Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive fault codes. Refer to the 'possible causes' section.


Step 1	Step ID 081C-a	SRT
Visual Inspection OFF the ignition key, disconnect the connector from component and ECU. Visually inspect all applicable connectors (bent, broken, corroded or loose pins) damage to wire harness, sign of exhaust leaks during each step of the diagnostic procedure.		
Was there evidence of any of the above?		

	<ul style="list-style-type: none">• No: Proceed to step 2.• Yes: Make the appropriate repairs or component replacements. <p>Use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">• If this related fault is no longer active, then this issue has been resolved.• If this related fault is still active, Proceed to step 2			
	<table><tr><td>Step 2</td><td>Step ID 081C-b</td><td>SRT</td></tr></table> <p>Data check</p> <ul style="list-style-type: none">• Lookup the technical data of the specific system• Perform the checking data test of the specific component <p>Is test pass?</p> <ul style="list-style-type: none">• No: Proceed to step 3• Yes : Proceed to step4	Step 2	Step ID 081C-b	SRT
	Step 2	Step ID 081C-b	SRT	
	<table><tr><td>Step 3</td><td>Step ID 081C-c</td><td>SRT</td></tr></table> <p>Repair or replace component</p> <ul style="list-style-type: none">• Repair or replace the component, also check for electrical connection and wiring harness.• Reconnect the connector• ON the ignition key <p>Use DAVIE to re-check for the presence of active faults:</p> <ul style="list-style-type: none">• Is DTC fault active: Proceed to step 4• Is DTC fault inactive: Issue resolved. Clear inactive fault.	Step 3	Step ID 081C-c	SRT
	Step 3	Step ID 081C-c	SRT	
<table><tr><td>Step 4</td><td>Step ID 081C-d</td><td>SRT</td></tr></table> <p>For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the Engine Support Call Center at 1-800-477-0251.</p>	Step 4	Step ID 081C-d	SRT	
Step 4	Step ID 081C-d	SRT		
Verification Drive Cycle	<p>To verify the repair:</p> <p>With the brakes set, turn the key to the ON position with the engine off, and allow 10 seconds for the system to initialize and run diagnostics.</p> <p>With the brakes set, start the engine and allow it to run at idle for 2 minutes.</p>			
	<div>Back to Index</div>			


P0833

Code number	P0833
Fault code description	CAN communication - Message (CCVS) out of range - Clutch switch from vehicle controller
Fault code information	3 drive cycle recovery Readiness group – None Freeze frame type – Generic
Description of component(s)	This code relates to a communication issue and not to a specific component.
Location of component(s)	This code relates to a communication issue and not to a specific component.
Diagnostic condition	This diagnostic runs continuously when the ignition is on.
Set condition of fault code	
Reset condition of fault code	This DTC changes to inactive as soon as the error is no longer detected.


Electrical diagram(s)




NAMUX 4 Architecture (Phase 1): T680



NAMUX 3 Architecture



NAMUX 4 Architecture



Technical data

This code relates to a communication issue and not to a specific component.

Possible causes

Check cabin ECU for faults

Additional information

No additional information available

Diagnostic Step-by-Step



Perform the troubleshooting steps below using the breakout harness, if necessary, to check electrical components, such as sensors, electrical control units, and harnesses. Back probing is not recommended, as it could damage the harness. The ignition should always be in the OFF position when connecting or disconnecting electrical components in order to reduce the likelihood of damage to electrical components.



- Disconnecting the EAS connectors during the troubleshooting process will result in multiple errors.
- For specific electrical component information and pinout locations, always refer to the technical data.
- It is necessary to exit the fault code menu in DAVIE and run the diagnostic test again to identify a change in errors.
- Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive fault codes. Refer to the 'possible causes' section.


Step 1	Step ID 0833a	SRT
<p>Visual Inspection</p> <p>OFF the ignition key, disconnect the connector from component and ECU. Visually inspect all applicable connectors (bent, broken, corroded or loose pins) damage to wire harness, sign of exhaust leaks during each step of the diagnostic procedure.</p> <p>Was there evidence of any of the above?</p>		

	<ul style="list-style-type: none">No: Proceed to step 2.Yes: Make the appropriate repairs or component replacements. <p>Use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">If this related fault is no longer active, then this issue has been resolved.If this related fault is still active, Proceed to step 2			
	<table><tr><td>Step 2</td><td>Step ID 0833b</td><td>SRT</td></tr></table> <p>Data check</p> <ul style="list-style-type: none">Lookup the technical data of the specific systemPerform the checking data test of the specific component <p>Is test pass?</p> <ul style="list-style-type: none">No: Proceed to step 3Yes : Proceed to step4	Step 2	Step ID 0833b	SRT
	Step 2	Step ID 0833b	SRT	
	<table><tr><td>Step 3</td><td>Step ID 0833c</td><td>SRT</td></tr></table> <p>Repair or replace component</p> <ul style="list-style-type: none">Repair or replace the component, also check for electrical connection and wiring harness.Reconnect the connectorON the ignition key <p>Use DAVIE to re-check for the presence of active faults:</p> <ul style="list-style-type: none">Is DTC fault active: Proceed to step 4Is DTC fault inactive: Issue resolved. Clear inactive fault.	Step 3	Step ID 0833c	SRT
	Step 3	Step ID 0833c	SRT	
<table><tr><td>Step 4</td><td>Step ID 0833d</td><td>SRT</td></tr></table> <p>For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the Engine Support Call Center at 1-800-477-0251.</p>	Step 4	Step ID 0833d	SRT	
Step 4	Step ID 0833d	SRT		
Verification Drive Cycle	<p>To verify the repair:</p> <p>With the brakes set, turn the key to the ON position with the engine off, and allow 10 seconds for the system to initialize and run diagnostics.</p> <p>With the brakes set, start the engine and allow it to run at idle for 2 minutes.</p>			
	Back to Index			


P0865

Code number	P0865
Fault code description	CAN communication - Message (PROPB_AST) rate too low from transmission
Fault code information	3 drive cycle recovery Readiness group – None Freeze frame type – Generic
Description of component(s)	This code relates to a communication issue and not to a specific component.
Location of component(s)	This code relates to a communication issue and not to a specific component.
Diagnostic condition	This diagnostic runs continuously when the ignition is on.
Set condition of fault code	
Reset condition of fault code	This DTC changes to inactive as soon as the error is no longer detected.
Electrical diagram(s)	<p style="text-align: center;"><i>NAMUX 3 Architecture: 2010 B-Cab</i></p> <p>The diagram illustrates the NAMUX 3 Architecture for a 2010 B-Cab. The central component is the CECU 3 (Central Electronic Control Unit 3). It is connected to several key systems and components:</p> <ul style="list-style-type: none"> Steering Wheel: Connected via Cab CAN. MCS (Motor Control System): Connected to CECU 3. Diagnostic CAN: Connected to CECU 3 and the Diagnostic Connector. Cluster: Connected via Instrumentation CAN. CVSG BUS: Connected to CECU 3 and Electronic CVSG's. SWITCHES and SPARE INPUTS: Connected to CECU 3. Vehicle CAN: Connected to CECU 3 and the CHASSIS NODE. CHASSIS NODE: Connected to CECU 3 and various sensors/actuators. <ul style="list-style-type: none"> Front Lamps and Tail / Trailer Lamps: Connected to the CHASSIS NODE. Sensors: VOLTAGE SENSORS, FUEL SENDERS, CURRENT SENSOR, PRESSURE SENSORS, VACUUM SENSOR, and TEMP SENSORS are connected to the CHASSIS NODE. Engine and Aftertreatment CAN: Connected to CECU 3 and the CHASSIS NODE. <ul style="list-style-type: none"> Engine: Connected to CECU 3 and the CHASSIS NODE. Aftertreatment CAN: Connected to CECU 3 and the CHASSIS NODE. VGT Actuator and After-treatment DCU: Connected to the CHASSIS NODE. <p>The diagram also shows a FIREWALL separating the CECU 3 from the CHASSIS NODE and the Engine/Aftertreatment CAN system.</p>


NAMUX 4 Architecture (Phase 1): T680



NAMUX 3 Architecture



NAMUX 4 Architecture



Technical data

This code relates to a communication issue and not to a specific component.

Possible causes

- Breakdown in communication in the CAN network
- Open circuit, short circuit to ground, or short circuit to supply in the CAN network wiring

Additional information

No additional information available

Diagnostic Step-by-Step



Perform the troubleshooting steps below using the breakout harness, if necessary, to check electrical components, such as sensors, electrical control units, and harnesses. Back probing is not recommended, as it could damage the harness. The ignition should always be in the OFF position when connecting or disconnecting electrical components in order to reduce the likelihood of damage to electrical components.




- Disconnecting the EAS connectors during the troubleshooting process will result in multiple errors.
- For specific electrical component information and pinout locations, always refer to the technical data.
- It is necessary to exit the fault code menu in DAVIE and run the diagnostic test again to identify a change in errors.
- Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive fault codes. Refer to the 'possible causes' section.



Step 1	Step ID 0865a	SRT
Visual Inspection OFF the ignition key, disconnect the connector from component and ECU. Visually inspect all applicable connectors (bent, broken, corroded or loose pins) damage to wire harness, sign of exhaust leaks during each step of the diagnostic		

	<p>procedure.</p> <ul style="list-style-type: none">Was there evidence of any of the above?No: Proceed to step 2. <p>Yes: Make the appropriate repairs or component replacements. Use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">If this related fault is no longer active, then this issue has been resolved.If this related fault is still active, Proceed to step 2					
	<table><tr><td>Step 2</td><td>Step ID 0865b</td><td>SRT</td></tr></table> <p>Data check</p> <ul style="list-style-type: none">Lookup the technical data of the specific systemPerform the checking data test of the specific component <p>Is test pass?</p> <ul style="list-style-type: none">No: Proceed to step 3Yes : Proceed to step4			Step 2	Step ID 0865b	SRT
	Step 2	Step ID 0865b	SRT			
	<table><tr><td>Step 3</td><td>Step ID 0865c</td><td>SRT</td></tr></table> <p>Repair or replace component</p> <ul style="list-style-type: none">Repair or replace the component, also check for electrical connection and wiring harness.Reconnect the connectorON the ignition key <p>Use DAVIE to re-check for the presence of active faults:</p> <ul style="list-style-type: none">Is DTC fault active: Proceed to step 4Is DTC fault inactive: Issue resolved. Clear inactive fault.			Step 3	Step ID 0865c	SRT
	Step 3	Step ID 0865c	SRT			
<table><tr><td>Step 4</td><td>Step ID 0865d</td><td>SRT</td></tr></table> <p>For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the Engine Support Call Center at 1-800-477-0251.</p>			Step 4	Step ID 0865d	SRT	
Step 4	Step ID 0865d	SRT				
Verification Drive Cycle	To validate repair: <ul style="list-style-type: none">With the brakes set, turn the key to the ON position with the engine off, and allow 10 seconds for the system to initialize and run diagnostics.With the brakes set, start the engine and allow it to run at idle for 2 minutes.					
	Back to Index					

P101E


Code number	P101E
Fault code description	BPV actuator position - Unable to reach target
Fault code information	<p>1 trip MIL</p> <p>3 drive cycle recovery</p> <p>Readiness group - None</p> <p>Freeze frame type - Exhaust gas</p>
Description of component(s)	<p>Back pressure valve (BPV) actuator (L096)</p> <p>The BPV actuator consists of an actuator and a BPV valve.</p> <p>The main task of the BPV valve is to create back pressure in the engine exhaust system and control exhaust gas mass flow.</p> <div style="display: flex; align-items: flex-start;"> <div style="margin-right: 20px;"> <p>1 Lever</p> <p>2 Spring</p> <p>3 Butterfly valve</p> <p>4 BPV actuator</p> </div> <div style="text-align: center;">  <p>0% 100%</p> </div> </div> <p style="text-align: right; font-size: small;">1402268</p> <p>The main components of the BPV actuator are:</p> <ul style="list-style-type: none"> • ECU • Electromotor The electromotor rotates the output shaft via internal gears. • Output shaft The butterfly valve is moved via a lever by rotating the output shaft. • Electromotor position sensor The position of the electromotor is monitored. • Output shaft position sensor The position of the output shaft is monitored. • Temperature sensor The temperature of the ECU printed circuit board is monitored

	<p>Control</p> <p>The BPV actuator is a smart actuator that communicates with the PCI ECU via E-CAN. The actuator ECU is controlled by the PCI ECU but has its own diagnostics on the following actuator inputs and outputs:</p> <ul style="list-style-type: none"> • Power supply voltage • Electromotor position • Electromotor current • Output shaft position • ECU printed circuit board temperature • ECU hardware and software <p>After the ignition is keyed on, the valve position is 100% until the actuator is controlled by the PCI ECU.</p> <p>Unpowered and fail-safe position</p> <p>The unpowered and fail-safe positions of the valve are controlled by a spring and are fully open (100%). If a failure is detected the BPV valve moves to the fail-safe position, if possible.</p> <p>Effect on the system:</p> <ul style="list-style-type: none"> • Creating heat in the exhaust system to heat up the EAS system. A lower opening percentage results in a higher back pressure and more heat. • Decreasing the exhaust gas flow in the exhaust system to heat up the EAS system. A lower opening percentage results in a lower exhaust gas flow in the exhaust system and more heat. • Altering the pressure drop across the turbine rotor for VTG turbo control. • Creating back pressure to create EGR gas flow. • Creating back pressure to create engine braking.
--	--


Location of component(s)	
Diagnostic condition	<p>This diagnostic runs continuously when the ignition is on.</p>
Set condition of fault code	<p>The BPV valve (L096) detects a difference between the actual shaft position and the required shaft position for greater than 5 seconds.</p>
Reset condition of fault code	<p>This DTC changes to inactive after the ignition is keyed off for at least 15 seconds and keyed on again, and the fault is no longer detected.</p>
Electrical diagram(s)	

122E 12-pin interface connector
 123E 7-pin interface connector
 A204 electronic fan interface connector
 D420 PCI ECU
 F852 humidity sensor
 L037 VTG turbocharger actuator
 L095 EGR valve module
 L096 BPV valve

D420	L096	Function
C90	1	E-CAN high
C92	2	E-CAN low
	3	Ground
	4	Power supply after ignition



Wiring harness connector D420.C front view



Wiring harness connector L096 front view



Handle connectors and pins with care and use matching measuring probes.

Technical data

Component check, BPV valve (L096)



This type of component cannot be checked with a multimeter or oscilloscope. Perform the following to assess the component:

- Monitor/test the component with DAVIE
- Perform the wiring check

Wiring check, BPV valve (L096)

Preparation

- Key off the ignition
- Disconnect connector L096

	<ul style="list-style-type: none">Measure on the front side of wiring harness connector L096 <table><tr><th>Pin (+ probe)</th><th>Pin (- probe)</th><th>Value</th><th>Additional information</th></tr><tr><td>4</td><td>3</td><td>Ubat</td><td>Ignition keyed on</td></tr><tr><td>1</td><td>2</td><td>± 60 Ω</td><td><ul style="list-style-type: none">Ignition keyed offGround cable from the battery disconnectedDAVIE Vehicle Communication Interface (VCI) disconnected</td></tr></table>	Pin (+ probe)	Pin (- probe)	Value	Additional information	4	3	Ubat	Ignition keyed on	1	2	± 60 Ω	<ul style="list-style-type: none">Ignition keyed offGround cable from the battery disconnectedDAVIE Vehicle Communication Interface (VCI) disconnected
Pin (+ probe)	Pin (- probe)	Value	Additional information										
4	3	Ubat	Ignition keyed on										
1	2	± 60 Ω	<ul style="list-style-type: none">Ignition keyed offGround cable from the battery disconnectedDAVIE Vehicle Communication Interface (VCI) disconnected										
Possible causes	<ul style="list-style-type: none">Bent actuator lever and/or link rod.Sticking or blocked BPV valve or mechanism.												
Additional information	<ul style="list-style-type: none">The position of the actuator shaft, and therefore the position of the BPV valve, is monitored. Valve position: 0% is fully closed and 100% is fully open.The actuator motor is switched off and the BPV valve is fully open (100% position).Engine torque is reduced after 10 hours of engine operation.												
Diagnostic Step-by-Step	<div><div></div><div><p>The ignition should always be in the OFF position when connecting or disconnecting electrical components to reduce the likelihood of damage to the components.</p></div></div> <div><div></div><div><ul style="list-style-type: none">This troubleshooting procedure is based on the assumption that supply power and ground to the PCI are functioning properly.Disconnecting the PCI connectors during the troubleshooting process will result in multiple errors.Specific electrical component information and pin out locations are provided in this procedure as a reference only. Always refer to the technical data sections in Rapido for the most up-to-date changes.It is necessary to use DAVIE to clear all current DTCs from the PCI and EAS-3 ECUs, and then run the Quick Check to identify a change in DTC status.This DTC can be set as a result of multiple failure modes. For proper fault isolation, complete all troubleshooting steps in the sequence provided.</div></div> <div><p>Step 1 Confirm DTC Status</p><table><tr><th colspan="2">Step 1A Perform a key-cycle</th></tr><tr><td colspan="2">Action</td></tr><tr><td colspan="2">1. Key the ignition off for at least 15 seconds, then key it on again.</td></tr><tr><td colspan="2">Is P101E active?</td></tr><tr><td>Yes</td><td>No</td></tr></table></div>	Step 1A Perform a key-cycle		Action		1. Key the ignition off for at least 15 seconds, then key it on again.		Is P101E active?		Yes	No		
Step 1A Perform a key-cycle													
Action													
1. Key the ignition off for at least 15 seconds, then key it on again.													
Is P101E active?													
Yes	No												


	Refer to step 3A to clear all current codes and run the corresponding repair verification cycles and rechecks, to determine if this DTC was an intermittent or random occurrence.
Go to step 2A	If this DTC is still present, go to step 2A

Step 2 Backpressure Valve (L096) Checks

Step 2A Visual inspection, connection rod installation, BPV valve (L096)

Action

1. Key off the ignition
2. Visually check that the connection rod of the BPV valve mechanism is installed correctly. The arrow must point upward.



1403009

BPV connection rod installation

3. Visually check that the connection rod of the BPV valve mechanism is not damaged.



1402265

Example of a bent lever and connection rod

Is the BPV valve connection rod damaged or installed incorrectly?

Yes

No

Correct the installed connection rod or replace if damaged.
Refer to step 3A to perform the corresponding repair verification cycles and rechecks.

If this DTC is still present, go to step 2B

Go to step 2B

Step 2B Check the free movement of the BPV mechanism



Always set the ignition switch to OFF when working on the BPV mechanism. The valve mechanism can move when the ignition is keyed on, and touching the mechanism can result in physical injury.

Action


1. Set the ignition switch to OFF.
2. Check for free movement of the BPV mechanism by moving the connection rod (1) by hand.






Caution: Do not use a tool to move the backpressure valve mechanism.

Movement of the backpressure valve mechanism requires the application of some force because of the presence of a return spring. During the movement, check that:

- The resistance of the mechanism to move is uniform over the full travel path of the connection rod (1), and
- The actuator shaft (3) and valve shaft (2) rotate over the full travel path of the connection rod (1).



	Backpressure valve mechanism movement	
	Does the BPV mechanism move freely throughout its full range?	
	Yes	No
		Correct any issues found, or replace the BPV (L096) if the valve mechanism does not move freely over the full travel path of the connection rod. Refer to step 3A to perform the corresponding repair verification cycles and rechecks.
	Go to step 2C	If this DTC is still present, go to step 2C
Step 2C Visual inspection, blockage, BPV valve (L096)		
<div><div>Always set the ignition switch to OFF when working on the BPV valve mechanism. The valve mechanism can move when the ignition is keyed on, and touching the mechanism can result in physical injury.</div></div>		
Action		
<div><div>1. Set the ignition switch to OFF.</div><div>2. Loosen the exhaust pipe between the turbocharger and flexible pipe as outlined in the maintenance procedure, “<u>replace back pressure valve assembly</u>” (job ID 66144).</div><div>3. Check if there is an internal blockage or excessive soot accumulation around the butterfly valve and housing. Open the valve by moving the connection rod (1).</div></div>		
<div><div></div><div>Caution: Do not use a tool to move the backpressure valve mechanism.</div></div>		



Manually moving the BPV butterfly valve

Was any internal blockage found within the BPV valve?

Yes

Correct any issues found, or replace the BPV if it was found to be damaged. Refer to step 3A to perform the corresponding repair verification cycles and rechecks.

Go to step 2D

No

A malfunctioning BPV valve has been detected. Replace the BPV valve. Refer to step 3A to perform the corresponding repair verification cycles and rechecks.

If this DTC is still present after performing all steps in the procedure, contact the PACCAR Engine Support Center for further assistance.

Step 2D Exchange BPV valve

Action




1. Key off the ignition.
2. Disconnect the BPV valve connector from the engine wiring harness connector.
3. If available, connect another BPV without installing it.
4. Set the ignition switch to ON, and use DAVIE to view any current DTCs.


Is P101E active?

Yes

No


A malfunctioning BPV valve has been detected. Replace the BPV valve.

	<table border="1"> <tr> <td data-bbox="456 121 1008 258"></td><td data-bbox="1008 121 1531 258">Refer to step 3A to perform the corresponding repair verification cycles and rechecks.</td></tr> <tr> <td data-bbox="456 258 1008 436">If all steps have been completed and this DTC is still present, contact the PACCAR Engine Support Center for further assistance.</td><td data-bbox="1008 258 1531 436"></td></tr> </table>		Refer to step 3A to perform the corresponding repair verification cycles and rechecks.	If all steps have been completed and this DTC is still present, contact the PACCAR Engine Support Center for further assistance.															
	Refer to step 3A to perform the corresponding repair verification cycles and rechecks.																		
If all steps have been completed and this DTC is still present, contact the PACCAR Engine Support Center for further assistance.																			
	<p>Step 3 Repair Verification</p> <table border="1"> <tr> <td colspan="2" data-bbox="456 436 1531 562">Step 3A Repair verification cycles</td></tr> <tr> <td colspan="2" data-bbox="456 562 1531 835"> Perform these repair verification cycles following any corrective actions taken, to enable related OBD monitors to reach a readiness state associated with the DTC or system being investigated. <div>  <p>Before beginning these repair verification cycles, use the DAVIE Diagnostics, Quick Check function to "Clear all" current DTCs from the PCI and EAS-3 ECUs.</p> </div> </td></tr> <tr> <td colspan="2" data-bbox="456 835 1531 993"> Action <ol style="list-style-type: none"> Start-up <p>With the brakes set, start the engine and allow it to run at idle for 2 minutes.</p> </td></tr> <tr> <td colspan="2" data-bbox="456 993 1531 1056">Were the identified repair verification cycles able to be completed?</td></tr> <tr> <td data-bbox="456 1056 1008 1119">Yes</td><td data-bbox="1008 1056 1531 1119">No</td></tr> <tr> <td data-bbox="456 1119 1008 1329"></td><td data-bbox="1008 1119 1531 1329">Investigate and correct any issues preventing these repair verification cycles from being completed, then re-run. For additional assistance, contact the PACCAR Engine Support Center.</td></tr> <tr> <td data-bbox="456 1329 1008 1371">Go to step 3B</td><td data-bbox="1008 1329 1531 1371">Go to step 3B</td></tr> </table> <table border="1"> <tr> <td colspan="2" data-bbox="456 1434 1531 1507">Step 3B DAVIE Diagnostics, Quick Check, OBD Readiness Monitors</td></tr> <tr> <td colspan="2" data-bbox="456 1507 1531 1896"> Action <p>Use DAVIE Diagnostics to perform a Quick Check for current DTCs to determine whether the actions taken have cleared this DTC.</p> <ol style="list-style-type: none"> Confirm that the corresponding OBD Monitor Readiness Status value is displayed as "Ready." <p>A status of Ready indicates that the corresponding OBD monitor has run successfully and the problem has been resolved—no further action. If the displayed status is "Not ready," continue to action step 2.</p> View the DTC overview display, and confirm that P101E has been cleared. </td></tr> </table>	Step 3A Repair verification cycles		Perform these repair verification cycles following any corrective actions taken, to enable related OBD monitors to reach a readiness state associated with the DTC or system being investigated. <div>  <p>Before beginning these repair verification cycles, use the DAVIE Diagnostics, Quick Check function to "Clear all" current DTCs from the PCI and EAS-3 ECUs.</p> </div>		Action <ol style="list-style-type: none"> Start-up <p>With the brakes set, start the engine and allow it to run at idle for 2 minutes.</p> 		Were the identified repair verification cycles able to be completed?		Yes	No		Investigate and correct any issues preventing these repair verification cycles from being completed, then re-run. For additional assistance, contact the PACCAR Engine Support Center.	Go to step 3B	Go to step 3B	Step 3B DAVIE Diagnostics, Quick Check, OBD Readiness Monitors		Action <p>Use DAVIE Diagnostics to perform a Quick Check for current DTCs to determine whether the actions taken have cleared this DTC.</p> <ol style="list-style-type: none"> Confirm that the corresponding OBD Monitor Readiness Status value is displayed as "Ready." <p>A status of Ready indicates that the corresponding OBD monitor has run successfully and the problem has been resolved—no further action. If the displayed status is "Not ready," continue to action step 2.</p> View the DTC overview display, and confirm that P101E has been cleared. 	
Step 3A Repair verification cycles																			
Perform these repair verification cycles following any corrective actions taken, to enable related OBD monitors to reach a readiness state associated with the DTC or system being investigated. <div>  <p>Before beginning these repair verification cycles, use the DAVIE Diagnostics, Quick Check function to "Clear all" current DTCs from the PCI and EAS-3 ECUs.</p> </div>																			
Action <ol style="list-style-type: none"> Start-up <p>With the brakes set, start the engine and allow it to run at idle for 2 minutes.</p> 																			
Were the identified repair verification cycles able to be completed?																			
Yes	No																		
	Investigate and correct any issues preventing these repair verification cycles from being completed, then re-run. For additional assistance, contact the PACCAR Engine Support Center.																		
Go to step 3B	Go to step 3B																		
Step 3B DAVIE Diagnostics, Quick Check, OBD Readiness Monitors																			
Action <p>Use DAVIE Diagnostics to perform a Quick Check for current DTCs to determine whether the actions taken have cleared this DTC.</p> <ol style="list-style-type: none"> Confirm that the corresponding OBD Monitor Readiness Status value is displayed as "Ready." <p>A status of Ready indicates that the corresponding OBD monitor has run successfully and the problem has been resolved—no further action. If the displayed status is "Not ready," continue to action step 2.</p> View the DTC overview display, and confirm that P101E has been cleared. 																			



	Is the related OBD Monitor Readiness Status set to "Ready." Or, has P101E been cleared?	
	Yes	No
	Problem resolved. No further actions.	<p>Continue with the next step in this troubleshooting procedure.</p> <p>If all steps have been completed and this DTC is still present:</p> <ul style="list-style-type: none"> • continue to operate the truck to extend the run time, allowing the corresponding OBD monitor sufficient time to complete • or, return to step 3A and perform this repair verification again. <p>If this issue is still present after extending or re-running the repair verification, contact the PACCAR Engine Support Center for further assistance.</p>
	<div>  <p> Contacting the PACCAR Engine Support Center For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center. </p> </div>	
	Back to Index	

P101F


Code number	P101F
Fault code description	BPV actuator current – Data valid but too high
Fault code information	<p>1 trip MIL</p> <p>3 drive cycle recovery</p> <p>Readiness group - None</p> <p>Freeze frame type - Comprehensive</p>
Description of component(s)	<p>The BPV actuator consists of an actuator and a BPV valve.</p> <p>The main task of the BPV valve is to create back pressure in the engine exhaust system and control exhaust gas mass flow.</p> <ul style="list-style-type: none"> • Lever • Spring • Butterfly valve • BPV actuator <p>The main components of the BPV actuator are:</p> <ul style="list-style-type: none"> • ECU • Electromotor • The electromotor rotates the output shaft via internal gears. • output shaft • The butterfly is moved via a lever by rotating the output shaft • electromotor position sensor • The position of the electromotor is monitored. • output shaft position sensor • The position of the output shaft is monitored. • temperature sensor <p>The temperature of the printed circuit board of the ECU is monitored.</p> <p>Control</p> <p>The BPV actuator is a smart actuator that communicates with the PCI ECU via E-CAN. The actuator ECU is controlled by the PCI ECU but has its own diagnostics on the following actuator inputs and outputs:</p> <ul style="list-style-type: none"> • power supply voltage • electromotor position • electromotor current • output shaft position • ECU printed circuit board temperature • ECU hardware and software <p>After the ignition is keyed on, the valve position is 100% until the actuator is controlled by the PCI ECU.</p> <p>Unpowered and fail-safe position</p> <p>The unpowered and fail-safe positions of the valve are controlled by a spring and are fully open (100%). If a failure is detected the BPV valve moves to the fail-safe position, if possible.</p> <p>Effect on the system:</p> <ul style="list-style-type: none"> • Creating heat in the exhaust system to heat up the EAS system.

	<ul style="list-style-type: none"> • A lower opening percentage results in a higher back pressure and more heat. • Decreasing the exhaust gas flow in the exhaust system to heat up the EAS system. • A lower opening percentage results in a lower exhaust gas flow in the exhaust system and more heat. • Altering the pressure drop across the turbine rotor for VTG turbo control. • Creating back pressure to create EGR gas flow. <p>Creating back pressure to create engine braking.</p>
Location of component(s)	<p style="text-align: center;">L096</p> 
Diagnostic condition	This diagnostic runs continuously when the ignition is on.
Set condition of fault code	The BPV actuator (L020) detects that the measured actuator current is greater than a temperature-dependent value for more than 6 seconds.
Reset condition of fault code	This DTC changes to inactive as soon as the error is no longer detected.

Electrical diagram(s)



Wiring harness connector D420.C front view




Wiring harness connector L096 front view

- 122E 12-pin interface connector
- 123E 7-pin interface connector
- A204 electronic fan interface connector
- D420 PCI ECU
- F852 humidity sensor
- L037 VTG turbocharger actuator
- L095 EGR valve module



	<div>L096 BPV valve</div> <div>D420 L096 Function</div> <div>C90 1 E-CAN high</div> <div>C92 2 E-CAN low</div> <div> 3 Ground</div> <div> </div>
--	--

	diagnostic procedure. Proceed to step 2.		
	Step 2	Step ID 101Fb	SRT
	<p>Electrical Checks (L020)</p> <p>Ensure that the ignition key/switch has been set to OFF before disconnecting related cables.</p> <ul style="list-style-type: none"> • Supply and signal voltages. • Cable continuity (no opens or shorts). <p>Are measured electrical values outside of expected range or limits?</p> <ul style="list-style-type: none"> • No: Continue to the next step 3 in the troubleshooting process. • Yes: Make the appropriate repairs or component replacements. <p>Use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none"> • If this related fault is no longer active, then this issue has been resolved. • If this related fault is still active, continue to the next step 3 in the troubleshooting process. 		
	Step 3	Step ID 101Fc	SRT
	<p>Replace: BPV Actuator</p> <p>If no problems were detected in the preceding steps, an internal problem has most likely occurred with the BPV Actuator.</p> <p>Replace the identified faulty component.</p> <p>Use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none"> • If this related fault is no longer active, then this issue has been resolved. <p>If this related fault is still active, continue to the next step 4 in the troubleshooting process.</p>		
	Step 4	Step ID 101Fd	SRT
	<p>Contact the PACCAR Engine Support Call Center</p> <p>For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center at 1-800-477-0251.</p>		
Verification Drive Cycle	To validate repair, with the brakes set, turn the key to the ON position with the engine off, and allow 10 seconds for the system to initialize and run diagnostics.		
	Back to Index		

P1020


Code number	P1020
Fault code description	BPV actuator – Internal error
Fault code information	1 trip MIL 3 drive cycle recovery Readiness group – None Freeze frame type - Comprehensive
Description of component(s)	<p>Back pressure valve (BPV) actuator (L096)</p> <p>The BPV actuator consists of an actuator and a BPV valve.</p> <p>The main task of the BPV valve is to create back pressure in the engine exhaust system and control exhaust gas mass flow.</p> <div style="display: flex; align-items: flex-start;"> <div style="margin-right: 20px;"> <p>5 Lever</p> <p>6 Spring</p> <p>7 Butterfly valve</p> <p>8 BPV actuator</p> </div> <div style="text-align: center;">  <p style="font-size: small;">1402268</p> </div> </div> <p>The main components of the BPV actuator are:</p> <ul style="list-style-type: none"> • ECU • Electromotor <p>The electromotor rotates the output shaft via internal gears.</p> • Output shaft <p>The butterfly is moved via a lever by rotating the output shaft.</p> • Electromotor position sensor <p>The position of the electromotor is monitored.</p> • Output shaft position sensor <p>The position of the output shaft is monitored.</p> • Temperature sensor <p>The temperature of the ECU printed circuit board is monitored</p>

	<p>Control</p> <p>The BPV actuator is a smart actuator that communicates with the PCI ECU via E-CAN. The actuator ECU is controlled by the PCI ECU but has its own diagnostics on the following actuator inputs and outputs:</p> <ul style="list-style-type: none"> • Power supply voltage • Electromotor position • Electromotor current • Output shaft position • ECU printed circuit board temperature • ECU hardware and software <p>After the ignition is switched on, the valve position is 100% until the actuator is controlled by the PCI ECU.</p> <p>Unpowered and fail-safe position</p> <p>The unpowered and fail-safe positions of the valve are controlled by a spring and are fully open (100%). If a failure is detected the BPV valve moves to the fail-safe position, if possible.</p> <p>Effect on the system:</p> <ul style="list-style-type: none"> • Creating heat in the exhaust system to heat up the EAS system. A lower opening percentage results in a higher back pressure and more heat. • Decreasing the exhaust gas flow in the exhaust system to heat up the EAS system. A lower opening percentage results in a lower exhaust gas flow in the exhaust system and more heat. • Altering the pressure drop across the turbine rotor for VTG turbo control. • Creating back pressure to create EGR gas flow.
--	---


Location of component(s)	
Diagnostic condition	This diagnostic runs continuously when the ignition is on.
Set condition of fault code	The BPV valve (L096) detects an internal error.
Reset condition of fault code	This DTC changes to inactive after the ignition is switched off for at least 15 seconds and switched on again and the error is no longer detected.
Electrical diagram(s)	

122E 12-pin interface connector
 123E 7-pin interface connector
 A204 electronic fan interface connector
 D420 PCI ECU
 F852 humidity sensor
 L037 VTG turbocharger actuator
 L095 EGR valve module
 L096 BPV valve

D420	L096	Function
C90	1	E-CAN high
C92	2	E-CAN low
	3	Ground
	4	Power supply after ignition



Wiring harness connector D420.C front view



Wiring harness connector L096 front view



Handle connectors and pins with care and use matching measuring probes.

Technical data

Component check, BPV valve (L096)



This type of component cannot be checked with a multimeter or oscilloscope. Perform the following to assess the component:

- Monitor/test the component with DAVIE
- Perform the wiring check


Wiring check, BPV valve (L096)

Preparation

- Switch off the ignition
- Disconnect connector L096
- Measure on the front side of wiring harness connector L096

	<table><tr><th>Pin (+ probe)</th><th>Pin (- probe)</th><th>Value</th><th>Additional information</th></tr><tr><td>4</td><td>3</td><td>Ubat</td><td>Ignition switched on</td></tr><tr><td>1</td><td>2</td><td>± 60 Ω</td><td><ul style="list-style-type: none">Ignition switched offGround cable from the battery disconnectedDAVIE Vehicle Communication Interface (VCI) disconnected</td></tr></table>	Pin (+ probe)	Pin (- probe)	Value	Additional information	4	3	Ubat	Ignition switched on	1	2	± 60 Ω	<ul style="list-style-type: none">Ignition switched offGround cable from the battery disconnectedDAVIE Vehicle Communication Interface (VCI) disconnected
Pin (+ probe)	Pin (- probe)	Value	Additional information										
4	3	Ubat	Ignition switched on										
1	2	± 60 Ω	<ul style="list-style-type: none">Ignition switched offGround cable from the battery disconnectedDAVIE Vehicle Communication Interface (VCI) disconnected										
Possible causes	Faulty BPV valve actuator.												
Additional information	<ul style="list-style-type: none">The actuator motor is switched off with this fault active.Engine torque is reduced with this fault active.												
Diagnostic Step-by-Step	<div><div> </div><div><p>The ignition should always be in the OFF position when connecting or disconnecting electrical components to reduce the likelihood of damage to the components.</p><ul style="list-style-type: none">This troubleshooting procedure is based on the assumption that supply power and ground to the PCI are functioning properly.Disconnecting the PCI connectors during the troubleshooting process will result in multiple errors.Specific electrical component information and pin out locations are provided in this procedure as a reference only. Always refer to the technical data sections in Rapido for the most up-to-date changes.It is necessary to use DAVIE to clear all current DTCs from the PCI and EAS-3 ECUs and then run the Quick Check to identify a change in DTC status.This DTC can be set as a result of multiple failure modes. For proper fault isolation, complete all troubleshooting steps in the sequence provided.</div></div> <div><p>Step 1 Investigate Related DTCs</p><p>Before troubleshooting this DTC, take notice of any other active or inactive DTCs. One or multiple other DTCs could have been the cause of this DTC.</p><table><tr><td>Step 1A Investigate related DTCs</td></tr><tr><td>Action 1. Use DAVIE Diagnostics to perform a Quick Check for current DTCs.</td></tr><tr><td>Are these or other related DTCs active? P101E; P1022; P1024; P1025; P1026</td></tr></table></div>			Step 1A Investigate related DTCs	Action 1. Use DAVIE Diagnostics to perform a Quick Check for current DTCs.	Are these or other related DTCs active? P101E; P1022; P1024; P1025; P1026							
Step 1A Investigate related DTCs													
Action 1. Use DAVIE Diagnostics to perform a Quick Check for current DTCs.													
Are these or other related DTCs active? P101E; P1022; P1024; P1025; P1026													

	Yes		No	
	Go to the troubleshooting information for these DTCs before continuing with this procedure.			
			Go to step 1B	
	Step 1B Confirm DTC active state			
	Action			
	1. Power-up/Electrical With the brakes set, switch on the ignition with the engine off, and allow 10 seconds for the system to initialize and run diagnostics.			
	Is P1020 active?			
	Yes		No	
			Refer to step 3A to clear all current DTCs and run the corresponding repair verification cycles and rechecks to determine if this DTC was an intermittent or random occurrence.	
Go to step 2A		If this DTC is still present, go to step 2A		
Step 2 Back Pressure Valve (L096) Checks				
Step 2A Visual inspection, connection rod installation, BPV valve (L096)				
Action				
1. Switch off the ignition.				
2. Visually check that the connection rod of the BPV valve mechanism is installed correctly. The arrow must point upward.				



I403009

BPV connection rod installation

3. Visually check that the connection rod of the BPV valve mechanism is not damaged.



I402265

Example of a bent lever and connection rod

Is the BPV valve connection rod damaged or installed incorrectly?

Yes

No

Correct the installed connection rod or replace if damaged.
Refer to step 3A to perform the corresponding repair verification cycles and rechecks.

If this DTC is still present, go to step 2B

Go to step 2B

Step 2B Check the free movement of the BPV mechanism



Always switch off the ignition when working on the BPV mechanism. The valve mechanism can move when the ignition is switched on and touching the mechanism can result in physical injury.

Action


1. Switch off the ignition.
2. Check for free movement of the BPV mechanism by moving the connection rod (1) by hand.



Caution: Do not use a tool to move the back pressure valve mechanism.

Movement of the back pressure valve mechanism requires the application of some force because of the presence of a return spring. During the movement, check that:

- The resistance of the mechanism to move is uniform over the full travel path of the connection rod (1), and
- The actuator shaft (3) and valve shaft (2) rotate over the full travel path of the connection rod (1).



Back pressure valve mechanism movement

Does the BPV mechanism move freely throughout its full range?

Yes

No

Correct any issues found if the valve mechanism does not move freely over the full travel path of the connection rod.
Refer to step 3A to perform the corresponding repair verification cycles and rechecks.

Go to step 2C

If this DTC is still present, go to step 2C

Step 2C Visual inspection, blockage, BPV valve (L096)




Always switch off the ignition when working on the BPV valve mechanism. The valve mechanism can move when the ignition is switched on and touching the mechanism can result in physical injury.

Action

1. Switch off the ignition.
2. Loosen the exhaust pipe between the BPV valve and flexible pipe as outlined in the maintenance procedure, "replace assembly back pressure valve (aftertreatment, eng.)", job code J 1435 264406 001 033.
3. Check if there is an internal blockage or excessive soot accumulation around the butterfly valve and housing. Open the valve by moving the connection rod (1).



Caution: Do not use a tool to move the back pressure valve mechanism.



Manually moving the BPV butterfly valve

Was any internal blockage found within the BPV valve?

Yes

Correct any issues found or replace the BPV if it was found to be damaged. Refer to step 3A to perform the corresponding repair verification cycles and rechecks.

If this DTC is still present, go to step 2D

No

Go to step 2D

Step 2D Replace BPV valve (L096)

Action

1. Switch off the ignition.
2. Disconnect the BPV valve connector from the engine wiring harness connector.
3. If available, connect another BPV without installing it.
4. Switch on the ignition, and use DAVIE to view any current DTCs.

Is P1020 active?

Yes

No

A malfunctioning BPV valve has been detected. Contact the PACCAR Engine Support Center for further assistance in diagnosing this issue and replacement of the BPV valve.
Refer to step 3A to perform the corresponding repair verification cycles and rechecks.

If all steps have been completed and this DTC is still present, contact the PACCAR Engine Support Center for further assistance.

Step 3 Repair Verification

Step 3A Repair verification cycles

Perform these repair verification cycles following any corrective actions taken to enable related OBD monitors to reach a readiness state associated with the DTC or system being investigated.




Before beginning these repair verification cycles, use the DAVIE Diagnostics, Quick Check function to “Clear all” current DTCs from the PCI and EAS-3 ECUs.

Action


1. Power-up/Electrical
With the brakes set, switch on the ignition with the engine off, and allow 10 seconds for the system to initialize and run diagnostics.

Were the identified repair verification cycles able to be completed?

	Yes	No
		Investigate and correct any issues preventing these repair verification cycles from being completed, then re-run. For additional assistance, contact the PACCAR Engine Support Center.
	Go to step 3B	
	Step 3B DAVIE Diagnostics, Quick Check, OBD Readiness Monitors	
	Action Use DAVIE Diagnostics to perform a Quick Check for current DTCs to determine whether the actions taken have cleared this DTC. 1. Confirm that the corresponding OBD Monitor Readiness Status value is displayed as “Ready.” A status of Ready indicates that the corresponding OBD monitor has run successfully and the problem has been resolved—no further action. If the displayed status is “Not ready,” continue to action step 2. 2. View the DTC overview display and confirm that P1020 has been cleared.	
	Is the related OBD Monitor Readiness Status set to “Ready.” Or, has P1020 been cleared?	
	Yes	No
	Problem resolved. No further actions.	Continue with the next step in this troubleshooting procedure. If all steps have been completed and this DTC is still present: <ul style="list-style-type: none">• continue to operate the truck to extend the run time, allowing the corresponding OBD monitor sufficient time to complete• or, return to step 3A and perform this repair verification again. If this issue is still present after extending or re-running the repair verification, contact the PACCAR Engine Support Center for further assistance.

	 <p>Contacting the PACCAR Engine Support Call Center</p> <p>For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center.</p>
	Back to Index

P1021

Code number	P1021
Fault code description	BPV actuator – CAN communication error
Fault code information	<p>1 trip MIL</p> <p>3 drive cycle recovery</p> <p>Readiness group – None</p> <p>Freeze frame type – Comprehensive</p>
Description of component(s)	<p>Back pressure valve (BPV) actuator (L096)</p> <p>The BPV actuator consists of an actuator and a BPV valve.</p> <p>The main task of the BPV valve is to create back pressure in the engine exhaust system and control exhaust gas mass flow.</p> <div style="display: flex; align-items: flex-start;"> <div style="margin-right: 20px;"> <p>9 Lever</p> <p>10 Spring</p> <p>11 Butterfly valve</p> <p>12 BPV actuator</p> </div> <div style="text-align: center;">  <p style="font-size: small;">1402268</p> </div> </div> <p>The main components of the BPV actuator are:</p> <ul style="list-style-type: none"> • ECU • Electromotor The electromotor rotates the output shaft via internal gears. • Output shaft The butterfly valve is moved via a lever by rotating the output shaft. • Electromotor position sensor The position of the electromotor is monitored. • Output shaft position sensor The position of the output shaft is monitored. • Temperature sensor The temperature of the ECU printed circuit board is monitored

Control

The BPV actuator is a smart actuator that communicates with the PCI ECU via E-CAN. The actuator ECU is controlled by the PCI ECU but has its own diagnostics on the following actuator inputs and outputs:

- Power supply voltage
- Electromotor position
- Electromotor current
- Output shaft position
- ECU printed circuit board temperature
- ECU hardware and software



After the ignition is keyed on, the valve position is 100% until the actuator is controlled by the PCI ECU.

Unpowered and fail-safe position

The unpowered and fail-safe positions of the valve are controlled by a spring and are fully open (100%). If a failure is detected the BPV valve moves to the fail-safe position, if possible.


Effect on the system:

- Creating heat in the exhaust system to heat up the EAS system.
A lower opening percentage results in a higher back pressure and more heat.
- Decreasing the exhaust gas flow in the exhaust system to heat up the EAS system.
A lower opening percentage results in a lower exhaust gas flow in the exhaust system and more heat.
- Altering the pressure drop across the turbine rotor for VTG turbo control.
- Creating back pressure to create EGR gas flow.
- Creating back pressure to create engine braking.


<p>Location of component(s)</p>	 <p>I402298</p>
<p>Diagnostic condition</p>	<p>This diagnostic runs continuously when the ignition is on.</p>
<p>Set condition of fault code</p>	<p>The BPV actuator (L020) detects that the cyclic CAN command message transmitted by the PCI ECU (D420) is missing for more than 2 seconds.</p>
<p>Reset condition of fault code</p>	<p>This DTC changes to inactive as soon as the error is no longer detected.</p>
<p>Electrical diagram(s)</p>	 <p>I402298</p>

122E 12-pin interface connector
 123E 7-pin interface connector
 A204 electronic fan interface connector
 D420 PCI ECU
 F852 humidity sensor
 L037 VTG turbocharger actuator
 L095 EGR valve module
 L096 BPV valve

D420	L096	Function
C90	1	E-CAN high
C92	2	E-CAN low
	3	Ground
	4	Power supply after ignition



Wiring harness connector D420.C front view



Wiring harness connector L096 front view




Handle connectors and pins with care and use matching measuring probes.

Technical data

Component check, BPV valve (L096)

This type of component cannot be checked with a multimeter or oscilloscope. Perform the following to assess the component:

- Monitor/test the component with DAVIE
- Perform the wiring check

	<p>Wiring check, BPV valve (L096)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key off the ignition• Disconnect connector L096• Measure on the front side of wiring harness connector L096 <table><tr><th>Pin (+ probe)</th><th>Pin (- probe)</th><th>Value</th><th>Additional information</th></tr><tr><td>4</td><td>3</td><td>Ubat</td><td>Ignition keyed on</td></tr><tr><td>1</td><td>2</td><td>~ 60 Ω</td><td><ul style="list-style-type: none">• Ignition keyed off• Ground cable from the battery disconnected• DAVIE Vehicle Communication Interface (VCI) disconnected</td></tr></table>	Pin (+ probe)	Pin (- probe)	Value	Additional information	4	3	Ubat	Ignition keyed on	1	2	~ 60 Ω	<ul style="list-style-type: none">• Ignition keyed off• Ground cable from the battery disconnected• DAVIE Vehicle Communication Interface (VCI) disconnected
Pin (+ probe)	Pin (- probe)	Value	Additional information										
4	3	Ubat	Ignition keyed on										
1	2	~ 60 Ω	<ul style="list-style-type: none">• Ignition keyed off• Ground cable from the battery disconnected• DAVIE Vehicle Communication Interface (VCI) disconnected										
Possible causes	CAN wiring, see "General troubleshooting - CAN"												
Additional information	<ul style="list-style-type: none">• The BPV actuator (L020) is controlled by a cyclic CAN command message transmitted by the PCI ECU (D420) in which the operating mode and the target position are demanded.• There is still CAN communication between the BPV actuator and PCI ECU with this fault active.• The actuator motor is switched off and the BPV valve is fully opened (100% position) with this fault active.• Engine torque is reduced with this fault active.												
Diagnostic Step-by-Step	<div><div></div><div>This DTC can be set as a result of multiple failure modes. All steps of the troubleshooting tree must be completed.</div></div> <p>Step 1. Perform a key-cycle</p> <table><tr><th colspan="2">Step 1.A Perform a key-cycle</th></tr><tr><td colspan="2">Action</td></tr><tr><td colspan="2">2. Key the ignition off for at least 15 seconds, then key it on again.</td></tr><tr><td colspan="2">Is DTC P1021 active?</td></tr><tr><td>Yes</td><td>No</td></tr><tr><td>Go to Error! Reference source not found.</td><td>Go to 5.A</td></tr></table>	Step 1.A Perform a key-cycle		Action		2. Key the ignition off for at least 15 seconds, then key it on again.		Is DTC P1021 active?		Yes	No	Go to Error! Reference source not found.	Go to 5.A
Step 1.A Perform a key-cycle													
Action													
2. Key the ignition off for at least 15 seconds, then key it on again.													
Is DTC P1021 active?													
Yes	No												
Go to Error! Reference source not found.	Go to 5.A												

Step 2. Visual inspection , BPV valve

Step 2.A Visual inspection, BPV valve connections and wiring

Action

5. Key off the ignition.
6. Visually inspect the connections and wiring for any of the following:
 - Damaged or loose connectors
 - Bent, broken, corroded, or loose connector pins
 - Moisture or dirt in the connections
 - Damage to the wire harness or insulation
 - ECU connections are damaged or disconnected

Is there evidence of any of the above?

Yes

No

Correct any issues found.

Go to 3.A

Go to 5.A

Step 3. Electrical Checks, BPV valve

Step 3.A Check the BPV valve CAN connection and power supply

Action

1. Monitor the vehicle power supply during engine startup and operation.
2. Check the actuator CAN connection and power supply according to "Checking data, BPV valve (L096)".

Are the CAN connection and power supply values within the specifications?

Yes

No

Repair or replace components and/or wiring as necessary.

Go to 4.A

Go to 5.A

Step 4. Try another BPV valve

Step 4.A Try another BPV valve

Action

3. Key off the ignition.
4. Disconnect the BPV valve connector from the engine wiring harness connector.
5. If available, connect another BPV valve without installing it.

Is P1021 active?

Yes

No

A malfunctioning BPV valve has been detected. Replace the BPV valve.



Malfunctioning of the originally installed actuator can be confirmed if DTC P1021 becomes active again when it is reconnected to the engine wiring harness connector.

For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center at 1-800-477-0251.

Go to 5.A

Step 5. Reset the DTCs

Step 5.A Reset the DTCs

Action


1. Reset the DTCs
2. Troubleshooting active DTCs

DTCs reset?


Yes

No

Return to troubleshooting steps.

	Repair complete	Go to 1.A
Verification Drive Cycle	<p>Perform these repair verification cycles following any corrective actions taken, to confirm that this fault is no longer active.</p> <div>  <p>Before beginning these repair verification cycles, use the DAVIE Quick Check function to clear all current DTCs from the PCI and EAS-3 ECUs.</p> </div> <p>Start-up</p> <p>With the brakes set, start the engine and allow it to run at idle for 2 minutes.</p>	
	Back to Index	

P1022

Code number	P1022
Fault code description	BPV actuator – Internal short circuit detected
Fault code information	1 trip MIL 3 drive cycle recovery Readiness group – None Freeze frame type - Comprehensive
Description of component(s)	<p>Back pressure valve (BPV) actuator (L096)</p> <p>The BPV actuator consists of an actuator and a BPV valve.</p> <p>The main task of the BPV valve is to create back pressure in the engine exhaust system and control exhaust gas mass flow.</p> <div style="display: flex; align-items: flex-start;"> <div style="margin-right: 20px;"> <p>13 Lever</p> <p>14 Spring</p> <p>15 Butterfly valve</p> <p>16 BPV actuator</p> </div> <div style="text-align: center;">  </div> </div> <p>The main components of the BPV actuator are:</p> <ul style="list-style-type: none"> • ECU • Electromotor The electromotor rotates the output shaft via internal gears. • Output shaft The butterfly valve is moved via a lever by rotating the output shaft. • Electromotor position sensor The position of the electromotor is monitored. • Output shaft position sensor The position of the output shaft is monitored. • Temperature sensor The temperature of the ECU printed circuit board is monitored

Control

The BPV actuator is a smart actuator that communicates with the PCI ECU via E-CAN. The actuator ECU is controlled by the PCI ECU but has its own diagnostics on the following actuator inputs and outputs:

- Power supply voltage
- Electromotor position
- Electromotor current
- Output shaft position
- ECU printed circuit board temperature
- ECU hardware and software



After the ignition is keyed on, the valve position is 100% until the actuator is controlled by the PCI ECU.

Unpowered and fail-safe position

The unpowered and fail-safe positions of the valve are controlled by a spring and are fully open (100%). If a failure is detected the BPV valve moves to the fail-safe position, if possible.


Effect on the system:

- Creating heat in the exhaust system to heat up the EAS system.
A lower opening percentage results in a higher back pressure and more heat.
- Decreasing the exhaust gas flow in the exhaust system to heat up the EAS system.
A lower opening percentage results in a lower exhaust gas flow in the exhaust system and more heat.
- Altering the pressure drop across the turbine rotor for VTG turbo control.
- Creating back pressure to create EGR gas flow.
- Creating back pressure to create engine braking.


Location of component(s)	
Diagnostic condition	This diagnostic runs continuously when the ignition is on.
Set condition of fault code	The BPV valve (L096) detects that the internal actuator current is too high.
Reset condition of fault code	This DTC changes to inactive as soon as the fault is no longer detected.
Electrical diagram(s)	

122E 12-pin interface connector
 123E 7-pin interface connector
 A204 electronic fan interface connector
 D420 PCI ECU
 F852 humidity sensor
 L037 VTG turbocharger actuator
 L095 EGR valve module
 L096 BPV valve

D420	L096	Function
C90	1	E-CAN high
C92	2	E-CAN low
	3	Ground
	4	Power supply after ignition



Wiring harness connector D420.C front view



Wiring harness connector L096 front view



Handle connectors and pins with care and use matching measuring probes.

Technical data

Component check, BPV valve (L096)

This type of component cannot be checked with a multimeter or oscilloscope. Perform the following to assess the component:

- Monitor/test the component with DAVIE
- Perform the wiring check

Wiring check, BPV valve (L096)

Preparation

- Key off the ignition
- Disconnect connector L096
- Measure on the front side of wiring harness connector L096

Pin (+ probe)	Pin (- probe)	Value	Additional information
4	3	Ubat	Ignition keyed on
1	2	~ 60 Ω	<ul style="list-style-type: none"> • Ignition keyed off • Ground cable from the battery disconnected • DAVIE Vehicle Communication Interface (VCI) disconnected

Possible causes

- High friction or sticking BPV valve bearings or mechanism.
- Blocked BPV valve.

Additional information

- The actuator current is monitored.
- The actuator motor is switched off and the BPV valve is fully opened (100% position) with this fault active.
- Engine torque is reduced after 10 hours of engine operation.

Diagnostic Step-by-Step



This DTC can be set as a result of multiple failure modes. All steps of the troubleshooting tree must be completed.

Step 1. Perform a key-cycle

Step 1. A Perform a key-cycle

Action

3. Key the ignition off for at least 15 seconds, then key it on again.

Is DTC P1022 active?

Yes

No

Go to 2.A

Step 2.B


Step 2. Check the BPV valve

Step 2. A Visual inspection, BPV valve mechanism

Action

4. Key off the ignition
5. Visually check that the connection rod of the BPV valve mechanism is installed correctly. The arrow must point upward.

Correct the installed connection rod.



I403009

Is the BPV valve mechanism free of damage?

Yes

No

Go to 2.B

Go to 4.A

Step 2.B Visual inspection, BPV valve mechanism

Action

1. Key off the ignition
2. Visually check that the connection rod of the BPV valve mechanism is free of damage.

Correct valve mechanism



I402210

Example of a bent lever and connection rod



I402265

Is the BPV valve mechanism free of damage?

Yes

No

Go to 2.C

Go to 4.A

Step 2.C Check the free movement of the BPV valve mechanism



The valve mechanism can move when the ignition is keyed on. Touching the mechanism can result in physical injury.


- Always key off the ignition when working on the BPV valve mechanism

Action

3. Key off the ignition
4. Check the free movement of the valve mechanism by moving the connection rod (1) by hand.

The movement requires some force because of the presence of a return spring. Check during the movement that:

- The resistance of the mechanism to move is uniform over the full travel path of the connection rod (1), and
- The actuator shaft (3) and valve shaft (2) rotate over the full travel path of the connection rod (1).



Do not use a tool to move the mechanism.

Does the BPV valve mechanism move freely?

Yes

No

Go to 3.A

Go to 2.D

Step 2.D Check for blockage in the BPV valve housing




The valve mechanism can move when the ignition is keyed on. Touching the mechanism can result in physical injury.

- Always key off the ignition when working on the BPV valve mechanism.
- Maintain a safe distance if the valve is monitored with the ignition keyed on.

Action

4. Key off the ignition
5. Loosen the exhaust pipe between the turbocharger and flexible pipe according to the job, Replace back pressure valve assembly.
6. Check if there is an internal blockage or excessive soot accumulation around the butterfly valve and housing. Open the valve by moving the connection rod (1).



Do not use a tool to move the mechanism.

Was any blockage found?

Yes	No
<ol style="list-style-type: none"> 1. Remove blockage/clean the internal valve housing. 2. Monitor the BPV valve position with DAVIE, to check that the cleaning was effective. 3. Install the exhaust pipe between the turbocharger and flexible pipe according to the job, <u>Replace back pressure valve assembly</u>. 	<p>A malfunctioning BPV valve has been detected. Replace the BPV valve.</p>
Go to 4.A	Go to 4.A

Step 3. Try another BPV valve

Step 3. A Try another BPV valve

Action

7. Key off the ignition.
8. Disconnect the BPV valve connector from the engine wiring harness connector.
9. If available, connect another BPV valve without installing it.

Is P1022 active?

Yes

No

A malfunctioning BPV valve has been detected. Replace the BPV valve.



Malfunctioning of the originally installed actuator can be confirmed if DTC P1022 becomes active again when it is reconnected to the engine wiring harness connector.

For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center at 1-800-477-0251.

Go to 4.A

Step 4. Reset the DTCs

Step 4.A Reset the DTCs

Action

- Reset the DTCs
- If DTCs are still present, troubleshoot the active DTCs.

DTCs reset?

Yes

No


Return to troubleshooting steps.

Repair complete


Go to 1.A

Verification Drive Cycle	<p>Perform these repair verification cycles following any corrective actions taken, to confirm that this fault is no longer active.</p> <div data-bbox="444 306 532 394" data-label="Image"> </div> <p>Before beginning these repair verification cycles, use the DAVIE Quick Check function to clear all current DTCs from the PCI and EAS-3 ECUs.</p> <p>Start-up</p> <p>With the brakes set, start the engine and allow it to run at idle for 2 minutes.</p>
	Back to Index


P1023

Code number	P1023
Fault code description	BPV actuator temperature - Data valid but too high
Fault code information	<p>1 trip MIL</p> <p>3 drive cycle recovery</p> <p>Readiness group – None</p> <p>Freeze frame type – Exhaust gas</p>
Description of component(s)	<p>Back pressure valve (BPV) actuator (L096)</p> <p>The BPV actuator consists of an actuator and a BPV valve.</p> <p>The main task of the BPV valve is to create back pressure in the engine exhaust system and control exhaust gas mass flow.</p> <div style="display: flex; align-items: flex-start;"> <div style="margin-right: 20px;"> <p>17 Lever</p> <p>18 Spring</p> <p>19 Butterfly valve</p> <p>20 BPV actuator</p> </div> <div style="text-align: center;">  <p>0% 100%</p> <p style="font-size: small;">1402266</p> </div> </div> <p>The main components of the BPV actuator are:</p> <ul style="list-style-type: none"> • ECU • Electromotor The electromotor rotates the output shaft via internal gears. • Output shaft The butterfly valve is moved via a lever by rotating the output shaft. • Electromotor position sensor The position of the electromotor is monitored. • Output shaft position sensor The position of the output shaft is monitored. • Temperature sensor

	<p>The temperature of the ECU printed circuit board is monitored</p> <p>Control</p> <p>The BPV actuator is a smart actuator that communicates with the PCI ECU via E-CAN. The actuator ECU is controlled by the PCI ECU but has its own diagnostics on the following actuator inputs and outputs:</p> <ul style="list-style-type: none"> • Power supply voltage • Electromotor position • Electromotor current • Output shaft position • ECU printed circuit board temperature • ECU hardware and software <p>After the ignition is keyed on, the valve position is 100% until the actuator is controlled by the PCI ECU.</p> <p>Unpowered and fail-safe position</p> <p>The unpowered and fail-safe positions of the valve are controlled by a spring and are fully open (100%). If a failure is detected the BPV valve moves to the fail-safe position, if possible.</p> <p>Effect on the system:</p> <ul style="list-style-type: none"> • Creating heat in the exhaust system to heat up the EAS system. A lower opening percentage results in a higher back pressure and more heat. • Decreasing the exhaust gas flow in the exhaust system to heat up the EAS system. A lower opening percentage results in a lower exhaust gas flow in the exhaust system and more heat. • Altering the pressure drop across the turbine rotor for VTG turbo control. • Creating back pressure to create EGR gas flow. • Creating back pressure to create engine braking.
--	---

Location of component(s)	 <p style="text-align: right;">1402298</p>
Diagnostic condition	<p>This diagnostic runs continuously when the ignition is on.</p>
Set conditions	<p>The BPV valve (L096) detects that the temperature of the actuator is greater than 142°C for more than 30 seconds.</p>
Reset conditions	<p>This DTC changes to inactive after the ignition is keyed off for at least 15 seconds and keyed on again, and the fault is no longer detected.</p>

Electrical diagram(s)



122E 12-pin interface connector

123E 7-pin interface connector

A204 electronic fan interface connector

D420 PCI ECU


F852 humidity sensor

L037 VTG turbocharger actuator


L095 EGR valve module

L096 BPV valve

D420	L096	Function
C90	1	E-CAN high
C92	2	E-CAN low
	3	Ground
	4	Power supply after ignition



Wiring harness connector D420.C front view



Wiring harness connector L096 front view

E504124



Handle connectors and pins with care and use matching measuring probes.

Technical data

Component check, BPV valve (L096)

This type of component cannot be checked with a multimeter or oscilloscope.
Perform the following to assess the component:

- Monitor/test the component with DAVIE
- Perform the wiring check

Wiring check, BPV valve (L096)

Preparation

- Key off the ignition
- Disconnect connector L096
- Measure on the front side of wiring harness connector L096


Pin (+ probe)	Pin (- probe)	Value	Additional information
4	3	Ubat	Ignition keyed on
1	2	~ 60 Ω	<ul style="list-style-type: none"> • Ignition keyed off • Ground cable from the battery disconnected • DAVIE Vehicle Communication Inter (VCI) disconnected


Possible causes


- The ignition is keyed on shortly after a hot engine shutdown.
- Malfunctioning cooling system
Check the engine cooling system for:
 - Low coolant level
 - Air in cooling system
 - Blocked cooling pipes to the actuator

Additional information


- The temperature is measured on the (printed circuit board) of the actuator.
- The actuator motor is switched off and the BPV valve is fully opened (100% position) with this fault active.

	<ul style="list-style-type: none">Engine torque is reduced with this fault active.																																				
Diagnostic Step-by-Step	<div><div></div><div>This DTC can be set as a result of multiple failure modes. All steps of the troubleshooting tree must be completed.</div></div> <div>Step 1. Perform a key cycle</div> <table><tr><td colspan="2">Step 1. A Perform a key-cycle</td></tr><tr><td colspan="2">Action</td></tr><tr><td colspan="2">4. Key the ignition off for at least 15 seconds, then key it on again.</td></tr><tr><td colspan="2">Is DTC P1023 active?</td></tr><tr><td>Yes</td><td>No</td></tr><tr><td>Go to 3.A</td><td>Step 2.A</td></tr></table> <div>Step 2. Operate the engine at normal operating temperature</div> <table><tr><td colspan="2">Step 2. A Check for an active P1023</td></tr><tr><td colspan="2">Action</td></tr><tr><td colspan="2">1. Operate the engine at normal operating temperature.</td></tr><tr><td colspan="2">Is DTC P1023 active?</td></tr><tr><td>Yes</td><td>No</td></tr><tr><td>Go to 3.A</td><td>Step 5.A</td></tr></table> <div>Step 3. Check the cooling system</div> <table><tr><td colspan="2">Step 3. A Check the coolant level of the vehicle cooling system</td></tr><tr><td colspan="2">Action</td></tr><tr><td colspan="2">1. Check the coolant level</td></tr><tr><td colspan="2">Is the coolant level correct?</td></tr><tr><td>Yes</td><td>No</td></tr><tr><td></td><td>Refill the coolant level</td></tr></table>	Step 1. A Perform a key-cycle		Action		4. Key the ignition off for at least 15 seconds, then key it on again.		Is DTC P1023 active?		Yes	No	Go to 3.A	Step 2.A	Step 2. A Check for an active P1023		Action		1. Operate the engine at normal operating temperature.		Is DTC P1023 active?		Yes	No	Go to 3.A	Step 5.A	Step 3. A Check the coolant level of the vehicle cooling system		Action		1. Check the coolant level		Is the coolant level correct?		Yes	No		Refill the coolant level
Step 1. A Perform a key-cycle																																					
Action																																					
4. Key the ignition off for at least 15 seconds, then key it on again.																																					
Is DTC P1023 active?																																					
Yes	No																																				
Go to 3.A	Step 2.A																																				
Step 2. A Check for an active P1023																																					
Action																																					
1. Operate the engine at normal operating temperature.																																					
Is DTC P1023 active?																																					
Yes	No																																				
Go to 3.A	Step 5.A																																				
Step 3. A Check the coolant level of the vehicle cooling system																																					
Action																																					
1. Check the coolant level																																					
Is the coolant level correct?																																					
Yes	No																																				
	Refill the coolant level																																				


	Go to 3.B	Step 2.A
	Step 3. B Inspect the actuator cooling circuit	
	Action <ol style="list-style-type: none"> 1. Check the coolant supply and return pipes of the BPV actuator according to the maintenance job, <u>Check/clean all coolant pipes</u>. 	
	Does the actuator cooling work sufficiently?	
	Yes	No
		Clean/replace the contaminated or damaged coolant pipe.
	Go to 4.A	Step 2.A
	Step 4. Try another BPV valve	
	Step 4. A Try another BPV valve	
	Action <ol style="list-style-type: none"> 10. Key off the ignition. 11. Disconnect the BPV valve connector from the engine wiring harness connector. 12. If available, connect another BPV valve without installing it. 	
	Is P1023 active?	
	Yes	No
		A malfunctioning BPV valve has been detected. Replace the BPV valve. <div>  Malfunctioning of the original P1022 becomes active again when the original harness connector is reconnected. </div>
	For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call	Go to 4.A

	<div data-bbox="495 130 1510 310"> <div>Center at 1-800-477-0251.</div> <div></div> </div> <div data-bbox="495 382 773 411"> <p>Step 5. Reset the DTCs</p> </div> <div data-bbox="495 436 1520 1035"> <div data-bbox="495 436 1520 550"> <p>Step 5.A Reset the DTCs</p> </div> <div data-bbox="495 550 1520 737"> <p>Action</p> <p>Reset the DTCs</p> <p>If DTCs are still present, troubleshoot the active DTCs.</p> </div> <div data-bbox="495 737 1520 810"> <p>DTCs reset?</p> </div> <div data-bbox="495 810 1520 884"> <table> <tr> <td>Yes</td><td>No</td></tr> </table> </div> <div data-bbox="495 884 1520 957"> <table> <tr> <td></td><td>Return to troubleshooting step 1.A</td></tr> </table> </div> <div data-bbox="495 957 1520 1035"> <table> <tr> <td>Repair complete</td><td>Go to 1.A</td></tr> </table> </div> </div>	Yes	No		Return to troubleshooting step 1.A	Repair complete	Go to 1.A
Yes	No						
	Return to troubleshooting step 1.A						
Repair complete	Go to 1.A						
<p>Verification Drive Cycle</p>	<p>Perform these repair verification cycles following any corrective actions taken, to confirm that this fault is no longer active.</p> <div data-bbox="505 1281 591 1369">  </div> <p>Before beginning these repair verification cycles, use the DAVIE Quick Check function to clear DTCs from the PCI and EAS-3 ECUs.</p> <p>Start-up</p> <p>With the brakes set, start the engine and allow it to run at idle for 2 minutes.</p>						
	<p>Back to Index</p>						


P1024

Code number	P1024
Fault code description	BPV actuator power supply – Incorrect
Fault code information	<p>1 trip MIL</p> <p>3 drive cycle recovery</p> <p>Readiness group – None</p> <p>Freeze frame type – Comprehensive</p>
Description of component(s)	<p>Back pressure valve (BPV) actuator (L096)</p> <p>The BPV actuator consists of an actuator and a BPV valve.</p> <p>The main task of the BPV valve is to create back pressure in the engine exhaust system and control exhaust gas mass flow.</p> <div style="display: flex; align-items: flex-start;"> <div style="margin-right: 20px;"> <p>21 Lever</p> <p>22 Spring</p> <p>23 Butterfly valve</p> <p>24 BPV actuator</p> </div> <div style="text-align: center;">  <p style="font-size: small;">1402266</p> </div> </div> <p>The main components of the BPV actuator are:</p> <ul style="list-style-type: none"> • ECU • Electromotor The electromotor rotates the output shaft via internal gears. • Output shaft The butterfly valve is moved via a lever by rotating the output shaft. • Electromotor position sensor The position of the electromotor is monitored. • Output shaft position sensor The position of the output shaft is monitored. • Temperature sensor

	<p>The temperature of the ECU printed circuit board is monitored</p> <p>Control</p> <p>The BPV actuator is a smart actuator that communicates with the PCI ECU via E-CAN. The actuator ECU is controlled by the PCI ECU but has its own diagnostics on the following actuator inputs and outputs:</p> <ul style="list-style-type: none"> • Power supply voltage • Electromotor position • Electromotor current • Output shaft position • ECU printed circuit board temperature • ECU hardware and software <p>After the ignition is keyed on, the valve position is 100% until the actuator is controlled by the PCI ECU.</p> <p>Unpowered and fail-safe position</p> <p>The unpowered and fail-safe positions of the valve are controlled by a spring and are fully open (100%). If a failure is detected the BPV valve moves to the fail-safe position, if possible.</p> <p>Effect on the system:</p> <ul style="list-style-type: none"> • Creating heat in the exhaust system to heat up the EAS system. A lower opening percentage results in a higher back pressure and more heat. • Decreasing the exhaust gas flow in the exhaust system to heat up the EAS system. A lower opening percentage results in a lower exhaust gas flow in the exhaust system and more heat. • Altering the pressure drop across the turbine rotor for VTG turbo control. • Creating back pressure to create EGR gas flow. • Creating back pressure to create engine braking.
--	---


Location of component(s)	 <p style="text-align: right;">1402298</p>
Diagnostic condition	This diagnostic runs continuously when the ignition is on.
Set condition of fault code	The BPV actuator (L096) detects that the actuator power supply is less than 7.5 V or more than 35 V.
Reset condition of fault code	This DTC changes to inactive when the actuator power supply is between 8.5 V and 34 V.

Electrical diagram(s)




- 122E 12-pin interface connector
- 123E 7-pin interface connector
- A204 electronic fan interface connector
- D420 PCI ECU
- F852 humidity sensor
- L037 VTG turbocharger actuator
- L095 EGR valve module
- L096 BPV valve

D420	L096	Function
C90	1	E-CAN high
C92	2	E-CAN low
	3	Ground
	4	Power supply after ignition




Wiring harness connector D420.C front view



Wiring harness connector L096 front view

E504124

	<div><div></div><div>Handle connectors and pins with care and use matching measuring probes.</div></div>												
Technical data	<div><div>Component check, BPV valve (L096)</div><div>This type of component cannot be checked with a multimeter or oscilloscope. Perform the following to assess the component:<ul style="list-style-type: none">Monitor/test the component with DAVIEPerform the wiring check</div><div><div>Wiring check, BPV valve (L096)</div><div>Preparation<ul style="list-style-type: none">Key off the ignitionDisconnect connector L096Measure on the front side of wiring harness connector L096</div><table><tr><th>Pin (+ probe)</th><th>Pin (- probe)</th><th>Value</th><th>Additional information</th></tr><tr><td>4</td><td>3</td><td>Ubat</td><td>Ignition keyed on</td></tr><tr><td>1</td><td>2</td><td>~ 60 Ω</td><td><ul style="list-style-type: none">Ignition keyed offGround cable from the battery disconnectedDAVIE Vehicle Communication Interface (VCI) disconnected</td></tr></table></div></div>	Pin (+ probe)	Pin (- probe)	Value	Additional information	4	3	Ubat	Ignition keyed on	1	2	~ 60 Ω	<ul style="list-style-type: none">Ignition keyed offGround cable from the battery disconnectedDAVIE Vehicle Communication Interface (VCI) disconnected
Pin (+ probe)	Pin (- probe)	Value	Additional information										
4	3	Ubat	Ignition keyed on										
1	2	~ 60 Ω	<ul style="list-style-type: none">Ignition keyed offGround cable from the battery disconnectedDAVIE Vehicle Communication Interface (VCI) disconnected										
Possible causes	<ul style="list-style-type: none">Incorrect actuator power supply wiring.Malfunction in vehicle power supply system (battery or alternator or wiring).												
Additional information	<ul style="list-style-type: none">The actuator power supply is continuously monitored.The actuator motor is switched off and the BPV valve is fully open (100% position) with this DTC active.Engine torque is reduced after 10 hours of engine operation.												

Diagnostic Step-by-Step



This DTC can be set as a result of multiple failure modes. All steps of the troubleshooting tree must be completed.

Step 1. Perform a key cycle

Step 1. A Perform a key-cycle

Action

5. Key the ignition off for at least 15 seconds, then key it on again.

Is DTC P1024 active?

Yes

No

Go to 2.A

Step 5.A

Step 2. Electrical checks, BPV valve

Step 2.A Visual inspection, BPV valve connections and wiring

Action

1. Key the ignition off.
2. Visually inspect the connections and wiring for any of the following:
 - Damaged or loose connectors
 - Bent, broken, corroded, or loose connector pins
 - Moisture or dirt in the connections
 - Damage to the wire harness or insulation
 - ECU connections are damaged or disconnected

Is there evidence of any of the above?

Yes

No

Correct any issues found

Go to 4.A

Go to 2.B

Step 2.B Check the BPV vale power supply

Action

1. Monitor the vehicle power supply during engine startup and operation.
2. Check the actuator power supply according to, "Checking data, BPV valve (L096)."

Is the power supply within the specifications?

Yes

No

Repair or replace components and/or wiring as necessary.

Go to 3.A

Go to 4.A

Step 3. Try another BPV valve

Step 4. A Try another BPV valve

Action

13. Key off the ignition.
14. Disconnect the BPV valve connector from the engine wiring harness connector.
15. If available, connect another BPV valve without installing it.

Is P1024 active?


Yes

No


A malfunctioning BPV valve has been detected. Replace the BPV valve.





Malfunctioning of the originally installed actuator can be confirmed if DTC P1024 becomes active again when it is reconnected to the engine wiring harness connector.

	<div data-bbox="483 142 1122 342"> <p>For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center at 1-800-477-0251.</p> <p>Go to 4.A</p> </div> <div data-bbox="483 443 748 474"> <p>Step 4. Reset the DTCs</p> </div> <div data-bbox="483 552 802 583"> <p>Step 4.A Reset the DTCs</p> </div> <div data-bbox="483 625 565 657"> <p>Action</p> </div> <div data-bbox="532 688 1170 779"> <p>Reset the DTCs</p> <p>If DTCs are still present, troubleshoot the active DTCs.</p> </div> <div data-bbox="483 814 623 846"> <p>DTCs reset?</p> </div> <div data-bbox="483 888 526 919"> <p>Yes</p> </div> <div data-bbox="1029 888 1066 919"> <p>No</p> </div> <div data-bbox="1029 961 1414 993"> <p>Return to troubleshooting steps.</p> </div> <div data-bbox="483 1035 683 1066"> <p>Repair complete</p> </div> <div data-bbox="1029 1035 1143 1066"> <p>Go to 1.A</p> </div>
<p>Verification Drive Cycle</p>	<p>Perform these repair verification cycles following any corrective actions taken, to confirm that this fault is no longer active.</p> <div data-bbox="483 1346 565 1430">  </div> <div data-bbox="613 1360 1513 1413"> <p>Before beginning these repair verification cycles, use the DAVIE Quick Check function DTCs from the PCI and EAS-3 ECUs.</p> </div> <div data-bbox="483 1535 565 1566"> <p>Start-up</p> </div> <div data-bbox="483 1602 1377 1633"> <p>With the brakes set, start the engine and allow it to run at idle for 2 minutes.</p> </div>
	<p>Back to Index</p>

P1025


Code number	P1025
Fault code description	BPV actuator position - Malfunction on sensor
Fault code information	<p>1 trip MIL</p> <p>3 drive cycle recovery</p> <p>Readiness group – None</p> <p>Freeze frame type – Comprehensive</p>
Description of component(s)	<p>Back pressure valve (BPV) actuator (L096)</p> <p>The BPV actuator consists of an actuator and a BPV valve.</p> <p>The main task of the BPV valve is to create back pressure in the engine exhaust system and control exhaust gas mass flow.</p> <div style="display: flex; align-items: flex-start;"> <div style="margin-right: 20px;"> <p>25 Lever</p> <p>26 Spring</p> <p>27 Butterfly valve</p> <p>28 BPV actuator</p> </div> <div>  <p style="text-align: right; font-size: small;">1402268</p> </div> </div> <p>The main components of the BPV actuator are:</p> <ul style="list-style-type: none"> • ECU • Electromotor The electromotor rotates the output shaft via internal gears. • Output shaft The butterfly valve is moved via a lever by rotating the output shaft. • Electromotor position sensor The position of the electromotor is monitored. • Output shaft position sensor The position of the output shaft is monitored. • Temperature sensor

	<p>The temperature of the ECU printed circuit board is monitored</p> <p>Control</p> <p>The BPV actuator is a smart actuator that communicates with the PCI ECU via E-CAN. The actuator ECU is controlled by the PCI ECU but has its own diagnostics on the following actuator inputs and outputs:</p> <ul style="list-style-type: none"> • Power supply voltage • Electromotor position • Electromotor current • Output shaft position • ECU printed circuit board temperature • ECU hardware and software <p>After the ignition is keyed on, the valve position is 100% until the actuator is controlled by the PCI ECU.</p> <p>Unpowered and fail-safe position</p> <p>The unpowered and fail-safe positions of the valve are controlled by a spring and are fully open (100%). If a failure is detected the BPV valve moves to the fail-safe position, if possible.</p> <p>Effect on the system:</p> <ul style="list-style-type: none"> • Creating heat in the exhaust system to heat up the EAS system. A lower opening percentage results in a higher back pressure and more heat. • Decreasing the exhaust gas flow in the exhaust system to heat up the EAS system. A lower opening percentage results in a lower exhaust gas flow in the exhaust system and more heat. • Altering the pressure drop across the turbine rotor for VTG turbo control. • Creating back pressure to create EGR gas flow. • Creating back pressure to create engine braking.
--	---


Location of component(s)	
Diagnostic condition	This diagnostic runs continuously when the ignition is on.
Set condition of fault code	The BPV valve (L096) detects a failure or deviation on the internal position sensor.
Reset condition of fault code	This DTC changes to inactive after the ignition is keyed off for at least 15 seconds and keyed on again and the error is no longer detected.
Electrical diagram(s)	

122E 12-pin interface connector
 123E 7-pin interface connector
 A204 electronic fan interface connector
 D420 PCI ECU
 F852 humidity sensor
 L037 VTG turbocharger actuator
 L095 EGR valve module
 L096 BPV valve

D420	L096	Function
C90	1	E-CAN high
C92	2	E-CAN low
	3	Ground
	4	Power supply after ignition



Wiring harness connector D420.C front view



Wiring harness connector L096 front view



Handle connectors and pins with care and use matching measuring probes.

Technical data

Component check, BPV valve (L096)

This type of component cannot be checked with a multimeter or oscilloscope. Perform the following to assess the component:

- Monitor/test the component with DAVIE
- Perform the wiring check

	<div>Wiring check, BPV valve (L096)</div> <div>Preparation</div> <div><ul style="list-style-type: none">Key off the ignitionDisconnect connector L096Measure on the front side of wiring harness connector L096</div> <table><tr><th>Pin (+ probe)</th><th>Pin (- probe)</th><th>Value</th><th>Additional information</th></tr><tr><td>4</td><td>3</td><td>Ubat</td><td>Ignition keyed on</td></tr><tr><td>1</td><td>2</td><td>~ 60 Ω</td><td><ul style="list-style-type: none">Ignition keyed offGround cable from the battery disconnectedDAVIE Vehicle Communication Interface (VCI) disconnected</td></tr></table>	Pin (+ probe)	Pin (- probe)	Value	Additional information	4	3	Ubat	Ignition keyed on	1	2	~ 60 Ω	<ul style="list-style-type: none">Ignition keyed offGround cable from the battery disconnectedDAVIE Vehicle Communication Interface (VCI) disconnected
Pin (+ probe)	Pin (- probe)	Value	Additional information										
4	3	Ubat	Ignition keyed on										
1	2	~ 60 Ω	<ul style="list-style-type: none">Ignition keyed offGround cable from the battery disconnectedDAVIE Vehicle Communication Interface (VCI) disconnected										
Possible causes	<ul style="list-style-type: none">Bent actuator lever and/or connection rod.Incorrectly installed connection rod.												
Additional information	<ul style="list-style-type: none">The position of the BPV valve is monitored by a shaft position sensor in the actuator.The actuator motor is switched off and the BPV valve is fully opened (100% position) with this DTC active.Engine torque is reduced with this DTC active.												
Diagnostic Step-by-Step	<div><div><div>i</div></div><div>This DTC can be set as a result of multiple failure modes. All steps of the troubleshooting tree must be completed.</div></div> <div>Step 1. Perform a key cycle</div> <table><tr><td colspan="2">Step 1. A Perform a key-cycle</td></tr><tr><td colspan="2">Action</td></tr><tr><td colspan="2">6. Key the ignition off for at least 15 seconds, then key it on again.</td></tr><tr><td colspan="2">Is DTC P1025 active?</td></tr><tr><td>Yes</td><td>No</td></tr><tr><td>Go to 2.A</td><td>Step 2.B</td></tr></table>	Step 1. A Perform a key-cycle		Action		6. Key the ignition off for at least 15 seconds, then key it on again.		Is DTC P1025 active?		Yes	No	Go to 2.A	Step 2.B
Step 1. A Perform a key-cycle													
Action													
6. Key the ignition off for at least 15 seconds, then key it on again.													
Is DTC P1025 active?													
Yes	No												
Go to 2.A	Step 2.B												


Step 2. Check the BPV valve

Step 2. A Visual inspection, BPV valve mechanism

Action

6. Key off the ignition
7. Visually check that the connection rod of the BPV valve mechanism is installed correctly. The arrow must point upward.

Correct the installed connection rod.



Is the BPV valve mechanism free of damage?

Yes

No

Go to 2.B

Go to 4.A

Step 2.B Visual inspection, BPV valve mechanism

Action

3. Key off the ignition
4. Visually check that the connection rod of the BPV valve mechanism is free of damage.

Correct valve mechanism



I402210

Example of a bent lever and connection rod



I402265

Is the BPV valve mechanism free of damage?

Yes

No

Go to 2.C

Go to 4.A

Step 2.C Check the free movement of the BPV valve mechanism




The valve mechanism can move when the ignition is keyed on. Touching the mechanism can result in physical injury.

- Always key off the ignition when working on the BPV valve mechanism

Action

5. Key off the ignition
6. Check the free movement of the valve mechanism by moving the connection rod (1) by hand.
The movement requires some force because of the presence of a return spring. Check during the movement that:
 - The resistance of the mechanism to move is uniform over the full travel path of the connection rod (1), and
 - The actuator shaft (3) and valve shaft (2) rotate over the full travel path of the connection rod (1).



Do not use a tool to move the mechanism.

Does the BPV valve mechanism move freely?

Yes

No

Go to 3.A

Go to 2.D

Step 2.D Check for blockage in the BPV valve housing




The valve mechanism can move when the ignition is keyed on. Touching the mechanism can result in physical injury.

- Always key off the ignition when working on the BPV valve mechanism.
- Maintain a safe distance if the valve is monitored with the ignition keyed on.

Action

7. Key off the ignition
8. Loosen the exhaust pipe between the turbocharger and flexible pipe according to the job, Replace back pressure valve assembly.
9. Check if there is an internal blockage or excessive soot accumulation around the butterfly valve and housing. Open the valve by moving the connection rod (1).



Do not use a tool to move the mechanism.

Was any blockage found?

Yes	No
<ol style="list-style-type: none"> 4. Remove blockage/clean the internal valve housing. 5. Monitor the BPV valve position with DAVIE, to check that the cleaning was effective. 6. Install the exhaust pipe between the turbocharger and flexible pipe according to the job, <u>Replace back pressure valve assembly</u>. 	<p>A malfunctioning BPV valve has been detected. Replace the BPV valve.</p>
Go to 4.A	Go to 4.A

Step 3. Try another BPV valve

Step 4. A Try another BPV valve

Action

16. Key off the ignition.
17. Disconnect the BPV valve connector from the engine wiring harness connector.
18. If available, connect another BPV valve without installing it.

Is P1024 active?

Yes

No

A malfunctioning BPV valve has been detected. Replace the BPV valve.



Malfunctioning of the originally installed actuator can be confirmed if DTC P1024 becomes active again when it is reconnected to the engine wiring harness connector.

For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center at 1-800-477-0251.


Go to 4.A

Step 4. Reset the DTCs

Step 4.A Reset the DTCs



Action


- Reset the DTCs
- If DTCs are still present, troubleshoot the active DTCs.

	DTCs reset?	
	Yes	No
		Return to troubleshooting steps.
	Repair complete	Go to 1.A
Verification Drive Cycle	<p>Perform these repair verification cycles following any corrective actions taken, to confirm that this fault is no longer active.</p> <div>  <p>Before beginning these repair verification cycles, use the DAVIE Quick Check function to clear all current DTCs from the PCI and EAS-3 ECUs.</p> </div> <p>Start-up</p> <p>With the brakes set, start the engine and allow it to run at idle for 2 minutes.</p>	
	Back to Index	


P1026

Code number	P1026
Fault code description	BPV actuator - Out of calibration
Fault code information	<p>1 trip MIL</p> <p>3 drive cycle recovery</p> <p>Readiness group – None</p> <p>Freeze frame type - Comprehensive</p>
Description of component(s)	<p>The BPV actuator consists of an actuator and a BPV valve.</p> <p>The main task of the BPV valve is to create back pressure in the engine exhaust system and control exhaust gas mass flow.</p> <p>The main components of the BPV actuator are:</p> <ul style="list-style-type: none"> • ECU • Electromotor • The electromotor rotates the output shaft via internal gears. • output shaft • The butterfly is moved via a lever by rotating the output shaft • electromotor position sensor • The position of the electromotor is monitored. • output shaft position sensor • The position of the output shaft is monitored. • temperature sensor • The temperature of the printed circuit board of the ECU is monitored. <p>Control</p> <p>The BPV actuator is a smart actuator that communicates with the PCI ECU via E-CAN. The actuator ECU is controlled by the PCI ECU but has its own diagnostics on the following actuator inputs and outputs:</p> <ul style="list-style-type: none"> • power supply voltage • electromotor position • electromotor current • output shaft position • ECU printed circuit board temperature • ECU hardware and software <p>After the ignition is keyed on, the valve position is 100% until the actuator is controlled by the PCI ECU.</p> <p>Unpowered and fail-safe position</p> <p>The unpowered and fail-safe positions of the valve are controlled by a spring and are fully open (100%). If a failure is detected the BPV valve moves to the fail-safe position, if possible.</p> <p>Effect on the system:</p> <ul style="list-style-type: none"> • Creating heat in the exhaust system to heat up the EAS system. • A lower opening percentage results in a higher back pressure and more heat. • Decreasing the exhaust gas flow in the exhaust system to heat up the EAS system. <p>A lower opening percentage results in a lower exhaust gas flow in the exhaust system and more heat.</p>

	<ul style="list-style-type: none"> Altering the pressure drop across the turbine rotor for VTG turbo control. Creating back pressure to create EGR gas flow. Creating back pressure to create engine braking.
Location of component(s)	<p style="text-align: center;">L096</p> 
Diagnostic condition	This diagnostic runs continuously when the ignition is on.
Set condition of fault code	The BPV actuator (L096) detects that the open (100%) position is out of range.
Reset condition of fault code	This DTC changes to inactive after the ignition is keyed off for at least 15 seconds and keyed on again and the error is no longer detected.
Electrical diagram(s)	



Wiring harness connector D420.C front view



Wiring harness connector L096 front view

- 122E 12-pin interface connector
- 123E 7-pin interface connector
- A204 electronic fan interface connector
- D420 PCI ECU
- F852 humidity sensor
- L037 VTG turbocharger actuator
- L095 EGR valve module
- L096 BPV valve

D420	L096	Function
C90	1	E-CAN high
C92	2	E-CAN low
	3	Ground
	4	Power supply after ignition



Technical data

Component & wiring check, BPV valve (L096)

Preparation


- Key off the ignition.
- Disconnect connector L096
- Measure on the front side of wiring harness connector L096

Pin (+ probe)	Pin (- probe)	Value	Additional information
4	3	Ubat	Ignition keyed on
1	2	$\pm 60 \Omega$	<ul style="list-style-type: none"> • Ignition keyed off


	<ul style="list-style-type: none">• Ground cable from battery disconnected• Vehicle Communication Interface (VCI) of DAVIE disconnected																		
Possible causes																			
Additional information	<ul style="list-style-type: none">• The open (100%) position of the BPV valve is checked by the actuator and compared with an ex-factory stored value.• The actuator motor is switched off and the BPV valve is fully opened (100% position) with this DTC active.• Engine torque is reduced with this DTC active.																		
Diagnostic Step-by-Step	<div><div></div><div></div></div> <p>Perform the troubleshooting steps below using the breakout harness, if necessary, to check electrical components, such as sensors, electrical control units, and harnesses. Back probing is not recommended, as it could damage the harness. The ignition should always be in the OFF position when connecting or disconnecting electrical components in order to reduce the likelihood of damage to electrical components.</p> <ul style="list-style-type: none">• Disconnecting the EAS connectors during the troubleshooting process will result in multiple errors.• For specific electrical component information and pinout locations, always refer to the technical data.• It is necessary to exit the fault code menu in DAVIE and run the diagnostic test again to identify a change in errors.• Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive fault codes. Refer to the 'possible causes' section. <table><tr><td>Step 1</td><td>Step ID 1026a</td><td>SRT</td></tr><tr><td colspan="3">Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.</td></tr></table> <table><tr><td>Step 2</td><td>Step ID 1026b</td><td>SRT</td></tr><tr><td colspan="3"><p>ECU Information</p><p>Use the DAVIE Direct selection, “ECU Information” to display ECU S/W information. Compare this information with current configuration information available through Engine Rapido, or by contacting the PACCAR Engine Support Call Center.</p><p>Is the installed ECU software incorrect?</p><ul style="list-style-type: none">• No: Continue to the next step in the troubleshooting process.• Yes: Make the appropriate updates or component replacements. Contact the PACCAR Engine Support Call Center for authorization and assistance in replacing the ECU or updating the corresponding software.<p>Use DAVIE to re-check for the presence of active faults.</p><ul style="list-style-type: none">• If this related fault is no longer active, then this issue has been resolved.• If this related fault is still active, proceed to step 3</td></tr></table> <table><tr><td>Step 3</td><td>Step ID 1026c</td><td>SRT</td></tr><tr><td colspan="3"><p>DAVIE Direct Monitor: BPV</p><p>Use DAVIE to select and monitor BPV Position and BPV Actuator to determine if the back pressure valve is working properly.</p></td></tr></table>	Step 1	Step ID 1026a	SRT	Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.			Step 2	Step ID 1026b	SRT	<p>ECU Information</p> <p>Use the DAVIE Direct selection, “ECU Information” to display ECU S/W information. Compare this information with current configuration information available through Engine Rapido, or by contacting the PACCAR Engine Support Call Center.</p> <p>Is the installed ECU software incorrect?</p> <ul style="list-style-type: none">• No: Continue to the next step in the troubleshooting process.• Yes: Make the appropriate updates or component replacements. Contact the PACCAR Engine Support Call Center for authorization and assistance in replacing the ECU or updating the corresponding software. <p>Use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">• If this related fault is no longer active, then this issue has been resolved.• If this related fault is still active, proceed to step 3			Step 3	Step ID 1026c	SRT	<p>DAVIE Direct Monitor: BPV</p> <p>Use DAVIE to select and monitor BPV Position and BPV Actuator to determine if the back pressure valve is working properly.</p>		
Step 1	Step ID 1026a	SRT																	
Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.																			
Step 2	Step ID 1026b	SRT																	
<p>ECU Information</p> <p>Use the DAVIE Direct selection, “ECU Information” to display ECU S/W information. Compare this information with current configuration information available through Engine Rapido, or by contacting the PACCAR Engine Support Call Center.</p> <p>Is the installed ECU software incorrect?</p> <ul style="list-style-type: none">• No: Continue to the next step in the troubleshooting process.• Yes: Make the appropriate updates or component replacements. Contact the PACCAR Engine Support Call Center for authorization and assistance in replacing the ECU or updating the corresponding software. <p>Use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">• If this related fault is no longer active, then this issue has been resolved.• If this related fault is still active, proceed to step 3																			
Step 3	Step ID 1026c	SRT																	
<p>DAVIE Direct Monitor: BPV</p> <p>Use DAVIE to select and monitor BPV Position and BPV Actuator to determine if the back pressure valve is working properly.</p>																			

	<p>Do the monitored values appear incorrect?</p> <ul style="list-style-type: none"> No: Continue to the next step in the troubleshooting process. Yes: Clean adjust, repair or replace affected components for any issues identified. <p>Use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none"> If this related fault is no longer active, then this issue has been resolved. If this related fault is still active, proceed to step 4 		
	Step 4	Step ID 1026d	SRT
	<p>Replace: BPV Actuator</p> <p>If no problems were detected in the preceding steps, an internal problem has most likely occurred with the BPV Actuator.</p> <p>Replace the identified faulty component.</p> <p>Use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none"> If this related fault is no longer active, then this issue has been resolved. If this related fault is still active, proceed to step 5 		
	Step 5	Step ID 1026e	SRT
	<p>For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center at 1-800-477-0251.</p>		
Verification Drive Cycle	<p>To validate repair, with the brakes set, turn the key to the ON position with the engine off, and allow 10 seconds for the system to initialize and run diagnostics</p>		
	<p style="text-align: right;">Back to Index</p>		



P1029

Code number	P1029
Fault code description	BPV Position sensor fault
Fault code information	1 trip MIL 3 drive cycle recovery Readiness group – None Freeze frame type – Comprehensive
Description of component(s)	<div>  <p>For further assistance: Contact the PACCAR Engine Support Call Center 1-800-477-0251</p> </div> <p>Please Contact the Engine Support Center</p>
Location of component(s)	
Diagnostic condition	
Set condition of fault code	
Reset condition of fault code	
Electrical diagram(s)	
Technical data	
Possible causes	
Additional information	
Diagnostic Step-by-Step	
Verification Drive Cycle	
	Back to Index

P102A


Code number	P102A
Fault code description	Temperature after BPV - Voltage too high or short circuit to supply on ECU D420 pin C11
Fault code information	1 trip MIL 3 drive cycle recovery Readiness group – None Freeze frame type - Generic
Description of component(s)	<p>The exhaust gas temperature after BPV is measured after the back pressure valve (BPV).</p> <p>Effect on the system:</p> <ul style="list-style-type: none"> • Calculates the NOx composition for correction of the NOx emissions by the engine • Higher measured temperature after BPV results in a higher calculated NO2 emission by the engine. • Calculate temperature before turbine • Higher measured temperature after BPV results in higher calculated exhaust gas temperature before the turbine.
Location of component(s)	 <p>F853</p>
Diagnostic condition	Diagnostic condition information is not available.
Set condition of fault code	When Sensor output voltage is greater than 4.343V.
Reset condition of fault code	This fault code will change to inactive immediately after the diagnostic

<p>Electrical diagram(s)</p>	<div data-bbox="714 168 1282 1512"> <p>Wiring harness connector D420.C front view</p> <p>Wiring harness connector F853 front view</p> </div> <div data-bbox="487 1564 1039 1774"> <p>D420 PCI ECU</p> <p>F853 temperature sensor after BPV</p> <p>D420 F853 Function</p> <p>C11 3 Signal, temperature after BPV</p> <p>C33 1 Ground</p> </div>
<p>Technical data</p>	<p>Component check, temperature sensor after BPV (F853)</p> <p>Preparation</p> <ul style="list-style-type: none"> Key off the ignition


	<ul style="list-style-type: none">• Disconnect connector F853• Measure on component connector F853 <table><tr><th>Pin (+ probe)</th><th>Pin (- probe)</th><th>Value</th><th>Additional information</th></tr><tr><td>1</td><td>3</td><td>197.6–204.6 Ω</td><td>Resistance value at 0°C [34°F]</td></tr><tr><td></td><td></td><td>217.1–224.15 Ω</td><td>Resistance value at 25°C [77°F]</td></tr><tr><td></td><td></td><td>349.5–356.1 Ω</td><td>Resistance value at 200°C [392°F]</td></tr><tr><td></td><td></td><td>622.5–634.1 Ω</td><td>Resistance value at 600°C [1112°F]</td></tr></table> <p>Component & circuit check, ECU (D420)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key off the ignition.• Disconnect connector F853• Measure on the front side of wiring harness connector F853 <table><tr><th>Pin (+ probe)</th><th>Pin (- probe)</th><th>Value</th><th>Additional information</th></tr><tr><td>3</td><td>1</td><td>5V</td><td>Ignition keyed on</td></tr></table>	Pin (+ probe)	Pin (- probe)	Value	Additional information	1	3	197.6–204.6 Ω	Resistance value at 0°C [34°F]			217.1–224.15 Ω	Resistance value at 25°C [77°F]			349.5–356.1 Ω	Resistance value at 200°C [392°F]			622.5–634.1 Ω	Resistance value at 600°C [1112°F]	Pin (+ probe)	Pin (- probe)	Value	Additional information	3	1	5V	Ignition keyed on
Pin (+ probe)	Pin (- probe)	Value	Additional information																										
1	3	197.6–204.6 Ω	Resistance value at 0°C [34°F]																										
		217.1–224.15 Ω	Resistance value at 25°C [77°F]																										
		349.5–356.1 Ω	Resistance value at 200°C [392°F]																										
		622.5–634.1 Ω	Resistance value at 600°C [1112°F]																										
Pin (+ probe)	Pin (- probe)	Value	Additional information																										
3	1	5V	Ignition keyed on																										
Possible causes	No possible causes available.																												
Additional information	No additional information available.																												
Diagnostic Step-by-Step	<div><p>Perform the troubleshooting steps below using the breakout harness, if necessary, to check electrical components, such as sensors, electrical control units, and harnesses. Back probing is not recommended, as it could damage the harness. The ignition should always be in the OFF position when connecting or disconnecting electrical components to reduce the likelihood of damage to electrical components</p></div> <div><ul style="list-style-type: none">• This troubleshooting tree is based on the assumption that supply power and ground to the PCI are functioning properly.• Disconnecting the PCI connectors during the troubleshooting process will result in multiple errors.• For specific electrical component information and pinout locations, always refer to the technical data in Rapido.• It is necessary to exit the 'active errors' screen in DAVIE and run the diagnostic test again to identify changes in errors.• Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive codes. Refer to the 'possible causes' section in Rapido.</div> <table><tr><td>Step 1</td><td>Step ID 102Aa</td><td>SRT</td></tr><tr><td colspan="3">Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.</td></tr></table> <table><tr><td>Step 2</td><td>Step ID 102Ab</td><td>SRT</td></tr><tr><td colspan="3"><p>Electrical Checks</p><p>Ensure that the ignition key/switch has been set to OFF before disconnecting related cables.</p><p>Based on the fault message provided, confirm that the following electrical values are within specified ranges or limits:</p><ul style="list-style-type: none">• Supply and signal voltages (12V).• Cable continuity (no opens or shorts).</td></tr></table>	Step 1	Step ID 102Aa	SRT	Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.			Step 2	Step ID 102Ab	SRT	<p>Electrical Checks</p> <p>Ensure that the ignition key/switch has been set to OFF before disconnecting related cables.</p> <p>Based on the fault message provided, confirm that the following electrical values are within specified ranges or limits:</p> <ul style="list-style-type: none">• Supply and signal voltages (12V).• Cable continuity (no opens or shorts).																		
Step 1	Step ID 102Aa	SRT																											
Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.																													
Step 2	Step ID 102Ab	SRT																											
<p>Electrical Checks</p> <p>Ensure that the ignition key/switch has been set to OFF before disconnecting related cables.</p> <p>Based on the fault message provided, confirm that the following electrical values are within specified ranges or limits:</p> <ul style="list-style-type: none">• Supply and signal voltages (12V).• Cable continuity (no opens or shorts).																													

	Are measured electrical values outside of expected range or limits?		
	<ul style="list-style-type: none"> • Yes - Proceed to step 3 • No - Proceed to step 4 		
	Step 3	Step ID 102Ac	SRT
	Repair or replace After BPV Temperature sensor and use DAVIE to re-check for the presence of active faults. <ul style="list-style-type: none"> • Fault inactive – issue resolve • Fault active - Proceed to step 4 		
Verification Drive Cycle	Step 4	Step ID 102Ad	SRT
	For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center at 1-800-477-0251.		
	To validate repair, with the brakes set, start the engine and allow it to run at idle for 2 minutes.		
	Back to Index		


P102B

Code number	P102B
Fault code description	Temperature after BPV - Voltage too low or short circuit to ground on ECU D420 pin C11
Fault code information	<div>  <div> For further assistance: Contact the PACCAR Engine Support Call Center 1-800-477-0251 </div> </div> <p>Please Contact the Engine Support Center</p>
Description of component(s)	
Location of component(s)	
Diagnostic condition	
Set condition of fault code	
Reset condition of fault code	
Electrical diagram(s)	
Technical data	
Possible causes	
Additional information	
Diagnostic Step-by-Step	
Verification Drive Cycle	
	Back to Index


P102C

Code number	P102C
Fault code description	Broken Turbine fault
Fault code information	<div>  <p>For further assistance: Contact the PACCAR Engine Support Call Center 1-800-477-0251</p> </div> <p>Please Contact the Engine Support Center</p>
Description of component(s)	
Location of component(s)	
Diagnostic condition	
Set condition of fault code	
Reset condition of fault code	
Electrical diagram(s)	
Technical data	
Possible causes	
Additional information	
Diagnostic Step-by-Step	
Verification Drive Cycle	
	Back to Index

P102D


Code number	P102D
Fault code description	AMF CAN sensor burn off timeout fault
Fault code information	<div>  <div> For further assistance: Contact the PACCAR Engine Support Call Center 1-800-477-0251 </div> </div> <p>Please Contact the Engine Support Center</p>
Description of component(s)	
Location of component(s)	
Diagnostic condition	
Set condition of fault code	
Reset condition of fault code	
Electrical diagram(s)	
Technical data	
Possible causes	
Additional information	
Diagnostic Step-by-Step	
Verification Drive Cycle	
	Back to Index

P102E

Code number	P102E
Fault code description	AMF PCB temperature out of range at power up
Fault code information	<div>  <div> For further assistance: Contact the PACCAR Engine Support Call Center 1-800-477-0251 </div> </div> <p>Please Contact the Engine Support Center</p>
Description of component(s)	
Location of component(s)	
Diagnostic condition	
Set condition of fault code	
Reset condition of fault code	
Electrical diagram(s)	
Technical data	
Possible causes	
Additional information	
Diagnostic Step-by-Step	
Verification Drive Cycle	
	Back to Index

P102F

Code number	P102F
Fault code description	BPV actuator temperature – Data erratic , intermittent or incorrect at ignition on
Fault code information	<p>2 trip MIL</p> <p>3 drive cycle recovery</p> <p>Readiness group – None</p> <p>Freeze frame type - Generic</p>
Description of component(s)	<p>The BPV actuator consists of an actuator and a BPV valve.</p> <p>The main task of the BPV valve is to create back pressure in the engine exhaust system and control exhaust gas mass flow.</p> <ul style="list-style-type: none"> • Lever • Spring • Butterfly valve • BPV actuator <p>The main components of the BPV actuator are:</p> <ul style="list-style-type: none"> • ECU • Electromotor • The electromotor rotates the output shaft via internal gears. • output shaft • The butterfly is moved via a lever by rotating the output shaft • electromotor position sensor • The position of the electromotor is monitored. • output shaft position sensor • The position of the output shaft is monitored. • temperature sensor <p>The temperature of the printed circuit board of the ECU is monitored.</p> <p>Control</p> <p>The BPV actuator is a smart actuator that communicates with the PCI ECU via E-CAN. The actuator ECU is controlled by the PCI ECU but has its own diagnostics on the following actuator inputs and outputs:</p> <ul style="list-style-type: none"> • power supply voltage • electromotor position • electromotor current • output shaft position • ECU printed circuit board temperature • ECU hardware and software <p>After the ignition is keyed on, the valve position is 100% until the actuator is controlled by the PCI ECU.</p> <p>Unpowered and fail-safe position</p> <p>The unpowered and fail-safe positions of the valve are controlled by a spring and are fully open (100%). If a failure is detected the BPV valve moves to the fail-safe position, if possible.</p> <p>Effect on the system:</p> <ul style="list-style-type: none"> • Creating heat in the exhaust system to heat up the EAS system.



	<ul style="list-style-type: none"> • A lower opening percentage results in a higher back pressure and more heat. • Decreasing the exhaust gas flow in the exhaust system to heat up the EAS system. • A lower opening percentage results in a lower exhaust gas flow in the exhaust system and more heat. • Altering the pressure drop across the turbine rotor for VTG turbo control. • Creating back pressure to create EGR gas flow. • Creating back pressure to create engine braking.
Location of component(s)	<p style="text-align: center;">L096</p> 
Diagnostic condition	<p>This diagnostic runs:</p> <ul style="list-style-type: none"> • when the ignition is switched on (NO engine start), and; • the difference between the coolant temperature and ambient temperature is less than 15°C [59°F], and; • ambient temperature is more than -20°C [-4°F]
Set condition of fault code	<p>The PCI ECU (D420) detects that the actuator temperature from the BPV actuator (L096) differs by more than 3°C [37°F] from the average of other temperature sensors on the engine for more than 5 seconds (after the ignition has been keyed off for at least 8 hours).</p>
Reset condition of fault code	<p>The 8-hour ignition off diagnostics consists of three separate steps:</p> <ul style="list-style-type: none"> • The vehicle ignition may NOT be switched on or engine started for 8-10 consecutive hours (ideal situation would be overnight). • Once the 8 to 10 consecutive hours have been reached, key on the ignition

(NO engine start) and wait for 10 seconds to allow the system to power up and the diagnostics to run.


- Start the engine and let it idle for 2 minutes.

This DTC changes to inactive when the fault is no longer detected.

Electrical diagram(s)





Wiring harness connector D420.C front view




Wiring harness connector L096 front view

- 122E 12-pin interface connector
 123E 7-pin interface connector
 A204 electronic fan interface connector
 D420 PCI ECU

	<div><div>F852 humidity sensor</div><div>L037 VTG turbocharger actuator</div><div>L095 EGR valve module</div><div>L096 BPV valve</div></div> <div><div>D420 L096 Function</div><div>C90 1 E-CAN high</div><div>C92 2 E-CAN low</div><div> 3 Ground</div><div> 4 Power supply after ignition</div></div>												
Technical data	<div>Component & wiring check, BPV valve (L096)</div> <div>Preparation<ul style="list-style-type: none">Key off the ignition.Disconnect connector L096Measure on the front side of wiring harness connector L096</div> <table><thead><tr><th>Pin (+ probe)</th><th>Pin (- probe)</th><th>Value</th><th>Additional information</th></tr></thead><tbody><tr><td>4</td><td>3</td><td>Ubat</td><td>ignition keyed on</td></tr><tr><td>1</td><td>2</td><td>± 60 Ω</td><td><ul style="list-style-type: none">Ignition keyed offGround cable from the battery disconnectedVehicle Communication Interface (VCI) of DAVIE disconnected</td></tr></tbody></table>	Pin (+ probe)	Pin (- probe)	Value	Additional information	4	3	Ubat	ignition keyed on	1	2	± 60 Ω	<ul style="list-style-type: none">Ignition keyed offGround cable from the battery disconnectedVehicle Communication Interface (VCI) of DAVIE disconnected
Pin (+ probe)	Pin (- probe)	Value	Additional information										
4	3	Ubat	ignition keyed on										
1	2	± 60 Ω	<ul style="list-style-type: none">Ignition keyed offGround cable from the battery disconnectedVehicle Communication Interface (VCI) of DAVIE disconnected										
Possible causes	Faulty BPV actuator (L096)												
Additional information	<ul style="list-style-type: none">The BPV actuator is a smart actuator that communicates with the PCI ECU via E-CAN. The actuator ECU is controlled by the PCI ECU but has its own diagnostics.The temperature is measured on the (printed circuit board) of the actuator.For this diagnostic, the received actuator temperature from the BPV actuator (L020) is compared with an average of other temperature sensors on the engine after the ignition has been keyed off for at least 8 hours.												
Diagnostic Step-by-Step	<div><div></div><div>Perform the troubleshooting steps below using the breakout harness, if necessary, to check electrical components, such as sensors, electrical control units, and harnesses. Back probing is not recommended, as it could damage the harness. The ignition should always be in the OFF position when connecting or disconnecting electrical components in order to reduce the likelihood of damage to electrical components.</div></div> <div><div></div><ul style="list-style-type: none">Disconnecting the EAS connectors during the troubleshooting process will result in multiple errors.For specific electrical component information and pinout locations, always refer to the technical data.It is necessary to exit the fault code menu in DAVIE and run the diagnostic test again to identify a change in errors.Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive fault codes. Refer to the 'possible causes' section.</div> <table><tr><td>Step 1</td><td>Step ID 102F-a</td><td>SRT</td></tr><tr><td colspan="3">Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the</td></tr></table>	Step 1	Step ID 102F-a	SRT	Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the								
Step 1	Step ID 102F-a	SRT											
Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the													

	diagnostic procedure. Proceed to step 2.		
	Step 2	Step ID 102F-b	SRT
	<p>Electrical Checks</p> <p>Ensure that the ignition key/switch has been set to OFF before disconnecting related cables.</p> <p>Based on the fault message provided, confirm that the following electrical values are within specified ranges or limits:</p> <ul style="list-style-type: none"> • Supply and signal voltages (12V). • Cable continuity (no opens or shorts). <p>Are measured electrical values outside of expected range or limits?</p> <ul style="list-style-type: none"> • Yes - Proceed to step 3 • No - Proceed to step 4 		
	Step 3	Step ID 102F-c	SRT
	<p>Replace: BPV Actuator</p> <p>If no problems were detected in the preceding steps, an internal problem has most likely occurred with the BPV Actuator.</p> <p>Replace the identified faulty component.</p> <p>Use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none"> • If this related fault is no longer active, then this issue has been resolved. • If this related fault is still active, continue to the next step in the troubleshooting process. 		
	Step 4	Step ID 102F-d	SRT
	<p>For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the Engine Support Call Center at 1-800-477-0251.</p>		
Verification Drive Cycle	To validate repair, with the brakes set, turn the key to the ON position with the engine off, and allow 10 seconds for the system to initialize and run diagnostics		
	Back to Index		



P1030



Code number	P1030
Fault code description	EGR Temperature-Data erratic, intermittent or incorrect at ignition on.
Fault code information	2 trip MIL 3 drive cycle recovery Readiness group – None Freeze frame type - Generic
Description of component(s)	The EGR gas flow temperature is measured after the EGR cooler. Effect on the system: <ul style="list-style-type: none"> • Corrects EGR gas flow calculation (the temperature is an indication of the gas density) • Closes the EGR valve when the EGR temperature is too high • Monitors EGR cooler performance
Location of component(s)	<p style="text-align: center;">F749</p> 
Diagnostic condition	This diagnostic runs: <ul style="list-style-type: none"> • when the ignition has been keyed off continuously for at least 8 hours; • difference between the coolant temperature and ambient temperature is less than 15°C [59°F] • ambient temperature is more than -20°C [-4°F]
Set condition of fault code	The PCI ECU (D420) detects that the measured EGR temperature sensor differs by more than 3°C [37°F] from the average of other temperature sensor readings on/off the engine for more than 5 seconds (after the ignition has been keyed off for at least 8 hours).
Reset condition of fault code	The 8-hour ignition off diagnostics consists of three separate steps:

- The vehicle ignition may NOT be switched on or engine started for 8-10 consecutive hours (ideal situation would be overnight).
- Once the 8 to 10 consecutive hours have been reached, key on the ignition (NO engine start) and wait for 10 seconds to allow the system to power up and the diagnostics to run.
- Start the engine and let it idle for 2 minutes.

This DTC changes to inactive when the fault is no longer detected.

Electrical diagram(s)



	D420 F749 Function C9 1 Signal, EGR temperature C31 2 Ground																																
Technical data	<p>Component check, EGR temperature sensor (F749)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key off the ignition• Disconnect connector F749• Measure on component connector F749 <table><tr><th>Pin (+probe)</th><th>Pin (-probe)</th><th>Value</th><th>Additional information</th></tr><tr><td>1</td><td>2</td><td>97.7–100.3 Ω</td><td>Resistance value at 0°C [32°F]</td></tr><tr><td></td><td></td><td>107.4–108.2 Ω</td><td>Resistance value at 20°C [68°F]</td></tr><tr><td></td><td></td><td>137.5–139.1 Ω</td><td>Resistance value at 100°C [212°F]</td></tr><tr><td></td><td></td><td>167.3–169.7 Ω</td><td>Resistance value at 180°C [356°F]</td></tr><tr><td></td><td></td><td>192.5–195.5 Ω</td><td>Resistance value at 250°C [482°F]</td></tr></table> <p>Component & circuit check, ECU (D420)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key off the ignition• Disconnect connector F749• Measure on the front side of wiring harness connector F749 <table><tr><th>Pin (+probe)</th><th>Pin (-probe)</th><th>Value</th><th>Additional information</th></tr><tr><td>1</td><td>2</td><td>5V</td><td>Ignition keyed on</td></tr></table>	Pin (+probe)	Pin (-probe)	Value	Additional information	1	2	97.7–100.3 Ω	Resistance value at 0°C [32°F]			107.4–108.2 Ω	Resistance value at 20°C [68°F]			137.5–139.1 Ω	Resistance value at 100°C [212°F]			167.3–169.7 Ω	Resistance value at 180°C [356°F]			192.5–195.5 Ω	Resistance value at 250°C [482°F]	Pin (+probe)	Pin (-probe)	Value	Additional information	1	2	5V	Ignition keyed on
Pin (+probe)	Pin (-probe)	Value	Additional information																														
1	2	97.7–100.3 Ω	Resistance value at 0°C [32°F]																														
		107.4–108.2 Ω	Resistance value at 20°C [68°F]																														
		137.5–139.1 Ω	Resistance value at 100°C [212°F]																														
		167.3–169.7 Ω	Resistance value at 180°C [356°F]																														
		192.5–195.5 Ω	Resistance value at 250°C [482°F]																														
Pin (+probe)	Pin (-probe)	Value	Additional information																														
1	2	5V	Ignition keyed on																														
Possible causes	EGR temperature sensor deviation																																
Additional information	For this diagnostic, the EGR temperature sensor (F749) reading is compared with an average of other temperature sensors on the engine after the ignition has been keyed off for at least 8 hours.																																
Diagnostic Step-by-Step	<div><div><p>Perform the troubleshooting steps below using the breakout harness, if necessary, to check electrical components, such as sensors, electrical control units, and harnesses. Back probing is not recommended, as it could damage the harness. The ignition should always be in the OFF position when connecting or disconnecting electrical components to reduce the likelihood of damage to electrical components</p></div><div><ul style="list-style-type: none">• This troubleshooting tree is based on the assumption that supply power and ground to the PCI are functioning properly.• Disconnecting the PCI connectors during the troubleshooting process will result in multiple errors.• For specific electrical component information and pinout locations, always refer to the technical data in Rapido.• It is necessary to exit the 'active errors' screen in DAVIE and run the diagnostic test again to identify changes in errors.• Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive codes. Refer to the 'possible causes' section in Rapido.</div></div> <table><tr><td>Step 1</td><td>Step ID 1030a</td><td>SRT</td></tr><tr><td colspan="3">Visual inspection - Visually inspect the associated component connections and wiring for any of the following:<ul style="list-style-type: none">• Damaged or loose connectors</td></tr></table>	Step 1	Step ID 1030a	SRT	Visual inspection - Visually inspect the associated component connections and wiring for any of the following: <ul style="list-style-type: none">• Damaged or loose connectors																												
Step 1	Step ID 1030a	SRT																															
Visual inspection - Visually inspect the associated component connections and wiring for any of the following: <ul style="list-style-type: none">• Damaged or loose connectors																																	

- Bent, broken, corroded or loose connector pins
- Moisture or dirt in the connections
- Damage to the wire harness or insulation
- ECU connections damaged or disconnected
- Batteries are not okay, contacts are not tight
- Signs of exhaust or coolant leaks on the EGR
- Improper coolant level
- Broken or missing clamps on any air component part

Was there evidence of any of the above?

- No: Continue to the next step in the troubleshooting process.
- Yes: Clean, adjust, repair, or replace affected components for any issues identified.

Use DAVIE to re-check for the presence of active faults.

- If this related fault is no longer active, then this issue has been resolved.
- If this related fault is still active, continue to the next step in the troubleshooting process.

Step 2	Step ID 1030b	SRT
--------	---------------	-----

DAVIE Direct: Monitor EGR and related temperature sensors

Use DAVIE to monitor the following temperatures:

- EGR Temperature
- Ambient Temperature
- Intercooler Temperature
- Before Turbine Temperature
- Coolant Temperature

Idle the engine for a minimum of 10 minutes to allow temperatures to stabilize.

While monitoring, temperature values from sensor to sensor should not vary more than $\pm 30^{\circ}\text{F}$.

Do any monitored values vary by more than $\pm 30^{\circ}\text{F}$?

- No: Continue to the next step in the troubleshooting process.
- Yes: Clean adjust, repair or replace affected components for any issues identified.

Use DAVIE to re-check for the presence of active faults.

- If this related fault is no longer active, then this issue has been resolved.
- If this related fault is still active, continue to the next step in the troubleshooting process.

Step 3	Step ID 1030c	SRT
--------	---------------	-----

Ancillary Test: Air Side Pressure Test

Perform the prescribed testing to identify any potential leaks in the system.

Does the test fail to complete or result in a failed state?



- No: Continue to the next step in the troubleshooting process.
- Yes: Make the appropriate repairs or component replacements.

Use DAVIE to re-check for the presence of active faults.

- If this related fault is no longer active, then this issue has been resolved.
- If this related fault is still active, continue to the next step in the troubleshooting process.


	Step 4	Step ID 1030d	SRT
	Replace: EGR Temperature sensor Replace the identified smart sensor. Use DAVIE to re-check for the presence of active faults. <ul style="list-style-type: none"> • If this related fault is no longer active, then this issue has been resolved. • If this related fault is still active, continue to the next step in the troubleshooting process. 		
	Step 5	Step ID 1030e	SRT
	Contact the PACCAR Engine Support Call Center For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center at 1-800-477-0251.		
Verification Drive Cycle	To validate repair, with the brakes set, turn the key to the ON position with the engine off, and allow 10 seconds for the system to initialize and run diagnostics.		
	Back to Index		


P1032


Code number	P1032														
Fault code description	Vehicle speed - Data erratic, intermittent, or incorrect at ignition on														
Fault code information	3 drive cycle recovery Readiness group – None Freeze frame type – Generic														
Description of component(s)	Not required														
Location of component(s)	Not required														
Diagnostic condition	This diagnostic runs once after the ignition is on.														
Set condition of fault code	The PCI ECU (D420) detects that the measured vehicle speed is unlikely when the ignition is keyed on.														
Reset condition of fault code	This DTC changes to inactive when the fault is no longer detected. To validate the repair, key off the ignition for at least 15 seconds, key it on again, then monitor vehicle speed signal with DAVIE at vehicle standstill.														
Electrical diagram(s)	Not required														
Technical data	Not required														
Possible causes	Faulty vehicle speed signal														
Additional information	No additional information found.														
Diagnostic Step-by-Step	<div><div></div><div><p>Perform the troubleshooting steps below using the breakout harness, if necessary, to check electrical components, such as sensors, electrical control units, and harnesses. Back probing is not recommended, as it could damage the harness. The ignition should always be in the OFF position when connecting or disconnecting electrical components to reduce the likelihood of damage to electrical components</p><div><ul style="list-style-type: none">• This troubleshooting tree is based on the assumption that supply power and ground to the PCI are functioning properly.• Disconnecting the PCI connectors during the troubleshooting process will result in multiple errors.• For specific electrical component information and pinout locations, always refer to the technical data in Rapido.• It is necessary to exit the 'active errors' screen in DAVIE and run the diagnostic test again to identify changes in errors.• Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive codes. Refer to the 'possible causes' section in Rapido.</div></div></div> <table><tr><td>Step 1</td><td>Step ID 1032a</td><td>SRT</td></tr><tr><td colspan="3">Clear the fault codes<ul style="list-style-type: none">• Clear the fault codes.• Turn the key switch ON.Is fault code P1032 inactive?<ul style="list-style-type: none">• Yes – Repair complete• No –Proceed to step 2</td></tr></table> <table><tr><td>Step 2</td><td>Step ID 1032b</td><td>SRT</td></tr><tr><td colspan="3">For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the Engine Support Call Center at 1-800-477-0251.</td></tr></table>			Step 1	Step ID 1032a	SRT	Clear the fault codes <ul style="list-style-type: none">• Clear the fault codes.• Turn the key switch ON. Is fault code P1032 inactive? <ul style="list-style-type: none">• Yes – Repair complete• No –Proceed to step 2			Step 2	Step ID 1032b	SRT	For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the Engine Support Call Center at 1-800-477-0251.		
Step 1	Step ID 1032a	SRT													
Clear the fault codes <ul style="list-style-type: none">• Clear the fault codes.• Turn the key switch ON. Is fault code P1032 inactive? <ul style="list-style-type: none">• Yes – Repair complete• No –Proceed to step 2															
Step 2	Step ID 1032b	SRT													
For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the Engine Support Call Center at 1-800-477-0251.															
Verification Drive Cycle	To verify the repair:														



	With the brakes set, turn the key to the ON position with the engine off, and allow 10 seconds for the system to initialize and run diagnostics.
	Back to Index

P1039

Code number	P1039
Fault code description	Pressure after BPV – Data valid but too high
Fault code information	2 trip MIL 3 drive cycle recovery Readiness group – None Freeze frame type - Generic
Description of component(s)	Description, Pressure Sensor After BPV (F823)  <p>The diagram shows a cross-section of the engine and exhaust system. A green sensor (1) is mounted on the exhaust manifold. A red line (2) represents the steel tube connecting the sensor to the BPV valve. The BPV valve is shown as a circular component on the exhaust manifold. The red line (2) is shown as a curved tube connecting the sensor (1) to the BPV valve.</p> <p>The exhaust gas pressure after the BPV valve is measured by the sensor (1) via a steel tube (2).</p> <p>Effect on the system:</p> <ul style="list-style-type: none"> Correction of the NOx sensor before the catalyst signal. A higher measured exhaust gas pressure after the BPV valve results in lower calculated NOx emissions by the engine.


	<ul style="list-style-type: none"> • Calculates the exhaust gas temperature before the turbine • Lower measured exhaust gas pressure after the BPV valve results in higher calculated exhaust gas temperature before the turbine.
Location of component(s)	 <p>The diagram shows a detailed view of an engine. An inset image provides a close-up of the exhaust manifold area, where a green sensor labeled 'F823' is mounted. A curved arrow points from the main engine diagram to this inset, indicating the specific location of the component.</p>
Diagnostic condition	<ul style="list-style-type: none"> • The diagnostic runs if all the conditions mentioned in this chapter are met. • The air pressure sensor after BPV is fitted. • EGR and BPV are controlled normally. • No faults present on the pressure sensor after BPV, ambient pressure sensor, pressure sensor before turbine. • Exhaust gas flow rate > 250 g/s. • Time since engine start > 60 seconds.
Set condition of fault code	The DTC is set if the pressure after BPV corrected for the ambient pressure is higher than the threshold which is based on the exhaust gas mass flow.
Reset condition of fault code	This DTC changes to inactive when the fault is no longer detected.


<p>Electrical diagram(s)</p>	 <p>Wiring harness connector D420.C front view</p> <p>Wiring harness connector F823 front view</p>
<p>Technical data</p>	<p>Component & wiring check, ECU (D420)</p> <p>Preparation</p> <ul style="list-style-type: none"> • Key off the ignition. • Disconnect connector F823 • Measure on the front side of wiring harness connector F823


	<table><tr><th>Pin (+ probe)</th><th>Pin (- probe)</th><th>Value</th><th>Additional information</th></tr><tr><td>2</td><td>4</td><td>5V</td><td>Ignition keyed on</td></tr></table>	Pin (+ probe)	Pin (- probe)	Value	Additional information	2	4	5V	Ignition keyed on										
Pin (+ probe)	Pin (- probe)	Value	Additional information																
2	4	5V	Ignition keyed on																
Possible causes	None																		
Additional information	Part of the component check for OBD functionality.																		
Diagnostic Step-by-Step	<div><div></div><div></div></div> <p>Perform the troubleshooting steps below using the breakout harness, if necessary, to check electrical components, such as sensors, electrical control units, and harnesses. Back probing is not recommended, as it could damage the harness. The ignition should always be in the OFF position when connecting or disconnecting electrical components to reduce the likelihood of damage to electrical components</p> <ul style="list-style-type: none">• This troubleshooting tree is based on the assumption that supply power and ground to the PCI are functioning properly.• Disconnecting the PCI connectors during the troubleshooting process will result in multiple errors.• For specific electrical component information and pinout locations, always refer to the technical data in Rapido.• It is necessary to exit the 'active errors' screen in DAVIE and run the diagnostic test again to identify changes in errors.• Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive codes. Refer to the 'possible causes' section in Rapido. <table><tr><td>Step 1</td><td>Step ID 1039a</td><td>SRT</td></tr><tr><td colspan="3">Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.</td></tr></table> <table><tr><td>Step 2</td><td>Step ID 1039b</td><td>SRT</td></tr><tr><td colspan="3">Electrical Checks Ensure that the ignition key/switch has been set to OFF before disconnecting related cables. Based on the fault message provided, confirm that the following electrical values are within specified ranges or limits:<ul style="list-style-type: none">• Supply and signal voltages (12V).• Cable continuity (no opens or shorts).Are measured electrical values outside of expected range or limits?<ul style="list-style-type: none">• Yes - Proceed to step 3• No - Proceed to step 4</td></tr></table> <table><tr><td>Step 3</td><td>Step ID 1039c</td><td>SRT</td></tr><tr><td colspan="3">Visual inspection: DOC Inlet Remove the DOC inlet and visually inspect for any of the following:<ul style="list-style-type: none">• Signs of damage• Soot plugging; 50% or more of the cells in the catalyst being pluggedWas there evidence of any of the above?<ul style="list-style-type: none">• No: Continue to the Step 4 in the troubleshooting process.• Yes: Clean, adjust, repair, or replace affected components for any issues identified. Proceed to step 5</td></tr></table>	Step 1	Step ID 1039a	SRT	Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.			Step 2	Step ID 1039b	SRT	Electrical Checks Ensure that the ignition key/switch has been set to OFF before disconnecting related cables. Based on the fault message provided, confirm that the following electrical values are within specified ranges or limits: <ul style="list-style-type: none">• Supply and signal voltages (12V).• Cable continuity (no opens or shorts). Are measured electrical values outside of expected range or limits? <ul style="list-style-type: none">• Yes - Proceed to step 3• No - Proceed to step 4			Step 3	Step ID 1039c	SRT	Visual inspection: DOC Inlet Remove the DOC inlet and visually inspect for any of the following: <ul style="list-style-type: none">• Signs of damage• Soot plugging; 50% or more of the cells in the catalyst being plugged Was there evidence of any of the above? <ul style="list-style-type: none">• No: Continue to the Step 4 in the troubleshooting process.• Yes: Clean, adjust, repair, or replace affected components for any issues identified. Proceed to step 5		
Step 1	Step ID 1039a	SRT																	
Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.																			
Step 2	Step ID 1039b	SRT																	
Electrical Checks Ensure that the ignition key/switch has been set to OFF before disconnecting related cables. Based on the fault message provided, confirm that the following electrical values are within specified ranges or limits: <ul style="list-style-type: none">• Supply and signal voltages (12V).• Cable continuity (no opens or shorts). Are measured electrical values outside of expected range or limits? <ul style="list-style-type: none">• Yes - Proceed to step 3• No - Proceed to step 4																			
Step 3	Step ID 1039c	SRT																	
Visual inspection: DOC Inlet Remove the DOC inlet and visually inspect for any of the following: <ul style="list-style-type: none">• Signs of damage• Soot plugging; 50% or more of the cells in the catalyst being plugged Was there evidence of any of the above? <ul style="list-style-type: none">• No: Continue to the Step 4 in the troubleshooting process.• Yes: Clean, adjust, repair, or replace affected components for any issues identified. Proceed to step 5																			

	<p>If soot plugging was found, perform a manual cleaning of the DPF or perform a stationary regeneration.</p> <p>Use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">• If this related fault is no longer active, then this issue has been resolved.• If this related fault is still active, continue to the next step in the troubleshooting process.			
	<table><tr><td>Step 4</td><td>Step ID 1039d</td><td>SRT</td></tr></table> <p>Visual inspection: After BPV Pressure sensor</p> <p>Remove the After BPV Pressure sensor and visually inspect the sensor tip for any of the following:</p> <ul style="list-style-type: none">• Signs of damage• Excessive build-up on the sensor tip <p>Was there evidence of any of the above?</p> <ul style="list-style-type: none">• No: Continue to the next step in the troubleshooting process.• Yes: Clean, adjust, repair, or replace affected components for any issues identified. Proceed to step 5 <p>If soot plugging was found, perform a manual cleaning of the DPF or perform a stationary regeneration.</p> <p>Use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">• If this related fault is no longer active, then this issue has been resolved.• If this related fault is still active, continue to the next step in the troubleshooting process.	Step 4	Step ID 1039d	SRT
Step 4	Step ID 1039d	SRT		
	<table><tr><td>Step 5</td><td>Step ID 1039e</td><td>SRT</td></tr></table> <p>Replace the identified component.</p> <p>Use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">• If this related fault is no longer active, then this issue has been resolved.• If this related fault is still active, continue to the next step in the troubleshooting process.	Step 5	Step ID 1039e	SRT
Step 5	Step ID 1039e	SRT		
	<table><tr><td>Step 6</td><td>Step ID 1039f</td><td>SRT</td></tr></table> <p>Contact the PACCAR Engine Support Call Center</p> <p>For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center at 1-800-477-0251.</p>	Step 6	Step ID 1039f	SRT
Step 6	Step ID 1039f	SRT		
Verification Drive Cycle	<p>To validate repair:</p> <p>This cycle is best performed on a level grade road (least amount of incline possible) and under load using a trailer. If a loaded trailer is unavailable, produce engine load by turning the A/C and fan to ON.</p> <p>With the System Initiation cycle complete, proceed to a road with a minimum speed limit of 50 mph, then get to the highest gear possible with the engine speed between 1100-1500 rpm, and set the cruise control. Run this cycle for roughly 3 to 5 miles or in three separate 1-mile increments if a steady 3 to 5 miles is unachievable.</p>			
	<div>Back to Index</div>			

P103C

Code number	P103C
Fault code description	EGR control – unable to reach target
Fault code information	2 trip MIL 3 drive cycle recovery Readiness group – None Freeze frame type - Generic
Description of component(s)	 <p>1 Butterfly valve 2 EGR valve actuator 3 Lever 4 Spring</p> <p>The EGR module consists of an actuator and an EGR valve. The main task of the EGR valve is to control the EGR flow to the inlet manifold. The EGR position does not necessarily indicate the amount of EGR flow to the inlet manifold. The amount of EGR gas fed back mainly depends on the pressure difference between the pressure before turbine and the boost pressure, in combination with the EGR valve position The main components of the EGR valve actuator are:</p> <ul style="list-style-type: none"> • ECU • Electromotor <p>The electromotor rotates the output shaft via internal gears.</p> <ul style="list-style-type: none"> • output shaft <p>The butterfly is moved via a lever by rotating the output shaft</p> <ul style="list-style-type: none"> • electromotor position sensor <p>The position of the electromotor is monitored.</p> <ul style="list-style-type: none"> • output shaft position sensor

	<p>The position of the output shaft is monitored.</p> <ul style="list-style-type: none"> • temperature sensor <p>The temperature of the printed circuit board of the ECU is monitored.</p> <p>Control</p> <p>The EGR valve actuator is a smart actuator that communicates with the PCI ECU via E-CAN. The actuator ECU is controlled by the PCI ECU but has its own diagnostics on the following actuator inputs and outputs:</p> <ul style="list-style-type: none"> • power supply voltage • electromotor position • electromotor current • output shaft position • ECU printed circuit board temperature • ECU hardware and software <p>After the ignition is keyed on, the valve position is 0% until the PCI ECU commands the actuator.</p> <p>Unpowered and fail-safe position</p> <p>The unpowered and the fail-safe positions of the valve are controlled by a spring and are fully closed (0%). If a failure is detected the EGR valve moves to the fail-safe position, if possible.</p> <p>Effect on the system:</p> <p>Controlling the EGR gas flow to the inlet manifold. A higher opening percentage results in a higher amount of EGR flow at the same pressure difference between the pressure before turbine and the boost pressure</p>
<p>Location of component(s)</p>	<p style="text-align: center;">L095</p> 


Diagnostic condition	<p>This diagnostic runs:</p> <ul style="list-style-type: none"> when the engine is running at a steady load, and; coolant temperature is above 50°C [122°F]
Set condition of fault code	The PCI ECU (D420) detects that the demanded NOx conversion is limited by the EGR system limits for more than 300 seconds.
Reset condition of fault code	<p>This DTC changes to inactive when the fault is no longer detected. To validate the repair, drive the vehicle until the coolant temperature is at least 70°C [158°F]. Once the minimum target temperature has been reached, perform several low to higher speed accelerations with moderate engine load. Also perform high-load to low-load transitions. This activity should be conducted within the range of 15 km/h [10 mph] to 65 km/h [40 mph] for no more than 5 to 8 km [3 to 5 miles].</p>
Electrical diagram(s)	 <p>Wiring harness connector D420.C front view</p> <p>Wiring harness connector L095 front view</p>


	<div>122E 12-pin interface connector</div> <div>123E 7-pin interface connector</div> <div>A204 electronic fan interface connector</div> <div>D420 PCI ECU</div> <div>F852 humidity sensor</div> <div>L037 VTG turbocharger actuator</div> <div>L095 EGR valve module</div> <div>L096 BPV valve</div> <div><div><div>D420</div><div>L095</div><div>Function</div></div><div><div>C90</div><div>1</div><div>E-CAN high</div></div><div><div>C92</div><div>2</div><div>E-CAN low</div></div><div><div></div><div>3</div><div>Ground</div></div><div><div></div><div>4</div><div>Power supply after ignition</div></div></div>
Technical data	<div>Component & wiring check, EGR valve module (L095)</div> <div>Preparation</div> <div><div><div><div><div></div></div></div><div><div>Key off the ignition.</div></div></div><div><div><div><div></div></div></div><div><div>Disconnect connector L095</div></div></div><div><div><div><div></div></div></div><div><div>Measure on the front side of wiring harness connector L095</div></div></div></div> <div><div><div><div><div>Pin</div><div>Pin</div></div><div><div>(+ probe)</div><div>(- probe)</div></div><div><div>Value</div><div>Additional information</div></div></div><div><div><div>3</div><div>4</div><div>Ubat</div><div>ignition keyed on</div></div><div><div>1</div><div>2</div><div>± 60 Ω</div><div>1. Ignition keyed off</div><div>2. Ground cable from the battery disconnected</div><div>3. Vehicle Communication Interface (VCI) of DAVIE disconnected</div></div></div></div></div>
Possible causes	<div><div><div></div></div><div><div>Leaking EGR system</div></div></div> <div><div><div></div></div><div><div>Clogged EGR system</div></div></div> <div><div><div></div></div><div><div>Clogged EGR pressure difference sensor venturi</div></div></div> <div><div><div></div></div><div><div>NOx before catalyst sensor deviation.</div></div></div>
Additional information	<div>The engine NOx emission is, among others, controlled by varying the EGR flow toward the inlet manifold of the engine.</div>
Diagnostic Step-by-Step	<div><div><div><div></div></div><div>Perform the troubleshooting steps below using the breakout harness, if necessary, to check electrical components, such as sensors, electrical control units, and harnesses. Back probing is not recommended, as it could damage the harness. The ignition should always be in the OFF position when connecting or disconnecting electrical components to reduce the likelihood of damage to electrical components</div></div><div><div><div><div></div></div><div><div><div><div></div></div><div>This troubleshooting tree is based on the assumption that supply power and ground to the PCI are functioning properly.</div><div>Disconnecting the PCI connectors during the troubleshooting process will result in multiple errors.</div><div>For specific electrical component information and pinout locations, always refer to the technical data in Rapido.</div><div>It is necessary to exit the 'active errors' screen in DAVIE and run the diagnostic test again to identify changes in errors.</div><div>Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive codes. Refer to the 'possible</div></div></div></div></div></div>

causes' section in Rapido.		
Step 1	Step ID 103C-a	SRT
Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.		
Step 2	Step ID 103C-b	SRT
<p>Check for any Internal or external exhaust leakage in the EGR system. Is leakage present?</p> <ul style="list-style-type: none"> • Yes: - Replace the identified component. Use DAVIE to re-check for the presence of active faults. <ul style="list-style-type: none"> • If this related fault is no longer active, then this issue has been resolved. • If this related fault is still active, Proceed to step 3 • No: - Proceed to step 3 		
Step 3	Step ID 103C-c	SRT
<p>Check for clogged/restrictions in the lines connected to the EGR pressure differential sensor.</p> <ul style="list-style-type: none"> • Yes: - Clean the clogged/restrictions in the lines. Use DAVIE to re-check for the presence of active faults. <ul style="list-style-type: none"> • If this related fault is no longer active, then this issue has been resolved. • If this related fault is still active, Proceed to step 4 • No: - Proceed to step 4 		
Step 4	Step ID 103C-d	SRT
<p>Check for Clogged EGR system or in the EGR cooler. Is EGR system or EGR cooler is clogged?</p> <ul style="list-style-type: none"> • Yes: - Clean the EGR cooler. Use DAVIE to re-check for the presence of active faults. <ul style="list-style-type: none"> • If this related fault is no longer active, then this issue has been resolved. • If this related fault is still active, Proceed to step 5 • No: - Proceed to step 5 		
Step 5	Step ID 103C-e	SRT
<p>Check NOx Sensor, Before Catalyst Replace the identified component. Use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none"> • If this related fault is no longer active, then this issue has been resolved. • If this related fault is still active, Proceed to step 6 		
Step 6	Step ID 103C-f	SRT
For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center at 1-800-477-0251.		



Verification Drive Cycle	<p>To validate the repair :</p> <p>Drive the vehicle on a level grade road (least amount of incline possible) and under load using a trailer. If a loaded trailer is unavailable, produce engine load by turning the A/C and fan to ON.</p> <p>With the System Initiation cycle complete, proceed to a road with a minimum speed limit of 50 mph, then get to the highest gear possible with the engine speed between 1100-1500 rpm, and set the cruise control. Run this cycle for roughly 3 to 5 miles or in three separate 1-mile increments if a steady 3 to 5 miles is unachievable.</p>
	<p>Back to Index</p>

P1040

Code number	P1040
Fault code description	Pressure after BPV - Data valid but too low
Fault code information	2 trip MIL 3 drive cycle recovery Readiness group – None Freeze frame type - Generic
Description of component(s)	<p>The exhaust gas pressure after the BPV valve is measured by the sensor (1) via a steel tube (2).</p>  <p>The diagram shows a cross-section of the engine and its exhaust system. A green sensor, labeled '1', is mounted on the exhaust manifold. A red steel tube, labeled '2', connects the sensor to the BPV valve. The BPV valve is a circular component located in the exhaust system, and the steel tube (2) is connected to it. The diagram also shows the engine block, various hoses, and other components of the exhaust system.</p> <p>Effect on the system:</p> <ul style="list-style-type: none"> • Correction of the NOx sensor before the catalyst signal • A higher measured exhaust gas pressure after the BPV valve results in lower calculated NOx emissions by the engine. • Calculates the exhaust gas temperature before the turbine <p>Lower measured exhaust gas pressure after the BPV valve results in higher calculated exhaust gas temperature before the turbine.</p>

Location of component(s)	 <p>The diagram shows a detailed view of an engine. A curved arrow points from a specific location on the engine to a magnified inset. In the inset, a green cylindrical sensor, labeled F823, is shown mounted on the engine block. The sensor has a green cap and a black connector.</p>
Diagnostic condition	<ul style="list-style-type: none"> • The diagnostic runs if all the conditions mentioned in this chapter are met. • The air pressure sensor after BPV is fitted. • EGR and BPV are controlled normally. • No faults present on the pressure sensor after BPV, ambient pressure sensor, pressure sensor before turbine. • Exhaust gas flow rate > 250 g/s. • Time since engine start > 60 seconds.
Set condition of fault code	<p>The DTC is set if the pressure after BPV corrected for the ambient pressure is lower than the threshold which is based on the exhaust gas mass flow.</p>
Reset condition of fault code	<p>This DTC changes to inactive when the fault is no longer detected.</p>

Electrical diagram(s)





D420	F751	Function
C36	4	Ground
C59	2	Power supply
C81	1	Signal, pressure after BPV

Technical data


Component & wiring check, ECU (D420)
Preparation


- Key off the ignition.

	<ul style="list-style-type: none">• Disconnect connector F823• Measure on the front side of wiring harness connector F823 <table><tr><td>Pin</td><td>Pin</td><td></td><td></td></tr><tr><td>(+ probe)</td><td>(- probe)</td><td>Value</td><td>Additional information</td></tr><tr><td>2</td><td>4</td><td>5V</td><td>Ignition keyed on</td></tr></table>	Pin	Pin			(+ probe)	(- probe)	Value	Additional information	2	4	5V	Ignition keyed on									
Pin	Pin																					
(+ probe)	(- probe)	Value	Additional information																			
2	4	5V	Ignition keyed on																			
Possible causes	<ul style="list-style-type: none">• Leaking pressure sensor after BPV system• Faulty pressure sensor after BPV• NOx before catalyst sensor deviation.																					
Additional information	Part of the component check for OBD functionality.																					
Diagnostic Step-by-Step	<div> Perform the troubleshooting steps below using the breakout harness, if necessary, to check electrical components, such as sensors, electrical control units, and harnesses. Back probing is not recommended, as it could damage the harness. The ignition should always be in the OFF position when connecting or disconnecting electrical components to reduce the likelihood of damage to electrical components</div> <div><ul style="list-style-type: none">• This troubleshooting tree is based on the assumption that supply power and ground to the PCI are functioning properly.• Disconnecting the PCI connectors during the troubleshooting process will result in multiple errors.• For specific electrical component information and pinout locations, always refer to the technical data in Rapido.• It is necessary to exit the 'active errors' screen in DAVIE and run the diagnostic test again to identify changes in errors.• Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive codes. Refer to the 'possible causes' section in Rapido.</div> <table><tr><td>Step 1</td><td>Step 1040a</td><td>SRT</td></tr><tr><td colspan="3">Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.</td></tr></table> <table><tr><td>Step 2</td><td>Step 1040b</td><td>SRT</td></tr><tr><td colspan="3">Turn the key switch ON and use the DAVIE to Check for Fault Codes present on system. Is other fault codes are active?<ul style="list-style-type: none">• Yes – Proceed with the appropriate fault code resolution• No – Proceed to step 3</td></tr></table> <table><tr><td>Step 3</td><td>Step 1040c</td><td>SRT</td></tr><tr><td colspan="3">Check for any leakage in the BPV system. Is leakage present?<ul style="list-style-type: none">• Yes: - Replace the identified component. Use DAVIE to re-check for the presence of active faults.<ul style="list-style-type: none">• If this related fault is no longer active, then this issue has been resolved.• If this related fault is still active, Proceed to step 4• No: - Proceed to step 4</td></tr></table> <table><tr><td>Step 4</td><td>Step 1040d</td><td>SRT</td></tr></table>	Step 1	Step 1040a	SRT	Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.			Step 2	Step 1040b	SRT	Turn the key switch ON and use the DAVIE to Check for Fault Codes present on system. Is other fault codes are active? <ul style="list-style-type: none">• Yes – Proceed with the appropriate fault code resolution• No – Proceed to step 3			Step 3	Step 1040c	SRT	Check for any leakage in the BPV system. Is leakage present? <ul style="list-style-type: none">• Yes: - Replace the identified component. Use DAVIE to re-check for the presence of active faults.<ul style="list-style-type: none">• If this related fault is no longer active, then this issue has been resolved.• If this related fault is still active, Proceed to step 4• No: - Proceed to step 4			Step 4	Step 1040d	SRT
Step 1	Step 1040a	SRT																				
Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.																						
Step 2	Step 1040b	SRT																				
Turn the key switch ON and use the DAVIE to Check for Fault Codes present on system. Is other fault codes are active? <ul style="list-style-type: none">• Yes – Proceed with the appropriate fault code resolution• No – Proceed to step 3																						
Step 3	Step 1040c	SRT																				
Check for any leakage in the BPV system. Is leakage present? <ul style="list-style-type: none">• Yes: - Replace the identified component. Use DAVIE to re-check for the presence of active faults.<ul style="list-style-type: none">• If this related fault is no longer active, then this issue has been resolved.• If this related fault is still active, Proceed to step 4• No: - Proceed to step 4																						
Step 4	Step 1040d	SRT																				


	<p>Repair or replace the BPV Position Actuator.</p> <p>Use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">• If this related fault is no longer active, then this issue has been resolved.• If this related fault is still active, Proceed to step 5			
	<table><tr><td>Step 5</td><td>Step ID 1040e</td><td>SRT</td></tr></table> <p>Check NOx Sensor, Before Catalyst</p> <p>Replace the identified component.</p> <p>Use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">• If this related fault is no longer active, then this issue has been resolved.• If this related fault is still active, Proceed to step 6	Step 5	Step ID 1040e	SRT
Step 5	Step ID 1040e	SRT		
	<table><tr><td>Step 6</td><td>Step 1040f</td><td>SRT</td></tr></table> <p>Contact the PACCAR Engine Support Call Center</p> <p>For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center at 1-800-477-0251.</p>	Step 6	Step 1040f	SRT
Step 6	Step 1040f	SRT		
Verification Drive Cycle	<p>To validate the repair, drive the vehicle until the coolant temperature is at least 70°C [158°F]. Once the minimum target temperature has been reached, proceed at a minimum speed of 80 km/h [50 mph] in the highest gear possible with the engine speed between 1100 and 1500 rpm and set the cruise control. This test is best performed with a loaded vehicle/trailer, but if load is unavailable, turn as many engine power consumers on to produce engine load. Perform this test for roughly 5 to 8 km [3 to 5 miles] or in 3 separate 1.5 km [1 mile] increments if a steady 5 to 8 km [3 to 5 miles] is unachievable. Use a flat road, if possible.</p>			
	<p>Back to Index</p>			

P1042


Code number	P1042
Fault code description	VTG turbocharger control – Unable to reach target
Fault code information	2 trip MIL 3 drive cycle recovery Readiness group – None Freeze frame type - Generic
Description of component(s)	 <p>The exhaust gas pressure before the turbine is measured with sensor (1) via a steel tube (2) before the EGR valve.</p> <p>Effect on the system:</p> <ul style="list-style-type: none"> • Control of the VTG turbo charger • Control of the EGR flow • Control of the BPV valve • Control of the engine brake • Calculates the exhaust gas temperature before the turbine • Lower measured exhaust gas pressure before turbine results in higher calculated exhaust gas temperature before the turbine

Location of component(s)	
Diagnostic condition	<p>This diagnostic runs:</p> <ul style="list-style-type: none"> • engine speed is between 1050 and 1850 rpm, and • the engine mode is SCR high efficiency or standard.
Set condition of fault code	<ul style="list-style-type: none"> • The PCI ECU (D420) detects that the VTG turbocharger control is limited by the exhaust gas pressure before turbine for more than 300 seconds.
Reset condition of fault code	<ul style="list-style-type: none"> • This DTC changes to inactive when the fault is no longer detected. To validate the repair, drive the vehicle until the coolant temperature is at least 70°C [158°F]. Once the minimum target temperature has been reached, proceed at a minimum speed of 80 km/h [50 mph] in the highest gear possible with the engine speed between 1100 and 1500 rpm and set the cruise control. This test is best performed with a loaded vehicle/trailer, but if load is unavailable, turn as many engine power consumers on to produce engine load. Perform this test for roughly 5 to 8 km [3 to 5 miles] or in 3 separate 1.5 km [1 mile] increments if a steady 5 to 8 km [3 to 5 miles] is unachievable. Use a flat road, if possible.

Electrical diagram(s)





Wiring harness connector D420.C front view



Wiring harness connector F826 front view


D420	F829	Function
C38	4	Ground
C61	2	Power supply
C83	1	Signal, pressure before turbine

Technical data	<table><tr><td>Pin (+probe)</td><td>Pin (-probe)</td><td>Value</td><td>Additional information</td></tr><tr><td>2</td><td>4</td><td>5V</td><td>Ignition keyed on</td></tr></table>	Pin (+probe)	Pin (-probe)	Value	Additional information	2	4	5V	Ignition keyed on										
Pin (+probe)	Pin (-probe)	Value	Additional information																
2	4	5V	Ignition keyed on																
Possible causes	<ul style="list-style-type: none">Leaking exhaust systemLeaking pressure sensor before turbine tubePressure sensor before turbine deviation																		
Additional information	<ul style="list-style-type: none">The VTG turbocharger control depends, among other factors, on the exhaust gas pressure before turbine.The VTG turbocharger is controlled by the VTG turbocharger actuator (L037).The exhaust gas pressure before turbine is measured by the pressure sensor before turbine (F826).																		
Diagnostic Step-by-Step	<div><div></div><div><p>Perform the troubleshooting steps below using the breakout harness, if necessary, to check electrical components, such as sensors, electrical control units, and harnesses. Back probing is not recommended, as it could damage the harness. The ignition should always be in the OFF position when connecting or disconnecting electrical components in order to reduce the likelihood of damage to electrical components.</p></div></div> <div><div></div><ul style="list-style-type: none">Disconnecting the EAS connectors during the troubleshooting process will result in multiple errors.For specific electrical component information and pinout locations, always refer to the technical data.It is necessary to exit the fault code menu in DAVIE and run the diagnostic test again to identify a change in errors.Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive fault codes. Refer to the 'possible causes' section.</div> <table><tr><td>Step 1</td><td>Step 1042a</td><td>SRT</td></tr><tr><td colspan="3">Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.</td></tr></table> <table><tr><td>Step 2</td><td>Step 1042b</td><td>SRT</td></tr><tr><td colspan="3">Visual Inspection: Pressure sensor before turbo (P3) Visually inspect the identified component for any of the following: Damaged or blockage<ol style="list-style-type: none">If evidence for above is not found then proceed with Step 3If evidence of above is found then:<ul style="list-style-type: none">Clean, adjust, repair, or replace affected components for any issues identified.Use DAVIE to re-check for the presence of active faults.If this related fault is no longer active, then this issue has been resolved.If this related fault is still active, continue to the Step 3</td></tr></table> <table><tr><td>Step 3</td><td>Step 1042c</td><td>SRT</td></tr><tr><td colspan="3">Ancillary Test: Air Side Pressure Perform the prescribed test to determine if there are any leaks in the air system. Test failed to complete or result in a failed state<ol style="list-style-type: none">If the above test fails to complete then proceed with Step 4</td></tr></table>	Step 1	Step 1042a	SRT	Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.			Step 2	Step 1042b	SRT	Visual Inspection: Pressure sensor before turbo (P3) Visually inspect the identified component for any of the following: Damaged or blockage <ol style="list-style-type: none">If evidence for above is not found then proceed with Step 3If evidence of above is found then:<ul style="list-style-type: none">Clean, adjust, repair, or replace affected components for any issues identified.Use DAVIE to re-check for the presence of active faults.If this related fault is no longer active, then this issue has been resolved.If this related fault is still active, continue to the Step 3			Step 3	Step 1042c	SRT	Ancillary Test: Air Side Pressure Perform the prescribed test to determine if there are any leaks in the air system. Test failed to complete or result in a failed state <ol style="list-style-type: none">If the above test fails to complete then proceed with Step 4		
Step 1	Step 1042a	SRT																	
Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.																			
Step 2	Step 1042b	SRT																	
Visual Inspection: Pressure sensor before turbo (P3) Visually inspect the identified component for any of the following: Damaged or blockage <ol style="list-style-type: none">If evidence for above is not found then proceed with Step 3If evidence of above is found then:<ul style="list-style-type: none">Clean, adjust, repair, or replace affected components for any issues identified.Use DAVIE to re-check for the presence of active faults.If this related fault is no longer active, then this issue has been resolved.If this related fault is still active, continue to the Step 3																			
Step 3	Step 1042c	SRT																	
Ancillary Test: Air Side Pressure Perform the prescribed test to determine if there are any leaks in the air system. Test failed to complete or result in a failed state <ol style="list-style-type: none">If the above test fails to complete then proceed with Step 4																			


	<div>2. If the above test clears then:<ul style="list-style-type: none">• Make the appropriate repairs or component replacements.• Use DAVIE to re-check for the presence of active faults.• If this related fault is no longer active, then this issue has been resolved.• If this related fault is still active, continue to the Step 4.</div> <div><table><tr><td>Step 4</td><td>Step 1042d</td><td>SRT</td></tr></table><div>Replace: Pressure sensor before turbo (P3)<ol style="list-style-type: none">1. Replace the identified faulty component.2. Use DAVIE to check for the presence of active faults.<ul style="list-style-type: none">• If this related fault is no longer active, then this issue has been resolved.• If this related fault is still active, continue to the Step 5.</div></div> <div><table><tr><td>Step 5</td><td>Step 1042e</td><td>SRT</td></tr></table><div>Contact the PACCAR Engine Support Call Center For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center at 1-800-477-0251.</div></div>	Step 4	Step 1042d	SRT	Step 5	Step 1042e	SRT
Step 4	Step 1042d	SRT					
Step 5	Step 1042e	SRT					
Verification Drive Cycle	<div>To validate repair: This cycle is best performed on a level grade road (least amount of incline possible) and under load using a trailer. If a loaded trailer is unavailable, produce engine load by turning the A/C and fan to ON. With the System Initiation cycle complete, proceed to a road with a minimum speed limit of 50 mph, then get to the highest gear possible with the engine speed between 1100-1500 rpm, and set the cruise control. Run this cycle for roughly 3 to 5 miles or in three separate 1-mile increments if a steady 3 to 5 miles is unachievable.</div>						
	<div>Back to Index</div>						

P104B

Code number	P104B
Fault code description	Boost pressure – Data valid but too high
Fault code information	2 trip MIL 3 drive cycle recovery Readiness group – None Freeze frame type - Crankcase
Description of component(s)	<p>The boost pressure is measured in the inlet manifold, near cylinder 1.</p> <p>Effect on the system</p> <ul style="list-style-type: none"> • Determines the smoke limit A higher measured boost pressure increase results in higher torque for the same smoke level • Determines soot emissions A higher measured boost pressure results in lower calculated soot emission by the engine. • Determines NOx emissions A higher measured boost pressure results in higher calculated NOx emission by the engine. • Calculates exhaust gas mass flow used for DEF dosing estimation by the EAS-3 system. A higher measured boost pressure results in higher calculated exhaust gas mass flow. • Calculates the temperature after the compressor (VTG turbo charger) A higher measured boost pressure results in higher calculated temperature after the compressor. • Calculates the temperature before the turbine. A higher measured boost pressure results in lower calculated exhaust gas temperature before the turbine.

Location of component(s)	 <p style="text-align: right;">I402282</p>
Diagnostic condition	<p>This diagnostic runs:</p> <ul style="list-style-type: none"> • When the engine is running at a steady load, and; • When coolant temperature is above 50°C [122°F], and; • When ambient temperature is between -15 and 40°C [5 and 104°F], and; • The engine mode is SCR high efficiency or standard.
Set condition of fault code	<p>The PCI ECU (D420) detects that the measured boost pressure is more than 0.5 bar [7.3 psi] higher than the expected boost pressure for more than 50 seconds.</p>
Reset condition of fault code	<p>This DTC changes to inactive when the fault is no longer detected.</p> <p>To validate the repair, drive the vehicle until the coolant temperature is at least 70°C [158°F]. Once the minimum target temperature has been reached, proceed at a minimum speed of 80 km/h [50 mph] in the highest gear possible with the engine speed between 1100 and 1500 rpm and set the cruise control. This test is best performed with a loaded vehicle/trailer, but if load is unavailable, turn as many engine power consumers on to produce engine load. Perform this test for roughly 5 to 8 km [3 to 5 miles] or in 3 separate 1.5 km [1 mile] increments if a steady 5 to 8 km [3 to 5 miles] is unachievable. Use a flat road, if possible.</p>


Electrical diagram(s)




D420 PCI ECU

F802 Boost pressure sensor

D420	F802	Function
A39	4	Ground
A47	2	Power supply
A51	1	Signal, boost pressure



Wiring harness connector D420.A front view



Wiring harness connector F802 front view



Handle connectors and pins with care and use matching measuring probes.

Technical data

Component check, boost pressure sensor (F802)

This type of component cannot be checked with a multimeter or oscilloscope. Perform

	<p>the following to assess the component:</p> <ul style="list-style-type: none">• Monitor/test the component with DAVIE• Perform the wiring check <p>Component & wiring check, ECU (D420)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key off the ignition• Disconnect connector F802• Measure on the front side of wiring harness connector F802 <table><tr><th>Pin (+ probe)</th><th>Pin (- probe)</th><th>Value</th><th>Additional information</th></tr><tr><td>2</td><td>4</td><td>5V</td><td>Ignition keyed on</td></tr></table>	Pin (+ probe)	Pin (- probe)	Value	Additional information	2	4	5V	Ignition keyed on				
Pin (+ probe)	Pin (- probe)	Value	Additional information										
2	4	5V	Ignition keyed on										
Possible causes	<ul style="list-style-type: none">• Boost pressure sensor deviation• Turbocharger failure												
Additional information	<ul style="list-style-type: none">• The measured boost pressure is compared with an expected boost pressure.• The boost pressure is measured by the boost pressure sensor (F802).												
Diagnostic Step-by-Step	<p>Step 1. Investigate Related Trouble Codes</p> <p>Before troubleshooting this code, take notice of any other active or inactive trouble codes. One or multiple other codes could have been the cause for this code.</p> <table><tr><td colspan="2">Step 1.A Investigate related trouble codes</td></tr><tr><td colspan="2"><p>Action</p><p>1. Use DAVIE Diagnostics to perform a Quick Check for current trouble codes.</p></td></tr><tr><td colspan="2"><p>Are these or any other related codes active?</p><ul style="list-style-type: none">• P0107; P0108• Any turbocharger related codes</td></tr><tr><td>Yes</td><td>No</td></tr><tr><td>Refer to the troubleshooting information for these codes before continuing with this procedure.</td><td></td></tr><tr><td></td><td>Go to step 2.A</td></tr></table>	Step 1.A Investigate related trouble codes		<p>Action</p> <p>1. Use DAVIE Diagnostics to perform a Quick Check for current trouble codes.</p>		<p>Are these or any other related codes active?</p> <ul style="list-style-type: none">• P0107; P0108• Any turbocharger related codes		Yes	No	Refer to the troubleshooting information for these codes before continuing with this procedure.			Go to step 2.A
Step 1.A Investigate related trouble codes													
<p>Action</p> <p>1. Use DAVIE Diagnostics to perform a Quick Check for current trouble codes.</p>													
<p>Are these or any other related codes active?</p> <ul style="list-style-type: none">• P0107; P0108• Any turbocharger related codes													
Yes	No												
Refer to the troubleshooting information for these codes before continuing with this procedure.													
	Go to step 2.A												

Step 2. Intake Manifold (Boost) Pressure Sensor (F802) Checks

Step 2. A Visual inspection, connections and wiring, boost pressure sensor (F802)

Action

1. Visually inspect the associated component connections and wiring for any of the following:
 - Damaged or loose connectors
 - Bent, broken, corroded or loose connector pins
 - Moisture or dirt in the connections
 - Damage to the wire harness or insulation
 - The correct parts are not installed
 - ECU connections are damaged or disconnected
 - Batteries not fully charged or contacts are not tight
 - Boost pressure sensor (F802) damaged or not installed correctly

Was there evidence of any of the above?

Yes

No

Correct any issues found. If the boost pressure sensor (F802) is found to be damaged or broken, replace it.

Refer to Step 3.A to perform the corresponding repair verification cycles and rechecks.

If this code is still present, go to Step 2.B

Go to step 2.B

Step 2.B Pressure testing, intake and exhaust elements

Action

1. Perform the steps outlined in the procedure, "pressure testing (intake/exhaust elem.)," job ID 84123, to determine whether there are any leaks in the intake air system.

Was there evidence of a leak in the air system?

Yes

No

Correct any issues found.

	Refer to step 3.A to perform the corresponding repair verification cycles and rechecks.	
	If this code is still present, go to step 2.C.	Go to step 2.C
	Step 2.C DAVIE Monitor, inlet air pressure in inlet manifold	
	Action	
	<ol style="list-style-type: none"> 1. Connect DAVIE. 2. Start the truck, and allow it to run at idle. 3. Use DAVIE to monitor the inlet air pressure in the inlet manifold: <ol style="list-style-type: none"> a. Confirm that the air pressure sensor supply voltage is within the referenced range. b. Compare the monitored signal values for inlet air pressure in inlet manifold (relative) to the ambient pressure. With the engine running at idle, the inlet manifold pressure should be slightly above the ambient pressure. 4. Turn on A/C and fan to ON, to create a load on the engine. 5. Increase the engine RPMs, and then use DAVIE to confirm there is a corresponding increase in the intake air pressure in the inlet manifold. The expected increase can be as much as two to three times the ambient pressure, depending on actual engine loads and turbocharger operation. 	
	Are monitored values within expected range at idle and higher engine RPMs?	
	Yes	No
		Replace the boost pressure sensor (F802). Refer to Step 3.A to perform the corresponding repair verification cycles and rechecks.
	If all steps have been completed and this trouble code is still present, contact the PACCAR Engine Support Center for further assistance.	If all steps have been completed and this trouble code is still present, contact the PACCAR Engine Support Center for further assistance.

Step 3. Repair Verification

Step 3.A Repair verification cycles

Perform these repair verification cycles following any corrective actions taken, to enable related OBD monitors to reach a readiness state associated with the trouble code or system being investigated.



Before beginning these repair verification cycles, use the DAVIE Diagnostics, Quick Check function to clear all current DTCs from the PCI and EAS-3 ECUs.

Action

1. Steady State

This cycle is best performed on a level grade road (least amount of incline possible) and under load using a trailer. If a loaded trailer is unavailable, produce engine load by turning the A/C and fan to ON.

With the System Initiation cycle complete, proceed to a road with a minimum speed limit of 50 mph, then get to the highest gear possible with the engine speed between 1100-1500 rpm, and set the cruise control. Run this cycle for roughly 3 to 5 miles or in three separate 1-mile increments if a steady 3 to 5 miles is unachievable.

Were the identified repair verification cycles able to be completed?

Yes

No

Investigate and correct any issues preventing these repair verification cycles from being completed, then re-run. For additional assistance, contact the PACCAR Engine Support Center.

Go to step 3.B

Go to step 3.B

Step 3.B DAVIE Diagnostics, Quick Check

Action

1. Use DAVIE Diagnostics to perform a Quick Check for current trouble codes to determine whether the actions taken have cleared this trouble code.


Has P104B been cleared?

Yes

No


Problem resolved. No further actions.

Continue with the next step in this troubleshooting procedure. If all steps have been completed and this trouble code is still present, contact the PACCAR Engine Support Center for further


	<div data-bbox="480 130 1006 319"></div> <div data-bbox="1006 130 1533 319">assistance.</div> <div data-bbox="490 390 578 478">  </div> <div data-bbox="594 403 1117 438">Contacting the PACCAR Engine Support Center</div> <div data-bbox="594 451 1446 537">For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center.</div>
	<div data-bbox="1357 709 1533 745">Back to Index</div>

P104C

Code number	P104C
Fault code description	Boost pressure – Data valid but too low
Fault code information	2 trip MIL 3 drive cycle recovery Readiness group – None Freeze frame type - Crankcase
Description of component(s)	<p>The boost pressure is measured in the inlet manifold, near cylinder 1.</p> <p>Effect on the system</p> <ul style="list-style-type: none"> • Determines the smoke limit A higher measured boost pressure increase results in higher torque for the same smoke level • Determines soot emissions A higher measured boost pressure results in lower calculated soot emission by the engine. • Determines NOx emissions A higher measured boost pressure results in higher calculated NOx emission by the engine. • Calculates exhaust gas mass flow used for DEF dosing estimation by the EAS-3 system. A higher measured boost pressure results in higher calculated exhaust gas mass flow. • Calculates the temperature after the compressor (VTG turbo charger) A higher measured boost pressure results in higher calculated temperature after the compressor. • Calculates the temperature before the turbine. A higher measured boost pressure results in lower calculated exhaust gas temperature before the turbine.

Location of component(s)	
Diagnostic condition	<p>This diagnostic runs:</p> <ul style="list-style-type: none"> • When the engine is running at a steady load, and; • When coolant temperature is above 50°C [122°F], and; • When ambient temperature is between -15 and 40°C [5 and 104°F], and; • The engine mode is SCR high efficiency or standard.
Set condition of fault code	<p>The PCI ECU (D420) detects that the measured boost pressure is more than 0.5 bar [7.3 psi] lower than the expected boost pressure for more than 50 seconds.</p>
Reset condition of fault code	<p>This DTC changes to inactive when the fault is no longer detected.</p> <p>To validate the repair, drive the vehicle until the coolant temperature is at least 70°C [158°F]. Once the minimum target temperature has been reached, proceed at a minimum speed of 80 km/h [50 mph] in the highest gear possible with the engine speed between 1100 and 1500 rpm and set the cruise control. This test is best performed with a loaded vehicle/trailer, but if load is unavailable, turn as many engine power consumers on to produce engine load. Perform this test for roughly 5 to 8 km [3 to 5 miles] or in 3 separate 1.5 km [1 mile] increments if a steady 5 to 8 km [3 to 5 miles] is unachievable. Use a flat road, if possible.</p>


Electrical diagram(s)




D420 PCI ECU

F802 Boost pressure sensor

D420	F802	Function
A39	4	Ground
A47	2	Power supply
A51	1	Signal, boost pressure





Wiring harness connector D420.A front view



Wiring harness connector F802 front view



Handle connectors and pins with care and use matching measuring probes.

Technical data	<p>Component check, boost pressure sensor (F802)</p> <p>This type of component cannot be checked with a multimeter or oscilloscope. Perform the following to assess the component:</p> <ul style="list-style-type: none">• Monitor/test the component with DAVIE• Perform the wiring check <p>Component & wiring check, ECU (D420)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key off the ignition• Disconnect connector F802• Measure on the front side of wiring harness connector F802 <table><tr><th>Pin (+ probe)</th><th>Pin (- probe)</th><th>Value</th><th>Additional information</th></tr><tr><td>2</td><td>4</td><td>5V</td><td>Ignition keyed on</td></tr></table>	Pin (+ probe)	Pin (- probe)	Value	Additional information	2	4	5V	Ignition keyed on
Pin (+ probe)	Pin (- probe)	Value	Additional information						
2	4	5V	Ignition keyed on						
Possible causes	<ul style="list-style-type: none">• Leaking inlet air system• Boost pressure sensor deviation• Turbocharger failure								
Additional information	<ul style="list-style-type: none">• The measured boost pressure is compared with an expected boost pressure.• The boost pressure is measured by the boost pressure sensor (F802).								
Diagnostic Step-by-Step	<div><div></div><div><p>The ignition should always be in the OFF position when connecting or disconnecting electrical components to reduce the likelihood of damage to the components.</p></div></div> <div><div></div><div><ul style="list-style-type: none">▪ This troubleshooting procedure is based on the assumption that supply power and ground to the PMCI are functioning properly.▪ Disconnecting the PMCI connectors during the troubleshooting process will result in multiple errors.▪ Specific electrical component information and pin out locations are provided in this procedure as a reference only. Always refer to the technical data sections in Rapido for the most up-to-date changes.▪ It is necessary to use DAVIE to clear all current trouble codes from the PCI and EAS-3 ECUs, and then run the Quick Check to identify a change in fault status.▪ This DTC can be set as a result of multiple failure modes. For proper fault isolation, complete all troubleshooting steps in the sequence provided.</div></div>								

Step 1. Investigate Related Trouble Codes

Before troubleshooting this code, take notice of any other active or inactive trouble codes. One or multiple other codes could have been the cause for this code.

Step 1.A Investigate related trouble codes

Action

1. Use DAVIE Diagnostics to perform a Quick Check for current trouble codes.

Are these or any other related codes active?

- P0107; P0108
- Any turbocharger related codes

Yes

No

Refer to the troubleshooting information for these codes before continuing with this procedure.

Go to step 2.A

Step 2. Intake Manifold (Boost) Pressure Sensor (F802) Checks

Step 2. A Visual inspection, connections and wiring, boost pressure sensor (F802)

Action

1. Visually inspect the associated component connections and wiring for any of the following:
 - Damaged or loose connectors
 - Bent, broken, corroded or loose connector pins
 - Moisture or dirt in the connections
 - Damage to the wire harness or insulation
 - The correct parts are not installed
 - ECU connections are damaged or disconnected
 - Batteries not fully charged or contacts are not tight
 - Boost pressure sensor (F802) damaged or not installed correctly

Was there evidence of any of the above?

Yes

No

	Correct any issues found. If the boost pressure sensor (F802) is found to be damaged or broken, replace it.	
	Refer to Step 3.A to perform the corresponding repair verification cycles and rechecks.	
	If this code is still present, go to Step 2.B	Go to step 2.B
	Step 2.B Pressure testing, intake and exhaust elements	
	Action	
	1. Perform the steps outlined in the procedure, “ <u>pressure testing (intake/exhaust elem.)</u> ,” job ID 84123, to determine whether there are any leaks in the intake air system.	
	Was there evidence of a leak in the air system?	
	Yes	No
	Correct any issues found. Refer to step 3.A to perform the corresponding repair verification cycles and rechecks.	
	If this code is still present, go to step 2.C.	Go to step 2.C

Step 2.C DAVIE Monitor, inlet air pressure in inlet manifold

Action

1. Connect DAVIE.
2. Start the truck, and allow it to run at idle.
3. Use DAVIE to monitor the inlet air pressure in the inlet manifold:
 - a. Confirm that the air pressure sensor supply voltage is within the referenced range.
 - b. Compare the monitored signal values for inlet air pressure in inlet manifold (relative) to the ambient pressure. With the engine running at idle, the inlet manifold pressure should be slightly above the ambient pressure.
4. Turn on A/C and fan to ON, to create a load on the engine.
5. Increase the engine RPMs, and then use DAVIE to confirm there is a corresponding increase in the intake air pressure in the inlet manifold. The expected increase can be as much as two to three times the ambient pressure, depending on actual engine loads and turbocharger operation.

Are monitored values within expected range at idle and higher engine RPMs?

Yes

No

Replace the boost pressure sensor (F802).

Refer to Step 3.A to perform the corresponding repair verification cycles and rechecks.

If all steps have been completed and this trouble code is still present, contact the PACCAR Engine Support Center for further assistance.

If all steps have been completed and this trouble code is still present, contact the PACCAR Engine Support Center for further assistance.

Step 3. Repair Verification

Step 3.A Repair verification cycles

Perform these repair verification cycles following any corrective actions taken, to enable related OBD monitors to reach a readiness state associated with the trouble code or system being investigated.



Before beginning these repair verification cycles, use the DAVIE Diagnostics, Quick Check function to clear all current DTCs from the PCI and EAS-3 ECUs.

Action

1. Steady State

This cycle is best performed on a level grade road (least amount of incline possible) and under load using a trailer. If a loaded trailer is unavailable, produce engine load by turning the A/C and fan to ON.

With the System Initiation cycle complete, proceed to a road with a minimum speed limit of 50 mph, then get to the highest gear possible with the engine speed between 1100-1500 rpm, and set the cruise control. Run this cycle for roughly 3 to 5 miles or in three separate 1-mile increments if a steady 3 to 5 miles is unachievable.

Were the identified repair verification cycles able to be completed?

Yes

No

Investigate and correct any issues preventing these repair verification cycles from being completed, then re-run. For additional assistance, contact the PACCAR Engine Support Center.

Go to step 3.B

Go to step 3.B

Step 3.B DAVIE Diagnostics, Quick Check

Action

1. Use DAVIE Diagnostics to perform a Quick Check for current trouble codes to determine whether the actions taken have cleared this trouble code.

Has P104C been cleared?

Yes


No


Problem resolved. No further actions.

Continue with the next step in this troubleshooting procedure. If all steps have been completed and this trouble code is still present, contact the PACCAR Engine Support Center for further assistance.


	<div data-bbox="492 134 578 220" data-label="Image"> </div> <div data-bbox="597 147 1445 279" data-label="Text"> <p>Contacting the PACCAR Engine Support Center</p> <p>For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center.</p> </div>
	<div data-bbox="1369 457 1528 487" data-label="Text"> <p>Back to Index</p> </div>

P104D


Code number	P104D
Fault code description	Pressure before turbine – Data valid but too high
Fault code information	2 trip MIL 3 drive cycle recovery Readiness group - None Freeze frame type - Generic
Description of component(s)	 <p>The exhaust gas pressure before the turbine is measured with sensor (1) via a steel tube (2) before the EGR valve.</p> <p>Effect on the system:</p> <ul style="list-style-type: none"> • Control of the VTG turbo charger • Control of the EGR flow • Control of the BPV valve • Control of the engine brake • Calculates the exhaust gas temperature before the turbine <p>Lower measured exhaust gas pressure before turbine results in higher calculated exhaust gas temperature before the turbine.</p>

<p>Location of component(s)</p>	
<p>Diagnostic condition</p>	<p>This diagnostic runs:</p> <ul style="list-style-type: none"> • engine speed 1000 and 1700 rpm, and; • when the engine is running at a steady load, and; • when coolant temperature is above 50°C [122°F], and; • The engine mode is SCR high efficiency or standard or protection.
<p>Set condition of fault code</p>	<p>The PCI ECU (D420) detects that the measured pressure before turbine is higher than the expected pressure before turbine for more than 50 seconds.</p>
<p>Reset condition of fault code</p>	<p>This DTC changes to inactive when the fault is no longer detected. To validate the repair, drive the vehicle until the coolant temperature is at least 70°C [158°F]. Once the minimum target temperature has been reached, proceed at a minimum speed of 80 km/h [50 mph] in the highest gear possible with the engine speed between 1100 and 1500 rpm and set the cruise control. This test is best performed with a loaded vehicle/trailer, but if load is unavailable, turn as many engine power consumers on to produce engine load. Perform this test for roughly 5 to 8 km [3 to 5 miles] or in 3 separate 1.5 km [1 mile] increments if a steady 5 to 8 km [3 to 5 miles] is unachievable. Use a flat road, if possible.</p>

Electrical diagram(s)





Wiring harness connector D420.C front view



Wiring harness connector F826 front view


D420	F829	Function
C38	4	Ground
C61	2	Power supply
C83	1	Signal, pressure before turbine


Technical data	<div>Component & wiring check, ECU (D420)</div> <div>Preparation</div> <div><ul style="list-style-type: none">Key off the ignition.Disconnect connector F826Measure on the front side of wiring harness connector F826</div> <div><table><tr><td>Pin</td><td>Pin</td><td></td><td></td></tr><tr><td>(+probe)</td><td>(-probe)</td><td>Value</td><td>Additional information</td></tr><tr><td>2</td><td>4</td><td>5V</td><td>Ignition keyed on</td></tr></table></div>	Pin	Pin			(+probe)	(-probe)	Value	Additional information	2	4	5V	Ignition keyed on
Pin	Pin												
(+probe)	(-probe)	Value	Additional information										
2	4	5V	Ignition keyed on										
Possible causes	<ul style="list-style-type: none">Blocked exhaust systemRestricted pressure sensor before turbine tubePressure sensor before turbine deviation												
Additional information	<ul style="list-style-type: none">The measured pressure before turbine is compared with an expected pressure before turbine.The pressure before turbine is measured by the pressure sensor before turbine (F826).												
Diagnostic Step-by-Step	<div><div></div><div><p>Perform the troubleshooting steps below using the breakout harness, if necessary, to check electrical components, such as sensors, electrical control units, and harnesses. Back probing is not recommended, as it could damage the harness. The ignition should always be in the OFF position when connecting or disconnecting electrical components in order to reduce the likelihood of damage to electrical components.</p></div></div> <div><div></div><div><ul style="list-style-type: none">Disconnecting the EAS connectors during the troubleshooting process will result in multiple errors.For specific electrical component information and pinout locations, always refer to the technical data.It is necessary to exit the fault code menu in DAVIE and run the diagnostic test again to identify a change in errors.Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive fault codes. Refer to the 'possible causes' section.</div></div> <div><table><tr><td>Step 1</td><td>Step 104Da</td><td>SRT</td></tr></table><div>Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.</div></div> <div><table><tr><td>Step 2</td><td>Step 104Db</td><td>SRT</td></tr></table><div>Ancillary Test: Air Side Pressure</div><div>Perform the prescribed test to determine if there are any leaks in the air system. Does the test fail to complete or result in a failed state?</div><div><ul style="list-style-type: none">No: Continue to the next step3 in the troubleshooting process.Yes: Make the appropriate repairs or component replacements.</div><div>Use DAVIE to re-check for the presence of active faults.</div><div><ul style="list-style-type: none">If this related fault is no longer active, then this issue has been resolved.If this related fault is still active, continue to the next step in the troubleshooting process.</div></div> <div><table><tr><td>Step 3</td><td>Step 104Dc</td><td>SRT</td></tr></table></div>	Step 1	Step 104Da	SRT	Step 2	Step 104Db	SRT	Step 3	Step 104Dc	SRT			
Step 1	Step 104Da	SRT											
Step 2	Step 104Db	SRT											
Step 3	Step 104Dc	SRT											

	<p>DAVIE Direct Monitor: Before Turbine Pressure</p> <p>Use DAVIE to monitor the Before Turbine Pressure, to determine if the Before Turbine Pressure Sensor (P3) is reading correctly.</p> <p>Does the monitored value appear incorrect?</p> <ul style="list-style-type: none">• No: Continue to the next step4 in the troubleshooting process.• Yes: Clean adjust, repair or replace affected components for any issues identified. <p>Use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">• If this related fault is no longer active, then this issue has been resolved.• If this related fault is still active, continue to the next step in the troubleshooting process.			
	<table><tr><td>Step 4</td><td>Step 104Dd</td><td>SRT</td></tr></table> <p>Visual Inspection: Pressure Sensor Before Turbo (P3)</p> <p>Visually inspect the identified component for any of the following:</p> <p>Damaged or blockage</p> <p>Was there evidence of any of the above?</p> <ul style="list-style-type: none">• No: Continue to the next step5 in the troubleshooting process.• Yes: Clean, adjust, repair, or replace affected components for any issues identified. <p>Use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">• If this related fault is no longer active, then this issue has been resolved.• If this related fault is still active, continue to the next step in the troubleshooting process.	Step 4	Step 104Dd	SRT
	Step 4	Step 104Dd	SRT	
	<table><tr><td>Step 5</td><td>Step 104De</td><td>SRT</td></tr></table> <p>Replace: Pressure sensor before turbo (P3)</p> <p>Replace the identified faulty component.</p> <p>Use DAVIE to check for the presence of active faults.</p> <ul style="list-style-type: none">• If this related fault is no longer active, then this issue has been resolved.• If this related fault is still active, continue to the next step in the troubleshooting process.	Step 5	Step 104De	SRT
Step 5	Step 104De	SRT		
<table><tr><td>Step 6</td><td>Step 104Df</td><td>SRT</td></tr></table> <p>Contact the PACCAR Engine Support Call Center</p> <p>For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center at 1-800-477-0251.</p>	Step 6	Step 104Df	SRT	
Step 6	Step 104Df	SRT		
Verification Drive Cycle	<p>To validate repair:</p> <p>This cycle is best performed on a level grade road (least amount of incline possible) and under load using a trailer. If a loaded trailer is unavailable, produce engine load by turning the A/C and fan to ON.</p> <p>With the System Initiation cycle complete, proceed to a road with a minimum speed limit of 50 mph, then get to the highest gear possible with the engine speed between 1100-1500 rpm, and set the cruise control. Run this cycle for roughly 3 to 5 miles or in three separate 1-mile increments if a steady 3 to 5 miles is unachievable.</p>			


	Back to Index
--	-------------------------------

P1050


Code number	P1050
Fault code description	Pressure after BPV – Data erratic, intermittent, or incorrect
Fault code information	2 trip MIL 3 drive cycle recovery Readiness group - None Freeze frame type - Generic
Description of component(s)	 <p>The exhaust gas pressure after the BPV valve is measured by the sensor (1) via a steel tube (2).</p> <p>Effect on the system:</p> <ul style="list-style-type: none"> • Correction of the NOx sensor before the catalyst signal A higher measured exhaust gas pressure after the BPV valve results in lower calculated NOx emissions by the engine. • Calculates the exhaust gas temperature before the turbine Lower measured exhaust gas pressure after the BPV valve results in higher calculated exhaust gas temperature before the turbine.

Location of component(s)	 <p style="text-align: center;">F823</p>
Diagnostic condition	<p>This diagnostic runs:</p> <ul style="list-style-type: none"> • engine speed is between 1000 and 1700 rpm, and; • engine is running at a steady load, and; • coolant temperature is above 50°C [122°F], and; • the engine mode is SCR high efficiency or standard.
Set condition of fault code	<p>The PCI ECU (D420) detects that measured pressure after BPV differs too much from the expected pressure after BPV for more than 50 seconds.</p>
Reset condition of fault code	<p>This DTC changes to inactive when the fault is no longer detected. To validate the repair, drive the vehicle until the coolant temperature is at least 70°C [158°F]. Once the minimum target temperature has been reached, proceed at a minimum speed of 80 km/h [50 mph] in the highest gear possible with the engine speed between 1100 and 1500 rpm and set the cruise control. This test is best performed with a loaded vehicle/trailer, but if load is unavailable, turn as many engine power consumers on to produce engine load. Perform this test for roughly 5 to 8 km [3 to 5 miles] or in 3 separate 1.5 km [1 mile] increments if a steady 5 to 8 km [3 to 5 miles] is unachievable. Use a flat road, if possible.</p>

Electrical diagram(s)



Wiring harness connector D420.C front view





Wiring harness connector F823 front view

D420	F823	Function
C36	4	Ground
C59	2	Power supply
C81	1	Signal, pressure after BPV


Technical data


Component & wiring check, ECU (D420)

	<p>Preparation</p> <ul style="list-style-type: none">• Key off the ignition.• Disconnect connector F823• Measure on the front side of wiring harness connector F823 <table><tr><td>Pin</td><td>Pin</td><td></td><td></td></tr><tr><td>(+probe)</td><td>(-probe)</td><td>Value</td><td>Additional information</td></tr><tr><td>2</td><td>4</td><td>5V</td><td>Ignition keyed on</td></tr></table>	Pin	Pin			(+probe)	(-probe)	Value	Additional information	2	4	5V	Ignition keyed on
Pin	Pin												
(+probe)	(-probe)	Value	Additional information										
2	4	5V	Ignition keyed on										
Possible causes	<ul style="list-style-type: none">• Leakage in the exhaust system between engine and DPF filter inlet.• Blockage in the exhaust system between engine and DPF filter inlet.• Pressure sensor after BPV deviation• DPF pressure sensor deviation												
Additional information	<ul style="list-style-type: none">• The measured pressure after BPV is compared with an expected pressure after BPV. For the calculation of the expected value, the DPF pressure sensor (F837) and ambient pressure are used, among others.• The pressure after BPV is measured by the pressure sensor after BPV (F823)												
Diagnostic Step-by-Step	<div><div></div><div><p>Perform the troubleshooting steps below using the breakout harness, if necessary, to check electrical components, such as sensors, electrical control units, and harnesses. Back probing is not recommended, as it could damage the harness. The ignition should always be in the OFF position when connecting or disconnecting electrical components in order to reduce the likelihood of damage to electrical components.</p></div></div> <div><div></div><ul style="list-style-type: none">• Disconnecting the EAS connectors during the troubleshooting process will result in multiple errors.• For specific electrical component information and pinout locations, always refer to the technical data.• It is necessary to exit the fault code menu in DAVIE and run the diagnostic test again to identify a change in errors.• Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive fault codes. Refer to the 'possible causes' section.</div> <table><tr><td>Step 1</td><td>Step 1050a</td><td>SRT</td></tr><tr><td colspan="3">Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.</td></tr></table> <table><tr><td>Step 2</td><td>Step 1050b</td><td>SRT</td></tr><tr><td colspan="3"><p>DAVIE Direct: Monitor related sensors</p><p>Use DAVIE to monitor and record values for the following:</p><ul style="list-style-type: none">• After BPV Pressure• After Turbo Pressure• BPV Position Actuator<p>Are all recorded values within OEM specifications?</p><ul style="list-style-type: none">• No: Continue to the next step3 in the troubleshooting process.• Yes: Clean adjust, repair or replace affected components for any issues identified.<p>Use DAVIE to re-check for the presence of active faults.</p><ul style="list-style-type: none">• If this related fault is no longer active, then this issue has been resolved.</td></tr></table>	Step 1	Step 1050a	SRT	Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.			Step 2	Step 1050b	SRT	<p>DAVIE Direct: Monitor related sensors</p> <p>Use DAVIE to monitor and record values for the following:</p> <ul style="list-style-type: none">• After BPV Pressure• After Turbo Pressure• BPV Position Actuator <p>Are all recorded values within OEM specifications?</p> <ul style="list-style-type: none">• No: Continue to the next step3 in the troubleshooting process.• Yes: Clean adjust, repair or replace affected components for any issues identified. <p>Use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">• If this related fault is no longer active, then this issue has been resolved.		
Step 1	Step 1050a	SRT											
Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.													
Step 2	Step 1050b	SRT											
<p>DAVIE Direct: Monitor related sensors</p> <p>Use DAVIE to monitor and record values for the following:</p> <ul style="list-style-type: none">• After BPV Pressure• After Turbo Pressure• BPV Position Actuator <p>Are all recorded values within OEM specifications?</p> <ul style="list-style-type: none">• No: Continue to the next step3 in the troubleshooting process.• Yes: Clean adjust, repair or replace affected components for any issues identified. <p>Use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">• If this related fault is no longer active, then this issue has been resolved.													


	<ul style="list-style-type: none">• If this related fault is still active, continue to the next step in the troubleshooting process.			
	<table><tr><td>Step 3</td><td>Step 1050c</td><td>SRT</td></tr></table> <p>Visual inspection: After BPV Pressure sensor Remove the After BPV Pressure sensor and visually inspect the sensor tip for any of the following:</p> <ul style="list-style-type: none">• Signs of damage• Excessive build-up on the sensor tip <p>Was there evidence of any of the above?</p> <ul style="list-style-type: none">• No: Continue to the next step 4 in the troubleshooting process.• Yes: Clean, adjust, repair, or replace affected components for any issues identified. <p>If soot plugging was found, perform a manual cleaning of the DPF or perform a stationary regeneration.</p> <p>Use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">• If this related fault is no longer active, then this issue has been resolved.• If this related fault is still active, continue to the next step in the troubleshooting process.	Step 3	Step 1050c	SRT
Step 3	Step 1050c	SRT		
	<table><tr><td>Step 4</td><td>Step 1050d</td><td>SRT</td></tr></table> <p>Replace: After BPV Pressure sensor Replace the identified component. Use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">• If this related fault is no longer active, then this issue has been resolved.• If this related fault is still active, continue to the next step in the troubleshooting process.	Step 4	Step 1050d	SRT
Step 4	Step 1050d	SRT		
	<table><tr><td>Step 5</td><td>Step 1050e</td><td>SRT</td></tr></table> <p>Contact the PACCAR Engine Support Call Center For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center at 1-800-477-0251.</p>	Step 5	Step 1050e	SRT
Step 5	Step 1050e	SRT		
Verification Drive Cycle	<p>To validate repair:</p> <p>This cycle is best performed on a level grade road (least amount of incline possible) and under load using a trailer. If a loaded trailer is unavailable, produce engine load by turning the A/C and fan to ON.</p> <p>With the System Initiation cycle complete, proceed to a road with a minimum speed limit of 50 mph, then get to the highest gear possible with the engine speed between 1100-1500 rpm, and set the cruise control. Run this cycle for roughly 3 to 5 miles or in three separate 1-mile increments if a steady 3 to 5 miles is unachievable.</p>			
	<div>Back to Index</div>			

P1057


Code number	P1057
Fault code description	Pressure before turbine – Data valid but too low
Fault code information	2 trip MIL 3 drive cycle recovery Readiness group – None Freeze frame type – Generic
Description of component(s)	 <p>The exhaust gas pressure before the turbine is measured with sensor (1) via a steel tube (2) before the EGR valve.</p> <p>Effect on the system:</p> <ul style="list-style-type: none"> • Control of the VTG turbo charger • Control of the EGR flow • Control of the BPV valve • Control of the engine brake • Calculates the exhaust gas temperature before the turbine <p>Lower measured exhaust gas pressure before turbine results in higher calculated exhaust gas temperature before the turbine.</p>

Location of component(s)	
Diagnostic condition	<p>This diagnostic runs:</p> <ul style="list-style-type: none"> • engine speed is between 1000 and 1700 rpm, and; • engine is running at a steady load, and; • coolant temperature is above 50°C [122°F], and; • the engine mode is SCR high efficiency or standard or protection.
Set condition of fault code	<p>The PCI ECU (D420) detects that measured pressure before turbine is lower than the expected pressure before turbine for more than 50 seconds.</p>
Reset condition of fault code	<p>This DTC changes to inactive when the fault is no longer detected. To validate the repair, drive the vehicle until the coolant temperature is at least 70°C [158°F]. Once the minimum target temperature has been reached, proceed at a minimum speed of 80 km/h [50 mph] in the highest gear possible with the engine speed between 1100 and 1500 rpm and set the cruise control. This test is best performed with a loaded vehicle/trailer, but if load is unavailable, turn as many engine power consumers on to produce engine load. Perform this test for roughly 5 to 8 km [3 to 5 miles] or in 3 separate 1.5 km [1 mile] increments if a steady 5 to 8 km [3 to 5 miles] is unachievable. Use a flat road, if possible.</p>

Electrical diagram(s)



Wiring harness connector D420.C front view





Wiring harness connector F826 front view

D420	F829	Function
C38	4	Ground
C61	2	Power supply
C83	1	Signal, pressure before turbine



Technical data


Pin (+probe)	Pin (-probe)	Value	Additional information
2	4	5V	Ignition keyed on

Possible causes	This DTC changes to inactive when the fault is no longer detected. To validate the repair, drive the vehicle until the coolant temperature is at least 70°C [158°F]. Once the minimum target temperature has been reached, proceed at a minimum speed of 80 km/h [50 mph] in the highest gear possible with the engine speed between 1100 and 1500 rpm and set the cruise control. This test is best performed with a loaded vehicle/trailer, but if load is unavailable, turn as many engine power consumers on to produce engine load. Perform this test for roughly 5 to 8 km [3 to 5 miles] or in 3 separate 1.5 km [1 mile] increments if a steady 5 to 8 km [3 to 5 miles] is unachievable. Use a flat road, if possible.																										
Additional information	<ul style="list-style-type: none">• The measured pressure before turbine is compared with an expected pressure before turbine.• The pressure before turbine is measured by the pressure sensor before turbine (F826).																										
Diagnostic Step-by-Step	<div><div><p>Perform the troubleshooting steps below using the breakout harness, if necessary, to check electrical components, such as sensors, electrical control units, and harnesses. Back probing is not recommended, as it could damage the harness. The ignition should always be in the OFF position when connecting or disconnecting electrical components in order to reduce the likelihood of damage to electrical components.</p></div><div><ul style="list-style-type: none">• Disconnecting the EAS connectors during the troubleshooting process will result in multiple errors.• For specific electrical component information and pinout locations, always refer to the technical data.• It is necessary to exit the fault code menu in DAVIE and run the diagnostic test again to identify a change in errors.• Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive fault codes. Refer to the 'possible causes' section.</div></div> <table><tr><td>Step 1</td><td>Step 1057a</td><td>SRT</td></tr><tr><td colspan="3">Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.</td></tr></table> <table><tr><td>Step 2</td><td>Step 1057b</td><td>SRT</td></tr><tr><td colspan="3">Ancillary Test: Air Side Pressure Check - Perform the prescribed test to determine if there are any leaks in the air system. Does the test fail to complete or result in a failed state?</td></tr><tr><td colspan="3"><ul style="list-style-type: none">• No: Continue to the next step in the troubleshooting process, Proceed to step 3.• Yes: Make the appropriate repairs or component replacements.Use DAVIE to re-check for the presence of active faults.</td></tr><tr><td colspan="3"><ul style="list-style-type: none">• If this related fault is no longer active, then this issue has been resolved.• If this related fault is still active, continue to the next step in the troubleshooting process.Verify if code is cleared using Verification Drive Cycle procedure.</td></tr></table> <table><tr><td>Step 3</td><td>Step 1057c</td><td>SRT</td></tr><tr><td colspan="3">DAVIE Direct Monitor: Before Turbine Pressure - Use DAVIE to monitor the Before</td></tr></table>			Step 1	Step 1057a	SRT	Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.			Step 2	Step 1057b	SRT	Ancillary Test: Air Side Pressure Check - Perform the prescribed test to determine if there are any leaks in the air system. Does the test fail to complete or result in a failed state?			<ul style="list-style-type: none">• No: Continue to the next step in the troubleshooting process, Proceed to step 3.• Yes: Make the appropriate repairs or component replacements. Use DAVIE to re-check for the presence of active faults.			<ul style="list-style-type: none">• If this related fault is no longer active, then this issue has been resolved.• If this related fault is still active, continue to the next step in the troubleshooting process. Verify if code is cleared using Verification Drive Cycle procedure.			Step 3	Step 1057c	SRT	DAVIE Direct Monitor: Before Turbine Pressure - Use DAVIE to monitor the Before		
Step 1	Step 1057a	SRT																									
Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.																											
Step 2	Step 1057b	SRT																									
Ancillary Test: Air Side Pressure Check - Perform the prescribed test to determine if there are any leaks in the air system. Does the test fail to complete or result in a failed state?																											
<ul style="list-style-type: none">• No: Continue to the next step in the troubleshooting process, Proceed to step 3.• Yes: Make the appropriate repairs or component replacements. Use DAVIE to re-check for the presence of active faults.																											
<ul style="list-style-type: none">• If this related fault is no longer active, then this issue has been resolved.• If this related fault is still active, continue to the next step in the troubleshooting process. Verify if code is cleared using Verification Drive Cycle procedure.																											
Step 3	Step 1057c	SRT																									
DAVIE Direct Monitor: Before Turbine Pressure - Use DAVIE to monitor the Before																											

	<p>Turbine Pressure, to determine if the Before Turbine Pressure Sensor (P3) is reading correctly. Check if the monitored value appears incorrect?</p> <ul style="list-style-type: none">No: Continue to the next step 4 in the troubleshooting process.Yes: Clean adjust, repair or replace affected components for any issues identified. <p>Use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">If this related fault is no longer active, then this issue has been resolved.If this related fault is still active, continue to the next step in the troubleshooting process. <p>Verify if code is cleared using Verification Drive Cycle procedure.</p>			
	<table><tr><td>Step 4</td><td>Step 1057d</td><td>SRT</td></tr></table> <p>Visual Inspection: Pressure Sensor Before Turbo (P3) Visually inspect the identified component for any Damaged or blockage Was there evidence of any of the Damaged or blockage?</p> <ul style="list-style-type: none">No: Continue to the next step 5 in the troubleshooting process.Yes: Clean, adjust, repair, or replace affected components for any issues identified. <p>Use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">If this related fault is no longer active, then this issue has been resolved.If this related fault is still active, continue to the next step in the troubleshooting process. <p>Verify if code is cleared using Verification Drive Cycle procedure.</p>	Step 4	Step 1057d	SRT
	Step 4	Step 1057d	SRT	
	<table><tr><td>Step 5</td><td>Step 1057e</td><td>SRT</td></tr></table> <p>Replace: Pressure sensor before turbo (P3) Replace the identified faulty component. Use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">If this related fault is no longer active, then this issue has been resolved.If this related fault is still active, continue to the next step in the troubleshooting process. <p>Verify if code is cleared using Verification Drive Cycle procedure.</p>	Step 5	Step 1057e	SRT
	Step 5	Step 1057e	SRT	
<table><tr><td>Step 6</td><td>Step 1057f</td><td>SRT</td></tr></table> <p>Contact the PACCAR Engine Support Call Center For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center at 1-800-477-0251.</p>	Step 6	Step 1057f	SRT	
Step 6	Step 1057f	SRT		
<p>Verification Drive Cycle</p>	<p>To validate repair: This cycle is best performed on a level grade road (least amount of incline possible) and under load using a trailer. If a loaded trailer is unavailable, produce engine load by turning the A/C and fan to ON. With the System Initiation cycle complete, proceed to a road with a minimum speed limit of 50 mph, then get to the highest gear possible with the engine speed between 1100-1500 rpm, and set the cruise control. Run this cycle for roughly 3 to 5 miles or in three separate 1-mile increments if a steady 3 to 5 miles is unachievable.</p>			
	<p>Back to Index</p>			

P1086

Code number	P1086
Fault code description	Engine rail pressure rise – Too slow
Fault code information	<p>1 trip MIL</p> <p>3 drive cycle recovery</p> <p>Readiness group – None</p> <p>Freeze frame type – Fuel</p>
Description of component(s)	<p>Common rail pressure sensor (F854)</p> <p>The rail pressure is measured in the common rail.</p> <p> The rail pressure sensor is part of the common rail and is not interchangeable as a separate part.</p> <p>Effect on the system:</p> <ul style="list-style-type: none"> Feedback on the rail pressure control. <p>The rail pressure is closed-loop controlled. A comparison is made between the rail pressure demands determined by the ECU and the rail pressure feedback measured by the common rail pressure sensor.</p> <p>Description, common rail pump unit 1 and 2 (L092, L093)</p> <p>Common rail pump units 1 and 2 supply fuel to the common rail.</p>  <p>I402301</p>



I403451

- 1 Outlet port
- 2 Solenoid connector
- 3 Sealing ring fuel supply gallery - outside
- 4 Sealing ring fuel supply gallery - fuel return gallery
- 5 Sealing ring fuel return gallery - crankcase
- 6 Spring
- 7 Roller lifter
- 8 Common rail pump unit cam
- 9 Fuel return port
- 10 Fuel supply port

Operation


The internal plunger is actuated via a roller lifter on the camshaft. Each pump has three pumping events for every two crankshaft revolutions.

Fuel from the fuel gallery can enter the pumping plunger area via an internal valve. A pumping event starts when the plunger travels up, the PCI ECU activates the solenoid briefly and the internal valve closes the opening to the fuel gallery. The internal valve is kept closed hydraulically, and the fuel is pumped to the rail via a check valve in the outlet bore of the pump unit.

The pumping event stops when the roller lifter passes the top of the camshaft lobe, causing the plunger to travel downwards again. Due to this, the pressure above the plunger decreases and the internal valve opens the opening to the fuel gallery. The check valve in the outlet bore closes and prevents fuel from flowing back from the rail to the plunger area.


Control

The amount of fuel pumped to the rail depends on the duration of the pumping

	<p>event (pump delivery percentage). The earlier the solenoid is activated by the PCI ECU in the up stroke of the pumping plunger the more fuel (mg/stroke) is pumped to the rail.</p> <p>Effect on the system:</p> <ul style="list-style-type: none"> • Rail pressure control. <p>The rail pressure is closed-loop controlled. A comparison is made between the actual rail pressure and rail pressure demands determined by the ECU. The rail pressure is adjusted by pumping more or less fuel to the rail with the common rail pump units.</p>
<p>Location of component(s)</p>	<p>Common rail pressure sensor (F854)</p> 

Common rail pump unit 1 (L092)


MX_EPA13, MX-13



402255

Common rail pump unit 2 (L093)

MX_EPA13, MX-13



Diagnostic condition

This diagnostic runs when the rail pressure operating state is: Filling rail (during starting)

Set condition of fault code


The PCI ECU (D420) detects that the actual rail pressure is below 150 bar [2176 psi] for more than 5 seconds.

Reset condition of fault code

This DTC changes to inactive when the fault is no longer detected.

Electrical diagram(s)


Checking data, common rail pressure sensor (F854)




D420 PCI ECU

F854 engine rail pressure sensor

D420	F854	Function
A44	2	Ground
A48	3	Power supply
A52	1	Signal, common rail pressure



Wiring harness connector D420.A front view




Wiring harness connector F854 front view



Handle connectors and pins with care and use matching measuring probes.

Checking data, common rail pump unit (L092-L093)




D420 PCI ECU

L092 common rail pump unit 1

L093 common rail pump unit 2

D420	L092	L093	Function
------	------	------	----------

A25	2		Signal low, common rail pump unit 1
A26	1		Signal high, common rail pump unit 1
A27		1	Signal high, common rail pump unit 2
A28		2	Signal low, common rail pump unit 2



Wiring harness connector D420.A front view



Handle connectors and pins with care and use matching measuring probes.

Technical data

Component check, common rail pressure sensor (F854)

This type of component cannot be checked with a multimeter/oscilloscope. Perform the following to assess the component:

- Monitor/test the component with DAVIE.
- Perform the wiring check (see below).

Component & wiring check, ECU (D420)

Preparation


- Key off the ignition.
- Disconnect connector F854
- Measure on the front side of wiring harness connector F854

Pin (+ probe)	Pin (- probe)	Value	Additional information
3	2	5V	Ignition keyed on

Component check, common rail pump unit 1 (L092)

Preparation

- Key off the ignition
- Disconnect connector L092

	<ul style="list-style-type: none">Measure on component connector L092 <table><tr><th>Pin (+ probe)</th><th>Pin (- probe)</th><th>Value</th><th>Additional information</th></tr><tr><td rowspan="2">1</td><td rowspan="2">2</td><td>± 0.67 Ω</td><td>Resistance value at 20°C [68°F]</td></tr><tr><td>maximum 0.94 Ω</td><td>Resistance value at 120°C [248°F]</td></tr></table> <p>Component check, common rail pump unit 2 (L093)</p> <p>Preparation</p> <ul style="list-style-type: none">Key off the ignitionDisconnect connector L093Measure on component connector L093 <table><tr><th>Pin (+ probe)</th><th>Pin (- probe)</th><th>Value</th><th>Additional information</th></tr><tr><td rowspan="2">1</td><td rowspan="2">2</td><td>± 0.67 Ω</td><td>Resistance value at 20°C [68°F]</td></tr><tr><td>maximum 0.94 Ω</td><td>Resistance value at 120°C [248°F]</td></tr></table>	Pin (+ probe)	Pin (- probe)	Value	Additional information	1	2	± 0.67 Ω	Resistance value at 20°C [68°F]	maximum 0.94 Ω	Resistance value at 120°C [248°F]	Pin (+ probe)	Pin (- probe)	Value	Additional information	1	2	± 0.67 Ω	Resistance value at 20°C [68°F]	maximum 0.94 Ω	Resistance value at 120°C [248°F]
Pin (+ probe)	Pin (- probe)	Value	Additional information																		
1	2	± 0.67 Ω	Resistance value at 20°C [68°F]																		
		maximum 0.94 Ω	Resistance value at 120°C [248°F]																		
Pin (+ probe)	Pin (- probe)	Value	Additional information																		
1	2	± 0.67 Ω	Resistance value at 20°C [68°F]																		
		maximum 0.94 Ω	Resistance value at 120°C [248°F]																		
Possible causes	<ul style="list-style-type: none">Air present in the fuel system. <p>If the fuel system or parts of it have been emptied during maintenance or repair, this DTC may become active temporarily after the engine is started. If the DTC stays inactive when the engine is running, no further investigation is necessary.</p> <ul style="list-style-type: none">Fuel gelling at very low ambient temperatures.Restriction in the fuel supply or low performance of the fuel lift pump.An external or internal leakage on the high-pressure fuel system components.																				
Additional information	<div> This DTC may be a result of P3834. If P3834 is active or inactive, troubleshoot P3834 first.</div> <ul style="list-style-type: none">The rail pressure is closed-loop controlled. A comparison is made between the requested and actual rail pressure measured by the common rail pressure sensor.The actual rail pressure is measured in the common rail by the common rail pressure sensor (F854)																				

Diagnostic Step-by-Step



The ignition should always be in the OFF position when connecting or disconnecting electrical components to reduce the likelihood of damage to the components.



- This troubleshooting procedure is based on the assumption that supply power and ground to the PMCI are functioning properly.
- Disconnecting the PMCI connectors during the troubleshooting process will result in multiple errors.
- Specific electrical component information and pin out locations are provided in this procedure as a reference only. Always refer to the technical data sections in Rapido for the most up-to-date changes.
- It is necessary to use DAVIE to clear all current trouble codes from the PCI and EAS-3 ECUs, and then run the Quick Check to identify a change in fault status.
- This DTC can be set as a result of multiple failure modes. For proper fault isolation, complete all troubleshooting steps in the sequence provided.

Step 1. Investigate Related Trouble Codes

Before troubleshooting this code, take notice of any other active or inactive trouble codes. One or multiple other codes could have been the cause for this code.

Step 1.A Investigate related trouble codes

Action

1. Use DAVIE Diagnostics to perform a Quick Check for current trouble codes.

Are these or any other related codes active?

P0263, P0266, P0269, P0272, P0275, P0278, P0301, P0302, P0303, P0304, P0305, P0306

Yes

No

Refer to the troubleshooting information for these codes before continuing with this procedure.

Go to step 2.A

Step 2. Fuel System Checks

Step 2.A Visual inspection, connections and wiring, common rail pressure sensor (F854)

Action

1. Visually inspect the associated component connections and wiring for any of the following:
 - Fuel gelling (thickening or crystallization of fuel in the fuel filter)
 - Damaged or loose connector
 - Bent, broken, corroded or loose connector pins
 - Moisture or dirt in the connection
 - Damage to the wire harness or insulation
 - Sensor is damaged
 - Signs of external fuel leaks
 - Any damaged, bent, or broken fuel lines
 - Related fuel components not installed correctly

Was there evidence of any of the above?

Yes

No

Correct any issues found.
Refer to Step 3.A to perform the corresponding repair verification cycles and rechecks.

If this code is still present, go to step 2.B

Go to step 2.B

Step 2.B Visual inspection, connections and wiring, common rail pump unit 1 and 2 (L092, L093)

Action


1. Visually inspect the associated component connections and wiring for any of the following:
 - Damaged or loose connector
 - Bent, broken, corroded or loose connector pins
 - Moisture or dirt in the connection
 - Damage to the wire harness or insulation
 - Sensor is damaged
 - Signs of external fuel leaks
 - Any damaged, bent, or broken fuel lines
 - Related fuel components not installed correctly

Was there evidence of any of the above?

Yes

No


Correct any issues found.


	Refer to Step 3.A to perform the corresponding repair verification cycles and rechecks.		
	If this code is still present, go to step 2.C		Go to step 2.C
	Step 2.C Rapido Maintenance: Check fuel supply, low pressure (Job ID: 68720)		
	Action		
	1. Check the low pressure fuel supply by performing the maintenance procedure, " <u>check fuel system low pressure (Fuel system), job ID 68720.</u> "		
	Do any of the tests result in a failed state based on the criteria provided?		
	Yes		No
	Correct any issues found. Refer to Step 3.A to perform the corresponding repair verification cycles and rechecks.		
	If this code is still present, go to step 2.D		Go to step 2.D
	Step 2.D Electrical checks, resistance, common rail pump units 1 and 2 (L092 and L093)		
 Refer to the corresponding Checking Data in Engine Service – Rapido for associated supply and signal voltages, resistance values, and related connector pin test points.			
Action			
1. Check the resistance level as outlined in the corresponding checking data, " <u>Component check, common rail pump unit 1 pump (L092)</u> " and " <u>Component check, common rail pump unit 2 pump (L093)</u> "			
Are measured values within expected range?			
Yes		No	
		Correct any issues found, or replace the common rail unit pump if measured values indicate an error. Refer to Step 3.A to perform the corresponding repair verification cycles	

	and rechecks.
Got to Step 2.E	If this code is still present, go to Step 2.E

Step 2.E Rapido Maintenance: Check Fuel System High Pressure (Job ID: M038143)	
Action	
<ol style="list-style-type: none"> 1. Check the high pressure valve process associated with this procedure, refer to the job "<u>Check Fuel System High Pressure (Fuel system), Job ID 73760.</u>" 	
Do any of the tests result in a failed state based on the criteria provided?	
Yes	No
Correct any issues found. Refer to Step 3.A to perform the corresponding repair verification cycles and rechecks.	
	If all steps have been completed and this trouble code is still present, contact the PACCAR Engine Support Center for further assistance.

Step 3. Repair Verification


Step 3.A Repair verification cycles	
Perform these repair verification cycles following any corrective actions taken, to enable related OBD monitors to reach a readiness state associated with the trouble code or system being investigated.	
 <ul style="list-style-type: none"> • Before beginning these repair verification cycles, use the DAVIE Diagnostics, Quick Check function to clear all current DTCs from the PCI and EAS-3 ECUs. 	
Action	
<ol style="list-style-type: none"> 1. If the fuel system has been serviced, perform the following steps: <ol style="list-style-type: none"> a. Bleed the fuel system associated with this procedure, refer to the job "<u>Bleed (fuel system), Job ID 67132.</u>" b. Operate the engine for 2 minutes to clear entrained air. c. Clear the DTCs. 2. Start-up 	
With the brakes set, start the engine and allow it to run at idle for 2 minutes.	

	Were the identified repair verification cycles able to be completed?	
	Yes	No
		Investigate and correct any issues preventing these repair verification cycles from being completed, then re-run. For additional assistance, contact the PACCAR Engine Support Center.
	Go to Step 3.B	Go to Step 3.B
	Step 3.B DAVIE Diagnostics, Quick Check	
	Action	
	1. Use DAVIE Diagnostics to perform a Quick Check for current trouble codes to determine whether the actions taken have cleared this trouble code.	
	Has P1086 been cleared?	
	Yes	No
	Problem resolved. Clear all DTCs. No further actions.	Continue with the next step in this troubleshooting procedure. If all steps have been completed and this trouble code is still present, contact the PACCAR Engine Support Center for further assistance.
	<div>  <div> <p>Contacting the PACCAR Engine Support Center</p> <p>For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center.</p> </div> </div>	
	Back to Index	

P1087


Code number	P1087
Fault code description	Fuel pressure - Data valid but too low, moderately severe
Fault code information	1 trip MIL 3 drive cycle recovery Readiness group – None Freeze frame type – Fuel
Description of component(s)	<p>Fuel pressure sensor (F801)</p> <p>The low-pressure fuel pressure is measured at the end of the low-pressure fuel supply gallery.</p> <p>Effect on the system:</p> <ul style="list-style-type: none"> Limitation of the engine torque when the fuel pressure is too low. <p>Fuel temperature sensor (F803)</p> <p>The fuel temperature is measured in the low-pressure fuel supply gallery between the common rail pump units.</p> <p>Effect on the system:</p> <p>preventing automatic fuel module water draining activation when the fuel temperature is very low (the water present may be frozen).</p> <p>limitation of the engine torque when the fuel temperature is too high.</p>
Location of component(s)	Fuel pressure sensor (F801)

F801



Fuel temperature sensor (F803)




F803




1402264

Diagnostic condition


This diagnostic runs when the engine is running for more than 200 seconds.

Set condition of fault code	<p>The PCI ECU (D420) detects that the fuel pressure is too low (gray area of the graph) for more than 50 seconds.</p> <div><p>P = Fuel pressure in bar; rpm = engine speed</p><p>P = Fuel pressure in psi; rpm = engine speed</p></div>									
Reset condition of fault code	<p>This DTC changes to inactive when the fault is no longer detected.</p>									
Electrical diagram(s)	<p>Checking data, fuel pressure sensor (F801)</p> <div><p>I401884</p></div> <table><tr><th>D420</th><th>F801</th><th>Function</th></tr><tr><td>A38</td><td>4</td><td>Ground</td></tr><tr><td>A50</td><td>1</td><td>Signal, fuel pressure</td></tr></table>	D420	F801	Function	A38	4	Ground	A50	1	Signal, fuel pressure
D420	F801	Function								
A38	4	Ground								
A50	1	Signal, fuel pressure								

A46	2	Power supply
-----	---	--------------



Wiring harness connector D420.A
front view




Wiring harness connector F801
front view

E504115



Handle connectors and pins with care and use matching measuring probes.

Checking data, fuel temperature sensor (F803)




I401890


D420 PCI ECU

F803 fuel temperature sensor

D420	F803	Function
A42	1	Signal, fuel pressure
A60	3	Ground



Wiring harness connector D420.A
front view



Wiring harness connector F801
front view

E504115



Handle connectors and pins with care and use matching measuring probes.

Technical data

Component and wiring check, fuel pressure sensor (F801)

Component check, fuel pressure sensor (F801)

This type of component cannot be checked with a multimeter or oscilloscope. Perform the following to assess the component:

- Monitor/test the component with DAVIE
- Perform the wiring check

Component & wiring check, ECU (D420)

Preparation



- Switch off the ignition.
- Disconnect connector F801.
- Measure on the front side of wiring harness connector F801.

Pin (+ probe)	Pin (- probe)	Value	Additional information
2	4	5V	Ignition keyed on

Component check, fuel temperature sensor (F803)

Preparation

- Switch off the ignition.
- Disconnect connector F803.
- Measure on component connector F803.

	Pin (+ probe)	Pin (- probe)	Value	Additional information							
	1	3	5633–6120 Ω	Resistance value at 0°C [34°F]							
			2411–2573 Ω	Resistance value at 20°C [68°F]							
			1128–1213 Ω	Resistance value at 40°C [104°F]							
			568–619 Ω	Resistance value at 60°C [140°F]							
			306–337 Ω	Resistance value at 80°C [176°F]							
			176–196 Ω	Resistance value at 100°C [212°F]							
Component & wiring check, ECU (D420) Preparation <ul style="list-style-type: none">• Switch off the ignition.• Disconnect connector F803.• Measure on the front side of wiring harness connector F803. <table><tr><td>Pin (+ probe)</td><td>Pin (- probe)</td><td>Value</td><td>Additional information</td></tr><tr><td>1</td><td>3</td><td>5V</td><td>Ignition switched on</td></tr></table>				Pin (+ probe)	Pin (- probe)	Value	Additional information	1	3	5V	Ignition switched on
Pin (+ probe)	Pin (- probe)	Value	Additional information								
1	3	5V	Ignition switched on								
Possible causes	<ul style="list-style-type: none">• Faulty fuel pressure control valve• Restriction in the fuel supply or low performance of the fuel lift pump.										
Additional information	The low-pressure fuel pressure is measured by the fuel pressure sensor (F801).										
Diagnostic Step-by-Step	<div>The ignition should always be in the OFF position when connecting or disconnecting electrical components to reduce the likelihood of damage to the components.</div> <div><ul style="list-style-type: none">• This troubleshooting procedure is based on the assumption that supply power and ground to the PCI are functioning properly.• Disconnecting the PCI connectors during the troubleshooting process will result in multiple errors.• Specific electrical component information and pin out locations are provided in this procedure as a reference only. Always refer to the technical data sections in Rapido for the most up-to-date changes.• It is necessary to use DAVIE to clear all current DTCs from the PCI and EAS-3 ECUs, and then run the Quick Check to identify a change in fault status.• This DTC can be set as a result of multiple failure modes. For proper fault isolation, complete all troubleshooting steps in the sequence provided.</div>										

Step 1 Investigate Related DTCs

Before troubleshooting this DTC, take notice of any other active or inactive DTCs. One or multiple other DTCs could have been the cause for this DTC.

Step 1A Investigate related DTCs

Action

1. Use DAVIE Diagnostics to perform a Quick Check for current DTCs.

Are these or any other related DTCs active?

P2541; P2542

Yes

No

Refer to the troubleshooting information for these DTCs before continuing with this procedure.

Go to step 2A

Step 2 Fuel System, Low Pressure Checks

Step 2A Visual inspection, connections and wiring, fuel pressure (F801) and fuel temperature (F803) sensors

Action

1. Visually inspect the associated component connections and wiring for any of the following:
 - Damaged or loose connectors
 - Bent, broken, corroded, or loose connector pins
 - Moisture or dirt in the connections
 - Damage to the wire harness or insulation
 - The correct parts are not installed
 - ECU connections are damaged or disconnected
 - Battery not fully charged or contacts not tight
 - Fuel pressure sensor (F801) broken or not installed correctly
 - Fuel temperature sensor (F803) broken or not installed correctly

Was there evidence of any of the above?

Yes

No

Correct any issues found.
Refer to step 3A to perform the

corresponding repair verification cycles and rechecks.	
If this DTC is still present, go to step 2B	Go to step 2B

Step 2B DAVIE Monitor, fuel pressure

Action

1. Ensure the ignition switch has been set to off.
2. Disconnect and remove the fuel temperature sensor (F803).
3. Install a pressure gauge at the fuel temperature sensor (F803) port.
4. Set the ignition switch to on.
5. Note the fuel pressure readings at 650 rpm and at 2100 rpm.
6. Use DAVIE to monitor the fuel pressure values at the same engine speeds.
7. Compare the monitored pressure values.

The expected results should be within the following pressure ranges:

Engine speed	Fuel pressure
650 rpm	108 to 122 psi
2100 rpm	128 to 142 psi

Are the compared fuel pressure values within the expected range?

Yes	No
	Possible obstruction or leakage in the fuel supply.
Go to step 2C	Go to step 2C

Step 2C Visual inspection, low pressure circuit

Action

1. Inspect the low pressure side of the fuel system for any of the following:



*For additional information related to some of these check points, see "replace fuel filter element (Fuel system), job ID 66433."

- Low fuel level in fuel tank
- Fuel filter is damaged or needs replacement*
- Air in fuel system*
- Fuel leaks
- Damaged or kinked fuel lines
- Dirt or debris in the priming pump sieve (E073)
- Damage to the fuel lift pump o-ring
- Fuel system is not primed*
- Fuel control valve located at the left-rear of the engine block is open
- Damage to the power steering pump o-ring



A damaged o-ring on the power steering pump could lead to an overheating condition for the power steering pump, which can be transmitted via thermal conduction to the fuel pump.

Did these checks identify any failing conditions?

Yes

No

Correct any issues found.

- If the fuel lift pump o-ring has failed, change the o-ring and inspect the fuel pump integrity. If the fuel lift pump is failing, replace it.
- If the power steering pump o-ring is damaged, replace the o-ring.

Refer to step 3A to perform the corresponding repair verification cycles and rechecks.

If all steps have been completed and this DTC is still present, contact the PACCAR Engine Support Center for further assistance.

If all steps have been completed and this DTC is still present, contact the PACCAR Engine Support Center for further assistance.

Step 3 Repair Verification

Step 3A Repair verification cycles

Perform these repair verification cycles following any corrective actions taken, to enable related OBD monitors to reach a readiness state associated with the trouble code or system being investigated.



Before beginning these repair verification cycles, use the DAVIE Diagnostics, Quick Check function to clear all current DTCs from the PCI and EAS-3 ECUs.

Action

1. Start-up

With the brakes set, start the engine and allow it to run at idle for 2 minutes.

Were the identified repair verification cycles able to be completed?

Yes

No

Investigate and correct any issues preventing these repair verification cycles from being completed, then re-run. For additional assistance, contact the PACCAR Engine Support Center.

Go to step 3B

Go to step 3B

Step 3B DAVIE Diagnostics, Quick Check, OBD Readiness Monitors

Action

Use DAVIE Diagnostics to perform a Quick Check for current DTCs to determine whether the actions taken have cleared this DTC.

1. Confirm that the corresponding OBD Monitor Readiness Status value is displayed as "Ready."
A status of Ready indicates that the corresponding OBD monitor has run successfully and the problem has been resolved—no further action.

If the displayed status is "Not ready," continue to action step 2.
2. View the DTC overview display, and confirm that P1087 has been cleared.


Is the related OBD Monitor Readiness Status set to "Ready." Or, has P1087 been cleared?

Yes


No

	<p>Problem resolved. No further actions.</p>	<p>Continue with the next step in this troubleshooting procedure.</p> <p>If all steps have been completed and this DTC is still present:</p> <ul style="list-style-type: none"> • continue to operate the truck to extend the run time, allowing the corresponding OBD monitor sufficient time to complete • or, return to step 3A and perform this repair verification again. <p>If this issue is still present after extending or re-running the repair verification, contact the PACCAR Engine Support Center for further assistance.</p>
		<p>Back to Index</p>


P1088

Code number	P1088
Fault code description	Engine rail pressure - Data valid but too high
Fault code information	<div>  <p>For further assistance: Contact the PACCAR Engine Support Call Center 1-800-477-0251</p> </div> <p>Please contact Engine support center</p>
Description of component(s)	
Location of component(s)	
Diagnostic condition	This diagnostic runs when the rail pressure operating state is: Release valve only
Set condition of fault code	The PCI ECU (D420) detects that the measured rail pressure is more than 2840 bar [41191 psi].
Reset condition of fault code	This DTC changes to inactive when the fault is no longer detected.
Electrical diagram(s)	
Technical data	
Possible causes	<ul style="list-style-type: none"> Common rail pressure release valve failure (stuck in the closed position) Multiple injectors stuck in the closed position.
Additional information	<ul style="list-style-type: none"> This DTC becomes active in combination with other fuel system related DTCs. Troubleshoot these faults first. The rail pressure is measured in the common rail by the common rail pressure sensor (F854). When this DTC is active: <ul style="list-style-type: none"> the engine torque is reduced the engine runs in protection mode the engine runs in rail pressure control state: Release valve only the maximum rail pressure is limited to 1300 bar
Diagnostic Step-by-Step	
Verification Drive Cycle	
	Back to Index


P1089

Code number	P1089
Fault code description	Engine rail pressure - Data valid but too high
Fault code information	1 trip MIL 3 drive cycle recovery Readiness group – None Freeze frame type - Fuel
Description of component(s)	<p>The rail pressure is measured in the common rail.</p> <p>The rail pressure sensor is part of the common rail and is not interchangeable as a separate part.</p> <p>Effect on the system:</p> <ul style="list-style-type: none"> Feedback on the rail pressure control. <p>The rail pressure is closed-loop controlled. A comparison is made between the rail pressure demands determined by the ECU and the rail pressure feedback measured by the common rail pressure sensor.</p>
Location of component(s)	 <p>The diagram illustrates the engine's common rail system. A green arrow points to the rail pressure sensor, which is labeled F854 in the inset image. The inset image provides a detailed view of the sensor's location on the common rail.</p>
Diagnostic condition	This diagnostic runs when the rail pressure operating state is: Pump unit only or Rail discharge
Set condition of fault code	The PCI ECU (D420) detects that the measured rail pressure is more than 2840 bar [41191 psi].
Reset condition of fault code	This DTC changes to inactive when the fault is no longer detected. To validate the repair, drive the vehicle until the coolant temperature is at least 70°C [158°F] in normal driving conditions. This activity can be best conducted with a loaded vehicle/trailer.

Electrical diagram(s)



Wiring harness connector D420.A front view



Wiring harness connector F854 front view



D420 PCI ECU

F854 engine rail pressure sensor

D420	F854	Function
A44	2	Ground
A48	3	Power supply
A52	1	Signal, common rail pressure


Technical data

Component & wiring check, ECU (D420)
Preparation


	<ul style="list-style-type: none">• Key off the ignition.• Disconnect connector F854• Measure on the front side of wiring harness connector F854 <table><tr><td>Pin (+ probe)</td><td>Pin (- probe)</td><td>Value</td><td>Additional information</td></tr><tr><td>3</td><td>2</td><td>5V</td><td>Ignition keyed on</td></tr></table>	Pin (+ probe)	Pin (- probe)	Value	Additional information	3	2	5V	Ignition keyed on																
Pin (+ probe)	Pin (- probe)	Value	Additional information																						
3	2	5V	Ignition keyed on																						
Possible causes	No possible causes information available.																								
Additional information	<ul style="list-style-type: none">• The rail pressure is measured in the common rail by the common rail pressure sensor (F854).• Engine torque is reduced.																								
Diagnostic Step-by-Step	<div><div></div><div><p>Perform the troubleshooting steps below using the breakout harness, if necessary, to check electrical components, such as sensors, electrical control units, and harnesses. Back probing is not recommended, as it could damage the harness. The ignition should always be in the OFF position when connecting or disconnecting electrical components in order to reduce the likelihood of damage to electrical components.</p></div></div> <div><div></div><ul style="list-style-type: none">• Disconnecting the EAS connectors during the troubleshooting process will result in multiple errors.• For specific electrical component information and pinout locations, always refer to the technical data.• It is necessary to exit the fault code menu in DAVIE and run the diagnostic test again to identify a change in errors.• Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive fault codes. Refer to the 'possible causes' section.</div> <table><tr><td>Step 1</td><td>Step ID 1089a</td><td>SRT</td></tr><tr><td colspan="3">Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2</td></tr></table> <table><tr><td>Step 2</td><td>Step ID 1089b</td><td>SRT</td></tr><tr><td colspan="3">DAVIE Direct Test: High Pressure Fuel Pump Unit test Run the prescribed DAVIE Direct test to determine if the electronic unit pumps are working correctly. Does the test fail to complete or result in a failed state?<ul style="list-style-type: none">• No: Proceed to step4• Yes: Proceed to step 3</td></tr></table> <table><tr><td>Step 3</td><td>Step ID 1089c</td><td>SRT</td></tr><tr><td colspan="3">Repairs or component replacements appropriate component and use DAVIE to re-check for the presence of active faults.<ul style="list-style-type: none">• Fault inactive – issue resolve• Fault active - Proceed to step 4</td></tr></table> <table><tr><td>Step 4</td><td>Step ID 1089d</td><td>SRT</td></tr><tr><td colspan="3">DAVIE Direct Test: Pressure Control Valve Run the prescribed DAVIE Direct test to determine if the high pressure valve is working correctly. Does the test fail to complete or result in a failed state?</td></tr></table>	Step 1	Step ID 1089a	SRT	Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2			Step 2	Step ID 1089b	SRT	DAVIE Direct Test: High Pressure Fuel Pump Unit test Run the prescribed DAVIE Direct test to determine if the electronic unit pumps are working correctly. Does the test fail to complete or result in a failed state? <ul style="list-style-type: none">• No: Proceed to step4• Yes: Proceed to step 3			Step 3	Step ID 1089c	SRT	Repairs or component replacements appropriate component and use DAVIE to re-check for the presence of active faults. <ul style="list-style-type: none">• Fault inactive – issue resolve• Fault active - Proceed to step 4			Step 4	Step ID 1089d	SRT	DAVIE Direct Test: Pressure Control Valve Run the prescribed DAVIE Direct test to determine if the high pressure valve is working correctly. Does the test fail to complete or result in a failed state?		
Step 1	Step ID 1089a	SRT																							
Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2																									
Step 2	Step ID 1089b	SRT																							
DAVIE Direct Test: High Pressure Fuel Pump Unit test Run the prescribed DAVIE Direct test to determine if the electronic unit pumps are working correctly. Does the test fail to complete or result in a failed state? <ul style="list-style-type: none">• No: Proceed to step4• Yes: Proceed to step 3																									
Step 3	Step ID 1089c	SRT																							
Repairs or component replacements appropriate component and use DAVIE to re-check for the presence of active faults. <ul style="list-style-type: none">• Fault inactive – issue resolve• Fault active - Proceed to step 4																									
Step 4	Step ID 1089d	SRT																							
DAVIE Direct Test: Pressure Control Valve Run the prescribed DAVIE Direct test to determine if the high pressure valve is working correctly. Does the test fail to complete or result in a failed state?																									


	<ul style="list-style-type: none">No: Proceed to step 6Yes: Proceed to step 5						
	<table><tr><td>Step 5</td><td>Step ID 1089e</td><td>SRT</td></tr><tr><td colspan="3">Repairs or component replacements appropriate component and use DAVIE to re-check for the presence of active faults.<ul style="list-style-type: none">Fault inactive – issue resolveFault active - Proceed to step 6</td></tr></table>	Step 5	Step ID 1089e	SRT	Repairs or component replacements appropriate component and use DAVIE to re-check for the presence of active faults. <ul style="list-style-type: none">Fault inactive – issue resolveFault active - Proceed to step 6		
	Step 5	Step ID 1089e	SRT				
	Repairs or component replacements appropriate component and use DAVIE to re-check for the presence of active faults. <ul style="list-style-type: none">Fault inactive – issue resolveFault active - Proceed to step 6						
	<table><tr><td>Step 6</td><td>Step ID 1089f</td><td>SRT</td></tr><tr><td colspan="3">Replace: Electronic Unit pump Replace the faulty Electronic Unit Pump. Use DAVIE to re-check for the presence of active faults.<ul style="list-style-type: none">Fault inactive – issue resolveIf this related fault is still active, proceed to step 7</td></tr></table>	Step 6	Step ID 1089f	SRT	Replace: Electronic Unit pump Replace the faulty Electronic Unit Pump. Use DAVIE to re-check for the presence of active faults. <ul style="list-style-type: none">Fault inactive – issue resolveIf this related fault is still active, proceed to step 7		
Step 6	Step ID 1089f	SRT					
Replace: Electronic Unit pump Replace the faulty Electronic Unit Pump. Use DAVIE to re-check for the presence of active faults. <ul style="list-style-type: none">Fault inactive – issue resolveIf this related fault is still active, proceed to step 7							
<table><tr><td>Step 7</td><td>Step ID 1089g</td><td>SRT</td></tr><tr><td colspan="3">Replace: High Pressure Valve (Common Rail) Replace the Common Rail assembly, which includes the High Pressure Valve. NOTE: The entire Common Rail must be replaced. The High Pressure Valve is a non-serviceable part and cannot be replaced or repaired separately. Contact the PACCAR Engine Support Call Center to confirm replacement of the Common Rail assembly. Use DAVIE to re-check for the presence of active faults.<ul style="list-style-type: none">Fault inactive – issue resolveIf this related fault is still active, proceed to step 8</td></tr></table>	Step 7	Step ID 1089g	SRT	Replace: High Pressure Valve (Common Rail) Replace the Common Rail assembly, which includes the High Pressure Valve. NOTE: The entire Common Rail must be replaced. The High Pressure Valve is a non-serviceable part and cannot be replaced or repaired separately. Contact the PACCAR Engine Support Call Center to confirm replacement of the Common Rail assembly. Use DAVIE to re-check for the presence of active faults. <ul style="list-style-type: none">Fault inactive – issue resolveIf this related fault is still active, proceed to step 8			
Step 7	Step ID 1089g	SRT					
Replace: High Pressure Valve (Common Rail) Replace the Common Rail assembly, which includes the High Pressure Valve. NOTE: The entire Common Rail must be replaced. The High Pressure Valve is a non-serviceable part and cannot be replaced or repaired separately. Contact the PACCAR Engine Support Call Center to confirm replacement of the Common Rail assembly. Use DAVIE to re-check for the presence of active faults. <ul style="list-style-type: none">Fault inactive – issue resolveIf this related fault is still active, proceed to step 8							
<table><tr><td>Step 8</td><td>Step ID 1089h</td><td>SRT</td></tr><tr><td colspan="3">For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center at 1-800-477-0251.</td></tr></table>	Step 8	Step ID 1089h	SRT	For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center at 1-800-477-0251.			
Step 8	Step ID 1089h	SRT					
For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center at 1-800-477-0251.							
Verification Drive Cycle	To validate repair, with the brakes set, start the engine and allow it to run at idle for 2 minutes.						
	Back to Index						



P1090

Code number	P1090
Fault code description	Detects when rail pressure goes over threshold (APV) in the absence of rail pressure sensor fault
Fault code information	<div>  <p>For further assistance: Contact the PACCAR Engine Support Call Center 1-800-477-0251</p> </div> <p>Please Contact the Engine Support Center</p>
Description of component(s)	
Location of component(s)	
Diagnostic condition	
Set condition of fault code	
Reset condition of fault code	
Electrical diagram(s)	
Technical data	
Possible causes	
Additional information	
Diagnostic Step-by-Step	
Verification Drive Cycle	
	Back to Index

P1091

Code number	P1091
Fault code description	Engine rail pressure control - Data erratic, intermittent, or incorrect
Fault code information	1 trip MIL 3 drive cycle recovery Readiness group – Fuel system Freeze frame type – Generic
Description of component(s)	<p>The rail pressure is measured in the common rail.</p> <p>The rail pressure sensor is part of the common rail and is not interchangeable as a separate part.</p> <p>Effect on the system:</p> <ul style="list-style-type: none"> Feedback on the rail pressure control. <p>The rail pressure is closed-loop controlled. A comparison is made between the rail pressure demands determined by the ECU and the rail pressure feedback measured by the common rail pressure sensor.</p>
Location of component(s)	 <p>The diagram illustrates the engine's internal components, specifically the common rail system. A green arrow points to the rail pressure sensor, labeled F854, which is mounted on the common rail. An inset image provides a magnified view of the sensor's location, showing its connection to the rail and surrounding components.</p>
Diagnostic condition	This diagnostic runs: <ul style="list-style-type: none"> during fuel injection cutoff event, and; engine speed is between 1200 and 1600 rpm, and; rail pressure operating state is: Release valve, and; this test is carried out after 30 minutes of engine running time when the conditions are met. It is repeated three times (total 90 minutes) before an



	evaluation is made.
Set condition of fault code	The PCI ECU (D420) detects that the controlled common rail pressure release valve current differs too much from the expected current.
Reset condition of fault code	This DTC changes to inactive when the fault is no longer detected.
Electrical diagram(s)	 <p>Wiring harness connector D420.A front view</p> <p>Wiring harness connector F854 front view</p> <p>D420 PCI ECU F854 engine rail pressure sensor</p> <p>D420 F854 Function</p>


	A44 2 Ground A48 3 Power supply A52 1 Signal, common rail pressure															
Technical data	<p>Component & wiring check, ECU (D420)</p> <p>Preparation</p> <ul style="list-style-type: none">Key off the ignition.Disconnect connector F854Measure on the front side of wiring harness connector F854 <table><tr><td>Pin (+ probe)</td><td>Pin (- probe)</td><td>Value</td><td>Additional information</td></tr><tr><td>3</td><td>2</td><td>5V</td><td>Ignition keyed on</td></tr></table>	Pin (+ probe)	Pin (- probe)	Value	Additional information	3	2	5V	Ignition keyed on							
Pin (+ probe)	Pin (- probe)	Value	Additional information													
3	2	5V	Ignition keyed on													
Possible causes	<ul style="list-style-type: none">Common rail pump unit failureCommon rail pressure release valve failureCommon rail pressure sensor deviation															
Additional information	<p>For this diagnostic, the high-pressure fuel system components are checked using an autonomous test. During this test, the rail pressure is controlled by the common rail pressure release valve (L094) during a fuel cutoff event. The PCI ECU controls the common rail pressure release valve current to keep the rail pressure at 1500 bar. This is compared with the common rail pressure sensor (F854) reading.</p>															
Diagnostic Step-by-Step	<div><div></div><p>Perform the troubleshooting steps below using the breakout harness, if necessary, to check electrical components, such as sensors, electrical control units, and harnesses. Back probing is not recommended, as it could damage the harness. The ignition should always be in the OFF position when connecting or disconnecting electrical components to reduce the likelihood of damage to electrical components</p></div> <div><div></div><ul style="list-style-type: none">This troubleshooting tree is based on the assumption that supply power and ground to the PCI are functioning properly.Disconnecting the PCI connectors during the troubleshooting process will result in multiple errors.For specific electrical component information and pinout locations, always refer to the technical data in Rapido.It is necessary to exit the 'active errors' screen in DAVIE and run the diagnostic test again to identify changes in errors.Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive codes. Refer to the 'possible causes' section in Rapido.</div> <table><tr><td>Step 1</td><td>Step ID 1091a</td><td>SRT</td></tr><tr><td colspan="3">Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.</td></tr></table> <table><tr><td>Step 2</td><td>Step ID 1091b</td><td>SRT</td></tr><tr><td colspan="3">Run DAVIE Direct test (Pressure Control Valve) to determine if the high pressure valve is working correctly. Does the test fail to complete or result in a failed state?<ul style="list-style-type: none">No: Proceed to step 3.Yes: Make the appropriate repairs or component replacements.</td></tr><tr><td colspan="3">Use DAVIE to re-check for the presence of active faults.</td></tr></table>	Step 1	Step ID 1091a	SRT	Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.			Step 2	Step ID 1091b	SRT	Run DAVIE Direct test (Pressure Control Valve) to determine if the high pressure valve is working correctly. Does the test fail to complete or result in a failed state? <ul style="list-style-type: none">No: Proceed to step 3.Yes: Make the appropriate repairs or component replacements.			Use DAVIE to re-check for the presence of active faults.		
Step 1	Step ID 1091a	SRT														
Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.																
Step 2	Step ID 1091b	SRT														
Run DAVIE Direct test (Pressure Control Valve) to determine if the high pressure valve is working correctly. Does the test fail to complete or result in a failed state? <ul style="list-style-type: none">No: Proceed to step 3.Yes: Make the appropriate repairs or component replacements.																
Use DAVIE to re-check for the presence of active faults.																

	<ul style="list-style-type: none">• Fault inactive – issue resolved• Fault active - Proceed to step 3						
	<table><tr><td>Step 3</td><td>Step ID 1091c</td><td>SRT</td></tr><tr><td colspan="3">Repair or replace High Pressure Valve (Common Rail) and use DAVIE to re-check for the presence of active faults.<ul style="list-style-type: none">• Fault inactive – issue resolved• Fault active - Proceed to step 4</td></tr></table>	Step 3	Step ID 1091c	SRT	Repair or replace High Pressure Valve (Common Rail) and use DAVIE to re-check for the presence of active faults. <ul style="list-style-type: none">• Fault inactive – issue resolved• Fault active - Proceed to step 4		
	Step 3	Step ID 1091c	SRT				
	Repair or replace High Pressure Valve (Common Rail) and use DAVIE to re-check for the presence of active faults. <ul style="list-style-type: none">• Fault inactive – issue resolved• Fault active - Proceed to step 4						
<table><tr><td>Step 4</td><td>Step ID 1091d</td><td>SRT</td></tr><tr><td colspan="3">For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center at 1-800-477-0251.</td></tr></table>	Step 4	Step ID 1091d	SRT	For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center at 1-800-477-0251.			
Step 4	Step ID 1091d	SRT					
For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center at 1-800-477-0251.							
Verification Drive Cycle	<p>To validate repair:</p> <p>This cycle is best performed on a level grade road (least amount of incline possible) and under load using a trailer. If a loaded trailer is unavailable, produce engine load by turning the A/C and fan to ON.</p> <p>With the System Initiation cycle complete, proceed to a road with a minimum speed limit of 50 mph, then get to the highest gear possible with the engine speed between 1100-1500 rpm, and set the cruise control. Run this cycle for roughly 3 to 5 miles or in three separate 1-mile increments if a steady 3 to 5 miles is unachievable.</p>						
	Back to Index						


P109C

Code number	P109C
Fault code description	Common rail pressure release valve - Current too low or open circuit on ECU D420 pin C4
Fault code information	1 trip MIL 3 drive cycle recovery Readiness group – None Freeze frame type - Fuel
Description of component(s)	<p>The common rail pressure release valve is used to control the rail pressure during a malfunction in the rail pressure control situation. Secondly, it has a pressure-limiting valve so that the rail pressure does not exceed 3250 ± 300 bar [47138 ± 4351 psi] in emergency situations (e.g., loss of rail pressure control).</p> <p>The common rail pressure release valve is part of the common rail and is not interchangeable as a separate part.</p> <p>Control During normal rail pressure control, the valve is controlled (duty cycle) to keep it closed. The current to keep the valve closed varies and depends on the required rail pressure.</p> <p>If it is not electronically controlled (e.g., faulty valve or wiring), the valve is normally closed and opens at approximately 320 ± 70 bar [4641 ± 1015 psi]. The opening pressure can vary depending on engine speed, fuel temperature, and other factors. If the valve opens, the fuel is dumped into the supply pipe of the fuel module.</p> <p>Learning function The current to control the common rail pressure release valve is determined by the PCI ECU and is stored in its memory. If a common rail pressure release valve is changed, the stored value in the PCI ECU must be reset with DAVIE.</p> <p>Effect of output signal on the system:</p> <ul style="list-style-type: none"> controlling the rail pressure in case the normal rail pressure control is lost (for example, a failure on high-pressure fuel system components is detected). Limits the maximum rail pressure in emergency situations

Location of component(s)	 <p>The diagram shows the engine assembly with a green arrow pointing to the High Pressure Common Rail Fuel Pressure Relief Valve (L094). An inset provides a close-up view of the valve, which is a green component with a circular opening.</p>
Diagnostic condition	<p>There is no Diagnostic condition information.</p>
Set condition of fault code	<p>This condition is set when High Pressure Common Rail Fuel Pressure Relief Valve current feedback is less than 0A.</p>
Reset condition of fault code	<p>This fault code will change to inactive immediately after the diagnostic runs and passes.</p>
Electrical diagram(s)	 <p>The electrical diagram shows the High Pressure Common Rail Fuel Pressure Relief Valve (L094) connected to the engine control unit (D420). The valve is represented by a symbol with a square and a diagonal line. It is connected to terminals 1 and 2. These terminals are connected to the engine control unit (D420) via a connector labeled C25 and C4.</p>



Wiring harness connector D420.C front view



Wiring harness connector L094 front view

D420 PCI ECU

L094 common rail pressure release valve

D420 L094 Function

C4 2 Signal, common rail pressure release valve

C26 1 Ground

Technical data

Component check, common rail pressure release valve (L094)

Preparation

- Key off the ignition
- Disconnect connector L094
- Measure on component connector L094

Pin	Pin	Value	Additional information
(+ probe)	(- probe)		
1	2	1.57–1.93 Ω	at 20°C [68°F]

Possible causes

No Possible causes available

Additional information

Engine torque is reduced.

Diagnostic Step-by-Step



Perform the troubleshooting steps below using the breakout harness, if necessary, to check electrical components, such as sensors, electrical control units, and harnesses. Back probing is not recommended, as it could damage the harness. The ignition should always be in the **OFF** position when connecting or disconnecting electrical components to reduce the likelihood of damage to electrical components



- This troubleshooting tree is based on the assumption that supply power and ground to the PCI are functioning properly.
- Disconnecting the PCI connectors during the troubleshooting process will result in multiple errors.
- For specific electrical component information and pinout locations, always refer to the technical data in Rapido.
- It is necessary to exit the 'active errors' screen in DAVIE and run the diagnostic test again to identify changes in errors.
- Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive codes. Refer to the 'possible causes' section in Rapido.

Step 1	Step ID 109Ca	SRT
--------	---------------	-----

Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.

Step 2	Step ID 109Cb	SRT
--------	---------------	-----

Electrical Checks
 Ensure that the ignition key/switch has been set to OFF before disconnecting related cables.
 Based on the fault message provided, confirm that the following electrical values are within specified ranges or limits:

- Supply and signal voltages (12V).
- Cable continuity (no opens or shorts).

Are measured electrical values outside of expected range or limits?

- Yes - Proceed to step 3
- No - Proceed to step 4

Step 3	Step ID 109Cc	SRT
--------	---------------	-----

Repair or replace Common Rail assembly and use DAVIE to re-check for the presence of active faults.

- Fault inactive – issue resolve
- Fault active - Proceed to step 4

Step 4	Step ID 109Cd	SRT
--------	---------------	-----

For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center at 1-800-477-0251.



Verification Drive Cycle


To validate repair, with the brakes set, start the engine and allow it to run at idle for 2 minutes.

[Back to Index](#)


P109D

Code number	P109D
Fault code description	Common rail pressure release valve - Current too high on ECU D420 pin C4
Fault code information	<p>1 trip MIL</p> <p>3 drive cycle recovery</p> <p>Readiness group – None</p> <p>Freeze frame type - Fuel</p>
Description of component(s)	<p>The common rail pressure release valve is used to control the rail pressure during a malfunction in the rail pressure control situation. Secondly, it has a pressure-limiting valve so that the rail pressure does not exceed 3250 ± 300 bar [47138 ± 4351 psi] in emergency situations (e.g., loss of rail pressure control).</p> <p>The common rail pressure release valve is part of the common rail and is not interchangeable as a separate part.</p> <p>Control</p> <p>During normal rail pressure control, the valve is controlled (duty cycle) to keep it closed. The current to keep the valve closed varies and depends on the required rail pressure.</p> <p>If it is not electronically controlled (e.g., faulty valve or wiring), the valve is normally closed and opens at approximately 320 ± 70 bar [4641 ± 1015 psi]. The opening pressure can vary depending on engine speed, fuel temperature, and other factors. If the valve opens, the fuel is dumped into the supply pipe of the fuel module.</p> <p>Learning function</p> <p>The current to control the common rail pressure release valve is determined by the PCI ECU and is stored in its memory. If a common rail pressure release valve is changed, the stored value in the PCI ECU must be reset with DAVIE.</p> <p>Effect of output signal on the system:</p> <ul style="list-style-type: none"> Controlling the rail pressure in case the normal rail pressure control is lost (for example, a failure on high-pressure fuel system components is detected). Limits the maximum rail pressure in emergency situations

Location of component(s)	 <p>The diagram shows the engine assembly with a green arrow pointing to the High Pressure Common Rail Fuel Pressure Relief Valve (L094). An inset provides a magnified view of the valve, also with a green arrow pointing to it.</p>
Diagnostic condition	<p>This diagnostic runs continuously when the ignition is on with the engine off, after 10 seconds of ignition ON</p>
Set condition of fault code	<p>If High Pressure Common Rail Fuel Pressure Relief Valve current feedback is greater than the threshold value of 2.3A then the condition is set.</p>
Reset condition of fault code	<p>This fault code will change to inactive immediately after the diagnostic runs and passes.</p>
Electrical diagram(s)	 <p>The electrical diagram shows the High Pressure Common Rail Fuel Pressure Relief Valve (L094) connected to terminals 1 and 2. These terminals are connected to a relay (C26, C4) which is connected to the engine control unit (D420).</p>



Wiring harness connector D420.C front view



Wiring harness connector L094 front view

D420 PCI ECU

L094 common rail pressure release valve

D420 L094 Function

C4 2 Signal, common rail pressure release valve

C26 1 Ground

Technical data

Component check, common rail pressure release valve (L094)

Preparation

- Key off the ignition
- Disconnect connector L094
- Measure on component connector L094

Pin	Pin	Value	Additional information
(+ probe)	(- probe)		
1	2	1.57–1.93 Ω	at 20°C [68°F]

Possible causes

No possible causes available.

Additional information

Engine torque is reduced.

Diagnostic Step-by-Step



Perform the troubleshooting steps below using the breakout harness, if necessary, to check electrical components, such as sensors, electrical control units, and harnesses. Back probing is not recommended, as it could damage the harness. The ignition should always be in the OFF position when connecting or disconnecting electrical components to reduce the likelihood of damage to electrical components.



- This troubleshooting tree is based on the assumption that supply power and ground to the PCI are functioning properly.
- Disconnecting the PCI connectors during the troubleshooting process will result in multiple errors.
- For specific electrical component information and pin out locations, always refer to the technical data in Rapido.
- It is necessary to exit the 'active errors' screen in DAVIE and run the diagnostic test again to identify changes in errors.
- Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive codes. Refer to the 'possible causes' section in Rapid.

Step 1	Step ID 109Da	SRT
Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.		

Step 2	Step ID 109Db	SRT
Electrical Checks Ensure that the ignition key/switch has been set to OFF before disconnecting related cables. Based on the fault message provided, confirm that the following electrical values are within specified ranges or limits: <ul style="list-style-type: none"> • Supply and signal voltages. • Cable continuity (no opens or shorts). Are measured electrical values outside of expected range or limits? <ul style="list-style-type: none"> • Yes - Proceed to step 3 • No - Proceed to step 4 		


Step 3	Step ID 109Dc	SRT
Repair or replace appropriate component and use DAVIE to re-check for the presence of active faults. <ul style="list-style-type: none"> • Fault inactive – issue resolved • Fault active - Proceed to step 4 		


Step 4	Step ID 109Dd	SRT
Replace: High Pressure Valve (Common Rail) Contact the PACCAR Engine Support Call Center to confirm replacement of the Common Rail assembly. Replace the Common Rail assembly, which includes the High Pressure Valve. Use DAVIE to re-check for the presence of active faults. <ul style="list-style-type: none"> • Fault inactive – issue resolve • Fault active - Proceed to step 5 		


Step 5	Step ID 109De	SRT
Contact the PACCAR Engine Support Call Center: For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center at 1-800-477-0251.		

Verification Drive Cycle	To validate repair, with the brakes set, turn the key to the ON position with the engine off, and allow 10 seconds for the system to initialize and run diagnostics.
	Back to Index

P1110

Code number	P1110
Fault code description	Intercooler efficiency - Too low
Fault code information	2 trip MIL 3 drive cycle recovery Readiness group – Boost Freeze frame type – Boost
Description of component(s)	<p>The intercooler outlet temperature is measured before the EGR mixer.</p> <p>Effect on the system</p> <ul style="list-style-type: none"> Monitors intercooler performance
Location of component(s)	 <p>The diagram illustrates the engine layout with the intercooler outlet temperature sensor (F750) highlighted. An inset shows a detailed view of the sensor's location on the intercooler outlet pipe, just before the EGR mixer. The sensor is a green plug-in type.</p>
Diagnostic condition	<p>This diagnostic runs:</p> <ul style="list-style-type: none"> 150 seconds after an engine start, and; engine is running at steady speed and load, and; coolant temperature is above 65°C [149°F], and;

	<ul style="list-style-type: none">vehicle speed is more than 25 km/h [15.5 mph]									
Set condition of fault code	The PCI ECU (D420) detects that cooling capacity of the intercooler is too low for more than 40 seconds.									
Reset condition of fault code	<p>This DTC changes to inactive when the fault is no longer detected.</p> <p>To validate the repair, drive the vehicle until the coolant temperature is at least 70°C [158°F]. Once the minimum target temperature has been reached, proceed at a minimum speed of 80 km/h [50 mph] in the highest gear possible with the engine speed between 1100 and 1500 rpm and set the cruise control. This test is best performed with a loaded vehicle/trailer, but if load is unavailable, turn as many engine power consumers on to produce engine load. Perform this test for roughly 5 to 8 km [3 to 5 miles] or in 3 separate 1.5 km [1 mile] increments if a steady 5 to 8 km [3 to 5 miles] is unachievable. Use a flat road, if possible.</p>									
Electrical diagram(s)	<div><p>D420 PCI ECU</p><p>F750 Intercooler temperature sensor</p><table><thead><tr><th>D420</th><th>F750</th><th>Function</th></tr></thead><tbody><tr><td>C17</td><td>1</td><td>Signal, intercooler temperature</td></tr><tr><td>C31</td><td>2</td><td>Ground</td></tr></tbody></table></div>	D420	F750	Function	C17	1	Signal, intercooler temperature	C31	2	Ground
D420	F750	Function								
C17	1	Signal, intercooler temperature								
C31	2	Ground								



Handle connectors and pins with care and use matching measuring probes.

Technical data

Component check, intercooler temperature sensor (F750)

Preparation


- Key off the ignition
- Disconnect connector F750
- Measure on the component connector F750

Pin (+ probe)	Pin (- probe)	Value	Additional information
1	2	5248–5732 Ω	Resistance value at 0°C [32°F]
		2334–2505 Ω	Resistance value at 20°C [68°F]
		1133–1198 Ω	Resistance value at 40°C [104°F]
		593–619 Ω	Resistance value at 60°C [140°F]
		331–341 Ω	Resistance value at 80°C [176°F]
		195–199 Ω	Resistance value at 100°C [212°F]

Component & circuit check, ECU (D420)

Preparation

- Key off the ignition

	<ul style="list-style-type: none">• Disconnect connector F750• Measure on the front side of wiring harness connector F750 <table><tr><th>Pin (+ probe)</th><th>Pin (- probe)</th><th>Value</th><th>Additional information</th></tr><tr><td>1</td><td>2</td><td>5V</td><td>Ignition keyed on</td></tr></table>	Pin (+ probe)	Pin (- probe)	Value	Additional information	1	2	5V	Ignition keyed on
Pin (+ probe)	Pin (- probe)	Value	Additional information						
1	2	5V	Ignition keyed on						
Possible causes	<ul style="list-style-type: none">• Contaminated or blocked intercooler• Fan not working correctly• Intercooler temperature sensor deviation• Ambient air temperature sensor deviation• Coolant temperature sensor deviation• EGR temperature sensor deviation• Pre-compressor air temperature sensor deviation• Boost (intake manifold) air temperature sensor deviation• Ambient air pressure sensor deviation• Boost air pressure sensor deviation• Use of a winterfront at temperatures above 40°F (4°C)• Use of an aftermarket winterfront that has excessive airflow restriction through the intercooler.								
Additional information	<p>The cooling efficiency of the intercooler is monitored.</p> <p>This diagnostics consists of two parts:</p> <ol style="list-style-type: none">1. The temperature across the intercooler drop is monitored by comparing the calculated temperature before the intercooler with the measured temperature after the intercooler.2. The measured temperature after the intercooler is compared with the ambient temperature. <p>The temperature after the intercooler is measured by the intercooler temperature sensor (F750).</p>								
Diagnostic Step-by-Step	<div><p>The ignition should always be in the OFF position when connecting or disconnecting electrical components to reduce the likelihood of damage to the components.</p></div>								



- This troubleshooting procedure is based on the assumption that supply power and ground to the PMCI are functioning properly.
- Disconnecting the PMCI connectors during the troubleshooting process will result in multiple errors.
- Specific electrical component information and pin out locations are provided in this procedure as a reference only. Always refer to the technical data sections in Rapido for the most up-to-date changes.
- It is necessary to use DAVIE to clear all current trouble codes from the PCI and EAS-3 ECUs, and then run the Quick Check to identify a change in fault status.
- This DTC can be set as a result of multiple failure modes. For proper fault isolation, complete all troubleshooting steps in the sequence provided.

Step 1. Investigate Related Trouble Codes

Before troubleshooting this code, take notice of any other active or inactive trouble codes. One or multiple other codes could have been the cause for this code.

Step 1.A Investigate related trouble codes

Action

1. Use DAVIE Diagnostics to perform a Quick Check for current trouble codes.

Are these or any other related codes active?

Ambient air temp sensor	P0072; P0073; P009A
Coolant temperature sensor	P0115; P0117; P0118; P1115; P2181; P2183
Post-intercooler air temperature sensor	P0095; P0097; P0098; P0127; P1127
EGR (venturi) temperature sensor	P040B; P040C; P040D, or related EGR codes
Pre-compressor air temperature sensor	P2199; U1071
Boost air temperature sensor	P0110; P0112; P0113; P1128; P1573
Ambient air pressure sensor	P2226; P2228; P2229
Boost air pressure sensor	P0069; P0107; P0108; P104B; P104C

Yes

Refer to the troubleshooting information for these codes before continuing with this procedure.

No

Go to step 2.A

Step 2. Intercooler (F750) Checks

Step 2. A Visual inspection, intercooler (F750)

Action

1. Visually inspect the intercooler (charge air cooler) and associated components for any of the following:
 - Loose or broken clamps on the air system
 - Dirt or debris build-up (blockage) at the front of the intercooler
 - Air system parts are removed or damaged
 - Hump hoses are folded over or have holes
 - Damage to or incorrect installation of any of the following sensors:
 - Coolant temperature sensor (F566)
 - Post-intercooler temperature sensor (F750)
 - Pre-compressor air (after BPV) temperature sensor (F853)
 - EGR (venturi) temperature sensor (F749)
 - Boost air temperature sensor (F804)
 - Boost air pressure sensor (F802)

Was there evidence of any of the above?

Yes

No

Correct any issues found. If a sensor is found to be damaged or broken, replace it.
Refer to Step 3.A to perform the corresponding repair verification cycles and rechecks.

If this code is still present, go to Step 2.B.

Go to step 2.B

Step 2.B DAVIE monitor, intercooler temperature and related sensors

Action

1. Use DAVIE to select and monitor the following temperature and pressure values for comparison:
 - Coolant temperature (turbo control)
 - Post-intercooler air temperature(turbo control)
 - Pre-compressor air temperature(turbo control)
 - EGR temperature (EGR control)
 - Boost air pressure (turbo control)

For initial temperature readings, monitor with the ignition key to ON and the engine to OFF.

Start the engine and allow it to idle for a minimum of 10 minutes to allow the temperature sensors to stabilize.

While monitoring, no temperature should vary by a value of more than 50°F for a period of more than 5 seconds.

Do any monitored values vary by more than 50°F (24°C) for more than 5 seconds?

Yes

Correct any issues found, or replace the related sensor if measured values indicate a sensor error.

Refer to Step 3.A to perform the corresponding repair verification cycles and rechecks.

If this code is still present, go to step 2.C.

No

Go to step 2.C

Step 2.C Pressure testing, intake and exhaust elements

Action

1. Perform the steps outlined in the procedure, "pressure testing (intake/exhaust elem.)," job ID 84123, to determine whether there are any leaks in the intake air system.

Was there evidence of a leak in the air system?

Yes

No

Correct any issues found.
Refer to Step 3.A to perform the corresponding repair verification cycles and rechecks.

If all steps have been completed and this trouble code is still present, contact the PACCAR Engine Support Center for further assistance.

If all steps have been completed and this trouble code is still present, contact the PACCAR Engine Support Center for further assistance.

Step 3. Repair Verification

Step 3.A Repair verification cycles

Perform these repair verification cycles following any corrective actions taken, to enable related OBD monitors to reach a readiness state associated with the trouble code or system being investigated.



Before beginning these repair verification cycles, use the DAVIE Diagnostics, Quick Check function to clear all current DTCs from the PCI and EAS-3 ECUs.

Action

1. Steady State

This cycle is best performed on a level grade road (least amount of incline possible) and under load using a trailer. If a loaded trailer is unavailable, produce engine load by turning the A/C and fan to ON.

With the System Initiation cycle complete, proceed to a road with a minimum speed limit of 50 mph, then get to the highest gear possible with the engine speed between 1100-1500 rpm, and set the cruise control. Run this cycle for roughly 3 to 5 miles or in three separate 1-mile increments if a steady 3 to 5 miles is unachievable.

Were the identified repair verification cycles able to be completed?


Yes

No


Investigate and correct any issues preventing these repair verification cycles from being completed, then re-run. For additional assistance, contact the PACCAR Engine Support Center.


Go to step 3.B



Go to step 3.B

	Step 3.B DAVIE Diagnostics, Quick Check	
	Action	
	1. Use DAVIE Diagnostics to perform a Quick Check for current trouble codes to determine whether the actions taken have cleared this trouble code.	
	Has P1110 been cleared?	
	Yes	No
	Problem resolved. No further actions.	Continue with the next step in this troubleshooting procedure. If all steps have been completed and this trouble code is still present, contact the PACCAR Engine Support Center for further assistance.
	 <p>Contacting the PACCAR Engine Support Center</p> <p>For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center.</p>	
	Back to Index	

P1115


Code number	P1115
Fault code description	Coolant temperature - Data valid but too high, moderately severe
Fault code information	1 trip MIL 3 drive cycle recovery Readiness group – None Freeze frame type – Cooling
Description of component(s)	<p>The coolant temperature is measured in the coolant return gallery at the right rear end of the cylinder block.</p> <p>Effect on the system:</p> <ul style="list-style-type: none"> • Calculates the quantity of fuel to inject and the injection timing • Displays the coolant temperature to the driver • Displays warnings to the driver concerning high coolant temperature • Limits the engine torque when the coolant temperature is too high • Limits the maximum engine speed when the engine is cold • Enables condition for severity of (OBD) diagnostic checks • Fast idle speed control • Cold start aid
Location of component(s)	
Diagnostic condition	This diagnostic runs continuously when the ignition is keyed on and when the engine is running.
Set condition of fault code	The PCI ECU (D420) detects that the measured coolant temperature is more than 110°C [230°F] for more than 10 seconds.
Reset condition of fault code	This DTC changes to inactive when the fault is no longer detected. To validate the repair, drive the vehicle until the coolant temperature is at least 70°C [158°F]. Once the minimum target temperature has been reached, perform several low to higher

	speed accelerations with moderate engine load. Also perform high-load to low-load transitions. This activity should be conducted within the range of 15 km/h [10 mph] to 65 km/h [40 mph] for no more than 5 to 8 km [3 to 5 miles].									
Electrical diagram(s)	<div><p>Wiring harness connector D420.A front view</p><p>Wiring harness connector F566 front view</p><p>D420 PCI ECU F566 coolant temperature sensor</p><table><tr><th>D420</th><th>F556</th><th>Function</th></tr><tr><td>A58</td><td>1</td><td>Signal, coolant temperature</td></tr><tr><td>A61</td><td>2</td><td>Ground</td></tr></table></div>	D420	F556	Function	A58	1	Signal, coolant temperature	A61	2	Ground
D420	F556	Function								
A58	1	Signal, coolant temperature								
A61	2	Ground								
Technical data	<p>Component check, coolant temperature sensor (F566)</p> <p>Preparation</p> <ul style="list-style-type: none">Key off the ignition									


	<ul style="list-style-type: none">• Disconnect connector F566• Measure on component connector F566 <table><tr><th>Pin (+ probe)</th><th>Pin (- probe)</th><th>Value</th><th>Additional information</th></tr><tr><td>1</td><td>2</td><td>14936–15961 Ω</td><td>Resistance value at -20°C [-4°F]</td></tr><tr><td></td><td></td><td>5727–6056 Ω</td><td>Resistance value at 0°C [32°F]</td></tr><tr><td></td><td></td><td>2439–2557 Ω</td><td>Resistance value at 20°C [68°F]</td></tr><tr><td></td><td></td><td>1151–1197 Ω</td><td>Resistance value at 40°C [104°F]</td></tr><tr><td></td><td></td><td>585–604 Ω</td><td>Resistance value at 60°C [140°F]</td></tr><tr><td></td><td></td><td>318–327 Ω</td><td>Resistance value at 80°C [176°F]</td></tr><tr><td></td><td></td><td>185–188 Ω</td><td>Resistance value at 100°C [212°F]</td></tr><tr><td></td><td></td><td>111–114 Ω</td><td>Resistance value at 120°C [248°F]</td></tr></table> <p>Component & circuit check, ECU (D420)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key off the ignition• Disconnect connector F566• Measure on the front side of wiring harness connector F566 <table><tr><th>Pin (+ probe)</th><th>Pin (- probe)</th><th>Value</th><th>Additional information</th></tr><tr><td>1</td><td>2</td><td>5V</td><td>Ignition keyed on</td></tr></table>	Pin (+ probe)	Pin (- probe)	Value	Additional information	1	2	14936–15961 Ω	Resistance value at -20°C [-4°F]			5727–6056 Ω	Resistance value at 0°C [32°F]			2439–2557 Ω	Resistance value at 20°C [68°F]			1151–1197 Ω	Resistance value at 40°C [104°F]			585–604 Ω	Resistance value at 60°C [140°F]			318–327 Ω	Resistance value at 80°C [176°F]			185–188 Ω	Resistance value at 100°C [212°F]			111–114 Ω	Resistance value at 120°C [248°F]	Pin (+ probe)	Pin (- probe)	Value	Additional information	1	2	5V	Ignition keyed on
Pin (+ probe)	Pin (- probe)	Value	Additional information																																										
1	2	14936–15961 Ω	Resistance value at -20°C [-4°F]																																										
		5727–6056 Ω	Resistance value at 0°C [32°F]																																										
		2439–2557 Ω	Resistance value at 20°C [68°F]																																										
		1151–1197 Ω	Resistance value at 40°C [104°F]																																										
		585–604 Ω	Resistance value at 60°C [140°F]																																										
		318–327 Ω	Resistance value at 80°C [176°F]																																										
		185–188 Ω	Resistance value at 100°C [212°F]																																										
		111–114 Ω	Resistance value at 120°C [248°F]																																										
Pin (+ probe)	Pin (- probe)	Value	Additional information																																										
1	2	5V	Ignition keyed on																																										
Possible causes	<ul style="list-style-type: none">• Coolant level too low• Contaminated radiator• Faulty engine cooling fan• Blocked thermostat• Coolant temperature sensor deviation																																												
Additional information	The engine coolant temperature is monitored by the coolant temperature sensor (F566).																																												
Diagnostic Step-by-Step	<div><p>Perform the troubleshooting steps below using the breakout harness, if necessary, to check electrical components, such as sensors, electrical control units, and harnesses. Back probing is not recommended, as it could damage the harness. The ignition should always be in the OFF position when connecting or disconnecting electrical components in order to reduce the likelihood of damage to electrical components.</p></div> <div><ul style="list-style-type: none">• Disconnecting the EAS connectors during the troubleshooting process will result in multiple errors.• For specific electrical component information and pinout locations, always refer to the technical data.• It is necessary to exit the fault code menu in DAVIE and run the diagnostic test again to identify a change in errors.• Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive fault codes. Refer to the 'possible causes' section.</div> <table><tr><td>Step 1</td><td>Step ID 1115a</td><td>SRT</td></tr><tr><td colspan="3">Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.</td></tr><tr><td>Step 2</td><td>Step ID 1115b</td><td>SRT</td></tr></table>	Step 1	Step ID 1115a	SRT	Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.			Step 2	Step ID 1115b	SRT																																			
Step 1	Step ID 1115a	SRT																																											
Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.																																													
Step 2	Step ID 1115b	SRT																																											





	<p>Ancillary Test: Coolant Leak</p> <p>Perform the prescribed testing to determine correct operation of the associated engine or aftertreatment system.</p> <p>Does the test fail to complete or result in a failed state?</p> <ul style="list-style-type: none">• No – Proceed to step 4• Yes – Proceed to Step 3		
	Step 3	Step ID 1115c	SRT
	<p>Repairs or component replacements appropriate component and use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">• Fault inactive – issue resolved• Fault active - Proceed to step 4		
	Step 4	Step ID 1115d	SRT
	<p>Remove and inspect the thermostat to verify it is not stuck in the open or closed position.</p> <p>Was the thermostat stuck in the open or closed position?</p> <ul style="list-style-type: none">• No – Proceed to step 6• Yes – Proceed to step 5		
	Step 5	Step ID 1115e	SRT
	<p>Repairs or component replacements appropriate component and use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">• Fault inactive – issue resolved• Fault active - Proceed to step 6		
	Step 6	Step ID 1115f	SRT
	<p>Replace the identified faulty Coolant temperature sensor and use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">• Fault inactive – issue resolved• Fault active - Proceed to step 7		
	Step 7	Step ID 1115g	SRT
<p>For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the Engine Support Call Center at 1-800-477-0251.</p>			
Verification Drive Cycle	<p>To validate repair:</p> <p>This cycle is best performed on a level grade road (least amount of incline possible) and under load using a trailer. If a loaded trailer is unavailable, produce engine load by turning the A/C and fan to ON.</p> <p>With the System Initiation cycle complete, proceed to a road with a minimum speed limit of 50 mph, then get to the highest gear possible with the engine speed between 1100-1500 rpm, and set the cruise control. Run this cycle for roughly 3 to 5 miles or in three separate 1-mile increments if a steady 3 to 5 miles is unachievable.</p>		
	Back to Index		

P1122

Code number	P1122
Fault code description	Sticking cruise fault
Fault code information	<div>  <div> For further assistance: Contact the PACCAR Engine Support Call Center 1-800-477-0251 </div> </div> <p>Please Contact the Engine Support Center</p>
Description of component(s)	
Location of component(s)	
Diagnostic condition	
Set condition of fault code	
Reset condition of fault code	
Electrical diagram(s)	
Technical data	
Possible causes	
Additional information	
Diagnostic Step-by-Step	
Verification Drive Cycle	
	Back to Index

P1127

Code number	P1127
Fault code description	Intercooler temperature - Data valid but too high, moderately severe
Fault code information	1 trip MIL 3 drive cycle recovery Readiness group – None Freeze frame type – Boost
Description of component(s)	<p>The intercooler outlet temperature is measured before the EGR mixer.</p> <p>Effect on the system</p> <ul style="list-style-type: none"> Monitors intercooler performance
Location of component(s)	 <p>The diagram illustrates the engine layout with the intercooler outlet temperature sensor (F750) highlighted. The sensor is positioned on the intercooler outlet pipe, upstream of the EGR mixer. An inset image provides a detailed view of the sensor (F750) and its connection to the intercooler outlet pipe.</p> <p>1402248</p>
Diagnostic condition	This diagnostic runs 300 seconds after the engine is started.
Set condition of fault code	The PCI ECU (D420) detects that the intercooler outlet temperature is more than 95°C

	[203°F] for more than 60 seconds.									
Reset condition of fault code	This DTC changes to inactive when the fault is no longer detected.									
Electrical diagram(s)	<div><p>D420 PCI ECU F750 Intercooler temperature sensor</p><table><tr><th>D420</th><th>F750</th><th>Function</th></tr><tr><td>C17</td><td>1</td><td>Signal, intercooler temperature</td></tr><tr><td>C31</td><td>2</td><td>Ground</td></tr></table><div><p>Wiring harness connector D420.C front view</p><p>Wiring harness connector F750 front view</p></div><div><p>Handle connectors and pins with care and use matching measuring probes.</p></div></div>	D420	F750	Function	C17	1	Signal, intercooler temperature	C31	2	Ground
D420	F750	Function								
C17	1	Signal, intercooler temperature								
C31	2	Ground								
Technical data	<p>Component check, intercooler temperature sensor (F750)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key off the ignition• Disconnect connector F750									

- Measure on the component connector F750

Pin (+ probe)	Pin (- probe)	Value	Additional information
1	2	5248–5732 Ω	Resistance value at 0°C [32°F]
		2334–2505 Ω	Resistance value at 20°C [68°F]
		1133–1198 Ω	Resistance value at 40°C [104°F]
		593–619 Ω	Resistance value at 60°C [140°F]
		331–341 Ω	Resistance value at 80°C [176°F]
		195–199 Ω	Resistance value at 100°C [212°F]

Component & circuit check, ECU (D420)

Preparation

- Key off the ignition
- Disconnect connector F750
- Measure on the front side of wiring harness connector F750

Pin (+ probe)	Pin (- probe)	Value	Additional information
1	2	5V	Ignition keyed on

Possible causes

- Restricted air flow through the intercooler/radiator
- Faulty engine cooling fan
- Intercooler temperature sensor deviation

Additional information

The intercooler outlet temperature is measured before the EGR mixer by the intercooler temperature sensor (F750).

Diagnostic Step-by-Step



The ignition should always be in the OFF position when connecting or disconnecting electrical components to reduce the likelihood of damage to the components.



- This troubleshooting procedure is based on the assumption that supply power and ground to the PCI are functioning properly.
- Disconnecting the PCI connectors during the troubleshooting process will result in multiple errors.
- Specific electrical component information and pin out locations are provided in this procedure as a reference only. Always refer to the technical data sections in Rapido for the most up-to-date changes.
- It is necessary to use DAVIE to clear all current DTCs from the PCI and EAS-3

ECUs, and then run the Quick Check to identify a change in DTC status.

- This DTC can be set as a result of multiple failure modes. For proper fault isolation, complete all troubleshooting steps in the sequence provided.

Step 1 Investigate Related DTCs

Before troubleshooting this DTC, take notice of any other active or inactive DTCs. One or multiple other DTCs could have been the cause for this DTC.

Step 1A Investigate related DTCs

Action

1. Use DAVIE Diagnostics to perform a Quick Check for current DTCs.

Are these or any other related DTCs active?

Ambient air temp sensor	P0072; P0073; P009A
Coolant temperature sensor	P0115; P0117; P0118; P1115; P2181; P2183
Post-intercooler air temperature sensor	P0095; P0097; P0098; P0127
EGR (venturi) temperature sensor	P040B; P040C; P040D, or related EGR DTCs
Pre-compressor air temperature sensor	P2199; U1071
Boost air temperature sensor	P0110; P0112; P0113; P1128; P1573

Yes

No

Refer to the troubleshooting information for these DTCs before continuing with this procedure.

Go to step 2A


Step 2 Intercooler (F750) Checks


Step 2A Visual inspection, intercooler (F750)


Action


1. Visually inspect the intercooler (charge air cooler) and associated components for any of the following:
 - Loose or broken clamps on the air system
 - Dirt or debris build-up (blockage) at the front of the intercooler
 - Air system parts are removed or damaged

	<ul style="list-style-type: none"> • Hump hoses are folded over or have holes • Damage to or incorrect installation of the Coolant temperature sensor (F566) • Damage to or incorrect installation of the Post-intercooler temperature sensor (F750) • Damage to or incorrect installation of the Pre-compressor air (after BPV) temperature sensor (F853) • Damage to or incorrect installation of the EGR (venturi) temperature sensor (F749) • Damage to or incorrect installation of the Boost air temperature sensor (F804) • Damage to or incorrect installation of the Boost air pressure sensor (F802) 	
Was there evidence of any of the above?		
Yes		No
Correct any issues found. If a sensor is found to be damaged or broken, replace it. Refer to step 3A to perform the corresponding repair verification cycles and rechecks.		
If this DTC is still present, go to step 2B		step 2B


Step 2B Electrical checks, resistance, intercooler temperature sensor (F750)	
	Refer to the corresponding checking data for associated supply and signal voltages, resistance values, and related connector pin test points.
Action 1. Confirm the sensor resistance values as outlined in the corresponding checking data, " <u>Component check, intercooler temperature sensor (F750)</u> ".	
Are measured values within expected range?	
Yes	No
	Correct any issues found, or replace the intercooler temperature sensor (F750) if measured values indicate a sensor error. Refer to step 3A to perform the corresponding repair verification cycles and rechecks.

	Go to step 2C	If this DTC is still present, go to step 2C
	Step 2C Electrical checks, supply voltage, intercooler temperature sensor (F750)	
	<div> Refer to the corresponding checking data for associated supply and signal voltages, resistance values, and related connector pin test points.</div>	
	Action 1. Confirm the sensor supply voltage as outlined in the corresponding checking data, “ <u>Component check, intercooler temperature sensor (F750)</u> .”	
	Are measured values within expected range?	
	Yes	No
		Correct any issues found. Refer to step 3A to perform the corresponding repair verification cycles and rechecks.
	Go to step 2D	If this DTC is still present, go to step 2D
	Step 2D DAVIE monitor, intercooler temperature and related sensors	
	Action 1. Use DAVIE to select and monitor the following temperature and pressure values for comparison: <ul style="list-style-type: none">• Coolant temperature (turbo control)• Post-intercooler air temperature(turbo control)• Pre-compressor air temperature(turbo control)• EGR temperature (EGR control)• Boost air pressure (turbo control) For initial temperature readings, monitor with the ignition key to ON and the engine to OFF. Start the engine and allow it to idle for a minimum of 10 minutes to allow the temperature sensors to stabilize. While monitoring, no temperature should vary by a value of more than 50°F for a period of more than 5 seconds.	
	Do any monitored values vary by more than 50°F (24°C) for more than 5 seconds?	
	Yes	No


	Correct any issues found, or replace the related sensor if measured values indicate a sensor error. Refer to step 3A to perform the corresponding repair verification cycles and rechecks.	
	If this DTC is still present, go to step 2E	Go to step 2E
Step 2E Special test, intake/exhaust leak		
Action		
1. Perform this test using the Intake/Exhaust Leak Test Kit (#1903034) to determine whether there are any leaks in the intake air system.		
Was there evidence of a leak in the air system?		
Yes		No
Correct any issues found. Refer to step 3A to perform the corresponding repair verification cycles and rechecks.		
If all steps have been completed and this DTC is still present, contact the PACCAR Engine Support Center for further assistance.		If all steps have been completed and this DTC is still present, contact the PACCAR Engine Support Center for further assistance.
Step 3 Repair Verification		
Step 3A Repair verification cycles		
Perform these repair verification cycles following any corrective actions taken, to enable related OBD monitors to reach a readiness state associated with the DTC or system being investigated.		
 Before beginning these repair verification cycles, use the DAVIE Diagnostics, Quick Check function to clear all current DTCs from the PCI and EAS-3 ECUs.		
Action		
1. Steady State		
This cycle is best performed on a level grade road (least amount of incline possible) and under load using a trailer. If a loaded trailer is unavailable, produce engine load by turning the A/C and fan to ON.		
With the System Initiation cycle complete, proceed to a road with a minimum speed limit of 50 mph, then get to the highest gear possible with the engine speed between 1100-1500 rpm, and set the cruise control. Run		


	this cycle for roughly 3 to 5 miles or in three separate 1-mile increments if a steady 3 to 5 miles is unachievable.	
	Were the identified repair verification cycles able to be completed?	
	Yes	No
		Investigate and correct any issues preventing these repair verification cycles from being completed, then re-run. For additional assistance, contact the PACCAR Engine Support Center.
	Go to step 3B	Go to step 3B
	Step 3B DAVIE Diagnostics, Quick Check	
	Action	
	1. Use DAVIE Diagnostics to perform a Quick Check for current DTCs to determine whether the actions taken have cleared this DTC.	
	Has P1127 been cleared?	
	Yes	No
	Problem resolved. No further actions.	Continue with the next step in this troubleshooting procedure. If all steps have been completed and this DTC is still present, contact the PACCAR Engine Support Center for further assistance.
<div>  <div> <p>Contacting the PACCAR Engine Support Center</p> <p>For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center.</p> </div> </div>		
	Back to Index	



P1128



Code number	P1128
Fault code description	Air temp too high.
Fault code information	<div>  <p>For further assistance: Contact the PACCAR Engine Support Call Center 1-800-477-0251</p> </div> <p>Please Contact the Engine Support Center</p>
Description of component(s)	
Location of component(s)	
Diagnostic condition	
Set condition of fault code	
Reset condition of fault code	
Electrical diagram(s)	
Technical data	
Possible causes	
Additional information	
Diagnostic Step-by-Step	
Verification Drive Cycle	
	Back to Index

P1133

Code number	P1133
Fault code description	Lambda sensor heater – Voltage too high or short circuit to supply on ECU D420 pin C46
Fault code information	1 trip MIL 3 drive cycle recovery Readiness group – None Freeze frame type – Exhaust gas
Description of component(s)	<p>The lambda sensor measures the oxygen concentration in the exhaust gases after the BPV valve.</p>  <p>Air/fuel ratio The PCI ECU uses the measured oxygen concentration in the exhaust to determine the air/fuel ratio of the combustion process. Typical air/fuel ratios are 18 to 45. A high value indicates a high oxygen concentration measured by the lambda sensor.</p> <p>Sensor heater The sensor has an integrated heater to maintain a sensor operating temperature of approximately 750°C [1382°F]. The PCI ECU controls the heater.</p> <p>Sensor heating control</p> <ul style="list-style-type: none"> • The first stage starts when the ignition is keyed on. The sensor is heated to a value at which any condensate evaporates from the sensor. • The second stage starts after the 'dew point' is reached. The sensor is heated to its operating temperature of approximately 750°C


	<p>[1382°F]. The PCI ECU determines the 'dew point' by calculating how much energy (heat by burning fuel in the engine) is pumped through the exhaust. If the 'dew point' is not/no longer reached, the sensor temperature stays at/drops to the standby temperature, similar to the first stage heating.</p> <p>Effect on the system</p> <ul style="list-style-type: none"> • Determines the air/fuel ratio of the combustion process • Controls the smoke limit; where the measured exhaust gas oxygen concentration is compared with a target value for smoke limitation. A higher measured oxygen concentration results in lower calculated soot formation by the engine. • Controls NOx emissions; determines whether the target Exhaust Gas Recirculation is being achieved to control NOx emissions. A higher measured oxygen concentration results in higher calculated NOx formation by the engine. • Controls regeneration of the diesel particulate filter (DPF). The soot particles in the DPF are 'burned' using the oxygen present in the exhaust gas.
<p>Location of component(s)</p>	
<p>Diagnostic condition</p>	<p>Need to consider all active/inactive faults: one or multiple faults may have triggered this fault</p> <ul style="list-style-type: none"> • when the engine speed is between 950 and 2000 rpm, and; • when the engine is running at a steady load, and; • when coolant temperature is above 50°C [122°F], and; • the engine mode is SCR high efficiency or standard or protection;


	<ul style="list-style-type: none"> The lambda sensor (F834) is in the operating mode.
Set condition of fault code	This diagnostic starts five minutes after the engine starts. The diagnostic runs continuously.
Reset condition of fault code	This fault code will change to inactive immediately after the diagnostic runs and passes.
Electrical diagram(s)	 <p>The diagram shows the electrical connection between the lambda sensor (F834) and the D420 component. A box labeled '2' with '123E' below it is connected to the sensor. The sensor (F834) has a 6-pin connector with pins labeled 4, 1, 5, 2, 6, and 3. These pins are connected to terminals C45, C21, C22, C23, and C46 on the D420 component. Below the main diagram is a top view of the wiring harness connector D420.C, showing a rectangular connector with pins labeled 46, 23, 24, 1, 92, 69, 70, and 47. A small inset shows the physical layout of the connector. The label 'E504139' is present.</p> <p>Wiring harness connector D420.C front view</p>  <p>The diagram shows the front view of the F834 wiring harness connector, which is a rectangular connector with six pins labeled 1, 5, 2, 6, 1, and 6.</p> <p>Wiring harness connector F834 front view</p>


	D420 F834 Function C21 5 Trimming resistor C22 2 Ground, sensor element C23 6 Signal, nernst sensor C45 1 Signal, pump cell current C46 3 Ground, heater element 4 Power supply, heater element																
Technical data	<p>Component check, lambda sensor (F834)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key the ignition off• Disconnect connector F834• Measure on component connector F834 <table><tr><td>Pin (+ probe)</td><td>Pin (- probe)</td><td>Value</td><td>Additional information</td></tr><tr><td>4</td><td>3</td><td>2.4–4.0 Ω</td><td>Heater element resistance at 20°C [68°C]</td></tr></table> <p>Component & circuit check, ECU (D420)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key the ignition off• Disconnect connector F834• Measure on the front side of wiring harness connector F834 <table><tr><td>Pin (+ probe)</td><td>Pin (- probe)</td><td>Value</td><td>Additional information</td></tr><tr><td>4</td><td>Ground</td><td>Ubat</td><td>Heater element power supply with ignition keyed on</td></tr></table>	Pin (+ probe)	Pin (- probe)	Value	Additional information	4	3	2.4–4.0 Ω	Heater element resistance at 20°C [68°C]	Pin (+ probe)	Pin (- probe)	Value	Additional information	4	Ground	Ubat	Heater element power supply with ignition keyed on
Pin (+ probe)	Pin (- probe)	Value	Additional information														
4	3	2.4–4.0 Ω	Heater element resistance at 20°C [68°C]														
Pin (+ probe)	Pin (- probe)	Value	Additional information														
4	Ground	Ubat	Heater element power supply with ignition keyed on														
Possible causes	<ul style="list-style-type: none">• Faulty wiring• Faulty connector• Faulty sensor																
Additional information	No additional information available.																
Diagnostic Step-by-Step	<div><div></div><div><p>Perform the troubleshooting steps below using the breakout harness, if necessary, to check electrical components, such as sensors, electrical control units, and harnesses. Back probing is not recommended, as it could damage the harness. The ignition should always be in the OFF position when connecting or disconnecting electrical components in order to reduce the likelihood of damage to electrical components.</p></div></div> <div><div></div><ul style="list-style-type: none">• Disconnecting the EAS connectors during the troubleshooting process will result in multiple errors.• For specific electrical component information and pinout locations, always refer to the technical data.• It is necessary to exit the fault code menu in DAVIE and run the diagnostic test again to identify a change in errors.• Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive fault codes. Refer to the 'possible causes' section.</div> <table><tr><td>Step 1</td><td>Step ID 1133a</td><td>SRT</td></tr><tr><td colspan="3">Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.</td></tr></table>	Step 1	Step ID 1133a	SRT	Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.												
Step 1	Step ID 1133a	SRT															
Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.																	



	<table><tr><td>Step 2</td><td>Step ID 1133b</td><td>SRT</td></tr><tr><td colspan="3">With the key OFF, disconnect the lambda sensor. Turn the key ON and navigate through DAVIE to read errors:<ul style="list-style-type: none">• If fault is inactive – Proceed to step 3.• If fault is active – Proceed to step 4.</td></tr></table>	Step 2	Step ID 1133b	SRT	With the key OFF, disconnect the lambda sensor. Turn the key ON and navigate through DAVIE to read errors: <ul style="list-style-type: none">• If fault is inactive – Proceed to step 3.• If fault is active – Proceed to step 4.		
	Step 2	Step ID 1133b	SRT				
	With the key OFF, disconnect the lambda sensor. Turn the key ON and navigate through DAVIE to read errors: <ul style="list-style-type: none">• If fault is inactive – Proceed to step 3.• If fault is active – Proceed to step 4.						
	<table><tr><td>Step 3</td><td>Step ID 1133c</td><td>SRT</td></tr><tr><td colspan="3">With key OFF, disconnect the harness from the lambda sensor. Turn the key on and measure the voltage between a battery ground and the supply terminal of the lambda sensor circuit on the engine harness:<ul style="list-style-type: none">• If the voltage is acceptable – Replace the lambda sensor and reconnect the harness and verify the fault as per verification drive cycle.• If the voltage is not acceptable – Proceed to step 4</td></tr></table>	Step 3	Step ID 1133c	SRT	With key OFF, disconnect the harness from the lambda sensor. Turn the key on and measure the voltage between a battery ground and the supply terminal of the lambda sensor circuit on the engine harness: <ul style="list-style-type: none">• If the voltage is acceptable – Replace the lambda sensor and reconnect the harness and verify the fault as per verification drive cycle.• If the voltage is not acceptable – Proceed to step 4		
	Step 3	Step ID 1133c	SRT				
With key OFF, disconnect the harness from the lambda sensor. Turn the key on and measure the voltage between a battery ground and the supply terminal of the lambda sensor circuit on the engine harness: <ul style="list-style-type: none">• If the voltage is acceptable – Replace the lambda sensor and reconnect the harness and verify the fault as per verification drive cycle.• If the voltage is not acceptable – Proceed to step 4							
<table><tr><td>Step 4</td><td>Step ID 1133d</td><td>SRT</td></tr><tr><td colspan="3">With key OFF, disconnect the engine harness from the PCI. Turn the key ON and navigate through DAVIE to read errors:<ul style="list-style-type: none">• If fault is inactive – Replace the engine harness and verify the fault as per verification drive cycle.• If fault is active – Proceed to step 5.</td></tr></table>	Step 4	Step ID 1133d	SRT	With key OFF, disconnect the engine harness from the PCI. Turn the key ON and navigate through DAVIE to read errors: <ul style="list-style-type: none">• If fault is inactive – Replace the engine harness and verify the fault as per verification drive cycle.• If fault is active – Proceed to step 5.			
Step 4	Step ID 1133d	SRT					
With key OFF, disconnect the engine harness from the PCI. Turn the key ON and navigate through DAVIE to read errors: <ul style="list-style-type: none">• If fault is inactive – Replace the engine harness and verify the fault as per verification drive cycle.• If fault is active – Proceed to step 5.							
<table><tr><td>Step 5</td><td>Step ID 1133e</td><td>SRT</td></tr><tr><td colspan="3">For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center at 1-800-477-0251.</td></tr></table>	Step 5	Step ID 1133e	SRT	For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center at 1-800-477-0251.			
Step 5	Step ID 1133e	SRT					
For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center at 1-800-477-0251.							
Verification Drive Cycle	To validate repair, drive the vehicle at a minimum speed of 80 km/h [50 mph] in the highest gear possible with the engine speed between 1100 and 1500 rpm and set the cruise control. This test is best performed with a loaded vehicle/trailer, but if load is unavailable, turn as many engine power consumers on to produce engine load. Perform this test for roughly 5 to 8 km [3 to 5 miles] or in 3 separate 1.5 km [1 mile] increments if a steady 5 to 8 km [3 to 5 miles] is unachievable. Use a flat road, if possible.						
	Back to Index						

P1134

Code number	P1134
Fault code description	Lambda sensor heater – Voltage too low or short circuit to ground on ECU D420 pin C46
Fault code information	1 trip MIL 3 drive cycle recovery Readiness group – None Freeze frame type – Exhaust gas
Description of component(s)	<p>The lambda sensor measures the oxygen concentration in the exhaust gases after the BPV valve.</p>  <p>Air/fuel ratio The PCI ECU uses the measured oxygen concentration in the exhaust to determine the air/fuel ratio of the combustion process. Typical air/fuel ratios are 18 to 45. A high value indicates a high oxygen concentration measured by the lambda sensor.</p> <p>Sensor heater The sensor has an integrated heater to maintain a sensor operating temperature of approximately 750°C [1382°F]. The PCI ECU controls the heater.</p> <p>Sensor heating control</p> <ul style="list-style-type: none"> • The first stage starts when the ignition is keyed on. The sensor is heated to a value at which any condensate evaporates from the sensor. • The second stage starts after the 'dew point' is reached. The sensor is heated to its operating temperature of approximately 750°C

	<p>[1382°F]. The PCI ECU determines the 'dew point' by calculating how much energy (heat by burning fuel in the engine) is pumped through the exhaust. If the 'dew point' is not/no longer reached, the sensor temperature stays at/drops to the standby temperature, similar to the first stage heating.</p> <p>Effect on the system</p> <ul style="list-style-type: none"> • Determines the air/fuel ratio of the combustion process • Controls the smoke limit; where the measured exhaust gas oxygen concentration is compared with a target value for smoke limitation. A higher measured oxygen concentration results in lower calculated soot formation by the engine. • Controls NOx emissions; determines whether the target Exhaust Gas Recirculation is being achieved to control NOx emissions. A higher measured oxygen concentration results in higher calculated NOx formation by the engine. • Controls regeneration of the diesel particulate filter (DPF). The soot particles in the DPF are 'burned' using the oxygen present in the exhaust gas.
<p>Location of component(s)</p>	
<p>Diagnostic condition</p>	<p>Need to consider all active/inactive faults: one or multiple faults may have triggered this fault</p> <ul style="list-style-type: none"> • when the engine speed is between 950 and 2000 rpm, and; • when the engine is running at a steady load, and; • when coolant temperature is above 50°C [122°F], and; • the engine mode is SCR high efficiency or standard or protection; • the lambda sensor (F834) is in the operating mode.


Set condition of fault code	This diagnostic starts five minutes after the engine starts. The diagnostic runs continuously
Reset condition of fault code	This fault code will change to inactive immediately after the diagnostic runs and passes.
Electrical diagram(s)	 <p>Wiring harness connector D420.C front view</p> <p>Wiring harness connector F834 front view</p> <p>D420 F834 Function C21 5 Trimming resistor</p>


	<table><tr><td>C22</td><td>2</td><td>Ground, sensor element</td></tr><tr><td>C23</td><td>6</td><td>Signal, nernst sensor</td></tr><tr><td>C45</td><td>1</td><td>Signal, pump cell current</td></tr><tr><td>C46</td><td>3</td><td>Ground, heater element</td></tr><tr><td></td><td>4</td><td>Power supply, heater element</td></tr></table>	C22	2	Ground, sensor element	C23	6	Signal, nernst sensor	C45	1	Signal, pump cell current	C46	3	Ground, heater element		4	Power supply, heater element	
C22	2	Ground, sensor element															
C23	6	Signal, nernst sensor															
C45	1	Signal, pump cell current															
C46	3	Ground, heater element															
	4	Power supply, heater element															
Technical data	<p>Component check, lambda sensor (F834)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key the ignition off• Disconnect connector F834• Measure on component connector F834 <table><tr><td>Pin (+ probe)</td><td>Pin (- probe)</td><td>Value</td><td>Additional information</td></tr><tr><td>4</td><td>3</td><td>2.4–4.0 Ω</td><td>Heater element resistance at 20°C [68°C]</td></tr></table> <p>Component & circuit check, ECU (D420)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key the ignition off• Disconnect connector F834• Measure on the front side of wiring harness connector F834 <table><tr><td>Pin (+ probe)</td><td>Pin (- probe)</td><td>Value</td><td>Additional information</td></tr><tr><td>4</td><td>Ground</td><td>Ubat</td><td>Heater element power supply with ignition keyed on</td></tr></table>	Pin (+ probe)	Pin (- probe)	Value	Additional information	4	3	2.4–4.0 Ω	Heater element resistance at 20°C [68°C]	Pin (+ probe)	Pin (- probe)	Value	Additional information	4	Ground	Ubat	Heater element power supply with ignition keyed on
Pin (+ probe)	Pin (- probe)	Value	Additional information														
4	3	2.4–4.0 Ω	Heater element resistance at 20°C [68°C]														
Pin (+ probe)	Pin (- probe)	Value	Additional information														
4	Ground	Ubat	Heater element power supply with ignition keyed on														
Possible causes	<ul style="list-style-type: none">• Faulty wiring• Faulty connector• Faulty sensor																
Additional information	No additional information available.																
Diagnostic Step-by-Step	<div><div></div><div><p>Perform the troubleshooting steps below using the breakout harness, if necessary, to check electrical components, such as sensors, electrical control units, and harnesses. Back probing is not recommended, as it could damage the harness. The ignition should always be in the OFF position when connecting or disconnecting electrical components in order to reduce the likelihood of damage to electrical components.</p></div></div> <div><div></div><ul style="list-style-type: none">• Disconnecting the EAS connectors during the troubleshooting process will result in multiple errors.• For specific electrical component information and pinout locations, always refer to the technical data.• It is necessary to exit the fault code menu in DAVIE and run the diagnostic test again to identify a change in errors.• Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive fault codes. Refer to the 'possible causes' section.</div> <table><tr><td>Step 1</td><td>Step ID 1134a</td><td>SRT</td></tr><tr><td colspan="3">Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.</td></tr></table>	Step 1	Step ID 1134a	SRT	Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.												
Step 1	Step ID 1134a	SRT															
Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.																	



	<table><tr><td>Step 2</td><td>Step ID 1134b</td><td>SRT</td></tr><tr><td colspan="3">With the key OFF, disconnect the lambda sensor. Turn the key ON and navigate through DAVIE to read errors:<ul style="list-style-type: none">• If fault is inactive – Proceed to step 3.• If fault is active – Proceed to step 4.</td></tr></table>	Step 2	Step ID 1134b	SRT	With the key OFF, disconnect the lambda sensor. Turn the key ON and navigate through DAVIE to read errors: <ul style="list-style-type: none">• If fault is inactive – Proceed to step 3.• If fault is active – Proceed to step 4.		
	Step 2	Step ID 1134b	SRT				
	With the key OFF, disconnect the lambda sensor. Turn the key ON and navigate through DAVIE to read errors: <ul style="list-style-type: none">• If fault is inactive – Proceed to step 3.• If fault is active – Proceed to step 4.						
	<table><tr><td>Step 3</td><td>Step ID 1134c</td><td>SRT</td></tr><tr><td colspan="3">With key OFF, disconnect the harness from the lambda sensor. Turn the key on and measure the voltage between a battery ground and the supply terminal of the lambda sensor circuit on the engine harness:<ul style="list-style-type: none">• If the voltage is acceptable – Replace the lambda sensor and reconnect the harness and verify the fault as per verification drive cycle.• If the voltage is not acceptable – Proceed to step 4</td></tr></table>	Step 3	Step ID 1134c	SRT	With key OFF, disconnect the harness from the lambda sensor. Turn the key on and measure the voltage between a battery ground and the supply terminal of the lambda sensor circuit on the engine harness: <ul style="list-style-type: none">• If the voltage is acceptable – Replace the lambda sensor and reconnect the harness and verify the fault as per verification drive cycle.• If the voltage is not acceptable – Proceed to step 4		
	Step 3	Step ID 1134c	SRT				
With key OFF, disconnect the harness from the lambda sensor. Turn the key on and measure the voltage between a battery ground and the supply terminal of the lambda sensor circuit on the engine harness: <ul style="list-style-type: none">• If the voltage is acceptable – Replace the lambda sensor and reconnect the harness and verify the fault as per verification drive cycle.• If the voltage is not acceptable – Proceed to step 4							
<table><tr><td>Step 4</td><td>Step ID 1134d</td><td>SRT</td></tr><tr><td colspan="3">With key OFF, disconnect the engine harness from the PCI. Turn the key ON and navigate through DAVIE to read errors:<ul style="list-style-type: none">• If fault is inactive – Replace the engine harness and verify the fault as per verification drive cycle.• If fault is active – Proceed to step 5.</td></tr></table>	Step 4	Step ID 1134d	SRT	With key OFF, disconnect the engine harness from the PCI. Turn the key ON and navigate through DAVIE to read errors: <ul style="list-style-type: none">• If fault is inactive – Replace the engine harness and verify the fault as per verification drive cycle.• If fault is active – Proceed to step 5.			
Step 4	Step ID 1134d	SRT					
With key OFF, disconnect the engine harness from the PCI. Turn the key ON and navigate through DAVIE to read errors: <ul style="list-style-type: none">• If fault is inactive – Replace the engine harness and verify the fault as per verification drive cycle.• If fault is active – Proceed to step 5.							
<table><tr><td>Step 5</td><td>Step ID 1134e</td><td>SRT</td></tr><tr><td colspan="3">For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the Engine Support Call Center at 1-800-477-0251.</td></tr></table>	Step 5	Step ID 1134e	SRT	For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the Engine Support Call Center at 1-800-477-0251.			
Step 5	Step ID 1134e	SRT					
For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the Engine Support Call Center at 1-800-477-0251.							
Verification Drive Cycle	To validate the repair: Drive the vehicle at a minimum speed of 80 km/h [50 mph] in the highest gear possible with the engine speed between 1100 and 1500 rpm and set the cruise control. This test is best performed with a loaded vehicle/trailer, but if load is unavailable, turn as many engine power consumers on to produce engine load. Perform this test for roughly 5 to 8 km [3 to 5 miles] or in 3 separate 1.5 km [1 mile] increments if a steady 5 to 8 km [3 to 5 miles] is unachievable. Use a flat road, if possible.						



[Back to Index](#)

P1135

Code number	P1135
Fault code description	Lambda sensor heater – Voltage too low or short circuit to supply on ECU D420 pin C46
Fault code information	1 trip MIL 3 drive cycle recovery Readiness group – None Freeze frame type – Exhaust gas
Description of component(s)	<p>The lambda sensor measures the oxygen concentration in the exhaust gases after the BPV valve.</p>  <p>Air/fuel ratio The PCI ECU uses the measured oxygen concentration in the exhaust to determine the air/fuel ratio of the combustion process. Typical air/fuel ratios are 18 to 45. A high value indicates a high oxygen concentration measured by the lambda sensor.</p> <p>Sensor heater The sensor has an integrated heater to maintain a sensor operating temperature of approximately 750°C [1382°F]. The PCI ECU controls the heater.</p> <p>Sensor heating control</p> <ul style="list-style-type: none"> • The first stage starts when the ignition is keyed on. The sensor is heated to a value at which any condensate evaporates from the sensor. • The second stage starts after the 'dew point' is reached. The sensor is heated to its operating temperature of approximately 750°C


	<p>[1382°F]. The PCI ECU determines the 'dew point' by calculating how much energy (heat by burning fuel in the engine) is pumped through the exhaust. If the 'dew point' is not/no longer reached, the sensor temperature stays at/drops to the standby temperature, similar to the first stage heating.</p> <p>Effect on the system</p> <ul style="list-style-type: none"> • Determines the air/fuel ratio of the combustion process • Controls the smoke limit; where the measured exhaust gas oxygen concentration is compared with a target value for smoke limitation. A higher measured oxygen concentration results in lower calculated soot formation by the engine. • Controls NOx emissions; determines whether the target Exhaust Gas Recirculation is being achieved to control NOx emissions. A higher measured oxygen concentration results in higher calculated NOx formation by the engine. • Controls regeneration of the diesel particulate filter (DPF). The soot particles in the DPF are 'burned' using the oxygen present in the exhaust gas.
<p>Location of component(s)</p>	
<p>Diagnostic condition</p>	<p>Need to consider all active/inactive faults: one or multiple faults may have triggered this fault</p> <ul style="list-style-type: none"> • when the engine speed is between 950 and 2000 rpm, and; • when the engine is running at a steady load, and; • when coolant temperature is above 50°C [122°F], and; • the engine mode is SCR high efficiency or standard or protection; • the lambda sensor (F834) is in the operating mode.


Set condition of fault code	This diagnostic starts five minutes after the engine starts. The diagnostic runs continuously
Reset condition of fault code	This fault code will change to inactive immediately after the diagnostic runs and passes.
Electrical diagram(s)	 <p>Wiring harness connector D420.C front view</p>  <p>Wiring harness connector F834 front view</p> <p>D420 F834 Function C21 5 Trimming resistor</p>

	<div>C222Ground, sensor element</div> <div>C236Signal, nernst sensor</div> <div>C451Signal, pump cell current</div> <div>C463Ground, heater element</div> <div>4Power supply, heater element</div>																
Technical data	<div>Component check, lambda sensor (F834)</div> <div>Preparation<ul style="list-style-type: none">Key the ignition offDisconnect connector F834Measure on component connector F834<table><tr><td>Pin (+ probe)</td><td>Pin (- probe)</td><td>Value</td><td>Additional information</td></tr><tr><td>4</td><td>3</td><td>2.4–4.0 Ω</td><td>Heater element resistance at 20°C [68°C]</td></tr></table></div> <div>Component & circuit check, ECU (D420)</div> <div>Preparation<ul style="list-style-type: none">Key the ignition offDisconnect connector F834Measure on the front side of wiring harness connector F834<table><tr><td>Pin (+ probe)</td><td>Pin (- probe)</td><td>Value</td><td>Additional information</td></tr><tr><td>4</td><td>Ground</td><td>Ubat</td><td>Heater element power supply with ignition keyed on</td></tr></table></div>	Pin (+ probe)	Pin (- probe)	Value	Additional information	4	3	2.4–4.0 Ω	Heater element resistance at 20°C [68°C]	Pin (+ probe)	Pin (- probe)	Value	Additional information	4	Ground	Ubat	Heater element power supply with ignition keyed on
Pin (+ probe)	Pin (- probe)	Value	Additional information														
4	3	2.4–4.0 Ω	Heater element resistance at 20°C [68°C]														
Pin (+ probe)	Pin (- probe)	Value	Additional information														
4	Ground	Ubat	Heater element power supply with ignition keyed on														
Possible causes	<ul style="list-style-type: none">Faulty wiringFaulty connectorFaulty sensor																
Additional information	No additional information available.																
Diagnostic Step-by-Step	<div><div></div><div>Perform the troubleshooting steps below using the breakout harness, if necessary, to check electrical components, such as sensors, electrical control units, and harnesses. Back probing is not recommended, as it could damage the harness. The ignition should always be in the OFF position when connecting or disconnecting electrical components to reduce the likelihood of damage to electrical components</div></div> <div><div></div><ul style="list-style-type: none">This troubleshooting tree is based on the assumption that supply power and ground to the PCI are functioning properly.Disconnecting the PCI connectors during the troubleshooting process will result in multiple errors.For specific electrical component information and pinout locations, always refer to the technical data in Rapido.It is necessary to exit the 'active errors' screen in DAVIE and run the diagnostic test again to identify changes in errors.Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive codes. Refer to the 'possible causes' section in Rapido.</div> <table><tr><td>Step 1</td><td>Step ID 1135a</td><td>SRT</td></tr></table> <div>Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.</div>	Step 1	Step ID 1135a	SRT													
Step 1	Step ID 1135a	SRT															



	<table><tr><td>Step 2</td><td>Step ID 1135b</td><td>SRT</td></tr><tr><td colspan="3">With the key OFF, disconnect the lambda sensor. Turn the key ON and navigate through DAVIE to read errors:<ul style="list-style-type: none">• If fault is inactive – Proceed to step 3.• If fault is active – Proceed to step 4.</td></tr></table>	Step 2	Step ID 1135b	SRT	With the key OFF, disconnect the lambda sensor. Turn the key ON and navigate through DAVIE to read errors: <ul style="list-style-type: none">• If fault is inactive – Proceed to step 3.• If fault is active – Proceed to step 4.		
	Step 2	Step ID 1135b	SRT				
	With the key OFF, disconnect the lambda sensor. Turn the key ON and navigate through DAVIE to read errors: <ul style="list-style-type: none">• If fault is inactive – Proceed to step 3.• If fault is active – Proceed to step 4.						
	<table><tr><td>Step 3</td><td>Step ID 1135c</td><td>SRT</td></tr><tr><td colspan="3">With key OFF, disconnect the harness from the lambda sensor. Turn the key on and measure the voltage between a battery ground and the supply terminal of the lambda sensor circuit on the engine harness:<ul style="list-style-type: none">• If the voltage is acceptable – Replace the lambda sensor and reconnect the harness and verify the fault as per verification drive cycle.• If the voltage is not acceptable – Proceed to step 4</td></tr></table>	Step 3	Step ID 1135c	SRT	With key OFF, disconnect the harness from the lambda sensor. Turn the key on and measure the voltage between a battery ground and the supply terminal of the lambda sensor circuit on the engine harness: <ul style="list-style-type: none">• If the voltage is acceptable – Replace the lambda sensor and reconnect the harness and verify the fault as per verification drive cycle.• If the voltage is not acceptable – Proceed to step 4		
	Step 3	Step ID 1135c	SRT				
With key OFF, disconnect the harness from the lambda sensor. Turn the key on and measure the voltage between a battery ground and the supply terminal of the lambda sensor circuit on the engine harness: <ul style="list-style-type: none">• If the voltage is acceptable – Replace the lambda sensor and reconnect the harness and verify the fault as per verification drive cycle.• If the voltage is not acceptable – Proceed to step 4							
<table><tr><td>Step 4</td><td>Step ID 1135d</td><td>SRT</td></tr><tr><td colspan="3">With key OFF, disconnect the engine harness from the PCI. Turn the key ON and navigate through DAVIE to read errors:<ul style="list-style-type: none">• If fault is inactive – Replace the engine harness and verify the fault as per verification drive cycle.• If fault is active – Proceed to step 5.</td></tr></table>	Step 4	Step ID 1135d	SRT	With key OFF, disconnect the engine harness from the PCI. Turn the key ON and navigate through DAVIE to read errors: <ul style="list-style-type: none">• If fault is inactive – Replace the engine harness and verify the fault as per verification drive cycle.• If fault is active – Proceed to step 5.			
Step 4	Step ID 1135d	SRT					
With key OFF, disconnect the engine harness from the PCI. Turn the key ON and navigate through DAVIE to read errors: <ul style="list-style-type: none">• If fault is inactive – Replace the engine harness and verify the fault as per verification drive cycle.• If fault is active – Proceed to step 5.							
<table><tr><td>Step 5</td><td>Step ID 1135e</td><td>SRT</td></tr><tr><td colspan="3">Contact the PACCAR Engine Support Call Center For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center at 1-800-477-0251.</td></tr></table>	Step 5	Step ID 1135e	SRT	Contact the PACCAR Engine Support Call Center For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center at 1-800-477-0251.			
Step 5	Step ID 1135e	SRT					
Contact the PACCAR Engine Support Call Center For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center at 1-800-477-0251.							
Verification Drive Cycle	To validate the repair: Drive the vehicle at a minimum speed of 80 km/h [50 mph] in the highest gear possible with the engine speed between 1100 and 1500 rpm and set the cruise control. This test is best performed with a loaded vehicle/trailer, but if load is unavailable, turn as many engine power consumers on to produce engine load. Perform this test for roughly 5 to 8 km [3 to 5 miles] or in 3 separate 1.5 km [1 mile] increments if a steady 5 to 8 km [3 to 5 miles] is unachievable. Use a flat road, if possible.						
	Back to Index						

P1136


Code number	P1136
Fault code description	Lambda sensor heater – Voltage too low or short circuit to ground on ECU D420 pin C46
Fault code information	1 trip MIL 3 drive cycle recovery Readiness group – None Freeze frame type – Exhaust gas
Description of component(s)	<p>The lambda sensor measures the oxygen concentration in the exhaust gases after the BPV valve.</p>  <p>Air/fuel ratio The PCI ECU uses the measured oxygen concentration in the exhaust to determine the air/fuel ratio of the combustion process. Typical air/fuel ratios are 18 to 45. A high value indicates a high oxygen concentration measured by the lambda sensor.</p> <p>Sensor heater The sensor has an integrated heater to maintain a sensor operating temperature of approximately 750°C [1382°F]. The PCI ECU controls the heater.</p> <p>Sensor heating control</p> <ul style="list-style-type: none"> • The first stage starts when the ignition is keyed on. The sensor is heated to a value at which any condensate evaporates from the sensor. • The second stage starts after the 'dew point' is reached. The sensor is heated to its operating temperature of approximately 750°C

	<p>[1382°F]. The PCI ECU determines the 'dew point' by calculating how much energy (heat by burning fuel in the engine) is pumped through the exhaust. If the 'dew point' is not/no longer reached, the sensor temperature stays at/drops to the standby temperature, similar to the first stage heating.</p> <p>Effect on the system</p> <ul style="list-style-type: none"> • Determines the air/fuel ratio of the combustion process • Controls the smoke limit; where the measured exhaust gas oxygen concentration is compared with a target value for smoke limitation. A higher measured oxygen concentration results in lower calculated soot formation by the engine. • Controls NOx emissions; determines whether the target Exhaust Gas Recirculation is being achieved to control NOx emissions. A higher measured oxygen concentration results in higher calculated NOx formation by the engine. • Controls regeneration of the diesel particulate filter (DPF). The soot particles in the DPF are 'burned' using the oxygen present in the exhaust gas.
Location of component(s)	
Diagnostic condition	The diagnostic runs after the engine run 5 min and Lambda value is more the 1.3
Set condition of fault code	This diagnostic starts five minutes after the engine starts. The diagnostic runs continuously.
Reset condition of fault code	This fault code will change to inactive immediately after the diagnostic runs and passes.

Electrical diagram(s)





Wiring harness connector D420.C front view




Wiring harness connector F834 front view


D420	F834	Function
C21	5	Trimming resistor
C22	2	Ground, sensor element
C23	6	Signal, nernst sensor
C45	1	Signal, pump cell current
C46	3	Ground, heater element

	4 Power supply, heater element																
Technical data	<div>Component check, lambda sensor (F834)</div> <div>Preparation<ul style="list-style-type: none">Key the ignition offDisconnect connector F834Measure on component connector F834<table><tr><td>Pin (+ probe)</td><td>Pin (- probe)</td><td>Value</td><td>Additional information</td></tr><tr><td>4</td><td>3</td><td>2.4–4.0 Ω</td><td>Heater element resistance at 20°C [68°C]</td></tr></table></div> <div>Component & circuit check, ECU (D420)</div> <div>Preparation<ul style="list-style-type: none">Key the ignition offDisconnect connector F834Measure on the front side of wiring harness connector F834<table><tr><td>Pin (+ probe)</td><td>Pin (- probe)</td><td>Value</td><td>Additional information</td></tr><tr><td>4</td><td>Ground</td><td>Ubat</td><td>Heater element power supply with ignition keyed on</td></tr></table></div>	Pin (+ probe)	Pin (- probe)	Value	Additional information	4	3	2.4–4.0 Ω	Heater element resistance at 20°C [68°C]	Pin (+ probe)	Pin (- probe)	Value	Additional information	4	Ground	Ubat	Heater element power supply with ignition keyed on
Pin (+ probe)	Pin (- probe)	Value	Additional information														
4	3	2.4–4.0 Ω	Heater element resistance at 20°C [68°C]														
Pin (+ probe)	Pin (- probe)	Value	Additional information														
4	Ground	Ubat	Heater element power supply with ignition keyed on														
Possible causes	<ul style="list-style-type: none">Faulty wiringFaulty connectorFaulty sensor																
Additional information	No Additional information available																
Diagnostic Step-by-Step	<div><div><p>Perform the troubleshooting steps below using the breakout harness, if necessary, to check electrical components, such as sensors, electrical control units, and harnesses. Back probing is not recommended, as it could damage the harness. The ignition should always be in the OFF position when connecting or disconnecting electrical components in order to reduce the likelihood of damage to electrical components.</p></div><div><ul style="list-style-type: none">Disconnecting the EAS connectors during the troubleshooting process will result in multiple errors.For specific electrical component information and pinout locations, always refer to the technical data.It is necessary to exit the fault code menu in DAVIE and run the diagnostic test again to identify a change in errors.Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive fault codes. Refer to the 'possible causes' section.</div></div> <table><tr><td>Step 1</td><td>Step ID 1136a</td><td>SRT</td></tr><tr><td colspan="3">Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.</td></tr></table> <table><tr><td>Step 2</td><td>Step ID 1136b</td><td>SRT</td></tr><tr><td colspan="3">With the key OFF, disconnect the lambda sensor. Turn the key ON and navigate through DAVIE to read errors:<ul style="list-style-type: none">If fault is inactive – Proceed to step 3.</td></tr></table>	Step 1	Step ID 1136a	SRT	Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.			Step 2	Step ID 1136b	SRT	With the key OFF, disconnect the lambda sensor. Turn the key ON and navigate through DAVIE to read errors: <ul style="list-style-type: none">If fault is inactive – Proceed to step 3.						
Step 1	Step ID 1136a	SRT															
Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.																	
Step 2	Step ID 1136b	SRT															
With the key OFF, disconnect the lambda sensor. Turn the key ON and navigate through DAVIE to read errors: <ul style="list-style-type: none">If fault is inactive – Proceed to step 3.																	

	<ul style="list-style-type: none"> If fault is active – Proceed to step 4. 		
	Step 3	Step ID 1136c	SRT
	<p>With key OFF, disconnect the harness from the lambda sensor. Turn the key on and measure the voltage between a battery ground and the supply terminal of the lambda sensor circuit on the engine harness:</p> <ul style="list-style-type: none"> If the voltage is acceptable – Replace the lambda sensor and reconnect the harness and verify the fault as per verification drive cycle. If the voltage is not acceptable – Proceed to step 4 		
	Step 4	Step ID 1136d	SRT
	<p>With key OFF, disconnect the engine harness from the PCI. Turn the key ON and navigate through DAVIE to read errors:</p> <ul style="list-style-type: none"> If fault is inactive – Replace the engine harness and verify the fault as per verification drive cycle. If fault is active – Proceed to step 5. 		
	Step 5	Step ID 1136e	SRT
	<p>Contact the PACCAR Engine Support Call Center For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center at 1-800-477-0251.</p>		
Verification Drive Cycle	<p>To validate repair: This cycle is best performed on a level grade road (least amount of incline possible) and under load using a trailer. If a loaded trailer is unavailable, produce engine load by turning the A/C and fan to ON. With the System Initiation cycle complete, proceed to a road with a minimum speed limit of 50 mph, then get to the highest gear possible with the engine speed between 1100-1500 rpm, and set the cruise control. Run this cycle for roughly 3 to 5 miles or in three separate 1-mile increments if a steady 3 to 5 miles is unachievable.</p>		
	Back to Index		



P1137

Code number	P1137
Fault code description	Lambda sensor heater power supply - Incorrect
Fault code information	<p>1 trip MIL</p> <p>3 drive cycle recovery</p> <p>Readiness group – None</p> <p>Freeze frame type – Exhaust gas</p>
Description of component(s)	<p>The lambda sensor measures the oxygen concentration in the exhaust gases after the BPV valve.</p>  <p>Air/fuel ratio The PCI ECU uses the measured oxygen concentration in the exhaust to determine the air/fuel ratio of the combustion process. Typical air/fuel ratios are 18 to 45. A high value indicates a high oxygen concentration measured by the lambda sensor.</p> <p>Sensor heater The sensor has an integrated heater to maintain a sensor operating temperature of approximately 750°C [1382°F]. The PCI ECU controls the heater.</p> <p>Sensor heating control</p> <ul style="list-style-type: none"> • The first stage starts when the ignition is keyed on. The sensor is heated to a value at which any condensate evaporates from the sensor. • The second stage starts after the 'dew point' is reached. The sensor is heated to its operating temperature of approximately 750°C [1382°F]. The PCI ECU determines the 'dew point' by calculating how much


	<p>energy (heat by burning fuel in the engine) is pumped through the exhaust. If the 'dew point' is not/no longer reached, the sensor temperature stays at/drops to the standby temperature, similar to the first stage heating.</p> <p>Effect on the system</p> <ul style="list-style-type: none"> • Determines the air/fuel ratio of the combustion process • Controls the smoke limit; where the measured exhaust gas oxygen concentration is compared with a target value for smoke limitation. A higher measured oxygen concentration results in lower calculated soot formation by the engine. • Controls NOx emissions; determines whether the target Exhaust Gas Recirculation is being achieved to control NOx emissions. A higher measured oxygen concentration results in higher calculated NOx formation by the engine. • Controls regeneration of the diesel particulate filter (DPF). The soot particles in the DPF are 'burned' using the oxygen present in the exhaust gas.
Location of component(s)	
Diagnostic condition	This diagnostic runs continuously when the engine is running.
Set condition of fault code	The PCI ECU (D420) detects that the power supply to control the lambda sensor heater is less than 9V for more than 5 seconds.
Reset condition of fault code	<p>This DTC changes to inactive when the fault is no longer detected. To validate the repair:</p> <ul style="list-style-type: none"> • Key the ignition off for at least 15 seconds, then key it on again. Then start the engine and let it idle for 2 minutes, and;

- Drive the vehicle until the coolant temperature is at least 70°C [158°F]. Once the minimum target temperature has been reached, proceed at a minimum speed of 80 km/h [50 mph] in the highest gear possible with the engine speed between 1100 and 1500 rpm and set the cruise control. This test is best performed with a loaded vehicle/trailer, but if load is unavailable, turn as many engine power consumers on to produce engine load. Perform this test for roughly 5 to 8 km [3 to 5 miles] or in 3 separate 1.5 km [1 mile] increments if a steady 5 to 8 km [3 to 5 miles] is unachievable. Use a flat road, if possible.

Electrical diagram(s)



Wiring harness connector D420.C front view

	<div></div> <p>Wiring harness connector F834 front view</p> <table><tr><td>D420</td><td>F834</td><td>Function</td></tr><tr><td>C21</td><td>5</td><td>Trimming resistor</td></tr><tr><td>C22</td><td>2</td><td>Ground, sensor element</td></tr><tr><td>C23</td><td>6</td><td>Signal, nernst sensor</td></tr><tr><td>C45</td><td>1</td><td>Signal, pump cell current</td></tr><tr><td>C46</td><td>3</td><td>Ground, heater element</td></tr><tr><td></td><td>4</td><td>Power supply, heater element</td></tr></table>	D420	F834	Function	C21	5	Trimming resistor	C22	2	Ground, sensor element	C23	6	Signal, nernst sensor	C45	1	Signal, pump cell current	C46	3	Ground, heater element		4	Power supply, heater element
D420	F834	Function																				
C21	5	Trimming resistor																				
C22	2	Ground, sensor element																				
C23	6	Signal, nernst sensor																				
C45	1	Signal, pump cell current																				
C46	3	Ground, heater element																				
	4	Power supply, heater element																				
Technical data	<p>Component check, lambda sensor (F834)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key the ignition off• Disconnect connector F834• Measure on component connector F834 <table><tr><th>Pin (+ probe)</th><th>Pin (- probe)</th><th>Value</th><th>Additional information</th></tr><tr><td>4</td><td>3</td><td>2.4–4.0 Ω</td><td>Heater element resistance at 20°C [68°C]</td></tr></table> <p>Component & circuit check, ECU (D420)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key the ignition off• Disconnect connector F834• Measure on the front side of wiring harness connector F834 <table><tr><th>Pin (+ probe)</th><th>Pin (- probe)</th><th>Value</th><th>Additional information</th></tr><tr><td>4</td><td>Ground</td><td>Ubat</td><td>Heater element power supply with ignition keyed on</td></tr></table>	Pin (+ probe)	Pin (- probe)	Value	Additional information	4	3	2.4–4.0 Ω	Heater element resistance at 20°C [68°C]	Pin (+ probe)	Pin (- probe)	Value	Additional information	4	Ground	Ubat	Heater element power supply with ignition keyed on					
Pin (+ probe)	Pin (- probe)	Value	Additional information																			
4	3	2.4–4.0 Ω	Heater element resistance at 20°C [68°C]																			
Pin (+ probe)	Pin (- probe)	Value	Additional information																			
4	Ground	Ubat	Heater element power supply with ignition keyed on																			
Possible causes	<ul style="list-style-type: none">• Power supply to the PCI ECU.• Check the PCI power supply.																					
Additional information	<p>The PCI ECU uses the oxygen concentration in the exhaust, measured by the lambda sensor (F834), to determine the air/fuel ratio of the combustion process. The sensor has an integrated heater to maintain a sensor operating temperature of approximately 750°C [1382°F].</p>																					

Diagnostic Step-by-Step



Perform the troubleshooting steps below using the breakout harness, if necessary, to check electrical components, such as sensors, electrical control units, and harnesses. Back probing is not recommended, as it could damage the harness. The ignition should always be in the OFF position when connecting or disconnecting electrical components in order to reduce the likelihood of damage to electrical components.



- Disconnecting the EAS connectors during the troubleshooting process will result in multiple errors.
- For specific electrical component information and pinout locations, always refer to the technical data.
- It is necessary to exit the fault code menu in DAVIE and run the diagnostic test again to identify a change in errors.
- Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive fault codes. Refer to the 'possible causes' section.

Step 1	Step ID 1137a	SRT
--------	---------------	-----

Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.

Step 2	Step ID 1137b	SRT
--------	---------------	-----

Electrical Checks

Ensure that the ignition key/switch has been set to OFF before disconnecting related cables.

Based on the fault message provided, confirm that the following electrical values are within specified ranges or limits:

- Supply and signal voltages (12V).
- Cable continuity (no opens or shorts).

Are measured electrical values outside of expected range or limits?

- Yes - Proceed to step 3
- No - Proceed to step 4

Step 3	Step ID 1137c	SRT
--------	---------------	-----

Repair or replace appropriate component and use DAVIE to re-check for the presence of active faults.

- Fault inactive – issue resolved
- Fault active - Proceed to step 4

Step 4	Step ID 1137d	SRT
--------	---------------	-----

Replace Lambda sensor and use DAVIE to re-check for the presence of active faults.


- Fault inactive – issue resolved
- Fault active - Proceed to step 5


Step 5	Step ID 1137e	SRT
--------	---------------	-----


For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the Engine Support Call Center at 1-800-477-0251.



Verification Drive Cycle	<p>To validate the repair:</p> <ul style="list-style-type: none"> • Key the ignition off for at least 15 seconds, then key it on again. Then start the engine and let it idle for 2 minutes, and; • Drive the vehicle until the coolant temperature is at least 70°C [158°F]. Once the minimum target temperature has been reached, proceed at a minimum speed of 80 km/h [50 mph] in the highest gear possible with the engine speed between 1100 and 1500 rpm and set the cruise control. This test is best performed with a loaded vehicle/trailer, but if load is unavailable, turn as many engine power consumers on to produce engine load. Perform this test for roughly 5 to 8 km [3 to 5 miles] or in 3 separate 1.5 km [1 mile] increments if a steady 5 to 8 km [3 to 5 miles] is unachievable. Use a flat road, if possible.
	<p style="text-align: right;">Back to Index</p>

P1138

Code number	P1138
Fault code description	Lambda Sensor heater – Voltage too low or short circuit to ground on ECU D420 pin C46
Fault code information	1 trip MIL 3 drive cycle recovery Readiness group – None Freeze frame type – Exhaust gas
Description of component(s)	<p>The lambda sensor measures the oxygen concentration in the exhaust gases after the BPV valve.</p>  <p>Air/fuel ratio The PCI ECU uses the measured oxygen concentration in the exhaust to determine the air/fuel ratio of the combustion process. Typical air/fuel ratios are 18 to 45. A high value indicates a high oxygen concentration measured by the lambda sensor.</p> <p>Sensor heater The sensor has an integrated heater to maintain a sensor operating temperature of approximately 750°C [1382°F]. The PCI ECU controls the heater.</p> <p>Sensor heating control</p> <ul style="list-style-type: none"> • The first stage starts when the ignition is keyed on. The sensor is heated to a value at which any condensate evaporates from the sensor. • The second stage starts after the 'dew point' is reached. The sensor is heated to its operating temperature of approximately 750°C


	<p>[1382°F]. The PCI ECU determines the 'dew point' by calculating how much energy (heat by burning fuel in the engine) is pumped through the exhaust. If the 'dew point' is not/no longer reached, the sensor temperature stays at/drops to the standby temperature, similar to the first stage heating.</p> <p>Effect on the system</p> <ul style="list-style-type: none"> • Determines the air/fuel ratio of the combustion process • Controls the smoke limit; where the measured exhaust gas oxygen concentration is compared with a target value for smoke limitation. A higher measured oxygen concentration results in lower calculated soot formation by the engine. • Controls NOx emissions; determines whether the target Exhaust Gas Recirculation is being achieved to control NOx emissions. A higher measured oxygen concentration results in higher calculated NOx formation by the engine. • Controls regeneration of the diesel particulate filter (DPF). The soot particles in the DPF are 'burned' using the oxygen present in the exhaust gas.
<p>Location of component(s)</p>	
<p>Diagnostic condition</p>	<p>Need to consider all active/inactive faults: one or multiple faults may have triggered this fault</p> <ul style="list-style-type: none"> • when the engine speed is between 950 and 2000 rpm, and; • when the engine is running at a steady load, and; • when coolant temperature is above 50°C [122°F], and; • the engine mode is SCR high efficiency or standard or protection; • the lambda sensor (F834) is in the operating mode.

Set condition of fault code	The PCI-2 ECU detects that the time it takes to control the temperature is too long.
Reset condition of fault code	This fault code will change to inactive immediately after the diagnostic runs and passes.
Electrical diagram(s)	 <p>Wiring harness connector D420.C front view</p> <p>Wiring harness connector F834 front view</p> <p>D420 F834 Function C21 5 Trimming resistor</p>


	<div>C222Ground, sensor element</div> <div>C236Signal, nernst sensor</div> <div>C451Signal, pump cell current</div> <div>C463Ground, heater element</div> <div>4Power supply, heater element</div>																
Technical data	<div>Component check, lambda sensor (F834)</div> <div>Preparation<ul style="list-style-type: none">Key the ignition offDisconnect connector F834Measure on component connector F834<table><tr><td>Pin (+ probe)</td><td>Pin (- probe)</td><td>Value</td><td>Additional information</td></tr><tr><td>4</td><td>3</td><td>2.4–4.0 Ω</td><td>Heater element resistance at 20°C [68°C]</td></tr></table></div> <div>Component & circuit check, ECU (D420)</div> <div>Preparation<ul style="list-style-type: none">Key the ignition offDisconnect connector F834Measure on the front side of wiring harness connector F834<table><tr><td>Pin (+ probe)</td><td>Pin (- probe)</td><td>Value</td><td>Additional information</td></tr><tr><td>4</td><td>Ground</td><td>Ubat</td><td>Heater element power supply with ignition keyed on</td></tr></table></div>	Pin (+ probe)	Pin (- probe)	Value	Additional information	4	3	2.4–4.0 Ω	Heater element resistance at 20°C [68°C]	Pin (+ probe)	Pin (- probe)	Value	Additional information	4	Ground	Ubat	Heater element power supply with ignition keyed on
Pin (+ probe)	Pin (- probe)	Value	Additional information														
4	3	2.4–4.0 Ω	Heater element resistance at 20°C [68°C]														
Pin (+ probe)	Pin (- probe)	Value	Additional information														
4	Ground	Ubat	Heater element power supply with ignition keyed on														
Possible causes	<ul style="list-style-type: none">Faulty wiringFaulty connectorFaulty sensor																
Additional information	No additional information available.																
Diagnostic Step-by-Step	<div><div></div><div>Perform the troubleshooting steps below using the breakout harness, if necessary, to check electrical components, such as sensors, electrical control units, and harnesses. Back probing is not recommended, as it could damage the harness. The ignition should always be in the OFF position when connecting or disconnecting electrical components to reduce the likelihood of damage to electrical components</div></div> <div><div></div><ul style="list-style-type: none">This troubleshooting tree is based on the assumption that supply power and ground to the PCI are functioning properly.Disconnecting the PCI connectors during the troubleshooting process will result in multiple errors.For specific electrical component information and pinout locations, always refer to the technical data in Rapido.It is necessary to exit the 'active errors' screen in DAVIE and run the diagnostic test again to identify changes in errors.Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive codes. Refer to the 'possible causes' section in Rapido.</div> <table><tr><td>Step 1</td><td>Step ID 1138a</td><td>SRT</td></tr><tr><td colspan="3">Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic</td></tr></table>	Step 1	Step ID 1138a	SRT	Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic												
Step 1	Step ID 1138a	SRT															
Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic																	


	procedure. Proceed to step 2.		
	Step 2	Step ID 1138b	SRT
	With the key OFF, disconnect the lambda sensor. Turn the key ON and navigate through DAVIE to read errors: <ul style="list-style-type: none">• If fault is inactive – Proceed to step 3.• If fault is active – Proceed to step 4.		
	Step 3	Step ID 1138c	SRT
	With key OFF, disconnect the harness from the lambda sensor. Turn the key on and measure the voltage between a battery ground and the supply terminal of the lambda sensor circuit on the engine harness: <ul style="list-style-type: none">• If the voltage is acceptable – Replace the lambda sensor and reconnect the harness and verify the fault as per verification drive cycle.• If the voltage is not acceptable – Proceed to step 4		
	Step 4	Step ID 1138d	SRT
	With key OFF, disconnect the engine harness from the PCI. Turn the key ON and navigate through DAVIE to read errors: <ul style="list-style-type: none">• If fault is inactive – Replace the engine harness and verify the fault as per verification drive cycle.• If fault is active – Proceed to step 5.		
	Step 5	Step ID 1138e	SRT
	Contact the PACCAR Engine Support Call Center For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center at 1-800-477-0251.		
Verification Drive Cycle	To validate the repair: Drive the vehicle at a minimum speed of 80 km/h [50 mph] in the highest gear possible with the engine speed between 1100 and 1500 rpm and set the cruise control. This test is best performed with a loaded vehicle/trailer, but if load is unavailable, turn as many engine power consumers on to produce engine load. Perform this test for roughly 5 to 8 km [3 to 5 miles] or in 3 separate 1.5 km [1 mile] increments if a steady 5 to 8 km [3 to 5 miles] is unachievable. Use a flat road, if possible.		
	Back to Index		


P1139



Code number	P1139
Fault code description	Lambda heater calibration test fault
Fault code information	<div>  <p>For further assistance: Contact the PACCAR Engine Support Call Center 1-800-477-0251</p> </div> <p>Please Contact the Engine Support Center</p>
Description of component(s)	
Location of component(s)	
Diagnostic condition	
Set condition of fault code	
Reset condition of fault code	
Electrical diagram(s)	
Technical data	
Possible causes	
Additional information	
Diagnostic Step-by-Step	
Verification Drive Cycle	
	Back to Index

P113A

Code number	P113A
Fault code description	Lambda sensor temperature – Unable to reach target temperature
Fault code information	<p>1 trip MIL</p> <p>3 drive cycle recovery</p> <p>Readiness group - EGS heater</p> <p>Freeze frame type - Exhaust gas</p>
Description of component(s)	<p>The lambda sensor measures the oxygen concentration in the exhaust gases after the BPV valve.</p>  <p>Air/fuel ratio The PCI ECU uses the measured oxygen concentration in the exhaust to determine the air/fuel ratio of the combustion process. Typical air/fuel ratios are 18 to 45. A high value indicates a high oxygen concentration measured by the lambda sensor.</p> <p>Sensor heater The sensor has an integrated heater to maintain a sensor operating temperature of approximately 750°C [1382°F]. The PCI ECU controls the heater.</p> <p>Sensor heating control</p> <ul style="list-style-type: none"> • The first stage starts when the ignition is keyed on. The sensor is heated to a value at which any condensate evaporates from the sensor. • The second stage starts after the 'dew point' is reached. The sensor is heated to its operating temperature of approximately 750°C [1382°F]. The PCI ECU determines the 'dew point' by calculating how much

	<p>energy (heat by burning fuel in the engine) is pumped through the exhaust. If the 'dew point' is not/no longer reached, the sensor temperature stays at/drops to the standby temperature, similar to the first stage heating.</p> <p>Effect on the system</p> <ul style="list-style-type: none"> • Determines the air/fuel ratio of the combustion process • Controls the smoke limit; where the measured exhaust gas oxygen concentration is compared with a target value for smoke limitation. A higher measured oxygen concentration results in lower calculated soot formation by the engine. • Controls NOx emissions; determines whether the target Exhaust Gas Recirculation is being achieved to control NOx emissions. A higher measured oxygen concentration results in higher calculated NOx formation by the engine. • Controls regeneration of the diesel particulate filter (DPF). The soot particles in the DPF are 'burned' using the oxygen present in the exhaust gas.
Location of component(s)	
Diagnostic condition	This diagnostic runs when the lambda sensor (F834) is in the operating mode.
Set condition of fault code	<p>The PCI ECU (D420) detects that the temperature of the lambda sensor:</p> <ul style="list-style-type: none"> • is not within the expected values within 25 seconds, or; • exceeds a safe maximum value
Reset condition of fault code	<p>This DTC changes to inactive when the fault is no longer detected. To validate the repair:</p> <ul style="list-style-type: none"> • Key the ignition off for at least 15 seconds, then key it on again. Then start

	<p>the engine and let it idle for 2 minutes, and;</p> <ul style="list-style-type: none"> • Drive the vehicle until the coolant temperature is at least 70°C [158°F]. Once the minimum target temperature has been reached, proceed at a minimum speed of 80 km/h [50 mph] in the highest gear possible with the engine speed between 1100 and 1500 rpm and set the cruise control. This test is best performed with a loaded vehicle/trailer, but if load is unavailable, turn as many engine power consumers on to produce engine load. Perform this test for roughly 5 to 8 km [3 to 5 miles] or in 3 separate 1.5 km [1 mile] increments if a steady 5 to 8 km [3 to 5 miles] is unachievable. Use a flat road, if possible.
<p>Electrical diagram(s)</p>	 <p>The diagram illustrates the electrical connection for the D420.C component. At the top, a box labeled '2' with '123E' below it is connected to a relay assembly labeled 'F834'. The relay assembly has six terminals at the bottom, numbered 4, 1, 5, 2, 6, and 3. Wires from terminals 1, 5, 2, and 6 lead to a blue rectangular component labeled 'D420'. These wires are also labeled 'C45', 'C21', 'C22', and 'C23' respectively. Below the D420 component is a detailed front view of the wiring harness connector. It is a long, rectangular unit with a multi-pin connector on the left. Various points are labeled with numbers: 46, 23, 24, 1, 92, 69, 70, and 47. A small inset shows the top view of the connector. The identifier 'E504139' is located at the bottom right of the front view.</p> <p>Wiring harness connector D420.C front view</p>

	<div></div> <p>Wiring harness connector F834 front view</p> <table><tr><td>D420</td><td>F834</td><td>Function</td></tr><tr><td>C21</td><td>5</td><td>Trimming resistor</td></tr><tr><td>C22</td><td>2</td><td>Ground, sensor element</td></tr><tr><td>C23</td><td>6</td><td>Signal, nernst sensor</td></tr><tr><td>C45</td><td>1</td><td>Signal, pump cell current</td></tr><tr><td>C46</td><td>3</td><td>Ground, heater element</td></tr><tr><td></td><td>4</td><td>Power supply, heater element</td></tr></table>	D420	F834	Function	C21	5	Trimming resistor	C22	2	Ground, sensor element	C23	6	Signal, nernst sensor	C45	1	Signal, pump cell current	C46	3	Ground, heater element		4	Power supply, heater element
D420	F834	Function																				
C21	5	Trimming resistor																				
C22	2	Ground, sensor element																				
C23	6	Signal, nernst sensor																				
C45	1	Signal, pump cell current																				
C46	3	Ground, heater element																				
	4	Power supply, heater element																				
Technical data	<p>Component check, lambda sensor (F834)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key the ignition off• Disconnect connector F834• Measure on component connector F834 <table><tr><th>Pin (+ probe)</th><th>Pin (- probe)</th><th>Value</th><th>Additional information</th></tr><tr><td>4</td><td>3</td><td>2.4–4.0 Ω</td><td>Heater element resistance at 20°C [68°C]</td></tr></table> <p>Component & circuit check, ECU (D420)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key the ignition off• Disconnect connector F834• Measure on the front side of wiring harness connector F834 <table><tr><th>Pin (+ probe)</th><th>Pin (- probe)</th><th>Value</th><th>Additional information</th></tr><tr><td>4</td><td>Ground</td><td>Ubat</td><td>Heater element power supply with ignition keyed on</td></tr></table>	Pin (+ probe)	Pin (- probe)	Value	Additional information	4	3	2.4–4.0 Ω	Heater element resistance at 20°C [68°C]	Pin (+ probe)	Pin (- probe)	Value	Additional information	4	Ground	Ubat	Heater element power supply with ignition keyed on					
Pin (+ probe)	Pin (- probe)	Value	Additional information																			
4	3	2.4–4.0 Ω	Heater element resistance at 20°C [68°C]																			
Pin (+ probe)	Pin (- probe)	Value	Additional information																			
4	Ground	Ubat	Heater element power supply with ignition keyed on																			
Possible causes	Faulty lambda sensor																					
Additional information	The PCI ECU uses the oxygen concentration in the exhaust, measured by the lambda sensor (F834), to determine the air/fuel ratio of the combustion process. The sensor has an integrated heater to maintain a sensor operating temperature of approximately																					
Diagnostic Step-by-Step	<div></div> <p>Perform the troubleshooting steps below using the breakout harness, if necessary, to check electrical components, such as sensors, electrical control units, and harnesses. Back probing is not recommended, as it could damage the harness. The ignition should always be in the OFF position when connecting or disconnecting electrical components to reduce the likelihood of damage to electrical components</p>																					



- This troubleshooting tree is based on the assumption that supply power and ground to the PCI are functioning properly.
- Disconnecting the PCI connectors during the troubleshooting process will result in multiple errors.
- For specific electrical component information and pinout locations, always refer to the technical data in Rapido.
- It is necessary to exit the 'active errors' screen in DAVIE and run the diagnostic test again to identify changes in errors.
- Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive codes. Refer to the 'possible causes' section in Rapido.

Step 1	Step ID 113A-a	SRT
Test Drive to Confirm Fault Perform the following pre-check steps to confirm this fault before continuing troubleshooting: <ul style="list-style-type: none"> • Use DAVIE to clear the existing active faults • Take the truck for a 30 minute test drive Use DAVIE to re-check for the presence of active faults. <ul style="list-style-type: none"> • If this related fault is no longer active, then this issue has been resolved. • If this related fault is still active, continue to the next step in the troubleshooting process. 		


Step 2	Step ID 113A-b	SRT
Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 3.		


Step 3	Step ID 113A-c	SRT
Replace Lambda sensor and use DAVIE to re-check for the presence of active faults. <ul style="list-style-type: none"> • Fault inactive – issue resolved • Fault active - Proceed to step 4 		

Step 4	Step ID 113A-d	SRT
For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center at 1-800-477-0251.		

Verification Drive Cycle	To validate repair: This cycle is best performed on a level grade road (least amount of incline possible) and under load using a trailer. If a loaded trailer is unavailable, produce engine load by turning the A/C and fan to ON. With the System Initiation cycle complete, proceed to a road with a minimum speed limit of 50 mph, then get to the highest gear possible with the engine speed between 1100-1500 rpm, and set the cruise control. Run this cycle for roughly 3 to 5 miles or in three separate 1-mile increments if a steady 3 to 5 miles is unachievable.
	Back to Index



P113B

Code number	P113B
Fault code description	Lambda sensor controller - Incorrect
Fault code information	<p>1 trip MIL</p> <p>3 drive cycle recovery</p> <p>Readiness group - EGS heater</p> <p>Freeze frame type - Exhaust gas</p>
Description of component(s)	<p>The lambda sensor measures the oxygen concentration in the exhaust gases after the BPV valve.</p>  <p>Air/fuel ratio The PCI ECU uses the measured oxygen concentration in the exhaust to determine the air/fuel ratio of the combustion process. Typical air/fuel ratios are 18 to 45. A high value indicates a high oxygen concentration measured by the lambda sensor.</p> <p>Sensor heater The sensor has an integrated heater to maintain a sensor operating temperature of approximately 750°C [1382°F]. The PCI ECU controls the heater.</p> <p>Sensor heating control</p> <ul style="list-style-type: none"> • The first stage starts when the ignition is keyed on. The sensor is heated to a value at which any condensate evaporates from the sensor. • The second stage starts after the 'dew point' is reached. The sensor is heated to its operating temperature of approximately 750°C [1382°F]. The PCI ECU determines the 'dew point' by calculating how much

	<p>energy (heat by burning fuel in the engine) is pumped through the exhaust. If the 'dew point' is not/no longer reached, the sensor temperature stays at/drops to the standby temperature, similar to the first stage heating.</p> <p>Effect on the system</p> <ul style="list-style-type: none"> • Determines the air/fuel ratio of the combustion process • Controls the smoke limit; where the measured exhaust gas oxygen concentration is compared with a target value for smoke limitation. A higher measured oxygen concentration results in lower calculated soot formation by the engine. • Controls NOx emissions; determines whether the target Exhaust Gas Recirculation is being achieved to control NOx emissions. A higher measured oxygen concentration results in higher calculated NOx formation by the engine. • Controls regeneration of the diesel particulate filter (DPF). The soot particles in the DPF are 'burned' using the oxygen present in the exhaust gas.
Location of component(s)	
Diagnostic condition	This diagnostic runs continuously when the engine is running.
Set condition of fault code	The PCI ECU (D420) detects that the lambda sensor heater controller inside the PCI ECU is malfunctioning.
Reset condition of fault code	<p>This DTC changes to inactive when the fault is no longer detected. To validate the repair:</p> <ul style="list-style-type: none"> • Key the ignition off for at least 15 seconds, then key it on again. Then start the engine and let it idle for 2 minutes, and;


- Drive the vehicle until the coolant temperature is at least 70°C [158°F]. Once the minimum target temperature has been reached, proceed at a minimum speed of 80 km/h [50 mph] in the highest gear possible with the engine speed between 1100 and 1500 rpm and set the cruise control. This test is best performed with a loaded vehicle/trailer, but if load is unavailable, turn as many engine power consumers on to produce engine load. Perform this test for roughly 5 to 8 km [3 to 5 miles] or in 3 separate 1.5 km [1 mile] increments if a steady 5 to 8 km [3 to 5 miles] is unachievable. Use a flat road, if possible.



Electrical diagram(s)



Wiring harness connector D420.C front view



E504139

	<div></div> <p>Wiring harness connector F834 front view</p> <table><tr><td>D420</td><td>F834</td><td>Function</td></tr><tr><td>C21</td><td>5</td><td>Trimming resistor</td></tr><tr><td>C22</td><td>2</td><td>Ground, sensor element</td></tr><tr><td>C23</td><td>6</td><td>Signal, nernst sensor</td></tr><tr><td>C45</td><td>1</td><td>Signal, pump cell current</td></tr><tr><td>C46</td><td>3</td><td>Ground, heater element</td></tr><tr><td></td><td>4</td><td>Power supply, heater element</td></tr></table>	D420	F834	Function	C21	5	Trimming resistor	C22	2	Ground, sensor element	C23	6	Signal, nernst sensor	C45	1	Signal, pump cell current	C46	3	Ground, heater element		4	Power supply, heater element
D420	F834	Function																				
C21	5	Trimming resistor																				
C22	2	Ground, sensor element																				
C23	6	Signal, nernst sensor																				
C45	1	Signal, pump cell current																				
C46	3	Ground, heater element																				
	4	Power supply, heater element																				
Technical data	<p>Component check, lambda sensor (F834)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key the ignition off• Disconnect connector F834• Measure on component connector F834 <table><tr><th>Pin (+ probe)</th><th>Pin (- probe)</th><th>Value</th><th>Additional information</th></tr><tr><td>4</td><td>3</td><td>2.4–4.0 Ω</td><td>Heater element resistance at 20°C [68°C]</td></tr></table> <p>Component & circuit check, ECU (D420)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key the ignition off• Disconnect connector F834• Measure on the front side of wiring harness connector F834 <table><tr><th>Pin (+ probe)</th><th>Pin (- probe)</th><th>Value</th><th>Additional information</th></tr><tr><td>4</td><td>Ground</td><td>Ubat</td><td>Heater element power supply with ignition keyed on</td></tr></table>	Pin (+ probe)	Pin (- probe)	Value	Additional information	4	3	2.4–4.0 Ω	Heater element resistance at 20°C [68°C]	Pin (+ probe)	Pin (- probe)	Value	Additional information	4	Ground	Ubat	Heater element power supply with ignition keyed on					
Pin (+ probe)	Pin (- probe)	Value	Additional information																			
4	3	2.4–4.0 Ω	Heater element resistance at 20°C [68°C]																			
Pin (+ probe)	Pin (- probe)	Value	Additional information																			
4	Ground	Ubat	Heater element power supply with ignition keyed on																			
Possible causes	<ul style="list-style-type: none">• Faulty lambda sensor• ECU connections are damaged or disconnected																					
Additional information	<ul style="list-style-type: none">• The PCI ECU uses the oxygen concentration in the exhaust, measured by the lambda sensor (F834), to determine the air/fuel ratio of the combustion process. The sensor has an integrated heater to maintain a sensor operating temperature of approximately 750°C [1382°F].																					

Diagnostic Step-by-Step	<div><p>Perform the troubleshooting steps below using the breakout harness, if necessary, to check electrical components, such as sensors, electrical control units, and harnesses. Back probing is not recommended, as it could damage the harness. The ignition should always be in the OFF position when connecting or disconnecting electrical components to reduce the likelihood of damage to electrical components</p></div> <div><ul style="list-style-type: none">• This troubleshooting tree is based on the assumption that supply power and ground to the PCI are functioning properly.• Disconnecting the PCI connectors during the troubleshooting process will result in multiple errors.• For specific electrical component information and pinout locations, always refer to the technical data in Rapido.• It is necessary to exit the 'active errors' screen in DAVIE and run the diagnostic test again to identify changes in errors.• Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive codes. Refer to the 'possible causes' section in Rapido.</div>						
	<table><tr><td>Step 1</td><td>Step ID 113B-a</td><td>SRT</td></tr><tr><td colspan="3"><p>Test Drive to Confirm Fault</p><p>Perform the following pre-check steps to confirm this fault before continuing troubleshooting:</p><ul style="list-style-type: none">• Use DAVIE to clear the existing active faults• Take the truck for a 30 minute test drive<p>Use DAVIE to re-check for the presence of active faults.</p><ul style="list-style-type: none">• If this related fault is no longer active, then this issue has been resolved.• If this related fault is still active, continue to the next step in the troubleshooting process.</td></tr></table>	Step 1	Step ID 113B-a	SRT	<p>Test Drive to Confirm Fault</p> <p>Perform the following pre-check steps to confirm this fault before continuing troubleshooting:</p> <ul style="list-style-type: none">• Use DAVIE to clear the existing active faults• Take the truck for a 30 minute test drive <p>Use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">• If this related fault is no longer active, then this issue has been resolved.• If this related fault is still active, continue to the next step in the troubleshooting process.		
	Step 1	Step ID 113B-a	SRT				
	<p>Test Drive to Confirm Fault</p> <p>Perform the following pre-check steps to confirm this fault before continuing troubleshooting:</p> <ul style="list-style-type: none">• Use DAVIE to clear the existing active faults• Take the truck for a 30 minute test drive <p>Use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">• If this related fault is no longer active, then this issue has been resolved.• If this related fault is still active, continue to the next step in the troubleshooting process.						
	<table><tr><td>Step 2</td><td>Step ID 113B-b</td><td>SRT</td></tr><tr><td colspan="3"><p>Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 3.</p></td></tr></table>	Step 2	Step ID 113B-b	SRT	<p>Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 3.</p>		
Step 2	Step ID 113B-b	SRT					
<p>Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 3.</p>							
<table><tr><td>Step 3</td><td>Step ID 113B-c</td><td>SRT</td></tr><tr><td colspan="3"><p>Replace Lambda sensor and use DAVIE to re-check for the presence of active faults.</p><ul style="list-style-type: none">• Fault inactive – issue resolved• Fault active - Proceed to step 4</td></tr></table>	Step 3	Step ID 113B-c	SRT	<p>Replace Lambda sensor and use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">• Fault inactive – issue resolved• Fault active - Proceed to step 4			
Step 3	Step ID 113B-c	SRT					
<p>Replace Lambda sensor and use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">• Fault inactive – issue resolved• Fault active - Proceed to step 4							
<table><tr><td>Step 4</td><td>Step ID 113B-d</td><td>SRT</td></tr><tr><td colspan="3"><p>For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center at 1-800-477-0251.</p></td></tr></table>	Step 4	Step ID 113B-d	SRT	<p>For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center at 1-800-477-0251.</p>			
Step 4	Step ID 113B-d	SRT					
<p>For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center at 1-800-477-0251.</p>							
Verification Drive Cycle	<p>To validate repair:</p> <p>This cycle is best performed on a level grade road (least amount of incline possible) and under load using a trailer. If a loaded trailer is unavailable, produce engine load by turning the A/C and fan to ON. With the System Initiation cycle complete, proceed to a road with a minimum speed limit of 50 mph, then get to the highest gear possible with the engine speed between 1100-1500 rpm, and set the cruise control. Run this</p>						

	cycle for roughly 3 to 5 miles or in three separate 1-mile increments if a steady 3 to 5 miles is unachievable.
	Back to Index

P1158

Code number	P1158
Fault code description	Wheel speed, front axle, left - Data erratic, intermittent or incorrect
Fault code information	1 trip MIL 3 drive cycle recovery Readiness group – None Freeze frame type - Comprehensive
Description of component(s)	The wheel speed sensor is a type of tachometer, consisting of a toothed ring and electrical pickup. It is a sender device used for reading the speed of a vehicle's wheel rotation.
Location of component(s)	The type of axle determines the sensor mounting location: <ul style="list-style-type: none"> Steering axle sensors are typically installed in the steering knuckle or in a bolted-on bracket. Drive axle sensors are typically mounted on a block, attached to the axle housing or in a bolted-on bracket.
Diagnostic condition	This diagnostic runs continuously when the ignition is on.
Set condition of fault code	The ECU detects that the speed of the left-front axle wheel speed sensor is > 160 km/h [99 mph].
Reset condition of fault code	This DTC changes to inactive when a normal wheel speed is detected.
Electrical diagram(s)	Refer to the OEM technical data for additional information.
Technical data	Refer to the OEM technical data for additional information.
Possible causes	Wheel speed sensor defect.
Additional information	The vehicle was driven excessively fast or the wheel speed sensor is malfunctioning.
Diagnostic Step-by-Step	<div>  <p>The ignition should always be in the OFF position when connecting or disconnecting electrical components to reduce the likelihood of damage to the components.</p> </div> <div>  <ul style="list-style-type: none"> This troubleshooting procedure is based on the assumption that supply power and ground to the PCI are functioning properly. Disconnecting the PCI connectors during the troubleshooting process will result in multiple errors. Specific electrical component information and pin out locations are provided in this procedure as a reference only. Always refer to the technical data sections in Rapido for the most up-to-date changes. It is necessary to use DAVIE to clear all current DTCs from the PCI and EAS-3 ECUs, and then run the Quick Check to identify a change in fault status. This DTC can be set as a result of multiple failure modes. For proper fault isolation, complete all troubleshooting steps in the sequence provided. </div>

Step 1 Wheel Speed Sensor Checks

Step 1A Visual inspection, connections and wiring, wheel speed sensor, front axle left

Action

1. Visually inspect the associated component connections and wiring for any of the following:
 - Damaged or loose connectors
 - Bent, broken, corroded or loose connector pins
 - Moisture or dirt in the connections
 - Damage to the wire harness or insulation
 - ECU connections are damaged or disconnected
 - Batteries not fully charged, contacts are not tight
 - The related sensor is not installed correctly or it is damaged
 - The installed wheel and tire size is incorrect

Was there evidence of any of the above?

Yes

No

Correct any issues found. If the wheel speed sensor is found to be damaged or broken, replace it.
Refer to step 3A to perform the corresponding repair verification cycles and rechecks.

If this DTC is still present, go to step 2A

Go to step 2A

Step 2 OEM Troubleshooting

Step 2A OEM troubleshooting

Action

1. Refer to the OEM technical data for related troubleshooting information.

Was an issue identified using the OEM troubleshooting?

Yes

No

Correct any issues found. If the wheel speed sensor is found to be damaged or broken, replace it.
Refer to step 3A to perform the

Contact the PACCAR Engine Support Center for further assistance in diagnosing this issue.

corresponding repair verification cycles and rechecks.	
If all steps have been completed and this DTC is still present, contact the PACCAR Engine Support Center for further assistance.	

Step 3 Repair Verification

Step 3A Repair verification cycles

Perform these repair verification cycles following any corrective actions taken, to enable related OBD monitors to reach a readiness state associated with the DTC or system being investigated.



Before beginning these repair verification cycles, use the DAVIE Diagnostics, Quick Check function to “Clear all” current DTCs from the PCI and EAS-3 ECUs.

Action

1. Overrun

With the System Initiation cycle complete, proceed to a road with minimum speed limit of 50 mph.

While remaining within the legally posted speed limit, get the truck in the highest gear possible with the engine speed at a minimum of 1800 rpm.

Once the target engine speed has been reached, leave the truck in gear and release the accelerator pedal, allowing the truck to coast until the engine speed has reached 900 rpm. Perform this cycle 4 times.

- For Eaton Ultrashift transmissions, idle drop can only go to 1000 rpm
- For Alison Autoshift transmission, this test will not be able to be conducted

Were the identified repair verification cycles able to be completed?

Yes	No
	Investigate and correct any issues preventing these repair verification cycles from being completed, then re-run. For additional assistance, contact the PACCAR Engine Support Center.
Go to step 3B	

Step 3B DAVIE Diagnostics, Quick Check, OBD Readiness Monitors

Action

Use DAVIE Diagnostics to perform a Quick Check for current DTCs to determine whether the actions taken have cleared this DTC.

1. Confirm that the corresponding OBD Monitor Readiness Status value is displayed as "Ready."
A status of Ready indicates that the corresponding OBD monitor has run successfully and the problem has been resolved—no further action.
If the displayed status is "Not ready," continue to action step 2.
2. View the DTC overview display, and confirm that P1158 has been cleared.

Is the related OBD Monitor Readiness Status set to "Ready." Or, has P1158 been cleared?

Yes

Problem resolved. No further actions.

No

Continue with the next step in this troubleshooting procedure.
If all steps have been completed and this DTC is still present:

- continue to operate the truck to extend the run time, allowing the corresponding OBD monitor sufficient time to complete
- or, return to step 3A and perform this repair verification again.

If this issue is still present after extending or re-running the repair verification, contact the PACCAR Engine Support Center for further assistance.





Contacting the PACCAR Engine Support Center

For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center.

[Back to Index](#)

P1159

Code number	P1159
Fault code description	Wheel speed , front axle , right – Data erratic , intermittent or incorrect
Fault code information	1 trip MIL 3 drive cycle recovery Readiness group – None Freeze frame type - Comprehensive
Description of component(s)	The wheel speed sensor is a type of tachometer, consisting of a toothed ring and electrical pickup. It is a sender device used for reading the speed of a vehicle's wheel rotation.
Location of component(s)	The type of axle determines the sensor mounting location: <ul style="list-style-type: none"> Steering axle sensors are typically installed in the steering knuckle or in a bolted-on bracket. Drive axle sensors are typically mounted on a block, attached to the axle housing or in a bolted-on bracket.
Diagnostic condition	This diagnostic runs continuously when the ignition is on.
Set condition of fault code	The ECU detects that the speed of the right-front axle wheel speed sensor is > 160 km/h [99 mph].
Reset condition of fault code	This DTC changes to inactive when a normal wheel speed is detected.
Electrical diagram(s)	Refer to the OEM technical data for additional information.
Technical data	Refer to the OEM technical data for additional information.
Possible causes	Wheel speed sensor defect.
Additional information	The vehicle was driven excessively fast or the wheel speed sensor is malfunctioning.
Diagnostic Step-by-Step	<div>  <p>The ignition should always be in the OFF position when connecting or disconnecting electrical components to reduce the likelihood of damage to the components.</p> </div> <div>  <ul style="list-style-type: none"> This troubleshooting procedure is based on the assumption that supply power and ground to the PCI are functioning properly. Disconnecting the PCI connectors during the troubleshooting process will result in multiple errors. Specific electrical component information and pin out locations are provided in this procedure as a reference only. Always refer to the technical data sections in Rapido for the most up-to-date changes. It is necessary to use DAVIE to clear all current DTCs from the PCI and EAS-3 ECUs, and then run the Quick Check to identify a change in fault status. This DTC can be set as a result of multiple failure modes. For proper fault </div>

isolation, complete all troubleshooting steps in the sequence provided.

Step 1 Wheel Speed Sensor Checks

Step 1A Visual inspection, connections and wiring, wheel speed sensor, front axle, right

Action

1. Visually inspect the associated component connections and wiring for any of the following:
 - Damaged or loose connectors
 - Bent, broken, corroded or loose connector pins
 - Moisture or dirt in the connections
 - Damage to the wire harness or insulation
 - ECU connections are damaged or disconnected
 - Batteries not fully charged, contacts are not tight
 - The related sensor is not installed correctly or it is damaged
 - The installed wheel and tire size is incorrect

Was there evidence of any of the above?

Yes

No

Correct any issues found. If the wheel speed sensor is found to be damaged or broken, replace it.
Refer to step 3A to perform the corresponding repair verification cycles and rechecks.

If this DTC is still present, go to step 2A

Go to step 2A

Step 2 OEM Troubleshooting

Step 2A OEM troubleshooting

Action

1. Refer to the OEM technical data for related troubleshooting information.

Was an issue identified using the OEM troubleshooting?

Yes


No

Correct any issues found. If the wheel speed sensor is found to be damaged or

Contact the PACCAR Engine Support Center for further assistance in

broken, replace it. Refer to step 3A to perform the corresponding repair verification cycles and rechecks.	diagnosing this issue.
If all steps have been completed and this DTC is still present, contact the PACCAR Engine Support Center for further assistance.	

Step 3 Repair Verification

Step 3A Repair verification cycles	
Perform these repair verification cycles following any corrective actions taken, to enable related OBD monitors to reach a readiness state associated with the DTC or system being investigated.	
<div>  <p>Before beginning these repair verification cycles, use the DAVIE Diagnostics, Quick Check function to "Clear all" current DTCs from the PCI and EAS-3 ECUs.</p> </div>	
Action <ol style="list-style-type: none"> Overrun <p>With the System Initiation cycle complete, proceed to a road with minimum speed limit of 50 mph.</p> <p>While remaining within the legally posted speed limit, get the truck in the highest gear possible with the engine speed at a minimum of 1800 rpm. Once the target engine speed has been reached, leave the truck in gear and release the accelerator pedal, allowing the truck to coast until the engine speed has reached 900 rpm. Perform this cycle 4 times.</p> <ul style="list-style-type: none"> For Eaton Ultrashift transmissions, idle drop can only go to 1000 rpm For Allison Autoshift transmission, this test will not be able to be conducted 	
Were the identified repair verification cycles able to be completed?	
Yes	No
	Investigate and correct any issues preventing these repair verification cycles from being completed, then re-run. For additional assistance, contact the PACCAR Engine Support Center.
Go to step 3B	

Step 3B DAVIE Diagnostics, Quick Check, OBD Readiness Monitors

Action

Use DAVIE Diagnostics to perform a Quick Check for current DTCs to determine whether the actions taken have cleared this DTC.

1. Confirm that the corresponding OBD Monitor Readiness Status value is displayed as "Ready."
A status of Ready indicates that the corresponding OBD monitor has run successfully and the problem has been resolved—no further action.
If the displayed status is "Not ready," continue to action step 2.
2. View the DTC overview display, and confirm that P1159 has been cleared.

Is the related OBD Monitor Readiness Status set to "Ready." Or, has P1159 been cleared?

Yes

Problem resolved. No further actions.

No

Continue with the next step in this troubleshooting procedure.
If all steps have been completed and this DTC is still present:

- continue to operate the truck to extend the run time, allowing the corresponding OBD monitor sufficient time to complete
- or, return to step 3A and perform this repair verification again.

If this issue is still present after extending or re-running the repair verification, contact the PACCAR Engine Support Center for further assistance.





Contacting the PACCAR Engine Support Center

For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center.

[Back to Index](#)

P1160

Code number	P1160
Fault code description	Wheel speed, rear axle, left – Data erratic, intermittent or incorrect
Fault code information	1 trip MIL 3 drive cycle recovery Readiness group – None Freeze frame type - Comprehensive
Description of component(s)	The wheel speed sensor is a type of tachometer, consisting of a toothed ring and electrical pickup. It is a sender device used for reading the speed of a vehicle's wheel rotation.
Location of component(s)	The type of axle determines the sensor mounting location: <ul style="list-style-type: none"> Steering axle sensors are typically installed in the steering knuckle or in a bolted-on bracket. Drive axle sensors are typically mounted on a block, attached to the axle housing or in a bolted-on bracket.
Diagnostic condition	This diagnostic runs continuously when the ignition is on.
Set condition of fault code	The ECU detects that the speed of the left-rear axle wheel speed sensor is > 160 km/h [99 mph].
Reset condition of fault code	This DTC changes to inactive when a normal wheel speed is detected.
Electrical diagram(s)	Refer to the OEM technical data for additional information.
Technical data	Refer to the OEM technical data for additional information.
Possible causes	Wheel speed sensor defect.
Additional information	The vehicle was driven excessively fast or the wheel speed sensor is malfunctioning.
Diagnostic Step-by-Step	<div>  <p>The ignition should always be in the OFF position when connecting or disconnecting electrical components to reduce the likelihood of damage to the components.</p> </div> <div>  <ul style="list-style-type: none"> This troubleshooting procedure is based on the assumption that supply power and ground to the PCI are functioning properly. Disconnecting the PCI connectors during the troubleshooting process will result in multiple errors. Specific electrical component information and pin out locations are provided in this procedure as a reference only. Always refer to the technical data sections in Rapido for the most up-to-date changes. It is necessary to use DAVIE to clear all current DTCs from the PCI and EAS-3 ECUs, and then run the Quick Check to identify a change in fault status. This DTC can be set as a result of multiple failure modes. For proper fault </div>

isolation, complete all troubleshooting steps in the sequence provided.

Step 1 Wheel Speed Sensor Checks

Step 1A Visual inspection, connections and wiring, wheel speed sensor, rear axle, left

Action

1. Visually inspect the associated component connections and wiring for any of the following:
 - Damaged or loose connectors
 - Bent, broken, corroded or loose connector pins
 - Moisture or dirt in the connections
 - Damage to the wire harness or insulation
 - ECU connections are damaged or disconnected
 - Batteries not fully charged, contacts are not tight
 - The related sensor is not installed correctly or it is damaged
 - The installed wheel and tire size is incorrect

Was there evidence of any of the above?

Yes

No

Correct any issues found. If the wheel speed sensor is found to be damaged or broken, replace it.
Refer to step 3A to perform the corresponding repair verification cycles and rechecks.

If this DTC is still present, go to step 2A

Go to step 2A

Step 2 OEM Troubleshooting

Step 2A OEM troubleshooting


Action

1. Refer to the OEM technical data for related troubleshooting information.


Was an issue identified using the OEM troubleshooting?

Yes



No

	Correct any issues found. If the wheel speed sensor is found to be damaged or broken, replace it. Refer to step 3A to perform the corresponding repair verification cycles and rechecks.	Contact the PACCAR Engine Support Center for further assistance in diagnosing this issue.
	If all steps have been completed and this DTC is still present, contact the PACCAR Engine Support Center for further assistance.	
Step 3 Repair Verification		
Step 3A Repair verification cycles		
Perform these repair verification cycles following any corrective actions taken, to enable related OBD monitors to reach a readiness state associated with the DTC or system being investigated.		
<div>  <p>Before beginning these repair verification cycles, use the DAVIE Diagnostics, Quick Check function to "Clear all" current DTCs from the PCI and EAS-3 ECUs.</p> </div>		
Action		
<ol style="list-style-type: none"> Overrun <p>With the System Initiation cycle complete, proceed to a road with minimum speed limit of 50 mph.</p> <p>While remaining within the legally posted speed limit, get the truck in the highest gear possible with the engine speed at a minimum of 1800 rpm. Once the target engine speed has been reached, leave the truck in gear and release the accelerator pedal, allowing the truck to coast until the engine speed has reached 900 rpm. Perform this cycle 4 times.</p> <ul style="list-style-type: none"> For Eaton Ultrashift transmissions, idle drop can only go to 1000 rpm For Alison Autoshift transmission, this test will not be able to be conducted 		
Were the identified repair verification cycles able to be completed?		
Yes		No
		Investigate and correct any issues preventing these repair

		verification cycles from being completed, then re-run. For additional assistance, contact the PACCAR Engine Support Center.
	Go to step 3B	
	Step 3B DAVIE Diagnostics, Quick Check, OBD Readiness Monitors	
	Action <p>Use DAVIE Diagnostics to perform a Quick Check for current DTCs to determine whether the actions taken have cleared this DTC.</p> <ol style="list-style-type: none"> Confirm that the corresponding OBD Monitor Readiness Status value is displayed as "Ready." <p>A status of Ready indicates that the corresponding OBD monitor has run successfully and the problem has been resolved—no further action.</p> <p>If the displayed status is "Not ready," continue to action step 2.</p> View the DTC overview display, and confirm that P1160 has been cleared. 	
	Is the related OBD Monitor Readiness Status set to "Ready." Or, has P1160 been cleared?	
	Yes	No

	<div data-bbox="495 130 1513 783"> <p>Problem resolved. No further actions.</p> <p>Continue with the next step in this troubleshooting procedure.</p> <p>If all steps have been completed and this DTC is still present:</p> <ul style="list-style-type: none"> • continue to operate the truck to extend the run time, allowing the corresponding OBD monitor sufficient time to complete • or, return to step 3A and perform this repair verification again. <p>If this issue is still present after extending or re-running the repair verification, contact the PACCAR Engine Support Center for further assistance.</p> </div> <div data-bbox="495 783 1513 1020"> <div data-bbox="505 850 592 938"></div> <p>Contacting the PACCAR Engine Support Center</p> <p>For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center.</p> </div>
	<p style="text-align: right;">Back to Index</p>

P1161

Code number	P1161
Fault code description	Wheel speed, rear axle, right – Data erratic, intermittent or incorrect
Fault code information	1 trip MIL 3 drive cycle recovery Readiness group – None Freeze frame type - Comprehensive
Description of component(s)	The wheel speed sensor is a type of tachometer, consisting of a toothed ring and electrical pickup. It is a sender device used for reading the speed of a vehicle's wheel rotation.
Location of component(s)	The type of axle determines the sensor mounting location: <ul style="list-style-type: none"> Steering axle sensors are typically installed in the steering knuckle or in a bolted-on bracket. Drive axle sensors are typically mounted on a block, attached to the axle housing or in a bolted-on bracket.
Diagnostic condition	This diagnostic runs continuously when the ignition is on.
Set condition of fault code	The ECU detects that the speed of the right-rear axle wheel speed sensor is > 160 km/h [99 mph].
Reset condition of fault code	This DTC changes to inactive when a normal wheel speed is detected.
Electrical diagram(s)	Refer to the OEM technical data for additional information.
Technical data	Refer to the OEM technical data for additional information.
Possible causes	Wheel speed sensor defect.
Additional information	The vehicle was driven excessively fast or the wheel speed sensor is malfunctioning.
Diagnostic Step-by-Step	<div>  <p>The ignition should always be in the OFF position when connecting or disconnecting electrical components to reduce the likelihood of damage to the components.</p> </div> <div>  <ul style="list-style-type: none"> This troubleshooting procedure is based on the assumption that supply power and ground to the PCI are functioning properly. Disconnecting the PCI connectors during the troubleshooting process will result in multiple errors. Specific electrical component information and pin out locations are provided in this procedure as a reference only. Always refer to the technical data sections in Rapido for the most up-to-date changes. It is necessary to use DAVIE to clear all current DTCs from the PCI and EAS-3 ECUs, and then run the Quick Check to identify a change in fault status. This DTC can be set as a result of multiple failure modes. For proper fault </div>

isolation, complete all troubleshooting steps in the sequence provided.

Step 1 Wheel Speed Sensor Checks

Step 1A Visual inspection, connections and wiring, wheel speed sensor, rear axle, right

Action

1. Visually inspect the associated component connections and wiring for any of the following:
 - Damaged or loose connectors
 - Bent, broken, corroded or loose connector pins
 - Moisture or dirt in the connections
 - Damage to the wire harness or insulation
 - ECU connections are damaged or disconnected
 - Batteries not fully charged, contacts are not tight
 - The related sensor is not installed correctly or it is damaged
 - The installed wheel and tire size is incorrect

Was there evidence of any of the above?

Yes

No

Correct any issues found. If the wheel speed sensor is found to be damaged or broken, replace it.
Refer to step 3A to perform the corresponding repair verification cycles and rechecks.

If this DTC is still present, go to step 2A

Go to step 2A

Step 2 OEM Troubleshooting

Step 2A OEM troubleshooting


Action

1. Refer to the OEM technical data for related troubleshooting information.

Was an issue identified using the OEM troubleshooting?

Yes

No

	Correct any issues found. If the wheel speed sensor is found to be damaged or broken, replace it. Refer to step 3A to perform the corresponding repair verification cycles and rechecks.	Contact the PACCAR Engine Support Center for further assistance in diagnosing this issue.
	If all steps have been completed and this DTC is still present, contact the PACCAR Engine Support Center for further assistance.	
Step 3 Repair Verification		
Step 3A Repair verification cycles		
Perform these repair verification cycles following any corrective actions taken, to enable related OBD monitors to reach a readiness state associated with the DTC or system being investigated.		
<div>  <p>Before beginning these repair verification cycles, use the DAVIE Diagnostics, Quick Check function to "Clear all" current DTCs from the PCI and EAS-3 ECUs.</p> </div>		
Action		
<ol style="list-style-type: none"> Overrun With the System Initiation cycle complete, proceed to a road with minimum speed limit of 50 mph. While remaining within the legally posted speed limit, get the truck in the highest gear possible with the engine speed at a minimum of 1800 rpm. Once the target engine speed has been reached, leave the truck in gear and release the accelerator pedal, allowing the truck to coast until the engine speed has reached 900 rpm. Perform this cycle 4 times. <ul style="list-style-type: none"> For Eaton Ultrashift transmissions, idle drop can only go to 1000 rpm For Alison Autoshift transmission, this test will not be able to be conducted 		
Were the identified repair verification cycles able to be completed?		
Yes		No
		Investigate and correct any issues preventing these repair verification


		cycles from being completed, then re-run. For additional assistance, contact the PACCAR Engine Support Center.
	Go to step 3B	
	Step 3B DAVIE Diagnostics, Quick Check, OBD Readiness Monitors	
	Action <p>Use DAVIE Diagnostics to perform a Quick Check for current DTCs to determine whether the actions taken have cleared this DTC.</p> <ol style="list-style-type: none"> Confirm that the corresponding OBD Monitor Readiness Status value is displayed as "Ready." <p>A status of Ready indicates that the corresponding OBD monitor has run successfully and the problem has been resolved—no further action.</p> <p>If the displayed status is "Not ready," continue to action step 2.</p> View the DTC overview display, and confirm that P1161 has been cleared. 	
	<p>Is the related OBD Monitor Readiness Status set to "Ready." Or, has P1161 been cleared?</p>	
	Yes	No
	<p>Problem resolved. No further actions.</p>	<p>Continue with the next step in this troubleshooting procedure.</p> <p>If all steps have been completed and this DTC is still present:</p> <ul style="list-style-type: none"> continue to operate the truck to extend the run time, allowing the corresponding OBD monitor sufficient time to complete or, return to step 3A and perform this repair verification again. <p>If this issue is still present after extending or re-running the repair verification, contact the PACCAR Engine Support Center for further assistance.</p>

	<div data-bbox="505 197 592 285" data-label="Image"> </div> <div data-bbox="638 212 1479 344" data-label="Text"> <p>Contacting the PACCAR Engine Support Center</p> <p>For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center.</p> </div>
	<div data-bbox="1349 371 1511 401" data-label="Text"> <p>Back to Index</p> </div>


P1163

Code number	P1163
Fault code description	CAN communication - Message (TCO1) out of range - vehicle speed from transmission
Fault code information	3 drive cycle recovery Readiness group – None Freeze frame type – Generic
Description of component(s)	This code relates to a communication issue and not to a specific component.
Location of component(s)	This code relates to a communication issue and not to a specific component.
Diagnostic condition	This diagnostic runs continuously when the ignition is on.
Set condition of fault code	
Reset condition of fault code	This DTC changes to inactive as soon as the error is no longer detected.
Electrical diagram(s)	<p style="text-align: center;">NAMUX 3 Architecture: 2010 B-Cab</p> <p>The diagram illustrates the NAMUX 3 Architecture for a 2010 B-Cab. The central component is the CECU 3, which is connected to several other components via various CAN buses and a CVSG BUS. The connections are as follows:</p> <ul style="list-style-type: none"> Diagnostic CAN: Connects CECU 3 to the MCS (Message Control System) and the Diagnostic Connector. Cab CAN: Connects CECU 3 to the Cluster, Steering Wheel, and Instrumentation CAN. Instrumentation CAN: Connects CECU 3 to the Cluster and CVSG BUS. CVSG BUS: Connects CECU 3 to the Electronic CVSG's. Vehicle CAN: Connects CECU 3 to the ABS, PACCAR Display, and Chassis Node. Engine CAN: Connects CECU 3 to the Engine, VGT Actuator, and After-treatment DCU. Frame CAN: Connects CECU 3 to the Chassis Node. Chassis Node: Connects CECU 3 to the Front Lamps, Tail / Trailer Lamps, and various sensors (Voltage, Fuel, Current, Pressure, Vacuum, Temp). After-treatment CAN: Connects CECU 3 to the After-treatment DCU. <p>Firewalls are indicated between the Diagnostic CAN and Vehicle CAN, and between the Vehicle CAN and Engine CAN.</p>


NAMUX 4 Architecture (Phase 1): T680



NAMUX 3 Architecture



NAMUX 4 Architecture



Technical data

This code relates to a communication issue and not to a specific component.

Possible causes

- Breakdown in communication in the CAN network.
- Interruption, short circuit to ground, or short circuit to supply in the CAN network wiring.

Additional information

No additional information available

Diagnostic Step-by-Step



Perform the troubleshooting steps below using the breakout harness, if necessary, to check electrical components, such as sensors, electrical control units, and harnesses. Back probing is not recommended, as it could damage the harness. The ignition should always be in the OFF position when connecting or disconnecting electrical components in order to reduce the likelihood of damage to electrical components.





- Disconnecting the EAS connectors during the troubleshooting process will result in multiple errors.
- For specific electrical component information and pinout locations, always refer to the technical data.
- It is necessary to exit the fault code menu in DAVIE and run the diagnostic test again to identify a change in errors.
- Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive fault codes. Refer to the 'possible causes' section.



Step 1	Step ID 1163a	SRT
Visual Inspection OFF the ignition key, disconnect the connector from component and ECU. Visually inspect all applicable connectors (bent, broken, corroded or loose pins) damage to wire harness, sign of exhaust leaks during each step of the diagnostic		

	<p>procedure.</p> <p>Was there evidence of any of the above?</p> <ul style="list-style-type: none">• No: Proceed to step 2.• Yes: Make the appropriate repairs or component replacements. <p>Use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">• If this related fault is no longer active, then this issue has been resolved.• If this related fault is still active, Proceed to step 2					
	<table><tr><td>Step 2</td><td>Step ID 1163b</td><td>SRT</td></tr></table> <p>Data check</p> <ul style="list-style-type: none">• Lookup the technical data of the specific system• Perform the checking data test of the specific component <p>Is test pass?</p> <ul style="list-style-type: none">• No: Proceed to step 3• Yes : Proceed to step4			Step 2	Step ID 1163b	SRT
	Step 2	Step ID 1163b	SRT			
	<table><tr><td>Step 3</td><td>Step ID 1163c</td><td>SRT</td></tr></table> <p>Repair or replace component</p> <ul style="list-style-type: none">• Repair or replace the component, also check for electrical connection and wiring harness.• Reconnect the connector• ON the ignition key <p>Use DAVIE to re-check for the presence of active faults:</p> <ul style="list-style-type: none">• Is DTC fault active: Proceed to step 4• Is DTC fault inactive: Issue resolved. Clear inactive fault.			Step 3	Step ID 1163c	SRT
Step 3	Step ID 1163c	SRT				
<table><tr><td>Step 4</td><td>Step ID 1163d</td><td>SRT</td></tr></table> <p>For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the Engine Support Call Center at 1-800-477-0251.</p>			Step 4	Step ID 1163d	SRT	
Step 4	Step ID 1163d	SRT				
Verification Drive Cycle	<p>To validate repair, with the brakes set, turn the key to the ON position with the engine off, and allow 10 seconds for the system to initialize and run diagnostics. With the brakes set, start the engine and allow it to run at idle for 2 minutes.</p>					
	<p>Back to Index</p>					

P1167


Code number	P1167
Fault code description	Fuel temperature - Data valid but too high, least severe
Fault code information	3 drive cycle recovery Readiness group – None Freeze frame type – Fuel
Description of component(s)	The fuel temperature is measured in the low-pressure fuel supply gallery between the common rail pump units. Effect on the system: <ul style="list-style-type: none"> Preventing automatic fuel module water draining activation when the fuel temperature is very low (the water present may be frozen). Limitation of the engine torque when the fuel temperature is too high.
Location of component(s)	<p>F803</p> 
Diagnostic condition	This diagnostic runs continuously when the ignition is on.
Set condition of fault code	The PCI ECU (D420) detects that the fuel temperature is more than 92°C [198°F] for more than 300 seconds.
Reset condition of fault code	This DTC changes to inactive when the fault is no longer detected. To validate the repair, key off the ignition for at least 15 seconds, key on again. Then start the engine and let it idle for more than 300 seconds.

Electrical diagram(s)	<div><p>Wiring harness connector D420.A front view</p><p>Wiring harness connector F803 front view</p><p>D420 PCI ECU F803 fuel temperature sensor</p><table><tr><th>D420</th><th>F803</th><th>Function</th></tr><tr><td>A42</td><td>1</td><td>Signal, fuel temperature</td></tr><tr><td>A60</td><td>3</td><td>Ground</td></tr></table></div>	D420	F803	Function	A42	1	Signal, fuel temperature	A60	3	Ground
D420	F803	Function								
A42	1	Signal, fuel temperature								
A60	3	Ground								
Technical data	<p>Component check, fuel temperature sensor (F803)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key off the ignition.• Disconnect connector F803• Measure on component connector F803									



	<table><tr><th>Pin (+ probe)</th><th>Pin (- probe)</th><th>Value</th><th>Additional information</th></tr><tr><td>1</td><td>3</td><td>5633–6120 Ω</td><td>Resistance value at 0°C [34°F]</td></tr><tr><td></td><td></td><td>2411–2573 Ω</td><td>Resistance value at 20°C [68°F]</td></tr><tr><td></td><td></td><td>1128–1213 Ω</td><td>Resistance value at 40°C [104°F]</td></tr><tr><td></td><td></td><td>568–619 Ω</td><td>Resistance value at 60°C [140°F]</td></tr><tr><td></td><td></td><td>306–337 Ω</td><td>Resistance value at 80°C [176°F]</td></tr><tr><td></td><td></td><td>176–196 Ω</td><td>Resistance value at 100°C [212°F]</td></tr></table> <p>Component & wiring check, ECU (D420)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key off the ignition.• Disconnect connector F803• Measure on the front side of wiring harness connector F803 <table><tr><th>Pin (+ probe)</th><th>Pin (- probe)</th><th>Value</th><th>Additional information</th></tr><tr><td>1</td><td>3</td><td>5V</td><td>Ignition keyed on</td></tr></table>	Pin (+ probe)	Pin (- probe)	Value	Additional information	1	3	5633–6120 Ω	Resistance value at 0°C [34°F]			2411–2573 Ω	Resistance value at 20°C [68°F]			1128–1213 Ω	Resistance value at 40°C [104°F]			568–619 Ω	Resistance value at 60°C [140°F]			306–337 Ω	Resistance value at 80°C [176°F]			176–196 Ω	Resistance value at 100°C [212°F]	Pin (+ probe)	Pin (- probe)	Value	Additional information	1	3	5V	Ignition keyed on
Pin (+ probe)	Pin (- probe)	Value	Additional information																																		
1	3	5633–6120 Ω	Resistance value at 0°C [34°F]																																		
		2411–2573 Ω	Resistance value at 20°C [68°F]																																		
		1128–1213 Ω	Resistance value at 40°C [104°F]																																		
		568–619 Ω	Resistance value at 60°C [140°F]																																		
		306–337 Ω	Resistance value at 80°C [176°F]																																		
		176–196 Ω	Resistance value at 100°C [212°F]																																		
Pin (+ probe)	Pin (- probe)	Value	Additional information																																		
1	3	5V	Ignition keyed on																																		
Possible causes	<ul style="list-style-type: none">• Restrictions in the fuel to tank return circuit or faulty fuel pressure regulating valve.• Check the fuel pressure according to the prescribed job.• Excessive dumping of fuel from the common rail through common rail pressure release valve (L094).																																				
Additional information	The low-pressure fuel temperature is measured by the fuel temperature sensor (F803).																																				
Diagnostic Step-by-Step	<div><div></div><div><p>Perform the troubleshooting steps below using the breakout harness, if necessary, to check electrical components, such as sensors, electrical control units, and harnesses. Back probing is not recommended, as it could damage the harness. The ignition should always be in the OFF position when connecting or disconnecting electrical components in order to reduce the likelihood of damage to electrical components.</p></div></div> <div><div></div><ul style="list-style-type: none">• Disconnecting the EAS connectors during the troubleshooting process will result in multiple errors.• For specific electrical component information and pinout locations, always refer to the technical data.• It is necessary to exit the fault code menu in DAVIE and run the diagnostic test again to identify a change in errors.• Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive fault codes. Refer to the 'possible causes' section.</div> <table><tr><td>Step 1</td><td>Step ID 1167a</td><td>SRT</td></tr><tr><td colspan="3"><p>Verify fuel level.</p><p>Verify that the fuel level is within normal range. Low fuel in a high ambient temperature can cause high fuel temperatures. Is fuel below the normal range and is the ambient temperature high?</p><ul style="list-style-type: none">• Yes – Add fuel. Proceed to step 2.• No – Proceed to step 2.</td></tr></table>	Step 1	Step ID 1167a	SRT	<p>Verify fuel level.</p> <p>Verify that the fuel level is within normal range. Low fuel in a high ambient temperature can cause high fuel temperatures. Is fuel below the normal range and is the ambient temperature high?</p> <ul style="list-style-type: none">• Yes – Add fuel. Proceed to step 2.• No – Proceed to step 2.																																
Step 1	Step ID 1167a	SRT																																			
<p>Verify fuel level.</p> <p>Verify that the fuel level is within normal range. Low fuel in a high ambient temperature can cause high fuel temperatures. Is fuel below the normal range and is the ambient temperature high?</p> <ul style="list-style-type: none">• Yes – Add fuel. Proceed to step 2.• No – Proceed to step 2.																																					

	<table><tr><td>Step 2</td><td>Step ID 1167b</td><td>SRT</td></tr><tr><td colspan="3">Check for fault codes Use DAVIE to find any other active fuel temperature fault codes. Are there other active fuel temperature fault codes?<ul style="list-style-type: none">• Yes – Proceed to the other active fuel temperature fault codes.• No – Proceed to step 3.</td></tr></table>	Step 2	Step ID 1167b	SRT	Check for fault codes Use DAVIE to find any other active fuel temperature fault codes. Are there other active fuel temperature fault codes? <ul style="list-style-type: none">• Yes – Proceed to the other active fuel temperature fault codes.• No – Proceed to step 3.		
	Step 2	Step ID 1167b	SRT				
	Check for fault codes Use DAVIE to find any other active fuel temperature fault codes. Are there other active fuel temperature fault codes? <ul style="list-style-type: none">• Yes – Proceed to the other active fuel temperature fault codes.• No – Proceed to step 3.						
<table><tr><td>Step 3</td><td>Step ID 1167c</td><td>SRT</td></tr><tr><td colspan="3">Validation<ul style="list-style-type: none">• Turn the key switch ON.• Drive the truck under conditions similar to those that caused the fault code.• Use DAVIE to view the active fault codes.Is P1167 still active?<ul style="list-style-type: none">• Yes – Contact the Engine Support Center (ESC).• No – The repair is complete.</td></tr></table>	Step 3	Step ID 1167c	SRT	Validation <ul style="list-style-type: none">• Turn the key switch ON.• Drive the truck under conditions similar to those that caused the fault code.• Use DAVIE to view the active fault codes. Is P1167 still active? <ul style="list-style-type: none">• Yes – Contact the Engine Support Center (ESC).• No – The repair is complete.			
Step 3	Step ID 1167c	SRT					
Validation <ul style="list-style-type: none">• Turn the key switch ON.• Drive the truck under conditions similar to those that caused the fault code.• Use DAVIE to view the active fault codes. Is P1167 still active? <ul style="list-style-type: none">• Yes – Contact the Engine Support Center (ESC).• No – The repair is complete.							
Verification Drive Cycle	To validate repair, drive the truck under normal conditions until the coolant temperature reaches a minimum of 150°F. This cycle can be conducted with a loaded trailer or bobtail.						
	Back to Index						


P1168

Code number	P1168
Fault code description	Fuel temperature - Data valid but too high, moderately severe
Fault code information	<p>1 trip MIL</p> <p>3 drive cycle recovery</p> <p>Readiness group – None</p> <p>Freeze frame type - Fuel</p>
Description of component(s)	<p>The fuel temperature is measured in the low-pressure fuel supply gallery between the common rail pump units.</p> <p>Effect on the system:</p> <ul style="list-style-type: none"> preventing automatic fuel module water draining activation when the fuel temperature is very low (the water present may be frozen). limitation of the engine torque when the fuel temperature is too high.
Location of component(s)	<p>F803</p> 
Diagnostic condition	This diagnostic runs when the engine is running for more than 200 seconds.
Set condition of fault code	The PCI ECU (D420) detects that the fuel temperature is more than 95°C [203°F] for more than 300 seconds.
Reset condition of fault code	This DTC changes to inactive when the fault is no longer detected. To validate the repair, key off the ignition for at least 15 seconds, key on again. Then start the engine and let it idle for more than 300 seconds.

Electrical diagram(s)



Wiring harness connector D420.A front view





Wiring harness connector F803 front view

D420	F803	Function
A42	1	Signal, fuel temperature
A60	3	Ground

Technical data



Component check, fuel temperature sensor (F803)
Preparation



	<ul style="list-style-type: none">• Key off the ignition.• Disconnect connector F803• Measure on component connector F803 <table><tr><th>Pin (+ probe)</th><th>Pin (- probe)</th><th>Value</th><th>Additional information</th></tr><tr><td>1</td><td>3</td><td>5633–6120 Ω</td><td>Resistance value at 0°C [34°F]</td></tr><tr><td>1</td><td>3</td><td>2411–2573 Ω</td><td>Resistance value at 20°C [68°F]</td></tr><tr><td>1</td><td>3</td><td>1128–1213 Ω</td><td>Resistance value at 40°C [104°F]</td></tr><tr><td>1</td><td>3</td><td>568–619 Ω</td><td>Resistance value at 60°C [140°F]</td></tr><tr><td>1</td><td>3</td><td>306–337 Ω</td><td>Resistance value at 80°C [176°F]</td></tr><tr><td>1</td><td>3</td><td>176–196 Ω</td><td>Resistance value at 100°C [212°F]</td></tr></table> <p>Component & wiring check, ECU (D420)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key off the ignition.• Disconnect connector F803• Measure on component connector F803 <table><tr><th>Pin (+ probe)</th><th>Pin (- probe)</th><th>Value</th><th>Additional information</th></tr><tr><td>1</td><td>3</td><td>5V</td><td>Ignition</td></tr></table>	Pin (+ probe)	Pin (- probe)	Value	Additional information	1	3	5633–6120 Ω	Resistance value at 0°C [34°F]	1	3	2411–2573 Ω	Resistance value at 20°C [68°F]	1	3	1128–1213 Ω	Resistance value at 40°C [104°F]	1	3	568–619 Ω	Resistance value at 60°C [140°F]	1	3	306–337 Ω	Resistance value at 80°C [176°F]	1	3	176–196 Ω	Resistance value at 100°C [212°F]	Pin (+ probe)	Pin (- probe)	Value	Additional information	1	3	5V	Ignition
Pin (+ probe)	Pin (- probe)	Value	Additional information																																		
1	3	5633–6120 Ω	Resistance value at 0°C [34°F]																																		
1	3	2411–2573 Ω	Resistance value at 20°C [68°F]																																		
1	3	1128–1213 Ω	Resistance value at 40°C [104°F]																																		
1	3	568–619 Ω	Resistance value at 60°C [140°F]																																		
1	3	306–337 Ω	Resistance value at 80°C [176°F]																																		
1	3	176–196 Ω	Resistance value at 100°C [212°F]																																		
Pin (+ probe)	Pin (- probe)	Value	Additional information																																		
1	3	5V	Ignition																																		
Possible causes	<ul style="list-style-type: none">• Restriction in the fuel to tank return circuit or faulty fuel pressure regulating valve. Check the fuel pressure according to the prescribed job.• Excessive dumping of fuel from the common rail through the common rail pressure release valve (L094).																																				
Additional information	<ul style="list-style-type: none">• The low-pressure fuel temperature is measured by the fuel temperature sensor (F803).• Engine torque is reduced with this DTC active.																																				
Diagnostic Step-by-Step	<div><div></div><div><p>Perform the troubleshooting steps below using the breakout harness, if necessary, to check electrical components, such as sensors, electrical control units, and harnesses. Back probing is not recommended, as it could damage the harness. The ignition should always be in the OFF position when connecting or disconnecting electrical components in order to reduce the likelihood of damage to electrical components.</p><ul style="list-style-type: none">• Disconnecting the EAS connectors during the troubleshooting process will result in multiple errors.• For specific electrical component information and pinout locations, always refer to the technical data.• It is necessary to exit the fault code menu in DAVIE and run the diagnostic test again to identify a change in errors.• Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive fault codes. Refer to the 'possible causes' section.</div></div> <table><tr><td>Step 1</td><td>Step ID 1168a</td><td>SRT</td></tr><tr><td colspan="3">Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.</td></tr></table>	Step 1	Step ID 1168a	SRT	Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.																																
Step 1	Step ID 1168a	SRT																																			
Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.																																					


	Step 2	Step ID 1168b	SRT
	Verify that the fuel level is within normal range. Low fuel in a high ambient temperature can cause high fuel temperatures. Is fuel below the normal range and is the ambient temperature high? <ul style="list-style-type: none"> • Yes – Add fuel. Proceed to step 3. • No – Proceed to step 3. 		
	Step 3	Step ID 1168c	SRT
	Does the fuel pressure pass these tests? <ul style="list-style-type: none"> • Yes – Proceed to step 4. • No – Repair as needed. Proceed to the validation step. 		
	Step 4	Step ID 1168d	SRT
	Troubleshooting steps <ul style="list-style-type: none"> • Drive the truck under conditions similar to those that caused the fault code. • Stop the truck. • Use DAVIE to view the fuel temperature. <ul style="list-style-type: none"> • A passing fuel blender temperature is 100 to 125°F. • A failing fuel blender temperature is above 160°F. • A passing fuel blender bypassed fuel is 80 to 100°F. Is the fuel blender temperature above 160°F? <ul style="list-style-type: none"> • Yes – Replace the fuel blender. Proceed to step 4. • No – Contact Engine Support Center (ESC). 		
	Step 5	Step ID 1168e	SRT
	Troubleshooting steps <ul style="list-style-type: none"> • Turn the key switch OFF. • Disconnect the fuel temperature sensor. • Inspect the fuel temperature sensor connector/harness interface for: <ul style="list-style-type: none"> ▪ corroded or dirty pins, ▪ damaged pins, ▪ pushed back or expanded pins, ▪ loose connector, ▪ moisture in or on the connector, ▪ connector shell damage, ▪ missing or damaged connector seals and/or ▪ wire insulation damage. Has dirt or damage been found? <ul style="list-style-type: none"> • Yes – Clean, repair or replace the damaged connection or harness if possible. Proceed to step 5. • No – Proceed to step 5. 		
	Step 6	Step ID 1168f	SRT
	Troubleshooting steps <ul style="list-style-type: none"> • Turn the key switch OFF. • Disconnect the fuel temperature sensor. 		

	<ul style="list-style-type: none">Pin the power supply leg.<ul style="list-style-type: none">If voltage is 4.8 V to 5.2 V – Pass. Proceed to step 6.If voltage is lower than 4.8 V or higher than 5.2 V – Fail. Repair/replace harness as needed, then retest. Proceed to step 6.			
	<table><tr><td>Step 7</td><td>Step ID 1168g</td><td>SRT</td></tr></table> <p>Troubleshooting steps</p> <ul style="list-style-type: none">Turn the key switch OFF.Disconnect the fuel sensor.Place a jumper wire between the power supply and harness at the sensor connector.Pin the return leg of the circuit.<ul style="list-style-type: none">If voltage is 4.8 V to 5.2 V – Pass. Proceed to step 7.If voltage is lower than 4.8 V or higher than 5.2 V – Fail. Repair/replace harness on signal return leg, as needed, then retest. Proceed to step 7	Step 7	Step ID 1168g	SRT
	Step 7	Step ID 1168g	SRT	
	<table><tr><td>Step 8</td><td>Step ID 1168h</td><td>SRT</td></tr></table> <p>Troubleshooting steps</p> <ul style="list-style-type: none">Turn the key switch OFF.Disconnect the fuel temperature sensor.Pin the sensor signal pin to the chassis ground. <p>Does the ohmmeter indicate that there is continuity between the sensor signal pin and the chassis ground?</p> <ul style="list-style-type: none">Yes – Repair/replace the grounded portion of the circuit on the return leg, as needed, then retest. Proceed to step 7.No – Proceed to step 8.	Step 8	Step ID 1168h	SRT
	Step 8	Step ID 1168h	SRT	
<table><tr><td>Step 9</td><td>Step ID 1168i</td><td>SRT</td></tr></table> <p>Troubleshooting steps</p> <ul style="list-style-type: none">Turn the key switch ON.Drive the truck under conditions similar to those that caused the fault code.Use DAVIE to view the active fault codes. <p>Is P1168 still active?</p> <ul style="list-style-type: none">Yes – Contact the Engine Support Center (ESC). Proceed to step 10.No – The repair is complete.	Step 9	Step ID 1168i	SRT	
Step 9	Step ID 1168i	SRT		
<table><tr><td>Step 10</td><td>Step ID 1168j</td><td>SRT</td></tr></table> <p>For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the Engine Support Call Center at 1-800-477-0251.</p>	Step 10	Step ID 1168j	SRT	
Step 10	Step ID 1168j	SRT		
Verification Drive Cycle	To verify the repairs, drive the vehicle with the brakes set, start the engine and allow it to run at idle for 2 minutes.			
	Back to Index			

P1180

Code number	P1180
Fault code description	Fuel temperature - Data valid but too high, moderately severe
Fault code information	3 drive cycle recovery Readiness group – None Freeze frame type – Fuel
Description of component(s)	<p>The fuel temperature is measured in the low-pressure fuel supply gallery between the common rail pump units.</p> <p>Effect on the system:</p> <ul style="list-style-type: none"> Preventing automatic fuel module water draining activation when the fuel temperature is very low (the water present may be frozen). Limitation of the engine torque when the fuel temperature is too high.
Location of component(s)	
Diagnostic condition	This diagnostic runs continuously when the engine is running.
Set condition of fault code	 <p>P fuel pressure in bar Rpm- Engine speed in rpm</p>

	 <p>P fuel pressure in psi Rpm- Engine speed in rpm</p> <p>The PCI ECU (D420) detects that:</p> <ul style="list-style-type: none"> • fuel temperature is more than 95°C [203°F], and • fuel pressure is too low (gray area of the graph), and • ambient temperature is more than 45°C [113°F], and • fuel tank level is low
Reset condition of fault code	<p>This DTC changes to inactive when the fault is no longer detected. To validate the repair, key off the ignition for at least 15 seconds, key on again. Then start the engine and operate it at several engine speeds</p>
Electrical diagram(s)	 <p>Wiring harness connector D420.A front view</p>



Wiring harness connector F803 front view

D420PCI ECU
F803fuel temperature sensor3

D420	F803	Function
A42	1	Signal, fuel temperature
A60	3	Ground

Technical data

Component check, fuel temperature sensor (F803)

Preparation

- Key off the ignition.
- Disconnect connector F803
- Measure on component connector F803

Pin (+ probe)	Pin (- probe)	Value	Additional information
1	3	5633–6120 Ω	Resistance value at 0°C [34°F]
		2411–2573 Ω	Resistance value at 20°C [68°F]
		1128–1213 Ω	Resistance value at 40°C [104°F]
		568–619 Ω	Resistance value at 60°C [140°F]
		306–337 Ω	Resistance value at 80°C [176°F]
		176–196 Ω	Resistance value at 100°C [212°F]

Component & wiring check, ECU (D420)

Preparation

- Key off the ignition.
- Disconnect connector F803
- Measure on the front side of wiring harness connector F803



Pin (+ probe)	Pin (- probe)	Value	Additional information
1	3	5V	Ignition keyed on

Possible causes


Fuel is hot due to low fuel tank level and high ambient temperatures.





Additional information

- The low-pressure fuel pressure is measured by the fuel pressure sensor (F801).
- The low-pressure fuel temperature is measured by the fuel temperature sensor (F803).
- Engine torque is reduced.

Diagnostic Step-by-Step	<div><div></div><div></div></div> <div><p>Perform the troubleshooting steps below using the breakout harness, if necessary, to check electrical components, such as sensors, electrical control units, and harnesses. Back probing is not recommended, as it could damage the harness. The ignition should always be in the OFF position when connecting or disconnecting electrical components in order to reduce the likelihood of damage to electrical components.</p><ul style="list-style-type: none">• Disconnecting the EAS connectors during the troubleshooting process will result in multiple errors.• For specific electrical component information and pinout locations, always refer to the technical data.• It is necessary to exit the fault code menu in DAVIE and run the diagnostic test again to identify a change in errors.• Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive fault codes. Refer to the 'possible causes' section.</div>					
	<table><tr><td>Step 1</td><td>Step ID 1180a</td><td>SRT</td></tr><tr><td colspan="3"><p>Verify fuel level.</p><p>Verify that the fuel level is within normal range. Low fuel in a high ambient temperature can cause high fuel temperatures. Is fuel below 5% and is the ambient temperature high?</p><ul style="list-style-type: none">• Yes – Add fuel. Proceed to other fault codes.• No – Proceed to other fault codes.</td></tr></table>	Step 1	Step ID 1180a	SRT	<p>Verify fuel level.</p> <p>Verify that the fuel level is within normal range. Low fuel in a high ambient temperature can cause high fuel temperatures. Is fuel below 5% and is the ambient temperature high?</p> <ul style="list-style-type: none">• Yes – Add fuel. Proceed to other fault codes.• No – Proceed to other fault codes.	
Step 1	Step ID 1180a	SRT				
<p>Verify fuel level.</p> <p>Verify that the fuel level is within normal range. Low fuel in a high ambient temperature can cause high fuel temperatures. Is fuel below 5% and is the ambient temperature high?</p> <ul style="list-style-type: none">• Yes – Add fuel. Proceed to other fault codes.• No – Proceed to other fault codes.						
Verification Drive Cycle	<p>To validate repair, drive the truck under normal conditions until the coolant temperature reaches a minimum of 150°F. This cycle can be conducted with a loaded trailer or bobtail.</p>					
	<div>Back to Index</div>					


P1191





Code number	P1191
Fault code description	Fuel filter – Clogged
Fault code information	3 drive cycle recovery Readiness group – None Freeze frame type – Fuel
Description of component(s)	 <p>The fuel filter filters dirt out of the fuel. The fuel enters via connection (1) and is forced through the filter element (2). There is a central tube (3) in the filter element. The filtered fuel flows to the fuel filter holder. There is an orifice in the screw on the fuel filter holder to bleed the air out of the system (filter). Open the screw to bleed air out of the system.</p>
Location of component(s)	Not available/required for this code
Diagnostic condition	This diagnostic runs continuously when the engine is running.
Set condition of fault code	The PCI ECU (D420) detects that: <ul style="list-style-type: none"> • fuel temperature is more than 95°C [203°F] and • fuel pressure is too low (gray area of the graph)

	 <p>P Fuel pressure in bar rpm Engine speed in rpm</p>  <p>P Fuel pressure in psi rpm Engine speed in rpm</p>
Reset condition of fault code	This DTC changes to inactive when the fault is no longer detected. To validate the repair, key off the ignition for at least 15 seconds, key on again. Then start the engine and operate it at several engine speeds.
Electrical diagram(s)	Not available/required for this code
Technical data	Not available/required for this code
Possible causes	Clogged fuel filter
Additional information	<ul style="list-style-type: none"> The low-pressure fuel pressure is measured by the fuel pressure sensor (F801). The low-pressure fuel temperature is measured by the fuel temperature sensor (F803).
Diagnostic Step-by-Step	<p> Perform the troubleshooting steps below using the breakout harness, if necessary, to check electrical components, such as sensors, electrical control units, and harnesses. Back probing is not recommended, as it could damage the harness. The ignition should always be in the OFF position when connecting or disconnecting electrical components to reduce the likelihood of damage to electrical components</p> <p> <ul style="list-style-type: none"> This troubleshooting tree is based on the assumption that supply power and ground to the PCI are functioning properly. </p>

	<ul style="list-style-type: none">• Disconnecting the PCI connectors during the troubleshooting process will result in multiple errors.• For specific electrical component information and pinout locations, always refer to the technical data in Rapido.• It is necessary to exit the 'active errors' screen in DAVIE and run the diagnostic test again to identify changes in errors.• Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive codes. Refer to the 'possible causes' section in Rapido.						
	<table><tr><td>Step 1</td><td>Step ID 1191a</td><td>SRT</td></tr><tr><td colspan="3">Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.</td></tr></table>	Step 1	Step ID 1191a	SRT	Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.		
	Step 1	Step ID 1191a	SRT				
	Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.						
	<table><tr><td>Step 2</td><td>Step ID 1191b</td><td>SRT</td></tr><tr><td colspan="3">Check fuel supply line for leakage and blockage: Repair or replace the supply line and use DAVIE to re-check for the presence of active faults.<ul style="list-style-type: none">• Fault inactive – issue resolve• Fault active – Proceed to step 3</td></tr></table>	Step 2	Step ID 1191b	SRT	Check fuel supply line for leakage and blockage: Repair or replace the supply line and use DAVIE to re-check for the presence of active faults. <ul style="list-style-type: none">• Fault inactive – issue resolve• Fault active – Proceed to step 3		
Step 2	Step ID 1191b	SRT					
Check fuel supply line for leakage and blockage: Repair or replace the supply line and use DAVIE to re-check for the presence of active faults. <ul style="list-style-type: none">• Fault inactive – issue resolve• Fault active – Proceed to step 3							
<table><tr><td>Step 3</td><td>Step ID 1191c</td><td>SRT</td></tr><tr><td colspan="3">Replace: Fuel filter Replace the identified faulty component. Use DAVIE to re-check for the presence of active faults.<ul style="list-style-type: none">• Fault inactive – issue resolve• Fault active – Proceed to step 4</td></tr></table>	Step 3	Step ID 1191c	SRT	Replace: Fuel filter Replace the identified faulty component. Use DAVIE to re-check for the presence of active faults. <ul style="list-style-type: none">• Fault inactive – issue resolve• Fault active – Proceed to step 4			
Step 3	Step ID 1191c	SRT					
Replace: Fuel filter Replace the identified faulty component. Use DAVIE to re-check for the presence of active faults. <ul style="list-style-type: none">• Fault inactive – issue resolve• Fault active – Proceed to step 4							
<table><tr><td>Step 4</td><td>Step ID 1191d</td><td>SRT</td></tr><tr><td colspan="3">Contact the PACCAR Engine Support Call Center For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center at 1-800-477-0251.</td></tr></table>	Step 4	Step ID 1191d	SRT	Contact the PACCAR Engine Support Call Center For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center at 1-800-477-0251.			
Step 4	Step ID 1191d	SRT					
Contact the PACCAR Engine Support Call Center For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center at 1-800-477-0251.							
Verification Drive Cycle	To validate the repair, key off the ignition for at least 15 seconds, key on again. Then start the engine and operate it at several engine speeds.						
	Back to Index						


P1194

Code number	P1194
Fault code description	Fuel filter - Very clogged
Fault code information	3 drive cycle recovery Readiness group – None Freeze frame type – Fuel
Description of component(s)	 <p>The fuel filter filters dirt out of the fuel.</p> <p>The fuel enters via connection (1) and is forced through the filter element (2). There is a central tube (3) in the filter element. The filtered fuel flows to the fuel filter holder. There is an orifice in the screw on the fuel filter holder to bleed the air out of the system (filter).</p> <p>Open the screw to bleed air out of the system.</p>
Location of component(s)	Not available/required for this code
Diagnostic condition	This diagnostic runs continuously when the engine is running.
Set condition of fault code	The PCI ECU (D420) detects that: <ul style="list-style-type: none"> • fuel temperature is more than 95°C [203°F], and • fuel pressure is too low (gray area of the graph).



	 <p>P Fuel pressure in bar rpm Engine speed in rpm</p>  <p>P Fuel pressure in psi rpm Engine speed in rpm</p>
Reset condition of fault code	This DTC changes to inactive when the fault is no longer detected. To validate the repair, key off the ignition for at least 15 seconds, key on again. Then start the engine and operate it at several engine speeds.
Electrical diagram(s)	Not available/required for this code
Technical data	Not available/required for this code
Possible causes	Very clogged fuel filter.
Additional information	<ul style="list-style-type: none"> The low-pressure fuel pressure is measured by the fuel pressure sensor (F801). The low-pressure fuel temperature is measured by the fuel temperature sensor (F803). Engine torque is reduced.
Diagnostic Step-by-Step	<p> Perform the troubleshooting steps below using the breakout harness, if necessary, to check electrical components, such as sensors, electrical control units, and harnesses. Back probing is not recommended, as it could damage the harness. The ignition should always be in the OFF position when connecting or disconnecting electrical components to reduce the likelihood of damage to electrical components</p> <p> <ul style="list-style-type: none"> This troubleshooting tree is based on the assumption that supply power and ground to the PCI are functioning properly. Disconnecting the PCI connectors during the troubleshooting process will result in multiple errors. For specific electrical component information and pinout locations, </p>

	<p>always refer to the technical data in Rapido.</p> <ul style="list-style-type: none">• It is necessary to exit the 'active errors' screen in DAVIE and run the diagnostic test again to identify changes in errors.• Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive codes. Refer to the 'possible causes' section in Rapido.						
	<table><tr><td>Step 1</td><td>Step ID 1194a</td><td>SRT</td></tr><tr><td colspan="3">Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.</td></tr></table>	Step 1	Step ID 1194a	SRT	Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.		
Step 1	Step ID 1194a	SRT					
Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.							
	<table><tr><td>Step 2</td><td>Step ID 1194b</td><td>SRT</td></tr><tr><td colspan="3">Check fuel supply line for leakage and blockage: Repair or replace the supply line and use DAVIE to re-check for the presence of active faults.<ul style="list-style-type: none">• Fault inactive – issue resolve• Fault active – Proceed to step 3</td></tr></table>	Step 2	Step ID 1194b	SRT	Check fuel supply line for leakage and blockage: Repair or replace the supply line and use DAVIE to re-check for the presence of active faults. <ul style="list-style-type: none">• Fault inactive – issue resolve• Fault active – Proceed to step 3		
Step 2	Step ID 1194b	SRT					
Check fuel supply line for leakage and blockage: Repair or replace the supply line and use DAVIE to re-check for the presence of active faults. <ul style="list-style-type: none">• Fault inactive – issue resolve• Fault active – Proceed to step 3							
	<table><tr><td>Step 3</td><td>Step ID 1194c</td><td>SRT</td></tr><tr><td colspan="3">Replace: Fuel filter Replace the identified faulty component. Use DAVIE to re-check for the presence of active faults.<ul style="list-style-type: none">• Fault inactive – issue resolve• Fault active – Proceed to step 4</td></tr></table>	Step 3	Step ID 1194c	SRT	Replace: Fuel filter Replace the identified faulty component. Use DAVIE to re-check for the presence of active faults. <ul style="list-style-type: none">• Fault inactive – issue resolve• Fault active – Proceed to step 4		
Step 3	Step ID 1194c	SRT					
Replace: Fuel filter Replace the identified faulty component. Use DAVIE to re-check for the presence of active faults. <ul style="list-style-type: none">• Fault inactive – issue resolve• Fault active – Proceed to step 4							
	<table><tr><td>Step 4</td><td>Step ID 1194d</td><td>SRT</td></tr><tr><td colspan="3">Contact the PACCAR Engine Support Call Center For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center at 1-800-477-0251.</td></tr></table>	Step 4	Step ID 1194d	SRT	Contact the PACCAR Engine Support Call Center For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center at 1-800-477-0251.		
Step 4	Step ID 1194d	SRT					
Contact the PACCAR Engine Support Call Center For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center at 1-800-477-0251.							
Verification Drive Cycle	To validate the repair, key off the ignition for at least 15 seconds, key on again. Then start the engine and operate it at several engine speeds.						
	Back to Index						


P1195

Code number	P1195
Fault code description	Engine rail pressure - Data erratic, intermittent, or incorrect at ignition on
Fault code information	2 trip MIL 3 drive cycle recovery Readiness group – None Freeze frame type - Fuel
Description of component(s)	<p>The rail pressure is measured in the common rail.</p> <p>The rail pressure sensor is part of the common rail and is not interchangeable as a separate part.</p> <p>Effect on the system:</p> <ul style="list-style-type: none"> feedback on the rail pressure control. <p>The rail pressure is closed-loop controlled. A comparison is made between the rail pressure demands determined by the ECU and the rail pressure feedback measured by the common rail pressure sensor.</p>
Location of component(s)	 <p>The diagram illustrates the engine's internal components, including the fuel rail and sensor. A green dot labeled 'F854' indicates the location of the rail pressure sensor on the common rail. A callout box provides a magnified view of this area.</p>
Diagnostic condition	<p>This diagnostic runs when:</p> <ul style="list-style-type: none"> engine is not running, and; the ignition is keyed on after it has been off for more than 200 seconds, and; fuel temperature is more than 0°C [32°F]
Set condition of fault code	The PCI ECU (D420) detects that the actual rail pressure is more than 245 bar [3553 psi].
Reset condition of fault code	This DTC changes to inactive when the fault is no longer detected. To validate the repair, drive the vehicle until the coolant temperature is at least 70°C [158°F] in normal driving conditions. This activity can be best conducted with a loaded vehicle/trailer.

Electrical diagram(s)



Wiring harness connector D420.A front view



Wiring harness connector F854 front view

D420 PCI ECU

F854 engine rail pressure sensor



D420	F854	Function
A44	2	Ground
A48	3	Power supply
A52	1	Signal, common rail pressure

Technical data

Component & wiring check, ECU (D420)


Preparation

- Key off the ignition.
- Disconnect connector F854


	<ul style="list-style-type: none">Measure on the front side of wiring harness connector F854 <table><tr><th>Pin (+ probe)</th><th>Pin (- probe)</th><th>Value</th><th>Additional information</th></tr><tr><td>3</td><td>2</td><td>5V</td><td>Ignition keyed on</td></tr></table>	Pin (+ probe)	Pin (- probe)	Value	Additional information	3	2	5V	Ignition keyed on										
Pin (+ probe)	Pin (- probe)	Value	Additional information																
3	2	5V	Ignition keyed on																
Possible causes	Common rail pressure sensor deviation																		
Additional information	<ul style="list-style-type: none">For this diagnostic, the actual rail pressure is monitored when the engine is not running.The rail pressure is measured in the common rail by the common rail pressure sensor (F854).Engine torque is reduced.																		
Diagnostic Step-by-Step	<div><div></div><div><p>Perform the troubleshooting steps below using the breakout harness, if necessary, to check electrical components, such as sensors, electrical control units, and harnesses. Back probing is not recommended, as it could damage the harness. The ignition should always be in the OFF position when connecting or disconnecting electrical components in order to reduce the likelihood of damage to electrical components.</p></div></div> <div><div></div><ul style="list-style-type: none">Disconnecting the EAS connectors during the troubleshooting process will result in multiple errors.For specific electrical component information and pinout locations, always refer to the technical data.It is necessary to exit the fault code menu in DAVIE and run the diagnostic test again to identify a change in errors.Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive fault codes. Refer to the 'possible causes' section.</div> <table><tr><td>Step 1</td><td>Step ID 1195a</td><td>SRT</td></tr><tr><td colspan="3">Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.</td></tr></table> <table><tr><td>Step 2</td><td>Step ID 1195b</td><td>SRT</td></tr><tr><td colspan="3"><p>Electrical Checks</p><p>Ensure that the ignition key/switch has been set to OFF before disconnecting related cables.</p><p>Based on the fault message provided, confirm that the following electrical values are within specified ranges or limits:</p><ul style="list-style-type: none">Supply and signal voltages (12V).Cable continuity (no opens or shorts).<p>Are measured electrical values outside of expected range or limits?</p><ul style="list-style-type: none">Yes - Proceed to step 3No - Proceed to step 4</td></tr></table> <table><tr><td>Step 3</td><td>Step ID 1195c</td><td>SRT</td></tr><tr><td colspan="3"><p>Make the appropriate repairs or component replacements and use DAVIE to re-check for the presence of active faults.</p><ul style="list-style-type: none">Fault inactive – issue resolveFault active - Proceed to step 4</td></tr></table>	Step 1	Step ID 1195a	SRT	Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.			Step 2	Step ID 1195b	SRT	<p>Electrical Checks</p> <p>Ensure that the ignition key/switch has been set to OFF before disconnecting related cables.</p> <p>Based on the fault message provided, confirm that the following electrical values are within specified ranges or limits:</p> <ul style="list-style-type: none">Supply and signal voltages (12V).Cable continuity (no opens or shorts). <p>Are measured electrical values outside of expected range or limits?</p> <ul style="list-style-type: none">Yes - Proceed to step 3No - Proceed to step 4			Step 3	Step ID 1195c	SRT	<p>Make the appropriate repairs or component replacements and use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">Fault inactive – issue resolveFault active - Proceed to step 4		
Step 1	Step ID 1195a	SRT																	
Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.																			
Step 2	Step ID 1195b	SRT																	
<p>Electrical Checks</p> <p>Ensure that the ignition key/switch has been set to OFF before disconnecting related cables.</p> <p>Based on the fault message provided, confirm that the following electrical values are within specified ranges or limits:</p> <ul style="list-style-type: none">Supply and signal voltages (12V).Cable continuity (no opens or shorts). <p>Are measured electrical values outside of expected range or limits?</p> <ul style="list-style-type: none">Yes - Proceed to step 3No - Proceed to step 4																			
Step 3	Step ID 1195c	SRT																	
<p>Make the appropriate repairs or component replacements and use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">Fault inactive – issue resolveFault active - Proceed to step 4																			

	Step 4	Step ID 1195d	SRT
	Replace: Common Rail Pressure sensor (Common Rail) Replace the Common Rail assembly, which includes the Common Rail Pressure sensor. NOTE: The entire Common Rail must be replaced. The Common Rail Pressure sensor is a non-serviceable part and cannot be replaced or repaired separately. Contact the PACCAR Engine Support Call Center to confirm replacement of the Common Rail assembly. Use DAVIE to re-check for the presence of active faults. <ul style="list-style-type: none"> • Fault inactive – issue resolve • If this related fault is still active, proceed to step 5 		
	Step 5	Step ID 1195e	SRT
	For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the Engine Support Call Center at 1-800-477-0251.		
Verification Drive Cycle	To validate repair, with the brakes set, turn the key to the ON position with the engine off, and allow 10 seconds for the system to initialize and run diagnostics.		
	Back to Index		

P1196



Code number	P1196
Fault code description	Engine rail pressure - Data erratic, intermittent, or incorrect at ignition on
Fault code information	2 trip MIL 3 drive cycle recovery Readiness group – None Freeze frame type – Fuel
Description of component(s)	<p>The rail pressure is measured in the common rail.</p> <p>The rail pressure sensor is part of the common rail and is not interchangeable as a separate part.</p> <p>Effect on the system:</p> <ul style="list-style-type: none"> feedback on the rail pressure control. <p>The rail pressure is closed-loop controlled. A comparison is made between the rail pressure demands determined by the ECU and the rail pressure feedback measured by the common rail pressure sensor.</p>
Location of component(s)	 <p>The diagram shows a side view of a diesel engine. A green arrow points to a sensor labeled F854, which is part of the common rail system. An inset image shows a close-up of the sensor area, with the label F854 pointing to the sensor.</p>
Diagnostic condition	<p>This diagnostic runs when:</p> <ul style="list-style-type: none"> engine is not running, and; the ignition is keyed on after it has been off for more than 200 seconds, and; fuel temperature is more than 0°C [32°F]
Set condition of fault code	The PCI ECU (D420) detects that the actual rail pressure is more than 140 bar [2030 psi].
Reset condition of fault code	This DTC changes to inactive when the fault is no longer detected. To validate the repair, drive the vehicle until the coolant temperature is at least 70°C [158°F] in normal driving conditions. This activity can be best conducted with a loaded vehicle/trailer.

Electrical diagram(s)




D420 PCI ECU
F854 engine rail pressure sensor

D420	F854	Function
A44	2	Ground
A48	3	Power supply



	A52 1 Signal, common rail pressure															
Technical data	<div>Component & wiring check, ECU (D420)</div> <div>Preparation<ul style="list-style-type: none">Key off the ignition.Disconnect connector F854Measure on the front side of wiring harness connector F854<table><tr><td>Pin</td><td>Pin</td><td></td><td></td></tr><tr><td>(+ probe)</td><td>(- probe)</td><td>Value</td><td>Additional information</td></tr><tr><td>3</td><td>2</td><td>5V</td><td>Ignition keyed on</td></tr></table></div>	Pin	Pin			(+ probe)	(- probe)	Value	Additional information	3	2	5V	Ignition keyed on			
Pin	Pin															
(+ probe)	(- probe)	Value	Additional information													
3	2	5V	Ignition keyed on													
Possible causes	Common rail pressure sensor deviation															
Additional information	<ul style="list-style-type: none">For this diagnostic, the actual rail pressure is monitored when the engine is not running.The rail pressure is measured in the common rail by the common rail pressure sensor (F854).Engine torque is reduced.															
Diagnostic Step-by-Step	<div><div></div><div><p>Perform the troubleshooting steps below using the breakout harness, if necessary, to check electrical components, such as sensors, electrical control units, and harnesses. Back probing is not recommended, as it could damage the harness. The ignition should always be in the OFF position when connecting or disconnecting electrical components in order to reduce the likelihood of damage to electrical components.</p><div><ul style="list-style-type: none">Disconnecting the EAS connectors during the troubleshooting process will result in multiple errors.For specific electrical component information and pinout locations, always refer to the technical data.It is necessary to exit the fault code menu in DAVIE and run the diagnostic test again to identify a change in errors.Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive fault codes. Refer to the 'possible causes' section.</div></div></div> <table><tr><td>Step 1</td><td>Step ID 1196a</td><td>SRT</td></tr><tr><td colspan="3">Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.</td></tr></table> <table><tr><td>Step 2</td><td>Step ID 1196b</td><td>SRT</td></tr><tr><td colspan="3"><div>Electrical Checks</div><div>Ensure that the ignition key/switch has been set to OFF before disconnecting related cables.</div><div>Based on the fault message provided, confirm that the following electrical values are within specified ranges or limits:<ul style="list-style-type: none">Supply and signal voltages (12V).Cable continuity (no opens or shorts).</div><div>Are measured electrical values outside of expected range or limits?<ul style="list-style-type: none">Yes - Proceed to step 3No - Proceed to step 4</div></td></tr></table> <table><tr><td>Step 3</td><td>Step ID 1196c</td><td>SRT</td></tr></table>	Step 1	Step ID 1196a	SRT	Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.			Step 2	Step ID 1196b	SRT	<div>Electrical Checks</div> <div>Ensure that the ignition key/switch has been set to OFF before disconnecting related cables.</div> <div>Based on the fault message provided, confirm that the following electrical values are within specified ranges or limits:<ul style="list-style-type: none">Supply and signal voltages (12V).Cable continuity (no opens or shorts).</div> <div>Are measured electrical values outside of expected range or limits?<ul style="list-style-type: none">Yes - Proceed to step 3No - Proceed to step 4</div>			Step 3	Step ID 1196c	SRT
Step 1	Step ID 1196a	SRT														
Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.																
Step 2	Step ID 1196b	SRT														
<div>Electrical Checks</div> <div>Ensure that the ignition key/switch has been set to OFF before disconnecting related cables.</div> <div>Based on the fault message provided, confirm that the following electrical values are within specified ranges or limits:<ul style="list-style-type: none">Supply and signal voltages (12V).Cable continuity (no opens or shorts).</div> <div>Are measured electrical values outside of expected range or limits?<ul style="list-style-type: none">Yes - Proceed to step 3No - Proceed to step 4</div>																
Step 3	Step ID 1196c	SRT														

	Repair or replace Common Rail assembly, which includes the Common Rail Pressure sensor, and use DAVIE to re-check for the presence of active faults. <ul style="list-style-type: none">• Fault inactive – issue resolve• Fault active - Proceed to step 4		
	Step 4	Step ID 1196d	SRT
	For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center at 1-800-477-0251.		
Verification Drive Cycle	To validate repair, with the brakes set, start the engine and allow it to run at idle for 2 minutes.		
	Back to Index		


P1201

Code number	P1201
Fault code description	Injector solenoid valve cylinder 1 - Current too low or open circuit on ECU D420 pin A2
Fault code information	1 trip MIL 3 drive cycle recovery Readiness group – None Freeze frame type – Comprehensive
Description of component(s)	<p>The fuel injector injects fuel into the combustion chamber. Control</p> <p>The amount of fuel injected depends on the duration of the injector solenoid activation in combination with the rail pressure. The longer the solenoid is activated by the PCI ECU at the same rail pressure, the more fuel is injected.</p> <p>Injector codes</p> <p>Every fuel injector is calibrated during production to compensate for any production tolerances. An injector calibration code is present on the housing and connector of the injector. These injector codes must be (re)programmed with DAVIE if one or more injectors have been replaced or fitted in another position, or if the PCI ECU is replaced.</p> <p>Not programming or incorrectly programmed injector codes can result in reduced engine performance or a warning to the driver.</p>
Location of component(s)	<p>B421</p> 
Diagnostic condition	The diagnostic runs continuously with the ignition on.
Set condition of fault code	This condition will be set if Current in Needle control valve is less than 4.5A.
Reset condition of fault code	This fault code will change to inactive immediately after the diagnostic runs and passes.

Electrical diagram(s)



Wiring harness connector D420.A front view



Wiring harness connector B460 & B461 front view

B460 connector cylinders 1-3

B461 connector cylinders 4-6

D420 PCI ECU

B421 solenoid valve injector cylinder 1

B422 solenoid valve injector cylinder 2

B423 solenoid valve injector cylinder 3



B424 solenoid valve injector cylinder 4

B425 solenoid valve injector cylinder 5

B426 solenoid valve injector cylinder 6


D420	B460	B421	B422	B423	Function
A1	7	2			Signal low, injector solenoid valve cylinder 1

	<table><tr><td>A2</td><td>1</td><td>1</td><td></td><td></td><td>Signal high, injector solenoid valve cylinder 1</td></tr><tr><td>A5</td><td>9</td><td></td><td>2</td><td></td><td>Signal low, injector solenoid valve cylinder 3</td></tr><tr><td>A6</td><td>3</td><td></td><td>1</td><td></td><td>Signal high, injector solenoid valve cylinder 3</td></tr><tr><td>A9</td><td>8</td><td></td><td></td><td>2</td><td>Signal low, injector solenoid valve cylinder 2</td></tr><tr><td>A10</td><td>2</td><td></td><td></td><td>1</td><td>Signal high, injector solenoid valve cylinder 2</td></tr><tr><td colspan="6"> </td></tr><tr><td>D420</td><td>B460</td><td>B424</td><td>B425</td><td>B426</td><td>Function</td></tr><tr><td>A3</td><td>2</td><td></td><td>1</td><td></td><td>Signal high, injector solenoid valve cylinder 5</td></tr><tr><td>A4</td><td>8</td><td></td><td>2</td><td></td><td>Signal low, injector solenoid valve cylinder 5</td></tr><tr><td>A7</td><td>3</td><td></td><td></td><td>1</td><td>Signal high, injector solenoid valve cylinder 6</td></tr><tr><td>A8</td><td>9</td><td></td><td></td><td>2</td><td>Signal low, injector solenoid valve cylinder 6</td></tr><tr><td>A11</td><td>1</td><td>1</td><td></td><td></td><td>Signal high, injector solenoid valve cylinder 4</td></tr><tr><td>A12</td><td>7</td><td>2</td><td></td><td></td><td>Signal low, injector solenoid valve cylinder 4</td></tr></table>					A2	1	1			Signal high, injector solenoid valve cylinder 1	A5	9		2		Signal low, injector solenoid valve cylinder 3	A6	3		1		Signal high, injector solenoid valve cylinder 3	A9	8			2	Signal low, injector solenoid valve cylinder 2	A10	2			1	Signal high, injector solenoid valve cylinder 2							D420	B460	B424	B425	B426	Function	A3	2		1		Signal high, injector solenoid valve cylinder 5	A4	8		2		Signal low, injector solenoid valve cylinder 5	A7	3			1	Signal high, injector solenoid valve cylinder 6	A8	9			2	Signal low, injector solenoid valve cylinder 6	A11	1	1			Signal high, injector solenoid valve cylinder 4	A12	7	2			Signal low, injector solenoid valve cylinder 4
A2	1	1			Signal high, injector solenoid valve cylinder 1																																																																														
A5	9		2		Signal low, injector solenoid valve cylinder 3																																																																														
A6	3		1		Signal high, injector solenoid valve cylinder 3																																																																														
A9	8			2	Signal low, injector solenoid valve cylinder 2																																																																														
A10	2			1	Signal high, injector solenoid valve cylinder 2																																																																														
D420	B460	B424	B425	B426	Function																																																																														
A3	2		1		Signal high, injector solenoid valve cylinder 5																																																																														
A4	8		2		Signal low, injector solenoid valve cylinder 5																																																																														
A7	3			1	Signal high, injector solenoid valve cylinder 6																																																																														
A8	9			2	Signal low, injector solenoid valve cylinder 6																																																																														
A11	1	1			Signal high, injector solenoid valve cylinder 4																																																																														
A12	7	2			Signal low, injector solenoid valve cylinder 4																																																																														
Technical data	<p>Component check, injector solenoid valve cylinder 1 (B421)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key off the ignition• Disconnect connector B460• Measure on wiring harness connector B460 <table><tr><td>Pin</td><td>Pin</td><td></td><td></td></tr><tr><td>(+ probe)</td><td>(- probe)</td><td>Value</td><td>Additional information</td></tr><tr><td>1</td><td>7</td><td>$\pm 0.67 \Omega$</td><td>Resistance value at 20°C [68°F]</td></tr><tr><td></td><td></td><td>maximum 0.94 Ω</td><td>Resistance value at 120°C [248°F]</td></tr></table> <p>Component check, injector solenoid valve cylinder 2 (B422)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key off the ignition• Disconnect connector B460• Measure on wiring harness connector B460 <table><tr><td>Pin</td><td>Pin</td><td></td><td></td></tr><tr><td>(+ probe)</td><td>(- probe)</td><td>Value</td><td>Additional information</td></tr><tr><td>2</td><td>8</td><td>$\pm 0.67 \Omega$</td><td>Resistance value at 20°C [68°F]</td></tr><tr><td></td><td></td><td>maximum 0.94 Ω</td><td>Resistance value at 120°C [248°F]</td></tr></table> <p>Component check, injector solenoid valve cylinder 3 (B423)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key off the ignition• Disconnect connector B460• Measure on wiring harness connector B460 <table><tr><td>Pin</td><td>Pin</td><td></td><td></td></tr><tr><td>(+ probe)</td><td>(- probe)</td><td>Value</td><td>Additional information</td></tr><tr><td>3</td><td>9</td><td>$\pm 0.67 \Omega$</td><td>Resistance value at 20°C [68°F]</td></tr><tr><td></td><td></td><td>maximum 0.94 Ω</td><td>Resistance value at 120°C [248°F]</td></tr></table> <p>Component check, injector solenoid valve cylinder 4 (B424)</p> <p>Preparation</p>					Pin	Pin			(+ probe)	(- probe)	Value	Additional information	1	7	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]			maximum 0.94 Ω	Resistance value at 120°C [248°F]	Pin	Pin			(+ probe)	(- probe)	Value	Additional information	2	8	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]			maximum 0.94 Ω	Resistance value at 120°C [248°F]	Pin	Pin			(+ probe)	(- probe)	Value	Additional information	3	9	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]			maximum 0.94 Ω	Resistance value at 120°C [248°F]																														
Pin	Pin																																																																																		
(+ probe)	(- probe)	Value	Additional information																																																																																
1	7	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]																																																																																
		maximum 0.94 Ω	Resistance value at 120°C [248°F]																																																																																
Pin	Pin																																																																																		
(+ probe)	(- probe)	Value	Additional information																																																																																
2	8	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]																																																																																
		maximum 0.94 Ω	Resistance value at 120°C [248°F]																																																																																
Pin	Pin																																																																																		
(+ probe)	(- probe)	Value	Additional information																																																																																
3	9	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]																																																																																
		maximum 0.94 Ω	Resistance value at 120°C [248°F]																																																																																



	<ul style="list-style-type: none">• Key off the ignition• Disconnect connector B461• Measure on wiring harness connector B461 <table><tr><th>Pin</th><th>Pin</th><th></th><th></th></tr><tr><th>(+ probe)</th><th>(- probe)</th><th>Value</th><th>Additional information</th></tr><tr><td>1</td><td>7</td><td>$\pm 0.67 \Omega$ maximum 0.94Ω</td><td>Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]</td></tr></table> <p>Component check, injector solenoid valve cylinder 5 (B425)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key off the ignition• Disconnect connector B461• Measure on wiring harness connector B461 <table><tr><th>Pin</th><th>Pin</th><th></th><th></th></tr><tr><th>(+ probe)</th><th>(- probe)</th><th>Value</th><th>Additional information</th></tr><tr><td>2</td><td>8</td><td>$\pm 0.67 \Omega$ maximum 0.94Ω</td><td>Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]</td></tr></table> <p>Component check, injector solenoid valve cylinder 6 (B426)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key off the ignition• Disconnect connector B461• Measure on wiring harness connector B461 <table><tr><th>Pin</th><th>Pin</th><th></th><th></th></tr><tr><th>(+ probe)</th><th>(- probe)</th><th>Value</th><th>Additional information</th></tr><tr><td>3</td><td>9</td><td>$\pm 0.67 \Omega$ maximum 0.94Ω</td><td>Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]</td></tr></table>	Pin	Pin			(+ probe)	(- probe)	Value	Additional information	1	7	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]	Pin	Pin			(+ probe)	(- probe)	Value	Additional information	2	8	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]	Pin	Pin			(+ probe)	(- probe)	Value	Additional information	3	9	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]
Pin	Pin																																				
(+ probe)	(- probe)	Value	Additional information																																		
1	7	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]																																		
Pin	Pin																																				
(+ probe)	(- probe)	Value	Additional information																																		
2	8	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]																																		
Pin	Pin																																				
(+ probe)	(- probe)	Value	Additional information																																		
3	9	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]																																		
Possible causes	<ul style="list-style-type: none">• Faulty sensor• Faulty connector• Faulty wiring																																				
Additional information	No additional information available.																																				
Diagnostic Step-by-Step	<div><p>Perform the troubleshooting steps below using the breakout harness, if necessary, to check electrical components, such as sensors, electrical control units, and harnesses. Back probing is not recommended, as it could damage the harness. The ignition should always be in the OFF position when connecting or disconnecting electrical components in order to reduce the likelihood of damage to electrical components.</p></div> <div><ul style="list-style-type: none">• Disconnecting the EAS connectors during the troubleshooting process will result in multiple errors.• For specific electrical component information and pinout locations, always refer to the technical data.• It is necessary to exit the fault code menu in DAVIE and run the diagnostic test again to identify a change in errors.• Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive fault codes. Refer to the 'possible causes' section.</div>																																				

	<table><tr><td>Step 1</td><td>Step ID 1201a</td><td>SRT</td></tr><tr><td colspan="3">Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.</td></tr></table>	Step 1	Step ID 1201a	SRT	Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.		
	Step 1	Step ID 1201a	SRT				
	Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.						
	<table><tr><td>Step 2</td><td>Step ID 1201b</td><td>SRT</td></tr><tr><td colspan="3"><p>Electrical Checks</p><p>Ensure that the ignition key/switch has been set to OFF before disconnecting related cables.</p><p>Based on the fault message provided, confirm that the following electrical values are within specified ranges or limits:</p><ul style="list-style-type: none">• Supply and signal voltages (12V).• Cable continuity (no opens or shorts).<p>Are measured electrical values outside of expected range or limits?</p><ul style="list-style-type: none">• Yes - Proceed to step 3• No - Proceed to step 4</td></tr></table>	Step 2	Step ID 1201b	SRT	<p>Electrical Checks</p> <p>Ensure that the ignition key/switch has been set to OFF before disconnecting related cables.</p> <p>Based on the fault message provided, confirm that the following electrical values are within specified ranges or limits:</p> <ul style="list-style-type: none">• Supply and signal voltages (12V).• Cable continuity (no opens or shorts). <p>Are measured electrical values outside of expected range or limits?</p> <ul style="list-style-type: none">• Yes - Proceed to step 3• No - Proceed to step 4		
Step 2	Step ID 1201b	SRT					
<p>Electrical Checks</p> <p>Ensure that the ignition key/switch has been set to OFF before disconnecting related cables.</p> <p>Based on the fault message provided, confirm that the following electrical values are within specified ranges or limits:</p> <ul style="list-style-type: none">• Supply and signal voltages (12V).• Cable continuity (no opens or shorts). <p>Are measured electrical values outside of expected range or limits?</p> <ul style="list-style-type: none">• Yes - Proceed to step 3• No - Proceed to step 4							
<table><tr><td>Step 3</td><td>Step ID 1201c</td><td>SRT</td></tr><tr><td colspan="3"><p>Repair or replace ‘Solenoid Valve Injector, Cylinder 1’ and use DAVIE to re-check for the presence of active faults.</p><ul style="list-style-type: none">• Fault inactive – issue resolved• Fault active - Proceed to step 4</td></tr></table>	Step 3	Step ID 1201c	SRT	<p>Repair or replace ‘Solenoid Valve Injector, Cylinder 1’ and use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">• Fault inactive – issue resolved• Fault active - Proceed to step 4			
Step 3	Step ID 1201c	SRT					
<p>Repair or replace ‘Solenoid Valve Injector, Cylinder 1’ and use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">• Fault inactive – issue resolved• Fault active - Proceed to step 4							
<table><tr><td>Step 4</td><td>Step ID 1201d</td><td>SRT</td></tr><tr><td colspan="3">For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the Engine Support Call Center at 1-800-477-0251.</td></tr></table>	Step 4	Step ID 1201d	SRT	For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the Engine Support Call Center at 1-800-477-0251.			
Step 4	Step ID 1201d	SRT					
For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the Engine Support Call Center at 1-800-477-0251.							
Verification Drive Cycle	To validate repair, with the brakes set, turn the key to the ON position with the engine off, and allow 10 seconds for the system to initialize and run diagnostics.						
	Back to Index						


P1202

Code number	P1202
Fault code description	Injector solenoid valve cylinder 1 - Short circuit between ECU D420 pin A1 and A2
Fault code information	<p>1 trip MIL</p> <p>3 drive cycle recovery</p> <p>Readiness group – None</p> <p>Freeze frame type - Comprehensive</p>
Description of component(s)	<p>The fuel injector injects fuel into the combustion chamber.</p> <p>Control</p> <p>The amount of fuel injected depends on the duration of the injector solenoid activation in combination with the rail pressure. The longer the solenoid is activated by the PCI ECU at the same rail pressure, the more fuel is injected.</p> <p>Injector codes</p> <p>Every fuel injector is calibrated during production to compensate for any production tolerances. An injector calibration code is present on the housing and connector of the injector. These injector codes must be (re)programmed with DAVIE if one or more injectors have been replaced or fitted in another position, or if the PCI ECU is replaced.</p> <p>Not programming or incorrectly programmed injector codes can result in reduced engine performance or a warning to the driver.</p>
Location of component(s)	 <p>The diagram shows a cross-section of an engine block with multiple injectors. One injector is highlighted in green and labeled B421, indicating its location within the engine assembly.</p>
Diagnostic condition	Diagnostic condition is set when Power stage hardware is active
Set condition of fault code	<ul style="list-style-type: none"> • If High side voltage on the injector (before injection) compared to battery voltage is less than the threshold value 20.00% and greater than the threshold value 80.00% then the condition is set • If Current passing through the sensor resistor is greater than the threshold value 25A then the condition is set
Reset condition of fault code	This fault code will change to inactive immediately after the diagnostic runs and passes.

Electrical diagram(s)



Wiring harness connector D420.A front view



Wiring harness connector B460 & B461 front view

B460 connector cylinders 1-3

B461 connector cylinders 4-6

D420 PCI ECU

B421 solenoid valve injector cylinder 1

B422 solenoid valve injector cylinder 2

B423 solenoid valve injector cylinder 3

B424 solenoid valve injector cylinder 4



B425 solenoid valve injector cylinder 5

B426 solenoid valve injector cylinder 6

D420	B460	B421	B422	B423	Function
A1	7	2			Signal low, injector solenoid valve cylinder 1


A1 7 2 Signal low, injector solenoid valve cylinder 1

	<table><tr><td>A2</td><td>1</td><td>1</td><td></td><td></td><td>Signal high, injector solenoid valve cylinder 1</td></tr><tr><td>A5</td><td>9</td><td></td><td>2</td><td></td><td>Signal low, injector solenoid valve cylinder 3</td></tr><tr><td>A6</td><td>3</td><td></td><td>1</td><td></td><td>Signal high, injector solenoid valve cylinder 3</td></tr><tr><td>A9</td><td>8</td><td></td><td></td><td>2</td><td>Signal low, injector solenoid valve cylinder 2</td></tr><tr><td>A10</td><td>2</td><td></td><td></td><td>1</td><td>Signal high, injector solenoid valve cylinder 2</td></tr><tr><td colspan="6"> </td></tr><tr><td>D420</td><td>B460</td><td>B424</td><td>B425</td><td>B426</td><td>Function</td></tr><tr><td>A3</td><td>2</td><td></td><td>1</td><td></td><td>Signal high, injector solenoid valve cylinder 5</td></tr><tr><td>A4</td><td>8</td><td></td><td>2</td><td></td><td>Signal low, injector solenoid valve cylinder 5</td></tr><tr><td>A7</td><td>3</td><td></td><td></td><td>1</td><td>Signal high, injector solenoid valve cylinder 6</td></tr><tr><td>A8</td><td>9</td><td></td><td></td><td>2</td><td>Signal low, injector solenoid valve cylinder 6</td></tr><tr><td>A11</td><td>1</td><td>1</td><td></td><td></td><td>Signal high, injector solenoid valve cylinder 4</td></tr><tr><td>A12</td><td>7</td><td>2</td><td></td><td></td><td>Signal low, injector solenoid valve cylinder 4</td></tr></table>					A2	1	1			Signal high, injector solenoid valve cylinder 1	A5	9		2		Signal low, injector solenoid valve cylinder 3	A6	3		1		Signal high, injector solenoid valve cylinder 3	A9	8			2	Signal low, injector solenoid valve cylinder 2	A10	2			1	Signal high, injector solenoid valve cylinder 2							D420	B460	B424	B425	B426	Function	A3	2		1		Signal high, injector solenoid valve cylinder 5	A4	8		2		Signal low, injector solenoid valve cylinder 5	A7	3			1	Signal high, injector solenoid valve cylinder 6	A8	9			2	Signal low, injector solenoid valve cylinder 6	A11	1	1			Signal high, injector solenoid valve cylinder 4	A12	7	2			Signal low, injector solenoid valve cylinder 4
A2	1	1			Signal high, injector solenoid valve cylinder 1																																																																														
A5	9		2		Signal low, injector solenoid valve cylinder 3																																																																														
A6	3		1		Signal high, injector solenoid valve cylinder 3																																																																														
A9	8			2	Signal low, injector solenoid valve cylinder 2																																																																														
A10	2			1	Signal high, injector solenoid valve cylinder 2																																																																														
D420	B460	B424	B425	B426	Function																																																																														
A3	2		1		Signal high, injector solenoid valve cylinder 5																																																																														
A4	8		2		Signal low, injector solenoid valve cylinder 5																																																																														
A7	3			1	Signal high, injector solenoid valve cylinder 6																																																																														
A8	9			2	Signal low, injector solenoid valve cylinder 6																																																																														
A11	1	1			Signal high, injector solenoid valve cylinder 4																																																																														
A12	7	2			Signal low, injector solenoid valve cylinder 4																																																																														
Technical data	<div>Component check, injector solenoid valve cylinder 1 (B421)</div> <div>Preparation<ul style="list-style-type: none">Key off the ignitionDisconnect connector B460Measure on wiring harness connector B460<table><tr><td>Pin (+ probe)</td><td>Pin (- probe)</td><td>Value</td><td>Additional information</td></tr><tr><td>1</td><td>7</td><td>$\pm 0.67 \Omega$</td><td>Resistance value at 20°C [68°F]</td></tr><tr><td></td><td></td><td>maximum 0.94 Ω</td><td>Resistance value at 120°C [248°F]</td></tr></table><div>Component check, injector solenoid valve cylinder 2 (B422)</div><div>Preparation<ul style="list-style-type: none">Key off the ignitionDisconnect connector B460Measure on wiring harness connector B460<table><tr><td>Pin (+ probe)</td><td>Pin (- probe)</td><td>Value</td><td>Additional information</td></tr><tr><td>2</td><td>8</td><td>$\pm 0.67 \Omega$</td><td>Resistance value at 20°C [68°F]</td></tr><tr><td></td><td></td><td>maximum 0.94 Ω</td><td>Resistance value at 120°C [248°F]</td></tr></table><div>Component check, injector solenoid valve cylinder 3 (B423)</div><div>Preparation<ul style="list-style-type: none">Key off the ignitionDisconnect connector B460Measure on wiring harness connector B460<table><tr><td>Pin (+ probe)</td><td>Pin (- probe)</td><td>Value</td><td>Additional information</td></tr><tr><td>3</td><td>9</td><td>$\pm 0.67 \Omega$</td><td>Resistance value at 20°C [68°F]</td></tr><tr><td></td><td></td><td>maximum 0.94 Ω</td><td>Resistance value at 120°C [248°F]</td></tr></table></div></div></div>					Pin (+ probe)	Pin (- probe)	Value	Additional information	1	7	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]			maximum 0.94 Ω	Resistance value at 120°C [248°F]	Pin (+ probe)	Pin (- probe)	Value	Additional information	2	8	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]			maximum 0.94 Ω	Resistance value at 120°C [248°F]	Pin (+ probe)	Pin (- probe)	Value	Additional information	3	9	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]			maximum 0.94 Ω	Resistance value at 120°C [248°F]																																										
Pin (+ probe)	Pin (- probe)	Value	Additional information																																																																																
1	7	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]																																																																																
		maximum 0.94 Ω	Resistance value at 120°C [248°F]																																																																																
Pin (+ probe)	Pin (- probe)	Value	Additional information																																																																																
2	8	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]																																																																																
		maximum 0.94 Ω	Resistance value at 120°C [248°F]																																																																																
Pin (+ probe)	Pin (- probe)	Value	Additional information																																																																																
3	9	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]																																																																																
		maximum 0.94 Ω	Resistance value at 120°C [248°F]																																																																																



	<p>Component check, injector solenoid valve cylinder 4 (B424)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key off the ignition• Disconnect connector B461• Measure on wiring harness connector B461 <table><tr><th>Pin (+ probe)</th><th>Pin (- probe)</th><th>Value</th><th>Additional information</th></tr><tr><td>1</td><td>7</td><td>$\pm 0.67 \Omega$ maximum 0.94Ω</td><td>Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]</td></tr></table> <p>Component check, injector solenoid valve cylinder 5 (B425)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key off the ignition• Disconnect connector B461• Measure on wiring harness connector B461 <table><tr><th>Pin (+ probe)</th><th>Pin (- probe)</th><th>Value</th><th>Additional information</th></tr><tr><td>2</td><td>8</td><td>$\pm 0.67 \Omega$ maximum 0.94Ω</td><td>Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]</td></tr></table> <p>Component check, injector solenoid valve cylinder 6 (B426)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key off the ignition• Disconnect connector B461• Measure on wiring harness connector B461 <table><tr><th>Pin (+ probe)</th><th>Pin (- probe)</th><th>Value</th><th>Additional information</th></tr><tr><td>3</td><td>9</td><td>$\pm 0.67 \Omega$ maximum 0.94Ω</td><td>Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]</td></tr></table>	Pin (+ probe)	Pin (- probe)	Value	Additional information	1	7	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]	Pin (+ probe)	Pin (- probe)	Value	Additional information	2	8	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]	Pin (+ probe)	Pin (- probe)	Value	Additional information	3	9	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]
Pin (+ probe)	Pin (- probe)	Value	Additional information																						
1	7	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]																						
Pin (+ probe)	Pin (- probe)	Value	Additional information																						
2	8	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]																						
Pin (+ probe)	Pin (- probe)	Value	Additional information																						
3	9	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]																						
Possible causes	No possible causes available.																								
Additional information	No additional information available.																								
Diagnostic Step-by-Step	<div><div></div><div><p>Perform the troubleshooting steps below using the breakout harness, if necessary, to check electrical components, such as sensors, electrical control units, and harnesses. Back probing is not recommended, as it could damage the harness. The ignition should always be in the OFF position when connecting or disconnecting electrical components in order to reduce the likelihood of damage to electrical components.</p><ul style="list-style-type: none">• Disconnecting the EAS connectors during the troubleshooting process will result in multiple errors.• For specific electrical component information and pinout locations, always refer to the technical data.• It is necessary to exit the fault code menu in DAVIE and run the diagnostic test again to identify a change in errors.• Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive fault codes. Refer to the</div></div>																								

	'possible causes' section.		
	Step 1	Step ID 1202a	SRT
	Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.		
	Step 2	Step ID 1202b	SRT
	<p>Electrical Checks</p> <p>Ensure that the ignition key/switch has been set to OFF before disconnecting related cables.</p> <p>Based on the fault message provided, confirm that the following electrical values are within specified ranges or limits:</p> <ul style="list-style-type: none"> • Supply and signal voltages (12V). • Cable continuity (no opens or shorts). <p>Are measured electrical values outside of expected range or limits?</p> <ul style="list-style-type: none"> • Yes - Proceed to step 3 • No - Proceed to step 4 		
	Step 3	Step ID 1202c	SRT
	<p>Repair or replace appropriate component and use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none"> • Fault inactive – issue resolve • Fault active - Proceed to step 4 		
	Step 4	Step ID 1202d	SRT
	<p>Replace the identified faulty component (Solenoid Valve Injector, Cylinder 1) and use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none"> • Fault inactive – issue resolved • Fault active - Proceed to step 5 		
	Step 5	Step ID 1202e	SRT
	For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the Engine Support Call Center at 1-800-477-0251.		
Verification Drive Cycle	To validate repair, with the brakes set, turn the key to the ON position with the engine off, and allow 10 seconds for the system to initialize and run diagnostics.		
	Back to Index		


P1203

Code number	P1203
Fault code description	Injector solenoid valve cylinder 1 - Voltage too low or short circuit to ground on ECU D420 pin A2
Fault code information	1 trip MIL 3 drive cycle recovery Readiness group – None Freeze frame type - Comprehensive
Description of component(s)	<p>The fuel injector injects fuel into the combustion chamber. Control</p> <p>The amount of fuel injected depends on the duration of the injector solenoid activation in combination with the rail pressure. The longer the solenoid is activated by the PCI ECU at the same rail pressure, the more fuel is injected.</p> <p>Injector codes</p> <p>Every fuel injector is calibrated during production to compensate for any production tolerances. An injector calibration code is present on the housing and connector of the injector. These injector codes must be (re)programmed with DAVIE if one or more injectors have been replaced or fitted in another position, or if the PCI ECU is replaced.</p> <p>Not programming or incorrectly programmed injector codes can result in reduced engine performance or a warning to the driver.</p>
Location of component(s)	 <p>The diagram shows a top-down view of an engine block with multiple cylinders. A green arrow points to the injector solenoid valve cylinder 1, which is labeled B421. The component is located on the left side of the engine block, near the front.</p>
Diagnostic condition	Diagnostic condition is set when Power stage hardware is active
Set condition of fault code	<ul style="list-style-type: none"> • If High side voltage on the injector (before injection) compared to battery voltage is less than the threshold value 20.00% then the condition is set. • If Current through sense resistor on driver bank A is less than the threshold value 4.50A then the condition is set.
Reset condition of fault code	This fault code will change to inactive immediately after the diagnostic runs and passes.

Electrical diagram(s)



Wiring harness connector D420.A front view



Wiring harness connector B460 & B461 front view

B460 connector cylinders 1-3

B461 connector cylinders 4-6

D420 PCI ECU

B421 solenoid valve injector cylinder 1

B422 solenoid valve injector cylinder 2

B423 solenoid valve injector cylinder 3



B424 solenoid valve injector cylinder 4

B425 solenoid valve injector cylinder 5

B426 solenoid valve injector cylinder 6


D420	B460	B421	B422	B423	Function
A1	7	2			Signal low, injector solenoid valve cylinder 1

	<table><tr><td>A2</td><td>1</td><td>1</td><td></td><td></td><td>Signal high, injector solenoid valve cylinder 1</td></tr><tr><td>A5</td><td>9</td><td></td><td>2</td><td></td><td>Signal low, injector solenoid valve cylinder 3</td></tr><tr><td>A6</td><td>3</td><td></td><td>1</td><td></td><td>Signal high, injector solenoid valve cylinder 3</td></tr><tr><td>A9</td><td>8</td><td></td><td></td><td>2</td><td>Signal low, injector solenoid valve cylinder 2</td></tr><tr><td>A10</td><td>2</td><td></td><td></td><td>1</td><td>Signal high, injector solenoid valve cylinder 2</td></tr><tr><td colspan="6"> </td></tr><tr><td>D420</td><td>B460</td><td>B424</td><td>B425</td><td>B426</td><td>Function</td></tr><tr><td>A3</td><td>2</td><td></td><td>1</td><td></td><td>Signal high, injector solenoid valve cylinder 5</td></tr><tr><td>A4</td><td>8</td><td></td><td>2</td><td></td><td>Signal low, injector solenoid valve cylinder 5</td></tr><tr><td>A7</td><td>3</td><td></td><td></td><td>1</td><td>Signal high, injector solenoid valve cylinder 6</td></tr><tr><td>A8</td><td>9</td><td></td><td></td><td>2</td><td>Signal low, injector solenoid valve cylinder 6</td></tr><tr><td>A11</td><td>1</td><td>1</td><td></td><td></td><td>Signal high, injector solenoid valve cylinder 4</td></tr><tr><td>A12</td><td>7</td><td>2</td><td></td><td></td><td>Signal low, injector solenoid valve cylinder 4</td></tr></table>					A2	1	1			Signal high, injector solenoid valve cylinder 1	A5	9		2		Signal low, injector solenoid valve cylinder 3	A6	3		1		Signal high, injector solenoid valve cylinder 3	A9	8			2	Signal low, injector solenoid valve cylinder 2	A10	2			1	Signal high, injector solenoid valve cylinder 2							D420	B460	B424	B425	B426	Function	A3	2		1		Signal high, injector solenoid valve cylinder 5	A4	8		2		Signal low, injector solenoid valve cylinder 5	A7	3			1	Signal high, injector solenoid valve cylinder 6	A8	9			2	Signal low, injector solenoid valve cylinder 6	A11	1	1			Signal high, injector solenoid valve cylinder 4	A12	7	2			Signal low, injector solenoid valve cylinder 4
A2	1	1			Signal high, injector solenoid valve cylinder 1																																																																														
A5	9		2		Signal low, injector solenoid valve cylinder 3																																																																														
A6	3		1		Signal high, injector solenoid valve cylinder 3																																																																														
A9	8			2	Signal low, injector solenoid valve cylinder 2																																																																														
A10	2			1	Signal high, injector solenoid valve cylinder 2																																																																														
D420	B460	B424	B425	B426	Function																																																																														
A3	2		1		Signal high, injector solenoid valve cylinder 5																																																																														
A4	8		2		Signal low, injector solenoid valve cylinder 5																																																																														
A7	3			1	Signal high, injector solenoid valve cylinder 6																																																																														
A8	9			2	Signal low, injector solenoid valve cylinder 6																																																																														
A11	1	1			Signal high, injector solenoid valve cylinder 4																																																																														
A12	7	2			Signal low, injector solenoid valve cylinder 4																																																																														
Technical data	<p>Component check, injector solenoid valve cylinder 1 (B421)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key off the ignition• Disconnect connector B460• Measure on wiring harness connector B460 <table><tr><td>Pin</td><td>Pin</td><td></td><td></td></tr><tr><td>(+ probe)</td><td>(- probe)</td><td>Value</td><td>Additional information</td></tr><tr><td>1</td><td>7</td><td>$\pm 0.67 \Omega$</td><td>Resistance value at 20°C [68°F]</td></tr><tr><td></td><td></td><td>maximum 0.94 Ω</td><td>Resistance value at 120°C [248°F]</td></tr></table> <p>Component check, injector solenoid valve cylinder 2 (B422)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key off the ignition• Disconnect connector B460• Measure on wiring harness connector B460 <table><tr><td>Pin</td><td>Pin</td><td></td><td></td></tr><tr><td>(+ probe)</td><td>(- probe)</td><td>Value</td><td>Additional information</td></tr><tr><td>2</td><td>8</td><td>$\pm 0.67 \Omega$</td><td>Resistance value at 20°C [68°F]</td></tr><tr><td></td><td></td><td>maximum 0.94 Ω</td><td>Resistance value at 120°C [248°F]</td></tr></table> <p>Component check, injector solenoid valve cylinder 3 (B423)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key off the ignition• Disconnect connector B460• Measure on wiring harness connector B460 <table><tr><td>Pin</td><td>Pin</td><td></td><td></td></tr><tr><td>(+ probe)</td><td>(- probe)</td><td>Value</td><td>Additional information</td></tr><tr><td>3</td><td>9</td><td>$\pm 0.67 \Omega$</td><td>Resistance value at 20°C [68°F]</td></tr><tr><td></td><td></td><td>maximum 0.94 Ω</td><td>Resistance value at 120°C [248°F]</td></tr></table> <p>Component check, injector solenoid valve cylinder 4 (B424)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key off the ignition					Pin	Pin			(+ probe)	(- probe)	Value	Additional information	1	7	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]			maximum 0.94 Ω	Resistance value at 120°C [248°F]	Pin	Pin			(+ probe)	(- probe)	Value	Additional information	2	8	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]			maximum 0.94 Ω	Resistance value at 120°C [248°F]	Pin	Pin			(+ probe)	(- probe)	Value	Additional information	3	9	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]			maximum 0.94 Ω	Resistance value at 120°C [248°F]																														
Pin	Pin																																																																																		
(+ probe)	(- probe)	Value	Additional information																																																																																
1	7	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]																																																																																
		maximum 0.94 Ω	Resistance value at 120°C [248°F]																																																																																
Pin	Pin																																																																																		
(+ probe)	(- probe)	Value	Additional information																																																																																
2	8	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]																																																																																
		maximum 0.94 Ω	Resistance value at 120°C [248°F]																																																																																
Pin	Pin																																																																																		
(+ probe)	(- probe)	Value	Additional information																																																																																
3	9	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]																																																																																
		maximum 0.94 Ω	Resistance value at 120°C [248°F]																																																																																



	<ul style="list-style-type: none">• Disconnect connector B461• Measure on wiring harness connector B461 <table><tr><th>Pin (+ probe)</th><th>Pin (- probe)</th><th>Value</th><th>Additional information</th></tr><tr><td>1</td><td>7</td><td>$\pm 0.67 \Omega$ maximum 0.94Ω</td><td>Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]</td></tr></table> <p>Component check, injector solenoid valve cylinder 5 (B425)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key off the ignition• Disconnect connector B461• Measure on wiring harness connector B461 <table><tr><th>Pin (+ probe)</th><th>Pin (- probe)</th><th>Value</th><th>Additional information</th></tr><tr><td>2</td><td>8</td><td>$\pm 0.67 \Omega$ maximum 0.94Ω</td><td>Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]</td></tr></table> <p>Component check, injector solenoid valve cylinder 6 (B426)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key off the ignition• Disconnect connector B461• Measure on wiring harness connector B461 <table><tr><th>Pin (+ probe)</th><th>Pin (- probe)</th><th>Value</th><th>Additional information</th></tr><tr><td>3</td><td>9</td><td>$\pm 0.67 \Omega$ maximum 0.94Ω</td><td>Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]</td></tr></table>	Pin (+ probe)	Pin (- probe)	Value	Additional information	1	7	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]	Pin (+ probe)	Pin (- probe)	Value	Additional information	2	8	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]	Pin (+ probe)	Pin (- probe)	Value	Additional information	3	9	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]
Pin (+ probe)	Pin (- probe)	Value	Additional information																						
1	7	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]																						
Pin (+ probe)	Pin (- probe)	Value	Additional information																						
2	8	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]																						
Pin (+ probe)	Pin (- probe)	Value	Additional information																						
3	9	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]																						
Possible causes	No possible causes available.																								
Additional information	No additional information available																								
Diagnostic Step-by-Step	<div><p>Perform the troubleshooting steps below using the breakout harness, if necessary, to check electrical components, such as sensors, electrical control units, and harnesses. Back probing is not recommended, as it could damage the harness. The ignition should always be in the OFF position when connecting or disconnecting electrical components in order to reduce the likelihood of damage to electrical components.</p></div> <div><ul style="list-style-type: none">• Disconnecting the EAS connectors during the troubleshooting process will result in multiple errors.• For specific electrical component information and pinout locations, always refer to the technical data.• It is necessary to exit the fault code menu in DAVIE and run the diagnostic test again to identify a change in errors.• Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive fault codes. Refer to the 'possible causes' section.</div> <table><tr><td>Step 1</td><td>Step ID 1203a</td><td>SRT</td></tr><tr><td colspan="3">Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.</td></tr></table>	Step 1	Step ID 1203a	SRT	Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.																				
Step 1	Step ID 1203a	SRT																							
Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.																									

	Step 2	Step ID 1203b	SRT
	Electrical Checks Ensure that the ignition key/switch has been set to OFF before disconnecting related cables. Based on the fault message provided, confirm that the following electrical values are within specified ranges or limits: <ul style="list-style-type: none">• Supply and signal voltages (12V).• Cable continuity (no opens or shorts). Are measured electrical values outside of expected range or limits? <ul style="list-style-type: none">• Yes - Proceed to step 3• No - Proceed to step 4		
	Step 3	Step ID 1203c	SRT
	Repair or replace appropriate component and use DAVIE to re-check for the presence of active faults. <ul style="list-style-type: none">• Fault inactive – issue resolve• Fault active - Proceed to step 4		
	Step 4	Step ID 1203d	SRT
	Replace the identified faulty component (Solenoid Valve Injector, Cylinder 1) and use DAVIE to re-check for the presence of active faults. <ul style="list-style-type: none">• Fault inactive – issue resolve• Fault active - Proceed to step 5		
	Step 5	Step ID 1203e	SRT
	For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the Engine Support Call Center at 1-800-477-0251.		
Verification Drive Cycle	To validate repair, with the brakes set, turn the key to the ON position with the engine off, and allow 10 seconds for the system to initialize and run diagnostics.		
	Back to Index		


P1204

Code number	P1204
Fault code description	Injector solenoid valve cylinder 1 - Voltage too high or short circuit to supply on ECU D420 pin A2
Fault code information	1 trip MIL 3 drive cycle recovery Readiness group – None Freeze frame type – Comprehensive
Description of component(s)	<p>The fuel injector injects fuel into the combustion chamber. Control</p> <p>The amount of fuel injected depends on the duration of the injector solenoid activation in combination with the rail pressure. The longer the solenoid is activated by the PCI ECU at the same rail pressure, the more fuel is injected.</p> <p>Injector codes</p> <p>Every fuel injector is calibrated during production to compensate for any production tolerances. An injector calibration code is present on the housing and connector of the injector. These injector codes must be (re)programmed with DAVIE if one or more injectors have been replaced or fitted in another position, or if the PCI ECU is replaced.</p> <p>Not programming or incorrectly programmed injector codes can result in reduced engine performance or a warning to the driver.</p>
Location of component(s)	 <p>The diagram shows a top-down view of an engine block with multiple injectors. One injector is highlighted in green and labeled B421, indicating its location on the driver bank.</p>
Diagnostic condition	This diagnostic runs whenever the engine is running at idle or higher RPM. This code will set if the voltage on the ground wire for the injector exceeds 9.6 volts during when the injector is commanded on while the engine is running.
Set condition of fault code	<p>This condition is set when</p> <ul style="list-style-type: none"> • High side voltage on the injector (before injection) compared to battery voltage is higher than 80% • Current through sense resistor on driver bank A is more than 25 A
Reset condition of fault code	This fault code will change to inactive immediately after the diagnostic runs and passes.

Electrical diagram(s)



Wiring harness connector D420.A front view



Wiring harness connector B460 & B461 front view

B460 connector cylinders 1-3

B461 connector cylinders 4-6

D420 PCI ECU

B421 solenoid valve injector cylinder 1

B422 solenoid valve injector cylinder 2

B423 solenoid valve injector cylinder 3

B424 solenoid valve injector cylinder 4



B425 solenoid valve injector cylinder 5

B426 solenoid valve injector cylinder 6

D420	B460	B421	B422	B423	Function
A1	7	2			Signal low, injector solenoid valve cylinder 1


A1 7 2 Signal low, injector solenoid valve cylinder 1

	<table><tr><td>A2</td><td>1</td><td>1</td><td></td><td></td><td>Signal high, injector solenoid valve cylinder 1</td></tr><tr><td>A5</td><td>9</td><td></td><td>2</td><td></td><td>Signal low, injector solenoid valve cylinder 3</td></tr><tr><td>A6</td><td>3</td><td></td><td>1</td><td></td><td>Signal high, injector solenoid valve cylinder 3</td></tr><tr><td>A9</td><td>8</td><td></td><td></td><td>2</td><td>Signal low, injector solenoid valve cylinder 2</td></tr><tr><td>A10</td><td>2</td><td></td><td></td><td>1</td><td>Signal high, injector solenoid valve cylinder 2</td></tr><tr><td colspan="6"> </td></tr><tr><td>D420</td><td>B460</td><td>B424</td><td>B425</td><td>B426</td><td>Function</td></tr><tr><td>A3</td><td>2</td><td></td><td>1</td><td></td><td>Signal high, injector solenoid valve cylinder 5</td></tr><tr><td>A4</td><td>8</td><td></td><td>2</td><td></td><td>Signal low, injector solenoid valve cylinder 5</td></tr><tr><td>A7</td><td>3</td><td></td><td></td><td>1</td><td>Signal high, injector solenoid valve cylinder 6</td></tr><tr><td>A8</td><td>9</td><td></td><td></td><td>2</td><td>Signal low, injector solenoid valve cylinder 6</td></tr><tr><td>A11</td><td>1</td><td>1</td><td></td><td></td><td>Signal high, injector solenoid valve cylinder 4</td></tr><tr><td>A12</td><td>7</td><td>2</td><td></td><td></td><td>Signal low, injector solenoid valve cylinder 4</td></tr></table>	A2	1	1			Signal high, injector solenoid valve cylinder 1	A5	9		2		Signal low, injector solenoid valve cylinder 3	A6	3		1		Signal high, injector solenoid valve cylinder 3	A9	8			2	Signal low, injector solenoid valve cylinder 2	A10	2			1	Signal high, injector solenoid valve cylinder 2							D420	B460	B424	B425	B426	Function	A3	2		1		Signal high, injector solenoid valve cylinder 5	A4	8		2		Signal low, injector solenoid valve cylinder 5	A7	3			1	Signal high, injector solenoid valve cylinder 6	A8	9			2	Signal low, injector solenoid valve cylinder 6	A11	1	1			Signal high, injector solenoid valve cylinder 4	A12	7	2			Signal low, injector solenoid valve cylinder 4
A2	1	1			Signal high, injector solenoid valve cylinder 1																																																																										
A5	9		2		Signal low, injector solenoid valve cylinder 3																																																																										
A6	3		1		Signal high, injector solenoid valve cylinder 3																																																																										
A9	8			2	Signal low, injector solenoid valve cylinder 2																																																																										
A10	2			1	Signal high, injector solenoid valve cylinder 2																																																																										
D420	B460	B424	B425	B426	Function																																																																										
A3	2		1		Signal high, injector solenoid valve cylinder 5																																																																										
A4	8		2		Signal low, injector solenoid valve cylinder 5																																																																										
A7	3			1	Signal high, injector solenoid valve cylinder 6																																																																										
A8	9			2	Signal low, injector solenoid valve cylinder 6																																																																										
A11	1	1			Signal high, injector solenoid valve cylinder 4																																																																										
A12	7	2			Signal low, injector solenoid valve cylinder 4																																																																										
Technical data	<p>Component check, injector solenoid valve cylinder 1 (B421)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key off the ignition• Disconnect connector B460• Measure on wiring harness connector B460 <table><tr><td>Pin</td><td>Pin</td><td></td><td></td></tr><tr><td>(+ probe)</td><td>(- probe)</td><td>Value</td><td>Additional information</td></tr><tr><td>1</td><td>7</td><td>$\pm 0.67 \Omega$</td><td>Resistance value at 20°C [68°F]</td></tr><tr><td></td><td></td><td>maximum 0.94 Ω</td><td>Resistance value at 120°C [248°F]</td></tr></table> <p>Component check, injector solenoid valve cylinder 2 (B422)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key off the ignition• Disconnect connector B460• Measure on wiring harness connector B460 <table><tr><td>Pin</td><td>Pin</td><td></td><td></td></tr><tr><td>(+ probe)</td><td>(- probe)</td><td>Value</td><td>Additional information</td></tr><tr><td>2</td><td>8</td><td>$\pm 0.67 \Omega$</td><td>Resistance value at 20°C [68°F]</td></tr><tr><td></td><td></td><td>maximum 0.94 Ω</td><td>Resistance value at 120°C [248°F]</td></tr></table> <p>Component check, injector solenoid valve cylinder 3 (B423)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key off the ignition• Disconnect connector B460• Measure on wiring harness connector B460 <table><tr><td>Pin</td><td>Pin</td><td></td><td></td></tr><tr><td>(+ probe)</td><td>(- probe)</td><td>Value</td><td>Additional information</td></tr><tr><td>3</td><td>9</td><td>$\pm 0.67 \Omega$</td><td>Resistance value at 20°C [68°F]</td></tr><tr><td></td><td></td><td>maximum 0.94 Ω</td><td>Resistance value at 120°C [248°F]</td></tr></table> <p>Component check, injector solenoid valve cylinder 4 (B424)</p> <p>Preparation</p>	Pin	Pin			(+ probe)	(- probe)	Value	Additional information	1	7	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]			maximum 0.94 Ω	Resistance value at 120°C [248°F]	Pin	Pin			(+ probe)	(- probe)	Value	Additional information	2	8	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]			maximum 0.94 Ω	Resistance value at 120°C [248°F]	Pin	Pin			(+ probe)	(- probe)	Value	Additional information	3	9	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]			maximum 0.94 Ω	Resistance value at 120°C [248°F]																														
Pin	Pin																																																																														
(+ probe)	(- probe)	Value	Additional information																																																																												
1	7	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]																																																																												
		maximum 0.94 Ω	Resistance value at 120°C [248°F]																																																																												
Pin	Pin																																																																														
(+ probe)	(- probe)	Value	Additional information																																																																												
2	8	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]																																																																												
		maximum 0.94 Ω	Resistance value at 120°C [248°F]																																																																												
Pin	Pin																																																																														
(+ probe)	(- probe)	Value	Additional information																																																																												
3	9	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]																																																																												
		maximum 0.94 Ω	Resistance value at 120°C [248°F]																																																																												



	<ul style="list-style-type: none"> • Key off the ignition • Disconnect connector B461 • Measure on wiring harness connector B461 <table> <tr> <th>Pin</th><th>Pin</th><th>Value</th><th>Additional information</th></tr> <tr> <td>(+ probe)</td><td>(- probe)</td><td></td><td></td></tr> <tr> <td>1</td><td>7</td><td>$\pm 0.67 \Omega$</td><td>Resistance value at 20°C [68°F]</td></tr> <tr> <td></td><td></td><td>maximum 0.94 Ω</td><td>Resistance value at 120°C [248°F]</td></tr> </table> <p>Component check, injector solenoid valve cylinder 5 (B425)</p> <p>Preparation</p> <ul style="list-style-type: none"> • Key off the ignition • Disconnect connector B461 • Measure on wiring harness connector B461 <table> <tr> <th>Pin</th><th>Pin</th><th>Value</th><th>Additional information</th></tr> <tr> <td>(+ probe)</td><td>(- probe)</td><td></td><td></td></tr> <tr> <td>2</td><td>8</td><td>$\pm 0.67 \Omega$</td><td>Resistance value at 20°C [68°F]</td></tr> <tr> <td></td><td></td><td>maximum 0.94 Ω</td><td>Resistance value at 120°C [248°F]</td></tr> </table> <p>Component check, injector solenoid valve cylinder 6 (B426)</p> <p>Preparation</p> <ul style="list-style-type: none"> • Key off the ignition • Disconnect connector B461 • Measure on wiring harness connector B461 <table> <tr> <th>Pin</th><th>Pin</th><th>Value</th><th>Additional information</th></tr> <tr> <td>(+ probe)</td><td>(- probe)</td><td></td><td></td></tr> <tr> <td>3</td><td>9</td><td>$\pm 0.67 \Omega$</td><td>Resistance value at 20°C [68°F]</td></tr> <tr> <td></td><td></td><td>maximum 0.94 Ω</td><td>Resistance value at 120°C [248°F]</td></tr> </table>			Pin	Pin	Value	Additional information	(+ probe)	(- probe)			1	7	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]			maximum 0.94 Ω	Resistance value at 120°C [248°F]	Pin	Pin	Value	Additional information	(+ probe)	(- probe)			2	8	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]			maximum 0.94 Ω	Resistance value at 120°C [248°F]	Pin	Pin	Value	Additional information	(+ probe)	(- probe)			3	9	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]			maximum 0.94 Ω	Resistance value at 120°C [248°F]
Pin	Pin	Value	Additional information																																																
(+ probe)	(- probe)																																																		
1	7	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]																																																
		maximum 0.94 Ω	Resistance value at 120°C [248°F]																																																
Pin	Pin	Value	Additional information																																																
(+ probe)	(- probe)																																																		
2	8	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]																																																
		maximum 0.94 Ω	Resistance value at 120°C [248°F]																																																
Pin	Pin	Value	Additional information																																																
(+ probe)	(- probe)																																																		
3	9	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]																																																
		maximum 0.94 Ω	Resistance value at 120°C [248°F]																																																
Possible causes	No possible causes available.																																																		
Additional information	No additional information available.																																																		
Diagnostic Step-by-Step	<div>  <p>Perform the troubleshooting steps below using the breakout harness, if necessary, to check electrical components, such as sensors, electrical control units, and harnesses. Back probing is not recommended, as it could damage the harness. The ignition should always be in the OFF position when connecting or disconnecting electrical components in order to reduce the likelihood of damage to electrical components.</p> </div> <div>  <ul style="list-style-type: none"> • Disconnecting the EAS connectors during the troubleshooting process will result in multiple errors. • For specific electrical component information and pinout locations, always refer to the technical data. • It is necessary to exit the fault code menu in DAVIE and run the diagnostic test again to identify a change in errors. • Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive fault codes. Refer to the 'possible causes' section. </div>																																																		
	Step 1	Step ID 1204a	SRT																																																

	Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.		
	Step 2	Step ID 1204b	SRT
	<p>Electrical Checks</p> <p>Ensure that the ignition key/switch has been set to OFF before disconnecting related cables.</p> <p>Based on the fault message provided, confirm that the following electrical values are within specified ranges or limits:</p> <ul style="list-style-type: none"> • Supply and signal voltages (12V). • Cable continuity (no opens or shorts). <p>Are measured electrical values outside of expected range or limits?</p> <ul style="list-style-type: none"> • Yes - Proceed to step 3 • No - Proceed to step 4 		
	Step 3	Step ID 1204c	SRT
	<p>Repairs or component replacements appropriate component 'Solenoid Valve Injector, Cylinder 1' and use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none"> • Fault inactive – issue resolve • Fault active - Proceed to step 4 		
Verification Drive Cycle	Step 4	Step ID 1204d	SRT
	For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the Engine Support Call Center at 1-800-477-0251.		
	Back to Index		


P1205

Code number	P1205
Fault code description	Injector solenoid valve cylinder 5 - Current too low or open circuit on ECU D420 pin A4
Fault code information	1 trip MIL 3 drive cycle recovery Readiness group – None Freeze frame type – Comprehensive
Description of component(s)	<p>The fuel injector injects fuel into the combustion chamber. Control</p> <p>The amount of fuel injected depends on the duration of the injector solenoid activation in combination with the rail pressure. The longer the solenoid is activated by the PCI ECU at the same rail pressure, the more fuel is injected.</p> <p>Injector codes</p> <p>Every fuel injector is calibrated during production to compensate for any production tolerances. An injector calibration code is present on the housing and connector of the injector. These injector codes must be (re)programmed with DAVIE if one or more injectors have been replaced or fitted in another position, or if the PCI ECU is replaced.</p> <p>Not programming or incorrectly programmed injector codes can result in reduced engine performance or a warning to the driver.</p>
Location of component(s)	
Diagnostic condition	This diagnostic runs when power stage hardware is active.
Set condition of fault code	This condition is set when current in Needle control valve is less than 4.5 A.
Reset condition of fault code	This fault code will change to inactive immediately after the diagnostic runs and passes.

Electrical diagram(s)



Wiring harness connector D420.A front view



Wiring harness connector B460 & B461 front view

B460 connector cylinders 1-3

B461 connector cylinders 4-6

D420 PCI ECU

B421 solenoid valve injector cylinder 1

B422 solenoid valve injector cylinder 2

B423 solenoid valve injector cylinder 3



B424 solenoid valve injector cylinder 4

B425 solenoid valve injector cylinder 5

B426 solenoid valve injector cylinder 6


D420	B460	B421	B422	B423	Function
A1	7	2			Signal low, injector solenoid valve cylinder 1

	<table><tr><td>A2</td><td>1</td><td>1</td><td></td><td></td><td>Signal high, injector solenoid valve cylinder 1</td></tr><tr><td>A5</td><td>9</td><td></td><td>2</td><td></td><td>Signal low, injector solenoid valve cylinder 3</td></tr><tr><td>A6</td><td>3</td><td></td><td>1</td><td></td><td>Signal high, injector solenoid valve cylinder 3</td></tr><tr><td>A9</td><td>8</td><td></td><td></td><td>2</td><td>Signal low, injector solenoid valve cylinder 2</td></tr><tr><td>A10</td><td>2</td><td></td><td></td><td>1</td><td>Signal high, injector solenoid valve cylinder 2</td></tr><tr><td colspan="6"> </td></tr><tr><td>D420</td><td>B460</td><td>B424</td><td>B425</td><td>B426</td><td>Function</td></tr><tr><td>A3</td><td>2</td><td></td><td>1</td><td></td><td>Signal high, injector solenoid valve cylinder 5</td></tr><tr><td>A4</td><td>8</td><td></td><td>2</td><td></td><td>Signal low, injector solenoid valve cylinder 5</td></tr><tr><td>A7</td><td>3</td><td></td><td></td><td>1</td><td>Signal high, injector solenoid valve cylinder 6</td></tr><tr><td>A8</td><td>9</td><td></td><td></td><td>2</td><td>Signal low, injector solenoid valve cylinder 6</td></tr><tr><td>A11</td><td>1</td><td>1</td><td></td><td></td><td>Signal high, injector solenoid valve cylinder 4</td></tr><tr><td>A12</td><td>7</td><td>2</td><td></td><td></td><td>Signal low, injector solenoid valve cylinder 4</td></tr></table>					A2	1	1			Signal high, injector solenoid valve cylinder 1	A5	9		2		Signal low, injector solenoid valve cylinder 3	A6	3		1		Signal high, injector solenoid valve cylinder 3	A9	8			2	Signal low, injector solenoid valve cylinder 2	A10	2			1	Signal high, injector solenoid valve cylinder 2							D420	B460	B424	B425	B426	Function	A3	2		1		Signal high, injector solenoid valve cylinder 5	A4	8		2		Signal low, injector solenoid valve cylinder 5	A7	3			1	Signal high, injector solenoid valve cylinder 6	A8	9			2	Signal low, injector solenoid valve cylinder 6	A11	1	1			Signal high, injector solenoid valve cylinder 4	A12	7	2			Signal low, injector solenoid valve cylinder 4
A2	1	1			Signal high, injector solenoid valve cylinder 1																																																																														
A5	9		2		Signal low, injector solenoid valve cylinder 3																																																																														
A6	3		1		Signal high, injector solenoid valve cylinder 3																																																																														
A9	8			2	Signal low, injector solenoid valve cylinder 2																																																																														
A10	2			1	Signal high, injector solenoid valve cylinder 2																																																																														
D420	B460	B424	B425	B426	Function																																																																														
A3	2		1		Signal high, injector solenoid valve cylinder 5																																																																														
A4	8		2		Signal low, injector solenoid valve cylinder 5																																																																														
A7	3			1	Signal high, injector solenoid valve cylinder 6																																																																														
A8	9			2	Signal low, injector solenoid valve cylinder 6																																																																														
A11	1	1			Signal high, injector solenoid valve cylinder 4																																																																														
A12	7	2			Signal low, injector solenoid valve cylinder 4																																																																														
Technical data	<div>Component check, injector solenoid valve cylinder 1 (B421)</div> <div>Preparation<ul style="list-style-type: none">Key off the ignitionDisconnect connector B460Measure on wiring harness connector B460<table><tr><td>Pin</td><td>Pin</td><td></td><td></td></tr><tr><td>(+ probe)</td><td>(- probe)</td><td>Value</td><td>Additional information</td></tr><tr><td>1</td><td>7</td><td>$\pm 0.67 \Omega$</td><td>Resistance value at 20°C [68°F]</td></tr><tr><td></td><td></td><td>maximum 0.94 Ω</td><td>Resistance value at 120°C [248°F]</td></tr></table></div> <div>Component check, injector solenoid valve cylinder 2 (B422)</div> <div>Preparation<ul style="list-style-type: none">Key off the ignitionDisconnect connector B460Measure on wiring harness connector B460<table><tr><td>Pin</td><td>Pin</td><td></td><td></td></tr><tr><td>(+ probe)</td><td>(- probe)</td><td>Value</td><td>Additional information</td></tr><tr><td>2</td><td>8</td><td>$\pm 0.67 \Omega$</td><td>Resistance value at 20°C [68°F]</td></tr><tr><td></td><td></td><td>maximum 0.94 Ω</td><td>Resistance value at 120°C [248°F]</td></tr></table></div> <div>Component check, injector solenoid valve cylinder 3 (B423)</div> <div>Preparation<ul style="list-style-type: none">Key off the ignitionDisconnect connector B460Measure on wiring harness connector B460<table><tr><td>Pin</td><td>Pin</td><td></td><td></td></tr><tr><td>(+ probe)</td><td>(- probe)</td><td>Value</td><td>Additional information</td></tr><tr><td>3</td><td>9</td><td>$\pm 0.67 \Omega$</td><td>Resistance value at 20°C [68°F]</td></tr><tr><td></td><td></td><td>maximum 0.94 Ω</td><td>Resistance value at 120°C [248°F]</td></tr></table></div> <div>Component check, injector solenoid valve cylinder 4 (B424)</div>					Pin	Pin			(+ probe)	(- probe)	Value	Additional information	1	7	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]			maximum 0.94 Ω	Resistance value at 120°C [248°F]	Pin	Pin			(+ probe)	(- probe)	Value	Additional information	2	8	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]			maximum 0.94 Ω	Resistance value at 120°C [248°F]	Pin	Pin			(+ probe)	(- probe)	Value	Additional information	3	9	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]			maximum 0.94 Ω	Resistance value at 120°C [248°F]																														
Pin	Pin																																																																																		
(+ probe)	(- probe)	Value	Additional information																																																																																
1	7	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]																																																																																
		maximum 0.94 Ω	Resistance value at 120°C [248°F]																																																																																
Pin	Pin																																																																																		
(+ probe)	(- probe)	Value	Additional information																																																																																
2	8	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]																																																																																
		maximum 0.94 Ω	Resistance value at 120°C [248°F]																																																																																
Pin	Pin																																																																																		
(+ probe)	(- probe)	Value	Additional information																																																																																
3	9	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]																																																																																
		maximum 0.94 Ω	Resistance value at 120°C [248°F]																																																																																



	<p>Preparation</p> <ul style="list-style-type: none">• Key off the ignition• Disconnect connector B461• Measure on wiring harness connector B461 <table><tr><th>Pin (+ probe)</th><th>Pin (- probe)</th><th>Value</th><th>Additional information</th></tr><tr><td>1</td><td>7</td><td>$\pm 0.67 \Omega$ maximum 0.94Ω</td><td>Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]</td></tr></table> <p>Component check, injector solenoid valve cylinder 5 (B425)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key off the ignition• Disconnect connector B461• Measure on wiring harness connector B461 <table><tr><th>Pin (+ probe)</th><th>Pin (- probe)</th><th>Value</th><th>Additional information</th></tr><tr><td>2</td><td>8</td><td>$\pm 0.67 \Omega$ maximum 0.94Ω</td><td>Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]</td></tr></table> <p>Component check, injector solenoid valve cylinder 6 (B426)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key off the ignition• Disconnect connector B461• Measure on wiring harness connector B461 <table><tr><th>Pin (+ probe)</th><th>Pin (- probe)</th><th>Value</th><th>Additional information</th></tr><tr><td>3</td><td>9</td><td>$\pm 0.67 \Omega$ maximum 0.94Ω</td><td>Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]</td></tr></table>	Pin (+ probe)	Pin (- probe)	Value	Additional information	1	7	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]	Pin (+ probe)	Pin (- probe)	Value	Additional information	2	8	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]	Pin (+ probe)	Pin (- probe)	Value	Additional information	3	9	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]
Pin (+ probe)	Pin (- probe)	Value	Additional information																						
1	7	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]																						
Pin (+ probe)	Pin (- probe)	Value	Additional information																						
2	8	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]																						
Pin (+ probe)	Pin (- probe)	Value	Additional information																						
3	9	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]																						
Possible causes	No possible causes available.																								
Additional information	No additional information available.																								
Diagnostic Step-by-Step	<div><p>Perform the troubleshooting steps below using the breakout harness, if necessary, to check electrical components, such as sensors, electrical control units, and harnesses. Back probing is not recommended, as it could damage the harness. The ignition should always be in the OFF position when connecting or disconnecting electrical components in order to reduce the likelihood of damage to electrical components.</p></div> <div><ul style="list-style-type: none">• Disconnecting the EAS connectors during the troubleshooting process will result in multiple errors.• For specific electrical component information and pinout locations, always refer to the technical data.• It is necessary to exit the fault code menu in DAVIE and run the diagnostic test again to identify a change in errors.• Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive fault codes. Refer to the 'possible causes' section.</div>																								

	<table><tr><td>Step 1</td><td>Step ID 1205a</td><td>SRT</td></tr><tr><td colspan="3">Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.</td></tr></table>	Step 1	Step ID 1205a	SRT	Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.		
	Step 1	Step ID 1205a	SRT				
	Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.						
	<table><tr><td>Step 2</td><td>Step ID 1205b</td><td>SRT</td></tr><tr><td colspan="3"><p>Electrical Checks</p><p>Ensure that the ignition key/switch has been set to OFF before disconnecting related cables.</p><p>Based on the fault message provided, confirm that the following electrical values are within specified ranges or limits:</p><ul style="list-style-type: none">• Supply and signal voltages (12V).• Cable continuity (no opens or shorts).<p>Are measured electrical values outside of expected range or limits?</p><ul style="list-style-type: none">• Yes - Proceed to step 3• No - Proceed to step 4</td></tr></table>	Step 2	Step ID 1205b	SRT	<p>Electrical Checks</p> <p>Ensure that the ignition key/switch has been set to OFF before disconnecting related cables.</p> <p>Based on the fault message provided, confirm that the following electrical values are within specified ranges or limits:</p> <ul style="list-style-type: none">• Supply and signal voltages (12V).• Cable continuity (no opens or shorts). <p>Are measured electrical values outside of expected range or limits?</p> <ul style="list-style-type: none">• Yes - Proceed to step 3• No - Proceed to step 4		
Step 2	Step ID 1205b	SRT					
<p>Electrical Checks</p> <p>Ensure that the ignition key/switch has been set to OFF before disconnecting related cables.</p> <p>Based on the fault message provided, confirm that the following electrical values are within specified ranges or limits:</p> <ul style="list-style-type: none">• Supply and signal voltages (12V).• Cable continuity (no opens or shorts). <p>Are measured electrical values outside of expected range or limits?</p> <ul style="list-style-type: none">• Yes - Proceed to step 3• No - Proceed to step 4							
<table><tr><td>Step 3</td><td>Step ID 1205c</td><td>SRT</td></tr><tr><td colspan="3"><p>Repairs or component replacements appropriate component ‘Solenoid Valve Injector, Cylinder 5’ and use DAVIE to re-check for the presence of active faults.</p><ul style="list-style-type: none">• Fault inactive – issue resolve• Fault active - Proceed to step 4</td></tr></table>	Step 3	Step ID 1205c	SRT	<p>Repairs or component replacements appropriate component ‘Solenoid Valve Injector, Cylinder 5’ and use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">• Fault inactive – issue resolve• Fault active - Proceed to step 4			
Step 3	Step ID 1205c	SRT					
<p>Repairs or component replacements appropriate component ‘Solenoid Valve Injector, Cylinder 5’ and use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">• Fault inactive – issue resolve• Fault active - Proceed to step 4							
<table><tr><td>Step 4</td><td>Step ID 1205d</td><td>SRT</td></tr><tr><td colspan="3">For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the Engine Support Call Center at 1-800-477-0251.</td></tr></table>	Step 4	Step ID 1205d	SRT	For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the Engine Support Call Center at 1-800-477-0251.			
Step 4	Step ID 1205d	SRT					
For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the Engine Support Call Center at 1-800-477-0251.							
Verification Drive Cycle	To validate repair, with the brakes set, turn the key to the ON position with the engine off, and allow 10 seconds for the system to initialize and run diagnostics.						
	Back to Index						


P1206

Code number	P1206
Fault code description	Injector solenoid valve cylinder 5-Short circuit between ECU D420 pin A3 and A4.
Fault code information	<p>1 trip MIL</p> <p>3 drive cycle recovery</p> <p>Readiness group – None</p> <p>Freeze frame type - Comprehensive</p>
Description of component(s)	<p>The fuel injector injects fuel into the combustion chamber.</p> <p>Control</p> <p>The amount of fuel injected depends on the duration of the injector solenoid activation in combination with the rail pressure. The longer the solenoid is activated by the PCI ECU at the same rail pressure, the more fuel is injected.</p> <p>Injector codes</p> <p>Every fuel injector is calibrated during production to compensate for any production tolerances. An injector calibration code is present on the housing and connector of the injector. These injector codes must be (re)programmed with DAVIE if one or more injectors have been replaced or fitted in another position, or if the PCI ECU is replaced.</p> <p>Not programming or incorrectly programmed injector codes can result in reduced engine performance or a warning to the driver.</p>
Location of component(s)	
Diagnostic condition	This diagnostic runs when power stage hardware is active.
Set condition of fault code	<ul style="list-style-type: none"> High side voltage on the injector (before injection) compared to battery voltage is less than 20% and greater than 80.00% of threshold value Current passing through sense resistor is greater than 25.00A of the threshold value
Reset condition of fault code	This fault code will change to inactive immediately after the diagnostic runs and passes.

Electrical diagram(s)



Wiring harness connector D420.A front view



Wiring harness connector B460 & B461 front view

B460 connector cylinders 1-3

B461 connector cylinders 4-6

D420 PCI ECU

B421 solenoid valve injector cylinder 1

B422 solenoid valve injector cylinder 2

B423 solenoid valve injector cylinder 3



B424 solenoid valve injector cylinder 4

B425 solenoid valve injector cylinder 5

B426 solenoid valve injector cylinder 6


D420 B460 B421 B422 B423 Function

A1 7 2 Signal low, injector solenoid valve cylinder 1



	<table><tr><td>A2</td><td>1</td><td>1</td><td></td><td></td><td>Signal high, injector solenoid valve cylinder 1</td></tr><tr><td>A5</td><td>9</td><td></td><td>2</td><td></td><td>Signal low, injector solenoid valve cylinder 3</td></tr><tr><td>A6</td><td>3</td><td></td><td>1</td><td></td><td>Signal high, injector solenoid valve cylinder 3</td></tr><tr><td>A9</td><td>8</td><td></td><td></td><td>2</td><td>Signal low, injector solenoid valve cylinder 2</td></tr><tr><td>A10</td><td>2</td><td></td><td></td><td>1</td><td>Signal high, injector solenoid valve cylinder 2</td></tr><tr><td colspan="6"> </td></tr><tr><td>D420</td><td>B460</td><td>B424</td><td>B425</td><td>B426</td><td>Function</td></tr><tr><td>A3</td><td>2</td><td></td><td>1</td><td></td><td>Signal high, injector solenoid valve cylinder 5</td></tr><tr><td>A4</td><td>8</td><td></td><td>2</td><td></td><td>Signal low, injector solenoid valve cylinder 5</td></tr><tr><td>A7</td><td>3</td><td></td><td></td><td>1</td><td>Signal high, injector solenoid valve cylinder 6</td></tr><tr><td>A8</td><td>9</td><td></td><td></td><td>2</td><td>Signal low, injector solenoid valve cylinder 6</td></tr><tr><td>A11</td><td>1</td><td>1</td><td></td><td></td><td>Signal high, injector solenoid valve cylinder 4</td></tr><tr><td>A12</td><td>7</td><td>2</td><td></td><td></td><td>Signal low, injector solenoid valve cylinder 4</td></tr></table>	A2	1	1			Signal high, injector solenoid valve cylinder 1	A5	9		2		Signal low, injector solenoid valve cylinder 3	A6	3		1		Signal high, injector solenoid valve cylinder 3	A9	8			2	Signal low, injector solenoid valve cylinder 2	A10	2			1	Signal high, injector solenoid valve cylinder 2							D420	B460	B424	B425	B426	Function	A3	2		1		Signal high, injector solenoid valve cylinder 5	A4	8		2		Signal low, injector solenoid valve cylinder 5	A7	3			1	Signal high, injector solenoid valve cylinder 6	A8	9			2	Signal low, injector solenoid valve cylinder 6	A11	1	1			Signal high, injector solenoid valve cylinder 4	A12	7	2			Signal low, injector solenoid valve cylinder 4
A2	1	1			Signal high, injector solenoid valve cylinder 1																																																																										
A5	9		2		Signal low, injector solenoid valve cylinder 3																																																																										
A6	3		1		Signal high, injector solenoid valve cylinder 3																																																																										
A9	8			2	Signal low, injector solenoid valve cylinder 2																																																																										
A10	2			1	Signal high, injector solenoid valve cylinder 2																																																																										
D420	B460	B424	B425	B426	Function																																																																										
A3	2		1		Signal high, injector solenoid valve cylinder 5																																																																										
A4	8		2		Signal low, injector solenoid valve cylinder 5																																																																										
A7	3			1	Signal high, injector solenoid valve cylinder 6																																																																										
A8	9			2	Signal low, injector solenoid valve cylinder 6																																																																										
A11	1	1			Signal high, injector solenoid valve cylinder 4																																																																										
A12	7	2			Signal low, injector solenoid valve cylinder 4																																																																										
Technical data	<p>Component check, injector solenoid valve cylinder 5 (B425)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key off the ignition• Disconnect connector B461• Measure on wiring harness connector B461 <table><tr><td>Pin (+ probe)</td><td>Pin (- probe)</td><td>Value</td><td>Additional information</td></tr><tr><td>2</td><td>8</td><td>± 0.67 Ω maximum 0.94 Ω</td><td>Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]</td></tr></table>	Pin (+ probe)	Pin (- probe)	Value	Additional information	2	8	± 0.67 Ω maximum 0.94 Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]																																																																						
Pin (+ probe)	Pin (- probe)	Value	Additional information																																																																												
2	8	± 0.67 Ω maximum 0.94 Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]																																																																												
Possible cause	No possible causes available.																																																																														
Additional information	No additional information available.																																																																														
Diagnostic Step-by-Step	<div><div></div><div><p>Perform the troubleshooting steps below using the breakout harness, if necessary, to check electrical components, such as sensors, electrical control units, and harnesses. Back probing is not recommended, as it could damage the harness. The ignition should always be in the OFF position when connecting or disconnecting electrical components in order to reduce the likelihood of damage to electrical components.</p></div></div> <div><div></div><ul style="list-style-type: none">• Disconnecting the EAS connectors during the troubleshooting process will result in multiple errors.• For specific electrical component information and pinout locations, always refer to the technical data.• It is necessary to exit the fault code menu in DAVIE and run the diagnostic test again to identify a change in errors.• Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive fault codes. Refer to the 'possible causes' section.</div> <table><tr><td>Step 1</td><td>Step ID 1206a</td><td>SRT</td></tr><tr><td colspan="3">Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.</td></tr></table> <table><tr><td>Step 2</td><td>Step ID 1206b</td><td>SRT</td></tr><tr><td colspan="3">Follow ESV through to find any electrical related problems</td></tr></table>	Step 1	Step ID 1206a	SRT	Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.			Step 2	Step ID 1206b	SRT	Follow ESV through to find any electrical related problems																																																																				
Step 1	Step ID 1206a	SRT																																																																													
Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.																																																																															
Step 2	Step ID 1206b	SRT																																																																													
Follow ESV through to find any electrical related problems																																																																															

	<p>Based on the fault message provided, confirm that the following electrical values are within specified ranges or limits:</p> <p>Ensure that the ignition key/switch has been set to OFF before disconnecting related cables.</p> <ul style="list-style-type: none">• Supply and signal voltages.• Cable continuity (no opens or shorts). <p>Are measured electrical values outside of expected range or limits?</p> <ul style="list-style-type: none">• No: Issue resolved.• Yes: Make the appropriate repairs or component replacements. Proceed to Step 3 <p>Use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">• If this related fault is no longer active, then this issue has been resolved.• If this related fault is still active, continue to the Step 4 in the troubleshooting process.						
	<table><tr><td>Step 3</td><td>Step ID 1206c</td><td>SRT</td></tr><tr><td colspan="3"><p>Replace: Solenoid Valve Injector, Cylinder 5</p><p>Replace the identified faulty component.</p><p>Use DAVIE to re-check for the presence of active faults.</p><ul style="list-style-type: none">• If this related fault is no longer active, then this issue has been resolved.• If this related fault is still active, continue to Step 4 in the troubleshooting process</td></tr></table>	Step 3	Step ID 1206c	SRT	<p>Replace: Solenoid Valve Injector, Cylinder 5</p> <p>Replace the identified faulty component.</p> <p>Use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">• If this related fault is no longer active, then this issue has been resolved.• If this related fault is still active, continue to Step 4 in the troubleshooting process		
Step 3	Step ID 1206c	SRT					
<p>Replace: Solenoid Valve Injector, Cylinder 5</p> <p>Replace the identified faulty component.</p> <p>Use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">• If this related fault is no longer active, then this issue has been resolved.• If this related fault is still active, continue to Step 4 in the troubleshooting process							
	<table><tr><td>Step 4</td><td>Step ID 1206d</td><td>SRT</td></tr><tr><td colspan="3"><p>Contact the PACCAR Engine Support Call Center</p><p>For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center at 1-800-477-0251.</p></td></tr></table>	Step 4	Step ID 1206d	SRT	<p>Contact the PACCAR Engine Support Call Center</p> <p>For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center at 1-800-477-0251.</p>		
Step 4	Step ID 1206d	SRT					
<p>Contact the PACCAR Engine Support Call Center</p> <p>For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center at 1-800-477-0251.</p>							
Verification Drive Cycle	To validate repair, with the brakes set, turn the key to the ON position with the engine off, and allow 10 seconds for the system to initialize and run diagnostics.						
	Back to Index						


P1207

Code number	P1207
Fault code description	Injector solenoid valve cylinder 5-Voltage too low or short circuit to ground on ECU D420 pin A4.
Fault code information	1 trip MIL 3 drive cycle recovery Readiness group – None Freeze frame type - Comprehensive
Description of component(s)	<p>The fuel injector injects fuel into the combustion chamber. Control</p> <p>The amount of fuel injected depends on the duration of the injector solenoid activation in combination with the rail pressure. The longer the solenoid is activated by the PCI ECU at the same rail pressure, the more fuel is injected.</p> <p>Injector codes</p> <p>Every fuel injector is calibrated during production to compensate for any production tolerances. An injector calibration code is present on the housing and connector of the injector. These injector codes must be (re)programmed with DAVIE if one or more injectors have been replaced or fitted in another position, or if the PCI ECU is replaced.</p> <p>Not programming or incorrectly programmed injector codes can result in reduced engine performance or a warning to the driver.</p>
Location of component(s)	
Diagnostic condition	This diagnostic runs when power stage hardware is active.
Set condition of fault code	<ul style="list-style-type: none"> High side voltage on the injector (before injection) compared to battery voltage is less than 20.00% of threshold value Current through sense resistor on driver bank B is less than 4.5A of the threshold value
Reset condition of fault code	This fault code will change to inactive immediately after the diagnostic runs and passes.

Electrical diagram(s)



Wiring harness connector D420.A front view



Wiring harness connector B460 & B461 front view

B460 connector cylinders 1-3

B461 connector cylinders 4-6

D420 PCI ECU

B421 solenoid valve injector cylinder 1

B422 solenoid valve injector cylinder 2



B423 solenoid valve injector cylinder 3

B424 solenoid valve injector cylinder 4

B425 solenoid valve injector cylinder 5


B426 solenoid valve injector cylinder 6

D420	B460	B421	B422	B423	Function
A1	7	2			Signal low, injector solenoid valve cylinder 1



	<table><tr><td>A2</td><td>1</td><td>1</td><td></td><td></td><td>Signal high, injector solenoid valve cylinder 1</td></tr><tr><td>A5</td><td>9</td><td></td><td>2</td><td></td><td>Signal low, injector solenoid valve cylinder 3</td></tr><tr><td>A6</td><td>3</td><td></td><td>1</td><td></td><td>Signal high, injector solenoid valve cylinder 3</td></tr><tr><td>A9</td><td>8</td><td></td><td></td><td>2</td><td>Signal low, injector solenoid valve cylinder 2</td></tr><tr><td>A10</td><td>2</td><td></td><td></td><td>1</td><td>Signal high, injector solenoid valve cylinder 2</td></tr><tr><td>D420</td><td>B460</td><td>B424</td><td>B425</td><td>B426</td><td>Function</td></tr><tr><td>A3</td><td>2</td><td></td><td>1</td><td></td><td>Signal high, injector solenoid valve cylinder 5</td></tr><tr><td>A4</td><td>8</td><td></td><td>2</td><td></td><td>Signal low, injector solenoid valve cylinder 5</td></tr><tr><td>A7</td><td>3</td><td></td><td></td><td>1</td><td>Signal high, injector solenoid valve cylinder 6</td></tr><tr><td>A8</td><td>9</td><td></td><td></td><td>2</td><td>Signal low, injector solenoid valve cylinder 6</td></tr><tr><td>A11</td><td>1</td><td>1</td><td></td><td></td><td>Signal high, injector solenoid valve cylinder 4</td></tr><tr><td>A12</td><td>7</td><td>2</td><td></td><td></td><td>Signal low, injector solenoid valve cylinder 4</td></tr></table>	A2	1	1			Signal high, injector solenoid valve cylinder 1	A5	9		2		Signal low, injector solenoid valve cylinder 3	A6	3		1		Signal high, injector solenoid valve cylinder 3	A9	8			2	Signal low, injector solenoid valve cylinder 2	A10	2			1	Signal high, injector solenoid valve cylinder 2	D420	B460	B424	B425	B426	Function	A3	2		1		Signal high, injector solenoid valve cylinder 5	A4	8		2		Signal low, injector solenoid valve cylinder 5	A7	3			1	Signal high, injector solenoid valve cylinder 6	A8	9			2	Signal low, injector solenoid valve cylinder 6	A11	1	1			Signal high, injector solenoid valve cylinder 4	A12	7	2			Signal low, injector solenoid valve cylinder 4
A2	1	1			Signal high, injector solenoid valve cylinder 1																																																																				
A5	9		2		Signal low, injector solenoid valve cylinder 3																																																																				
A6	3		1		Signal high, injector solenoid valve cylinder 3																																																																				
A9	8			2	Signal low, injector solenoid valve cylinder 2																																																																				
A10	2			1	Signal high, injector solenoid valve cylinder 2																																																																				
D420	B460	B424	B425	B426	Function																																																																				
A3	2		1		Signal high, injector solenoid valve cylinder 5																																																																				
A4	8		2		Signal low, injector solenoid valve cylinder 5																																																																				
A7	3			1	Signal high, injector solenoid valve cylinder 6																																																																				
A8	9			2	Signal low, injector solenoid valve cylinder 6																																																																				
A11	1	1			Signal high, injector solenoid valve cylinder 4																																																																				
A12	7	2			Signal low, injector solenoid valve cylinder 4																																																																				
Technical data	<p>Component check, injector solenoid valve cylinder 5 (B425)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key off the ignition• Disconnect connector B461• Measure on wiring harness connector B461 <table><tr><td>Pin</td><td>Pin</td><td></td><td></td></tr><tr><td>(+ probe)</td><td>(- probe)</td><td>Value</td><td>Additional information</td></tr><tr><td>2</td><td>8</td><td>± 0.67 Ω</td><td>Resistance value at 20°C [68°F]</td></tr><tr><td></td><td></td><td>maximum 0.94 Ω</td><td>Resistance value at 120°C [248°F]</td></tr></table>	Pin	Pin			(+ probe)	(- probe)	Value	Additional information	2	8	± 0.67 Ω	Resistance value at 20°C [68°F]			maximum 0.94 Ω	Resistance value at 120°C [248°F]																																																								
Pin	Pin																																																																								
(+ probe)	(- probe)	Value	Additional information																																																																						
2	8	± 0.67 Ω	Resistance value at 20°C [68°F]																																																																						
		maximum 0.94 Ω	Resistance value at 120°C [248°F]																																																																						
Possible causes	No possible causes available.																																																																								
Additional information	No additional information available.																																																																								
Diagnostic Step-by-Step	<div><div></div><div><p>Perform the troubleshooting steps below using the breakout harness, if necessary, to check electrical components, such as sensors, electrical control units, and harnesses. Back probing is not recommended, as it could damage the harness. The ignition should always be in the OFF position when connecting or disconnecting electrical components in order to reduce the likelihood of damage to electrical components.</p></div></div> <div><div></div><ul style="list-style-type: none">• Disconnecting the EAS connectors during the troubleshooting process will result in multiple errors.• For specific electrical component information and pinout locations, always refer to the technical data.• It is necessary to exit the fault code menu in DAVIE and run the diagnostic test again to identify a change in errors.• Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive fault codes. Refer to the 'possible causes' section.</div> <table><tr><td>Step 1</td><td>Step ID 1207a</td><td>SRT</td></tr><tr><td colspan="3">Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.</td></tr><tr><td>Step 2</td><td>Step ID 1207b</td><td>SRT</td></tr></table>	Step 1	Step ID 1207a	SRT	Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.			Step 2	Step ID 1207b	SRT																																																															
Step 1	Step ID 1207a	SRT																																																																							
Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.																																																																									
Step 2	Step ID 1207b	SRT																																																																							

	<p>Follow ESV through to find any electrical related problems Based on the fault message provided, confirm that the following electrical values are within specified ranges or limits: Ensure that the ignition key/switch has been set to OFF before disconnecting related cables.</p> <ul style="list-style-type: none">• Supply and signal voltages.• Cable continuity (no opens or shorts). <p>Are measured electrical values outside of expected range or limits?</p> <ul style="list-style-type: none">• No: Issue resolved.• Yes: Make the appropriate repairs or component replacements. <p>Use DAVIE to re-check for the presence of active faults. Proceed to step 3.</p> <ul style="list-style-type: none">• If this related fault is no longer active, then this issue has been resolved.• If this related fault is still active, continue to the step 4 in the troubleshooting process.						
	<table><tr><td>Step 3</td><td>Step ID 1207c</td><td>SRT</td></tr><tr><td colspan="3"><p>Replace: Solenoid Valve Injector, Cylinder 5 Replace the identified faulty component. Use DAVIE to re-check for the presence of active faults.</p><ul style="list-style-type: none">• If this related fault is no longer active, then this issue has been resolved.• If this related fault is still active, continue to the step 4 in the troubleshooting process</td></tr></table>	Step 3	Step ID 1207c	SRT	<p>Replace: Solenoid Valve Injector, Cylinder 5 Replace the identified faulty component. Use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">• If this related fault is no longer active, then this issue has been resolved.• If this related fault is still active, continue to the step 4 in the troubleshooting process		
Step 3	Step ID 1207c	SRT					
<p>Replace: Solenoid Valve Injector, Cylinder 5 Replace the identified faulty component. Use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">• If this related fault is no longer active, then this issue has been resolved.• If this related fault is still active, continue to the step 4 in the troubleshooting process							
	<table><tr><td>Step 4</td><td>Step ID 1207d</td><td>SRT</td></tr><tr><td colspan="3"><p>Contact the PACCAR Engine Support Call Center For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center at 1-800-477-0251.</p></td></tr></table>	Step 4	Step ID 1207d	SRT	<p>Contact the PACCAR Engine Support Call Center For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center at 1-800-477-0251.</p>		
Step 4	Step ID 1207d	SRT					
<p>Contact the PACCAR Engine Support Call Center For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center at 1-800-477-0251.</p>							
Verification Drive Cycle	To validate repair, with the brakes set, turn the key to the ON position with the engine off, and allow 10 seconds for the system to initialize and run diagnostics.						
	<div>Back to Index</div>						


P1208

Code number	P1208
Fault code description	Injector solenoid valve cylinder 5, Voltage too high or short circuit to supply on ECU D420 pin A4
Fault code information	1 trip MIL 3 drive cycle recovery Readiness group – None Freeze frame type – Comprehensive
Description of component(s)	<p>The fuel injector injects fuel into the combustion chamber. Control</p> <p>The amount of fuel injected depends on the duration of the injector solenoid activation in combination with the rail pressure. The longer the solenoid is activated by the PCI ECU at the same rail pressure, the more fuel is injected.</p> <p>Injector codes</p> <p>Every fuel injector is calibrated during production to compensate for any production tolerances. An injector calibration code is present on the housing and connector of the injector. These injector codes must be (re)programmed with DAVIE if one or more injectors have been replaced or fitted in another position, or if the PCI ECU is replaced.</p> <p>Not programming or incorrectly programmed injector codes can result in reduced engine performance or a warning to the driver.</p>
Location of component(s)	 <p>B425</p>
Diagnostic condition	The diagnostic condition begins when the power stage hardware is active
Set condition of fault code	<ul style="list-style-type: none"> High side voltage on the injector (before injection) compared to battery voltage is greater than 80% of threshold value Current through sense resistor on driver bank B is greater than 25A of threshold value
Reset condition of fault code	This fault code will change to inactive immediately after the diagnostic runs and passes.

Electrical diagram(s)



Wiring harness connector D420.A front view



Wiring harness connector B460 & B461 front view

B460 connector cylinders 1-3

B461 connector cylinders 4-6

D420 PCI ECU

B421 solenoid valve injector cylinder 1

B422 solenoid valve injector cylinder 2



B423 solenoid valve injector cylinder 3

B424 solenoid valve injector cylinder 4

B425 solenoid valve injector cylinder 5


B426 solenoid valve injector cylinder 6

D420	B460	B421	B422	B423	Function
A1	7	2			Signal low, injector solenoid valve cylinder 1



	<table><tr><td>A2</td><td>1</td><td>1</td><td></td><td></td><td>Signal high, injector solenoid valve cylinder 1</td></tr><tr><td>A5</td><td>9</td><td></td><td>2</td><td></td><td>Signal low, injector solenoid valve cylinder 3</td></tr><tr><td>A6</td><td>3</td><td></td><td>1</td><td></td><td>Signal high, injector solenoid valve cylinder 3</td></tr><tr><td>A9</td><td>8</td><td></td><td></td><td>2</td><td>Signal low, injector solenoid valve cylinder 2</td></tr><tr><td>A10</td><td>2</td><td></td><td></td><td>1</td><td>Signal high, injector solenoid valve cylinder 2</td></tr><tr><td colspan="6"> </td></tr><tr><td>D420</td><td>B460</td><td>B424</td><td>B425</td><td>B426</td><td>Function</td></tr><tr><td>A3</td><td>2</td><td></td><td>1</td><td></td><td>Signal high, injector solenoid valve cylinder 5</td></tr><tr><td>A4</td><td>8</td><td></td><td>2</td><td></td><td>Signal low, injector solenoid valve cylinder 5</td></tr><tr><td>A7</td><td>3</td><td></td><td></td><td>1</td><td>Signal high, injector solenoid valve cylinder 6</td></tr><tr><td>A8</td><td>9</td><td></td><td></td><td>2</td><td>Signal low, injector solenoid valve cylinder 6</td></tr><tr><td>A11</td><td>1</td><td>1</td><td></td><td></td><td>Signal high, injector solenoid valve cylinder 4</td></tr><tr><td>A12</td><td>7</td><td>2</td><td></td><td></td><td>Signal low, injector solenoid valve cylinder 4</td></tr></table>	A2	1	1			Signal high, injector solenoid valve cylinder 1	A5	9		2		Signal low, injector solenoid valve cylinder 3	A6	3		1		Signal high, injector solenoid valve cylinder 3	A9	8			2	Signal low, injector solenoid valve cylinder 2	A10	2			1	Signal high, injector solenoid valve cylinder 2							D420	B460	B424	B425	B426	Function	A3	2		1		Signal high, injector solenoid valve cylinder 5	A4	8		2		Signal low, injector solenoid valve cylinder 5	A7	3			1	Signal high, injector solenoid valve cylinder 6	A8	9			2	Signal low, injector solenoid valve cylinder 6	A11	1	1			Signal high, injector solenoid valve cylinder 4	A12	7	2			Signal low, injector solenoid valve cylinder 4
A2	1	1			Signal high, injector solenoid valve cylinder 1																																																																										
A5	9		2		Signal low, injector solenoid valve cylinder 3																																																																										
A6	3		1		Signal high, injector solenoid valve cylinder 3																																																																										
A9	8			2	Signal low, injector solenoid valve cylinder 2																																																																										
A10	2			1	Signal high, injector solenoid valve cylinder 2																																																																										
D420	B460	B424	B425	B426	Function																																																																										
A3	2		1		Signal high, injector solenoid valve cylinder 5																																																																										
A4	8		2		Signal low, injector solenoid valve cylinder 5																																																																										
A7	3			1	Signal high, injector solenoid valve cylinder 6																																																																										
A8	9			2	Signal low, injector solenoid valve cylinder 6																																																																										
A11	1	1			Signal high, injector solenoid valve cylinder 4																																																																										
A12	7	2			Signal low, injector solenoid valve cylinder 4																																																																										
Technical data	<p>Component check, injector solenoid valve cylinder 5 (B425)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key off the ignition• Disconnect connector B461• Measure on wiring harness connector B461 <table><tr><td>Pin</td><td>Pin</td><td></td><td></td></tr><tr><td>(+ probe)</td><td>(- probe)</td><td>Value</td><td>Additional information</td></tr><tr><td>2</td><td>8</td><td>± 0.67 Ω</td><td>Resistance value at 20°C [68°F]</td></tr><tr><td></td><td></td><td>maximum 0.94 Ω</td><td>Resistance value at 120°C [248°F]</td></tr></table>	Pin	Pin			(+ probe)	(- probe)	Value	Additional information	2	8	± 0.67 Ω	Resistance value at 20°C [68°F]			maximum 0.94 Ω	Resistance value at 120°C [248°F]																																																														
Pin	Pin																																																																														
(+ probe)	(- probe)	Value	Additional information																																																																												
2	8	± 0.67 Ω	Resistance value at 20°C [68°F]																																																																												
		maximum 0.94 Ω	Resistance value at 120°C [248°F]																																																																												
Possible causes	No possible causes																																																																														
Additional information	No additional information available																																																																														
Diagnostic Step-by-Step	<div><div></div><div><p>Perform the troubleshooting steps below using the breakout harness, if necessary, to check electrical components, such as sensors, electrical control units, and harnesses. Back probing is not recommended, as it could damage the harness. The ignition should always be in the OFF position when connecting or disconnecting electrical components in order to reduce the likelihood of damage to electrical components.</p></div></div> <div><div></div><ul style="list-style-type: none">• Disconnecting the EAS connectors during the troubleshooting process will result in multiple errors.• For specific electrical component information and pinout locations, always refer to the technical data.• It is necessary to exit the fault code menu in DAVIE and run the diagnostic test again to identify a change in errors.• Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive fault codes. Refer to the 'possible causes' section.</div> <table><tr><td>Step 1</td><td>Step ID 1208a</td><td>SRT</td></tr><tr><td colspan="3">Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.</td></tr><tr><td>Step 2</td><td>Step ID 1208b</td><td>SRT</td></tr></table>	Step 1	Step ID 1208a	SRT	Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.			Step 2	Step ID 1208b	SRT																																																																					
Step 1	Step ID 1208a	SRT																																																																													
Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.																																																																															
Step 2	Step ID 1208b	SRT																																																																													

	<p>Electrical Checks (B425)</p> <p>For all electrical checks and diagrams, refer to the Engine Service Rapido electrical schematic viewer (ESV) for detailed schematics, connector pin locations, and corresponding signal values.</p> <ul style="list-style-type: none">• Enter the Engine number• Select the ESV icon• Click the Search button• Select the “Component Code” within the Electrical Diagram Search pop-up window• In the component code box select B425 then Search. <p>Follow ESV through to find any electrical related problems</p> <p>Based on the fault message provided, confirm that the following electrical values are within specified ranges or limits:</p> <ul style="list-style-type: none">• Supply and signal voltages.• Cable continuity (no opens or shorts). <p>Are measured electrical values outside of expected range or limits?</p> <ul style="list-style-type: none">• No: Issue resolved• Yes: Make the appropriate repairs or component replacements. Proceed to step 3 <p>Use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">• If this related fault is no longer active, then this issue has been resolved.• If this related fault is still active, continue to the step 4 in the troubleshooting process.															
	<table><tr><td>Step 3</td><td>Step ID 1208c</td><td>SRT</td></tr><tr><td colspan="3">Replace: Solenoid Valve Injector, Cylinder 5</td></tr><tr><td colspan="3">Replace the identified faulty component.</td></tr><tr><td colspan="3">Use DAVIE to re-check for the presence of active faults.</td></tr><tr><td colspan="3"><ul style="list-style-type: none">• If this related fault is no longer active, then this issue has been resolved.• If this related fault is still active, continue to Step 4 in the troubleshooting process</td></tr></table>	Step 3	Step ID 1208c	SRT	Replace: Solenoid Valve Injector, Cylinder 5			Replace the identified faulty component.			Use DAVIE to re-check for the presence of active faults.			<ul style="list-style-type: none">• If this related fault is no longer active, then this issue has been resolved.• If this related fault is still active, continue to Step 4 in the troubleshooting process		
Step 3	Step ID 1208c	SRT														
Replace: Solenoid Valve Injector, Cylinder 5																
Replace the identified faulty component.																
Use DAVIE to re-check for the presence of active faults.																
<ul style="list-style-type: none">• If this related fault is no longer active, then this issue has been resolved.• If this related fault is still active, continue to Step 4 in the troubleshooting process																
	<table><tr><td>Step 4</td><td>Step ID 1208d</td><td>SRT</td></tr><tr><td colspan="3">Contact the PACCAR Engine Support Call Center</td></tr><tr><td colspan="3">For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center at 1-800-477-0251.</td></tr></table>	Step 4	Step ID 1208d	SRT	Contact the PACCAR Engine Support Call Center			For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center at 1-800-477-0251.								
Step 4	Step ID 1208d	SRT														
Contact the PACCAR Engine Support Call Center																
For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center at 1-800-477-0251.																
Verification Drive Cycle	To validate repair, with the brakes set, turn the key to the ON position with the engine off, and allow 10 seconds for the system to initialize and run diagnostics.															
	Back to Index															


P1209

Code number	P1209
Fault code description	Injector solenoid valve cylinder 3, Current too low or open circuit on ECU D420 pin A5
Fault code information	<p>1 trip MIL</p> <p>3 drive cycle recovery</p> <p>Readiness group – None</p> <p>Freeze frame type – Comprehensive</p>
Description of component(s)	<p>The fuel injector injects fuel into the combustion chamber.</p> <p>Control</p> <p>The amount of fuel injected depends on the duration of the injector solenoid activation in combination with the rail pressure. The longer the solenoid is activated by the PCI ECU at the same rail pressure, the more fuel is injected.</p> <p>Injector codes</p> <p>Every fuel injector is calibrated during production to compensate for any production tolerances. An injector calibration code is present on the housing and connector of the injector. These injector codes must be (re)programmed with DAVIE if one or more injectors have been replaced or fitted in another position, or if the PCI ECU is replaced.</p> <p>Not programming or incorrectly programmed injector codes can result in reduced engine performance or a warning to the driver.</p>
Location of component(s)	
Diagnostic condition	The diagnostic condition begins when the power stage hardware is active.
Set condition of fault code	Current in Needle control valve is less than 4.50A of the threshold value.
Reset condition of fault code	This fault code will change to inactive immediately after the diagnostic runs and passes.

Electrical diagram(s)



Wiring harness connector D420.A front view



Wiring harness connector B460 & B461 front view

B460 connector cylinders 1-3

B461 connector cylinders 4-6

D420 PCI ECU

B421 solenoid valve injector cylinder 1

B422 solenoid valve injector cylinder 2



B423 solenoid valve injector cylinder 3

B424 solenoid valve injector cylinder 4

B425 solenoid valve injector cylinder 5


B426 solenoid valve injector cylinder 6

D420	B460	B421	B422	B423	Function
A1	7	2			Signal low, injector solenoid valve cylinder 1



	<table><tr><td>A2</td><td>1</td><td>1</td><td></td><td></td><td>Signal high, injector solenoid valve cylinder 1</td></tr><tr><td>A5</td><td>9</td><td></td><td>2</td><td></td><td>Signal low, injector solenoid valve cylinder 3</td></tr><tr><td>A6</td><td>3</td><td></td><td>1</td><td></td><td>Signal high, injector solenoid valve cylinder 3</td></tr><tr><td>A9</td><td>8</td><td></td><td></td><td>2</td><td>Signal low, injector solenoid valve cylinder 2</td></tr><tr><td>A10</td><td>2</td><td></td><td></td><td>1</td><td>Signal high, injector solenoid valve cylinder 2</td></tr><tr><td colspan="6"> </td></tr><tr><td>D420</td><td>B460</td><td>B424</td><td>B425</td><td>B426</td><td>Function</td></tr><tr><td>A3</td><td>2</td><td></td><td>1</td><td></td><td>Signal high, injector solenoid valve cylinder 5</td></tr><tr><td>A4</td><td>8</td><td></td><td>2</td><td></td><td>Signal low, injector solenoid valve cylinder 5</td></tr><tr><td>A7</td><td>3</td><td></td><td></td><td>1</td><td>Signal high, injector solenoid valve cylinder 6</td></tr><tr><td>A8</td><td>9</td><td></td><td></td><td>2</td><td>Signal low, injector solenoid valve cylinder 6</td></tr><tr><td>A11</td><td>1</td><td>1</td><td></td><td></td><td>Signal high, injector solenoid valve cylinder 4</td></tr><tr><td>A12</td><td>7</td><td>2</td><td></td><td></td><td>Signal low, injector solenoid valve cylinder 4</td></tr></table>	A2	1	1			Signal high, injector solenoid valve cylinder 1	A5	9		2		Signal low, injector solenoid valve cylinder 3	A6	3		1		Signal high, injector solenoid valve cylinder 3	A9	8			2	Signal low, injector solenoid valve cylinder 2	A10	2			1	Signal high, injector solenoid valve cylinder 2							D420	B460	B424	B425	B426	Function	A3	2		1		Signal high, injector solenoid valve cylinder 5	A4	8		2		Signal low, injector solenoid valve cylinder 5	A7	3			1	Signal high, injector solenoid valve cylinder 6	A8	9			2	Signal low, injector solenoid valve cylinder 6	A11	1	1			Signal high, injector solenoid valve cylinder 4	A12	7	2			Signal low, injector solenoid valve cylinder 4
A2	1	1			Signal high, injector solenoid valve cylinder 1																																																																										
A5	9		2		Signal low, injector solenoid valve cylinder 3																																																																										
A6	3		1		Signal high, injector solenoid valve cylinder 3																																																																										
A9	8			2	Signal low, injector solenoid valve cylinder 2																																																																										
A10	2			1	Signal high, injector solenoid valve cylinder 2																																																																										
D420	B460	B424	B425	B426	Function																																																																										
A3	2		1		Signal high, injector solenoid valve cylinder 5																																																																										
A4	8		2		Signal low, injector solenoid valve cylinder 5																																																																										
A7	3			1	Signal high, injector solenoid valve cylinder 6																																																																										
A8	9			2	Signal low, injector solenoid valve cylinder 6																																																																										
A11	1	1			Signal high, injector solenoid valve cylinder 4																																																																										
A12	7	2			Signal low, injector solenoid valve cylinder 4																																																																										
Technical data	<p>Preparation</p> <ul style="list-style-type: none">key off the ignitionDisconnect connector B460Measure on wiring harness connector B460 <table><tr><td>Pin</td><td>Pin</td><td></td><td></td></tr><tr><td>(+ probe)</td><td>(- probe)</td><td>Value</td><td>Additional information</td></tr><tr><td>3</td><td>9</td><td>± 0.67 Ω</td><td>Resistance value at 20°C [68°F]</td></tr><tr><td></td><td></td><td>maximum 0.94 Ω</td><td>Resistance value at 120°C [248°F]</td></tr></table>	Pin	Pin			(+ probe)	(- probe)	Value	Additional information	3	9	± 0.67 Ω	Resistance value at 20°C [68°F]			maximum 0.94 Ω	Resistance value at 120°C [248°F]																																																														
Pin	Pin																																																																														
(+ probe)	(- probe)	Value	Additional information																																																																												
3	9	± 0.67 Ω	Resistance value at 20°C [68°F]																																																																												
		maximum 0.94 Ω	Resistance value at 120°C [248°F]																																																																												
Possible causes	No possible causes																																																																														
Additional information	No additional information available																																																																														
Diagnostic Step-by-Step	<div><div></div><div><p>Perform the troubleshooting steps below using the breakout harness, if necessary, to check electrical components, such as sensors, electrical control units, and harnesses. Back probing is not recommended, as it could damage the harness. The ignition should always be in the OFF position when connecting or disconnecting electrical components in order to reduce the likelihood of damage to electrical components.</p></div></div> <div><div></div><ul style="list-style-type: none">Disconnecting the EAS connectors during the troubleshooting process will result in multiple errors.For specific electrical component information and pinout locations, always refer to the technical data.It is necessary to exit the fault code menu in DAVIE and run the diagnostic test again to identify a change in errors.Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive fault codes. Refer to the 'possible causes' section.</div> <table><tr><td>Step 1</td><td>Step ID 1209a</td><td>SRT</td></tr><tr><td colspan="3">Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.</td></tr></table> <table><tr><td>Step 2</td><td>Step ID 1209b</td><td>SRT</td></tr><tr><td colspan="3">Electrical Checks (B423)</td></tr></table>	Step 1	Step ID 1209a	SRT	Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.			Step 2	Step ID 1209b	SRT	Electrical Checks (B423)																																																																				
Step 1	Step ID 1209a	SRT																																																																													
Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.																																																																															
Step 2	Step ID 1209b	SRT																																																																													
Electrical Checks (B423)																																																																															

	<p>For all electrical checks and diagrams, refer to the Engine Service Rapido electrical schematic viewer (ESV) for detailed schematics, connector pin locations, and corresponding signal values.</p> <ul style="list-style-type: none">• Enter the Engine number• Select the ESV icon• Click the Search button• Select the “Component Code” within the Electrical Diagram Search pop-up window• In the component code box select B425 then Search. <p>Follow ESV through to find any electrical related problems</p> <p>Based on the fault message provided, confirm that the following electrical values are within specified ranges or limits:</p> <ul style="list-style-type: none">• Supply and signal voltages.• Cable continuity (no opens or shorts). <p>Are measured electrical values outside of expected range or limits?</p> <ul style="list-style-type: none">• No: Issue Resolved.• Yes: Make the appropriate repairs or component replacements. Proceed to step 3 <p>Use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">• If this related fault is no longer active, then this issue has been resolved.• If this related fault is still active, continue to Step 4 in the troubleshooting process.						
	<table><tr><td>Step 3</td><td>Step ID 1209c</td><td>SRT</td></tr><tr><td colspan="3"><p>Replace: Solenoid Valve Injector, Cylinder 3</p><p>Replace the identified faulty component.</p><p>Use DAVIE to re-check for the presence of active faults.</p><ul style="list-style-type: none">• If this related fault is no longer active, then this issue has been resolved.• If this related fault is still active, continue to the Step 4 in the troubleshooting process</td></tr></table>	Step 3	Step ID 1209c	SRT	<p>Replace: Solenoid Valve Injector, Cylinder 3</p> <p>Replace the identified faulty component.</p> <p>Use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">• If this related fault is no longer active, then this issue has been resolved.• If this related fault is still active, continue to the Step 4 in the troubleshooting process		
Step 3	Step ID 1209c	SRT					
<p>Replace: Solenoid Valve Injector, Cylinder 3</p> <p>Replace the identified faulty component.</p> <p>Use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">• If this related fault is no longer active, then this issue has been resolved.• If this related fault is still active, continue to the Step 4 in the troubleshooting process							
	<table><tr><td>Step 4</td><td>Step ID 1209d</td><td>SRT</td></tr><tr><td colspan="3"><p>Contact the PACCAR Engine Support Call Center</p><p>For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center at 1-800-477-0251.</p></td></tr></table>	Step 4	Step ID 1209d	SRT	<p>Contact the PACCAR Engine Support Call Center</p> <p>For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center at 1-800-477-0251.</p>		
Step 4	Step ID 1209d	SRT					
<p>Contact the PACCAR Engine Support Call Center</p> <p>For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the PACCAR Engine Support Call Center at 1-800-477-0251.</p>							
Verification Drive Cycle	<p>To validate repair, with the brakes set, turn the key to the ON position with the engine off, and allow 10 seconds for the system to initialize and run diagnostics.</p>						
	<p>Back to Index</p>						


P1210

Code number	P1210
Fault code description	Injector solenoid valve cylinder 3 – Short circuit between ECU D420 pin A6 and A5
Fault code information	<p>1 trip MIL</p> <p>3 drive cycle recovery</p> <p>Readiness group – None</p> <p>Freeze frame type – Comprehensive</p>
Description of component(s)	<p>The fuel injector injects fuel into the combustion chamber.</p> <p>Control</p> <p>The amount of fuel injected depends on the duration of the injector solenoid activation in combination with the rail pressure. The longer the solenoid is activated by the PCI ECU at the same rail pressure, the more fuel is injected.</p> <p>Injector codes</p> <p>Every fuel injector is calibrated during production to compensate for any production tolerances. An injector calibration code is present on the housing and connector of the injector. These injector codes must be (re)programmed with DAVIE if one or more injectors have been replaced or fitted in another position, or if the PCI ECU is replaced.</p> <p>Not programming or incorrectly programmed injector codes can result in reduced engine performance or a warning to the driver.</p>
Location of component(s)	
Diagnostic condition	This diagnostic runs whenever the engine is running at idle or higher RPM.
Set condition of fault code	This code will set If the voltage on the ground wire for the injector below 2.4 volts or exceeds 9.6 volts during when the injector is commanded on while the engine is running.
Reset condition of fault code	This fault code will change to inactive immediately after the diagnostic runs and passes.

Electrical diagram(s)



Wiring harness connector D420.A front view



Wiring harness connector B460 & B461 front view

B460 connector cylinders 1-3

B461 connector cylinders 4-6

D420 PCI ECU

B421 solenoid valve injector cylinder 1

B422 solenoid valve injector cylinder 2

B423 solenoid valve injector cylinder 3


B424 solenoid valve injector cylinder 4

B425 solenoid valve injector cylinder 5

B426 solenoid valve injector cylinder 6

D420	B460	B421	B422	B423	Function
A1	7	2			Signal low, injector solenoid valve

	A2	1	1			cylinder 1 Signal high, injector solenoid valve cylinder 1																																
	A5	9		2		Signal low, injector solenoid valve cylinder 3																																
	A6	3		1		Signal high, injector solenoid valve cylinder 3																																
	A9	8			2	Signal low, injector solenoid valve cylinder 2																																
	A10	2			1	Signal high, injector solenoid valve cylinder 2																																
	D420	B460	B424	B425	B426	Function																																
	A3	2		1		Signal high, injector solenoid valve cylinder 5																																
	A4	8		2		Signal low, injector solenoid valve cylinder 5																																
	A7	3			1	Signal high, injector solenoid valve cylinder 6																																
	A8	9			2	Signal low, injector solenoid valve cylinder 6																																
	A11	1	1			Signal high, injector solenoid valve cylinder 4																																
	A12	7	2			Signal low, injector solenoid valve cylinder 4																																
Technical data	<div>Component check, injector solenoid valve cylinder 1 (B421)</div> <div>Preparation<ul style="list-style-type: none">Key off the ignitionDisconnect connector B460Measure on wiring harness connector B460<table><tr><td>Pin</td><td>Pin</td><td>Value</td><td>Additional information</td></tr><tr><td>(+ probe)</td><td>(- probe)</td><td></td><td></td></tr><tr><td>1</td><td>7</td><td>$\pm 0.67\ \Omega$</td><td>Resistance value at 20°C [68°F]</td></tr><tr><td></td><td></td><td>maximum 0.94 Ω</td><td>Resistance value at 120°C [248°F]</td></tr></table></div> <div>Component check, injector solenoid valve cylinder 2 (B422)</div> <div>Preparation<ul style="list-style-type: none">Key off the ignitionDisconnect connector B460Measure on wiring harness connector B460<table><tr><td>Pin</td><td>Pin</td><td>Value</td><td>Additional information</td></tr><tr><td>(+ probe)</td><td>(- probe)</td><td></td><td></td></tr><tr><td>2</td><td>8</td><td>$\pm 0.67\ \Omega$</td><td>Resistance value at 20°C [68°F]</td></tr><tr><td></td><td></td><td>maximum 0.94 Ω</td><td>Resistance value at 120°C [248°F]</td></tr></table></div> <div>Component check, injector solenoid valve cylinder 3 (B423)</div> <div>Preparation<ul style="list-style-type: none">Key off the ignitionDisconnect connector B460</div>						Pin	Pin	Value	Additional information	(+ probe)	(- probe)			1	7	$\pm 0.67\ \Omega$	Resistance value at 20°C [68°F]			maximum 0.94 Ω	Resistance value at 120°C [248°F]	Pin	Pin	Value	Additional information	(+ probe)	(- probe)			2	8	$\pm 0.67\ \Omega$	Resistance value at 20°C [68°F]			maximum 0.94 Ω	Resistance value at 120°C [248°F]
Pin	Pin	Value	Additional information																																			
(+ probe)	(- probe)																																					
1	7	$\pm 0.67\ \Omega$	Resistance value at 20°C [68°F]																																			
		maximum 0.94 Ω	Resistance value at 120°C [248°F]																																			
Pin	Pin	Value	Additional information																																			
(+ probe)	(- probe)																																					
2	8	$\pm 0.67\ \Omega$	Resistance value at 20°C [68°F]																																			
		maximum 0.94 Ω	Resistance value at 120°C [248°F]																																			

	<ul style="list-style-type: none">Measure on wiring harness connector B460 <table><tr><th>Pin (+ probe)</th><th>Pin (- probe)</th><th>Value</th><th>Additional information</th></tr><tr><td>3</td><td>9</td><td>$\pm 0.67 \Omega$ maximum 0.94Ω</td><td>Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]</td></tr></table> <p>Component check, injector solenoid valve cylinder 4 (B424)</p> <p>Preparation</p> <ul style="list-style-type: none">Key off the ignitionDisconnect connector B461Measure on wiring harness connector B461 <table><tr><th>Pin (+ probe)</th><th>Pin (- probe)</th><th>Value</th><th>Additional information</th></tr><tr><td>1</td><td>7</td><td>$\pm 0.67 \Omega$ maximum 0.94Ω</td><td>Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]</td></tr></table> <p>Component check, injector solenoid valve cylinder 5 (B425)</p> <p>Preparation</p> <ul style="list-style-type: none">Key off the ignitionDisconnect connector B461Measure on wiring harness connector B461 <table><tr><th>Pin (+ probe)</th><th>Pin (- probe)</th><th>Value</th><th>Additional information</th></tr><tr><td>2</td><td>8</td><td>$\pm 0.67 \Omega$ maximum 0.94Ω</td><td>Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]</td></tr></table> <p>Component check, injector solenoid valve cylinder 6 (B426)</p> <p>Preparation</p> <ul style="list-style-type: none">Key off the ignitionDisconnect connector B461Measure on wiring harness connector B461 <table><tr><th>Pin (+ probe)</th><th>Pin (- probe)</th><th>Value</th><th>Additional information</th></tr><tr><td>3</td><td>9</td><td>$\pm 0.67 \Omega$ maximum 0.94Ω</td><td>Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]</td></tr></table>	Pin (+ probe)	Pin (- probe)	Value	Additional information	3	9	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]	Pin (+ probe)	Pin (- probe)	Value	Additional information	1	7	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]	Pin (+ probe)	Pin (- probe)	Value	Additional information	2	8	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]	Pin (+ probe)	Pin (- probe)	Value	Additional information	3	9	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]
Pin (+ probe)	Pin (- probe)	Value	Additional information																														
3	9	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]																														
Pin (+ probe)	Pin (- probe)	Value	Additional information																														
1	7	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]																														
Pin (+ probe)	Pin (- probe)	Value	Additional information																														
2	8	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]																														
Pin (+ probe)	Pin (- probe)	Value	Additional information																														
3	9	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]																														
Possible causes	No possible causes available.																																
Additional information	No additional information available.																																
Diagnostic Step-by-Step	 Perform the troubleshooting steps below using the breakout harness, if necessary, to check electrical components, such as sensors, electrical control units, and harnesses. Back probing is not recommended, as it could damage the harness. The ignition should always be in the OFF position when connecting or disconnecting electrical components in order to reduce the likelihood of damage to electrical components.																																



- Disconnecting the EAS connectors during the troubleshooting process will result in multiple errors.
- For specific electrical component information and pinout locations, always refer to the technical data.
- It is necessary to exit the fault code menu in DAVIE and run the diagnostic test again to identify a change in errors.
- Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive fault codes. Refer to the 'possible causes' section.

Step 1	Step ID 1210a	SRT
--------	---------------	-----

Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.

Step 2	Step ID 1210b	SRT
--------	---------------	-----

Electrical Checks
 Ensure that the ignition key/switch has been set to OFF before disconnecting related cables.
 Based on the fault message provided, confirm that the following electrical values are within specified ranges or limits:

- Supply and signal voltages (12V).
- Cable continuity (no opens or shorts).

Are measured electrical values outside of expected range or limits?

- Yes - Proceed to step 3
- No - Proceed to step 4

Step 3	Step ID 1210c	SRT
--------	---------------	-----

Repair or replace the appropriate component and use DAVIE to re-check for the presence of active faults.

- Fault inactive – issue resolved
- Fault active - Proceed to step 4

Step 4	Step ID 1210d	SRT
--------	---------------	-----


For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the Engine Support Call Center at 1-800-477-0251.

Verification Drive Cycle



To validate repair, with the brakes set, turn the key to the ON position with the engine off, and allow 10 seconds for the system to initialize and run diagnostics.

[Back to Index](#)


P1211

Code number	P1211
Fault code description	Injector solenoid valve cylinder 3 – Voltage too low or short circuit to ground on ECU D420 pin A5
Fault code information	1 trip MIL 3 drive cycle recovery Readiness group – None Freeze frame type – Comprehensive
Description of component(s)	<p>The fuel injector injects fuel into the combustion chamber. Control</p> <p>The amount of fuel injected depends on the duration of the injector solenoid activation in combination with the rail pressure. The longer the solenoid is activated by the PCI ECU at the same rail pressure, the more fuel is injected.</p> <p>Injector codes</p> <p>Every fuel injector is calibrated during production to compensate for any production tolerances. An injector calibration code is present on the housing and connector of the injector. These injector codes must be (re)programmed with DAVIE if one or more injectors have been replaced or fitted in another position, or if the PCI ECU is replaced.</p> <p>Not programming or incorrectly programmed injector codes can result in reduced engine performance or a warning to the driver.</p>
Location of component(s)	 <p>The diagram shows a top-down view of an engine block with multiple cylinders. A specific injector solenoid valve is highlighted in green and labeled B423. The label is positioned above the green component, with a line pointing to it.</p>
Diagnostic condition	This diagnostic runs whenever the engine is running at idle or higher RPM.
Set condition of fault code	This code will set If the voltage on the ground wire for the injector below 2.4 volts during when the injector is commanded on while the engine is running.
Reset condition of fault code	This fault code will change to inactive immediately after the diagnostic runs and passes.

Electrical diagram(s)



Wiring harness connector D420.A front view



Wiring harness connector B460 & B461 front view

B460 connector cylinders 1-3

B461 connector cylinders 4-6

D420 PCI ECU

B421 solenoid valve injector cylinder 1

B422 solenoid valve injector cylinder 2

B423 solenoid valve injector cylinder 3

B424 solenoid valve injector cylinder 4



B425 solenoid valve injector cylinder 5

B426 solenoid valve injector cylinder 6

D420 B460 B421 B422 B423 Function

A1 7 2 Signal low, injector solenoid valve cylinder 1


	<div><div>A211Signal high, injector solenoid valve cylinder 1</div><div>A592Signal low, injector solenoid valve cylinder 3</div><div>A631Signal high, injector solenoid valve cylinder 3</div><div>A982Signal low, injector solenoid valve cylinder 2</div><div>A1021Signal high, injector solenoid valve cylinder 2</div></div> <div><div>D420B460B424B425B426Function</div><div>A321Signal high, injector solenoid valve cylinder 5</div><div>A482Signal low, injector solenoid valve cylinder 5</div><div>A731Signal high, injector solenoid valve cylinder 6</div><div>A892Signal low, injector solenoid valve cylinder 6</div><div>A1111Signal high, injector solenoid valve cylinder 4</div><div>A1272Signal low, injector solenoid valve cylinder 4</div></div>																												
Technical data	<div>Component check, injector solenoid valve cylinder 1 (B421)</div> <div>Preparation<ul style="list-style-type: none">Key off the ignitionDisconnect connector B460Measure on wiring harness connector B460<table><thead><tr><th>Pin (+ probe)</th><th>Pin (- probe)</th><th>Value</th><th>Additional information</th></tr></thead><tbody><tr><td>1</td><td>7</td><td>$\pm 0.67 \Omega$ maximum 0.94Ω</td><td>Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]</td></tr></tbody></table></div> <div>Component check, injector solenoid valve cylinder 2 (B422)</div> <div>Preparation<ul style="list-style-type: none">Key off the ignitionDisconnect connector B460Measure on wiring harness connector B460<table><thead><tr><th>Pin (+ probe)</th><th>Pin (- probe)</th><th>Value</th><th>Additional information</th></tr></thead><tbody><tr><td>2</td><td>8</td><td>$\pm 0.67 \Omega$ maximum 0.94Ω</td><td>Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]</td></tr></tbody></table></div> <div>Component check, injector solenoid valve cylinder 3 (B423)</div> <div>Preparation<ul style="list-style-type: none">Key off the ignitionDisconnect connector B460Measure on wiring harness connector B460<table><thead><tr><th>Pin (+ probe)</th><th>Pin (- probe)</th><th>Value</th><th>Additional information</th></tr></thead><tbody><tr><td>3</td><td>9</td><td>$\pm 0.67 \Omega$ maximum 0.94Ω</td><td>Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]</td></tr></tbody></table></div> <div>Component check, injector solenoid valve cylinder 4 (B424)</div>					Pin (+ probe)	Pin (- probe)	Value	Additional information	1	7	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]	Pin (+ probe)	Pin (- probe)	Value	Additional information	2	8	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]	Pin (+ probe)	Pin (- probe)	Value	Additional information	3	9	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]
Pin (+ probe)	Pin (- probe)	Value	Additional information																										
1	7	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]																										
Pin (+ probe)	Pin (- probe)	Value	Additional information																										
2	8	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]																										
Pin (+ probe)	Pin (- probe)	Value	Additional information																										
3	9	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]																										

	<p>Preparation</p> <ul style="list-style-type: none">• Key off the ignition• Disconnect connector B461• Measure on wiring harness connector B461 <table><tr><th>Pin (+ probe)</th><th>Pin (- probe)</th><th>Value</th><th>Additional information</th></tr><tr><td>1</td><td>7</td><td>$\pm 0.67 \Omega$ maximum 0.94Ω</td><td>Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]</td></tr></table> <p>Component check, injector solenoid valve cylinder 5 (B425)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key off the ignition• Disconnect connector B461• Measure on wiring harness connector B461 <table><tr><th>Pin (+ probe)</th><th>Pin (- probe)</th><th>Value</th><th>Additional information</th></tr><tr><td>2</td><td>8</td><td>$\pm 0.67 \Omega$ maximum 0.94Ω</td><td>Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]</td></tr></table> <p>Component check, injector solenoid valve cylinder 6 (B426)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key off the ignition• Disconnect connector B461• Measure on wiring harness connector B461 <table><tr><th>Pin (+ probe)</th><th>Pin (- probe)</th><th>Value</th><th>Additional information</th></tr><tr><td>3</td><td>9</td><td>$\pm 0.67 \Omega$ maximum 0.94Ω</td><td>Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]</td></tr></table>	Pin (+ probe)	Pin (- probe)	Value	Additional information	1	7	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]	Pin (+ probe)	Pin (- probe)	Value	Additional information	2	8	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]	Pin (+ probe)	Pin (- probe)	Value	Additional information	3	9	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]
Pin (+ probe)	Pin (- probe)	Value	Additional information																						
1	7	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]																						
Pin (+ probe)	Pin (- probe)	Value	Additional information																						
2	8	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]																						
Pin (+ probe)	Pin (- probe)	Value	Additional information																						
3	9	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]																						
Possible causes	No possible causes available.																								
Additional information	No additional information available.																								
Diagnostic Step-by-Step	<div><p>Perform the troubleshooting steps below using the breakout harness, if necessary, to check electrical components, such as sensors, electrical control units, and harnesses. Back probing is not recommended, as it could damage the harness. The ignition should always be in the OFF position when connecting or disconnecting electrical components in order to reduce the likelihood of damage to electrical components.</p></div> <div><ul style="list-style-type: none">• Disconnecting the EAS connectors during the troubleshooting process will result in multiple errors.• For specific electrical component information and pinout locations, always refer to the technical data.• It is necessary to exit the fault code menu in DAVIE and run the diagnostic test again to identify a change in errors.• Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive fault codes. Refer to the 'possible causes' section.</div>																								



	<table><tr><td>Step 1</td><td>Step ID 1211a</td><td>SRT</td></tr><tr><td colspan="3">Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.</td></tr></table>	Step 1	Step ID 1211a	SRT	Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.		
	Step 1	Step ID 1211a	SRT				
	Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.						
	<table><tr><td>Step 2</td><td>Step ID 1211b</td><td>SRT</td></tr><tr><td colspan="3"><p>Electrical Checks</p><p>Ensure that the ignition key/switch has been set to OFF before disconnecting related cables.</p><p>Based on the fault message provided, confirm that the following electrical values are within specified ranges or limits:</p><ul style="list-style-type: none">• Supply and signal voltages (12V).• Cable continuity (no opens or shorts).<p>Are measured electrical values outside of expected range or limits?</p><ul style="list-style-type: none">• Yes - Proceed to step 3• No - Proceed to step 4</td></tr></table>	Step 2	Step ID 1211b	SRT	<p>Electrical Checks</p> <p>Ensure that the ignition key/switch has been set to OFF before disconnecting related cables.</p> <p>Based on the fault message provided, confirm that the following electrical values are within specified ranges or limits:</p> <ul style="list-style-type: none">• Supply and signal voltages (12V).• Cable continuity (no opens or shorts). <p>Are measured electrical values outside of expected range or limits?</p> <ul style="list-style-type: none">• Yes - Proceed to step 3• No - Proceed to step 4		
	Step 2	Step ID 1211b	SRT				
<p>Electrical Checks</p> <p>Ensure that the ignition key/switch has been set to OFF before disconnecting related cables.</p> <p>Based on the fault message provided, confirm that the following electrical values are within specified ranges or limits:</p> <ul style="list-style-type: none">• Supply and signal voltages (12V).• Cable continuity (no opens or shorts). <p>Are measured electrical values outside of expected range or limits?</p> <ul style="list-style-type: none">• Yes - Proceed to step 3• No - Proceed to step 4							
<table><tr><td>Step 3</td><td>Step ID 1211c</td><td>SRT</td></tr><tr><td colspan="3"><p>Repair or replace the appropriate component and use DAVIE to re-check for the presence of active faults.</p><ul style="list-style-type: none">• Fault inactive – issue resolved• Fault active - Proceed to step 4</td></tr></table>	Step 3	Step ID 1211c	SRT	<p>Repair or replace the appropriate component and use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">• Fault inactive – issue resolved• Fault active - Proceed to step 4			
Step 3	Step ID 1211c	SRT					
<p>Repair or replace the appropriate component and use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">• Fault inactive – issue resolved• Fault active - Proceed to step 4							
<table><tr><td>Step 4</td><td>Step ID 1211d</td><td>SRT</td></tr><tr><td colspan="3"><p>For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the Engine Support Call Center at 1-800-477-0251.</p></td></tr></table>	Step 4	Step ID 1211d	SRT	<p>For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the Engine Support Call Center at 1-800-477-0251.</p>			
Step 4	Step ID 1211d	SRT					
<p>For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the Engine Support Call Center at 1-800-477-0251.</p>							
Verification Drive Cycle	To validate repair, with the brakes set, turn the key to the ON position with the engine off, and allow 10 seconds for the system to initialize and run diagnostics.						

Back to Index


P1212

Code number	P1212
Fault code description	Injector solenoid valve cylinder 3 – Voltage too high or short circuit to supply on ECU D420 pin A5
Fault code information	1 trip MIL 3 drive cycle recovery Readiness group – None Freeze frame type – Comprehensive
Description of component(s)	<p>The fuel injector injects fuel into the combustion chamber. Control</p> <p>The amount of fuel injected depends on the duration of the injector solenoid activation in combination with the rail pressure. The longer the solenoid is activated by the PCI ECU at the same rail pressure, the more fuel is injected.</p> <p>Injector codes</p> <p>Every fuel injector is calibrated during production to compensate for any production tolerances. An injector calibration code is present on the housing and connector of the injector. These injector codes must be (re)programmed with DAVIE if one or more injectors have been replaced or fitted in another position, or if the PCI ECU is replaced. Not programming or incorrectly programmed injector codes can result in reduced engine performance or a warning to the driver.</p>
Location of component(s)	 <p>The diagram shows a top-down view of an engine cylinder head. A label 'B423' with a leader line points to a specific injector on the right side of the engine, which is highlighted in green.</p>
Diagnostic condition	Diagnostic conditions runs when Power stage hardware is active
Set condition of fault code	<ul style="list-style-type: none"> High side voltage on the injector (before injection) compared to battery voltage is greater than 80.00% of threshold value Current through sense resistor on driver bank A is greater than 25.00% of the threshold value
Reset condition of fault code	This fault code will change to inactive immediately after the diagnostic runs and passes.

Electrical diagram(s)



Wiring harness connector D420.A front view



Wiring harness connector B460 & B461 front view

B460 connector cylinders 1-3

B461 connector cylinders 4-6

D420 PCI ECU

B421 solenoid valve injector cylinder 1

B422 solenoid valve injector cylinder 2

B423 solenoid valve injector cylinder 3

B424 solenoid valve injector cylinder 4

B425 solenoid valve injector cylinder 5

B426 solenoid valve injector cylinder 6

D420	B460	B421	B422	B423	Function
A1	7	2			Signal low, injector solenoid valve cylinder 1

	A2	1	1			Signal high, injector solenoid valve cylinder 1
	A5	9		2		Signal low, injector solenoid valve cylinder 3
	A6	3		1		Signal high, injector solenoid valve cylinder 3
	A9	8			2	Signal low, injector solenoid valve cylinder 2
	A10	2			1	Signal high, injector solenoid valve cylinder 2
	D420	B460	B424	B425	B426	Function
	A3	2		1		Signal high, injector solenoid valve cylinder 5
	A4	8		2		Signal low, injector solenoid valve cylinder 5
	A7	3			1	Signal high, injector solenoid valve cylinder 6
	A8	9			2	Signal low, injector solenoid valve cylinder 6
	A11	1	1			Signal high, injector solenoid valve cylinder 4
	A12	7	2			Signal low, injector solenoid valve cylinder 4
	Technical data					
	Component check, injector solenoid valve cylinder 1 (B421)					
	Preparation					

- Key off the ignition
- Disconnect connector B460
- Measure on wiring harness connector B460

Pin	Pin	Value	Additional information
(+ probe)	(- probe)		
1	7	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]
		maximum 0.94 Ω	Resistance value at 120°C [248°F]

Component check, injector solenoid valve cylinder 2 (B422)

Preparation

- Key off the ignition
- Disconnect connector B460
- Measure on wiring harness connector B460

Pin	Pin	Value	Additional information
(+ probe)	(- probe)		
2	8	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]
		maximum 0.94 Ω	Resistance value at 120°C [248°F]

Component check, injector solenoid valve cylinder 3 (B423)


Preparation

- Key off the ignition
- Disconnect connector B460
- Measure on wiring harness connector B460



	<table><tr><td>Pin (+ probe)</td><td>Pin (- probe)</td><td>Value</td><td>Additional information</td></tr><tr><td>3</td><td>9</td><td>$\pm 0.67 \Omega$</td><td>Resistance value at 20°C [68°F]</td></tr><tr><td></td><td></td><td>maximum 0.94 Ω</td><td>Resistance value at 120°C [248°F]</td></tr></table> <p>Component check, injector solenoid valve cylinder 4 (B424)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key off the ignition• Disconnect connector B461• Measure on wiring harness connector B461 <table><tr><td>Pin (+ probe)</td><td>Pin (- probe)</td><td>Value</td><td>Additional information</td></tr><tr><td>1</td><td>7</td><td>$\pm 0.67 \Omega$</td><td>Resistance value at 20°C [68°F]</td></tr><tr><td></td><td></td><td>maximum 0.94 Ω</td><td>Resistance value at 120°C [248°F]</td></tr></table> <p>Component check, injector solenoid valve cylinder 5 (B425)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key off the ignition• Disconnect connector B461• Measure on wiring harness connector B461 <table><tr><td>Pin (+ probe)</td><td>Pin (- probe)</td><td>Value</td><td>Additional information</td></tr><tr><td>2</td><td>8</td><td>$\pm 0.67 \Omega$</td><td>Resistance value at 20°C [68°F]</td></tr><tr><td></td><td></td><td>maximum 0.94 Ω</td><td>Resistance value at 120°C [248°F]</td></tr></table> <p>Component check, injector solenoid valve cylinder 6 (B426)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key off the ignition• Disconnect connector B461• Measure on wiring harness connector B461 <table><tr><td>Pin (+ probe)</td><td>Pin (- probe)</td><td>Value</td><td>Additional information</td></tr><tr><td>3</td><td>9</td><td>$\pm 0.67 \Omega$</td><td>Resistance value at 20°C [68°F]</td></tr><tr><td></td><td></td><td>maximum 0.94 Ω</td><td>Resistance value at 120°C [248°F]</td></tr></table>	Pin (+ probe)	Pin (- probe)	Value	Additional information	3	9	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]			maximum 0.94 Ω	Resistance value at 120°C [248°F]	Pin (+ probe)	Pin (- probe)	Value	Additional information	1	7	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]			maximum 0.94 Ω	Resistance value at 120°C [248°F]	Pin (+ probe)	Pin (- probe)	Value	Additional information	2	8	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]			maximum 0.94 Ω	Resistance value at 120°C [248°F]	Pin (+ probe)	Pin (- probe)	Value	Additional information	3	9	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]			maximum 0.94 Ω	Resistance value at 120°C [248°F]
Pin (+ probe)	Pin (- probe)	Value	Additional information																																														
3	9	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]																																														
		maximum 0.94 Ω	Resistance value at 120°C [248°F]																																														
Pin (+ probe)	Pin (- probe)	Value	Additional information																																														
1	7	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]																																														
		maximum 0.94 Ω	Resistance value at 120°C [248°F]																																														
Pin (+ probe)	Pin (- probe)	Value	Additional information																																														
2	8	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]																																														
		maximum 0.94 Ω	Resistance value at 120°C [248°F]																																														
Pin (+ probe)	Pin (- probe)	Value	Additional information																																														
3	9	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]																																														
		maximum 0.94 Ω	Resistance value at 120°C [248°F]																																														
Possible causes	No Possible causes available																																																
Additional information	No additional information available																																																

Diagnostic Step-by-Step	<div><div></div><div></div></div> <p>Perform the troubleshooting steps below using the breakout harness, if necessary, to check electrical components, such as sensors, electrical control units, and harnesses. Back probing is not recommended, as it could damage the harness. The ignition should always be in the OFF position when connecting or disconnecting electrical components in order to reduce the likelihood of damage to electrical components.</p> <ul style="list-style-type: none">• Disconnecting the EAS connectors during the troubleshooting process will result in multiple errors.• For specific electrical component information and pinout locations, always refer to the technical data.• It is necessary to exit the fault code menu in DAVIE and run the diagnostic test again to identify a change in errors.• Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive fault codes. Refer to the 'possible causes' section. <table><tr><td>Step 1</td><td>Step ID 1212a</td><td>SRT</td></tr><tr><td colspan="3">Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.</td></tr></table> <table><tr><td>Step 2</td><td>Step ID 1212b</td><td>SRT</td></tr><tr><td colspan="3"><p>Electrical Checks</p><p>Ensure that the ignition key/switch has been set to OFF before disconnecting related cables.</p><p>Based on the fault message provided, confirm that the following electrical values are within specified ranges or limits:</p><ul style="list-style-type: none">• Supply and signal voltages (12V).• Cable continuity (no opens or shorts).<p>Are measured electrical values outside of expected range or limits?</p><ul style="list-style-type: none">• Yes - Proceed to step 3• No - Proceed to step 4</td></tr></table> <table><tr><td>Step 3</td><td>Step ID 1212c</td><td>SRT</td></tr><tr><td colspan="3"><p>Repairs or component replacements appropriate component</p><p>“Solenoid Valve Injector, Cylinder 3 and use DAVIE to re-check for the presence of active faults.</p><ul style="list-style-type: none">• Fault inactive – issue resolve• Fault active - Proceed to step 4</td></tr></table> <table><tr><td>Step 4</td><td>Step ID 1212d</td><td>SRT</td></tr><tr><td colspan="3">For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the Engine Support Call Center at 1-800-477-0251.</td></tr></table>	Step 1	Step ID 1212a	SRT	Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.			Step 2	Step ID 1212b	SRT	<p>Electrical Checks</p> <p>Ensure that the ignition key/switch has been set to OFF before disconnecting related cables.</p> <p>Based on the fault message provided, confirm that the following electrical values are within specified ranges or limits:</p> <ul style="list-style-type: none">• Supply and signal voltages (12V).• Cable continuity (no opens or shorts). <p>Are measured electrical values outside of expected range or limits?</p> <ul style="list-style-type: none">• Yes - Proceed to step 3• No - Proceed to step 4			Step 3	Step ID 1212c	SRT	<p>Repairs or component replacements appropriate component</p> <p>“Solenoid Valve Injector, Cylinder 3 and use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">• Fault inactive – issue resolve• Fault active - Proceed to step 4			Step 4	Step ID 1212d	SRT	For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the Engine Support Call Center at 1-800-477-0251.		
Step 1	Step ID 1212a	SRT																							
Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.																									
Step 2	Step ID 1212b	SRT																							
<p>Electrical Checks</p> <p>Ensure that the ignition key/switch has been set to OFF before disconnecting related cables.</p> <p>Based on the fault message provided, confirm that the following electrical values are within specified ranges or limits:</p> <ul style="list-style-type: none">• Supply and signal voltages (12V).• Cable continuity (no opens or shorts). <p>Are measured electrical values outside of expected range or limits?</p> <ul style="list-style-type: none">• Yes - Proceed to step 3• No - Proceed to step 4																									
Step 3	Step ID 1212c	SRT																							
<p>Repairs or component replacements appropriate component</p> <p>“Solenoid Valve Injector, Cylinder 3 and use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">• Fault inactive – issue resolve• Fault active - Proceed to step 4																									
Step 4	Step ID 1212d	SRT																							
For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the Engine Support Call Center at 1-800-477-0251.																									
Verification Drive Cycle	To validate repair, with the brakes set, turn the key to the ON position with the engine off, and allow 10 seconds for the system to initialize and run diagnostics.																								
	Back to Index																								


P1213

Code number	P1213
Fault code description	Injector solenoid valve cylinder 6 – Current too low or open circuit on ECU D420 pin A8
Fault code information	1 trip MIL 3 drive cycle recovery Readiness group – None Freeze frame type – Comprehensive
Description of component(s)	<p>The fuel injector injects fuel into the combustion chamber. Control</p> <p>The amount of fuel injected depends on the duration of the injector solenoid activation in combination with the rail pressure. The longer the solenoid is activated by the PCI ECU at the same rail pressure, the more fuel is injected.</p> <p>Injector codes</p> <p>Every fuel injector is calibrated during production to compensate for any production tolerances. An injector calibration code is present on the housing and connector of the injector. These injector codes must be (re)programmed with DAVIE if one or more injectors have been replaced or fitted in another position, or if the PCI ECU is replaced.</p> <p>Not programming or incorrectly programmed injector codes can result in reduced engine performance or a warning to the driver.</p>
Location of component(s)	
Diagnostic condition	Diagnostic conditions runs when Power stage hardware is active
Set condition of fault code	Current in Needle control valve is less than 4.50A of threshold value
Reset condition of fault code	This fault code will change to inactive immediately after the diagnostic runs and passes.

Electrical diagram(s)



Wiring harness connector D420.A front view



Wiring harness connector B460 & B461 front view

B460 connector cylinders 1-3

B461 connector cylinders 4-6

D420 PCI ECU

B421 solenoid valve injector cylinder 1

B422 solenoid valve injector cylinder 2

B423 solenoid valve injector cylinder 3



B424 solenoid valve injector cylinder 4

B425 solenoid valve injector cylinder 5


B426 solenoid valve injector cylinder 6

	D420	B460	B421	B422	B423	Function
	A1	7	2			Signal low, injector solenoid valve cylinder 1
	A2	1	1			Signal high, injector solenoid valve cylinder 1
	A5	9		2		Signal low, injector solenoid valve cylinder 3
	A6	3		1		Signal high, injector solenoid valve cylinder 3
	A9	8			2	Signal low, injector solenoid valve cylinder 2
	A10	2			1	Signal high, injector solenoid valve cylinder 2
	D420	B460	B424	B425	B426	Function
	A3	2		1		Signal high, injector solenoid valve cylinder 5
	A4	8		2		Signal low, injector solenoid valve cylinder 5
	A7	3			1	Signal high, injector solenoid valve cylinder 6
	A8	9			2	Signal low, injector solenoid valve cylinder 6
	A11	1	1			Signal high, injector solenoid valve cylinder 4
	A12	7	2			Signal low, injector solenoid valve cylinder 4
	Technical data					
	Component check, injector solenoid valve cylinder 1 (B421)					
	Preparation					
	<ul style="list-style-type: none"> Key off the ignition Disconnect connector B460 Measure on wiring harness connector B460 					
	Pin	Pin				
	(+ probe)	(- probe)		Value		Additional information
	1	7		$\pm 0.67 \Omega$		Resistance value at 20°C [68°F]
				maximum 0.94 Ω		Resistance value at 120°C [248°F]
	Component check, injector solenoid valve cylinder 2 (B422)					
	Preparation					
	<ul style="list-style-type: none"> Key off the ignition Disconnect connector B460 Measure on wiring harness connector B460 					
	Pin	Pin				
	(+ probe)	(- probe)		Value		Additional information
	2	8		$\pm 0.67 \Omega$		Resistance value at 20°C [68°F]
				maximum 0.94 Ω		Resistance value at 120°C [248°F]
	Component check, injector solenoid valve cylinder 3 (B423)					
	Preparation					
	<ul style="list-style-type: none"> Key off the ignition Disconnect connector B460 Measure on wiring harness connector B460 					


	<p>Pin Pin (+ probe) (- probe) 3 9</p> <p>Value $\pm 0.67 \Omega$ maximum 0.94Ω</p> <p>Additional information Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]</p>
	<p>Component check, injector solenoid valve cylinder 4 (B424)</p> <p>Preparation</p> <ul style="list-style-type: none"> • Key off the ignition • Disconnect connector B461 • Measure on wiring harness connector B461
	<p>Pin Pin (+ probe) (- probe) 1 7</p> <p>Value $\pm 0.67 \Omega$ maximum 0.94Ω</p> <p>Additional information Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]</p>
	<p>Component check, injector solenoid valve cylinder 5 (B425)</p> <p>Preparation</p> <ul style="list-style-type: none"> • Key off the ignition • Disconnect connector B461 • Measure on wiring harness connector B461
	<p>Pin Pin (+ probe) (- probe) 2 8</p> <p>Value $\pm 0.67 \Omega$ maximum 0.94Ω</p> <p>Additional information Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]</p>
	<p>Component check, injector solenoid valve cylinder 6 (B426)</p> <p>Preparation</p> <ul style="list-style-type: none"> • Key off the ignition • Disconnect connector B461 • Measure on wiring harness connector B461
	<p>Pin Pin (+ probe) (- probe) 3 9</p> <p>Value $\pm 0.67 \Omega$ maximum 0.94Ω</p> <p>Additional information Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]</p>
Possible causes	No possible causes available
Additional information	No additional information available

Diagnostic Step-by-Step	<div><p>Perform the troubleshooting steps below using the breakout harness, if necessary, to check electrical components, such as sensors, electrical control units, and harnesses. Back probing is not recommended, as it could damage the harness. The ignition should always be in the OFF position when connecting or disconnecting electrical components in order to reduce the likelihood of damage to electrical components.</p></div> <div><ul style="list-style-type: none">• Disconnecting the EAS connectors during the troubleshooting process will result in multiple errors.• For specific electrical component information and pinout locations, always refer to the technical data.• It is necessary to exit the fault code menu in DAVIE and run the diagnostic test again to identify a change in errors.• Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive fault codes. Refer to the 'possible causes' section.</div>						
	<table><tr><td>Step 3</td><td>Step ID 1213c</td><td>SRT</td></tr><tr><td colspan="3">Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.</td></tr></table>	Step 3	Step ID 1213c	SRT	Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.		
	Step 3	Step ID 1213c	SRT				
	Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.						
	<table><tr><td>Step 2</td><td>Step ID 1213b</td><td>SRT</td></tr><tr><td colspan="3"><p>Electrical Checks</p><p>Ensure that the ignition key/switch has been set to OFF before disconnecting related cables.</p><p>Based on the fault message provided, confirm that the following electrical values are within specified ranges or limits:</p><ul style="list-style-type: none">• Supply and signal voltages (12V).• Cable continuity (no opens or shorts).<p>Are measured electrical values outside of expected range or limits?</p><ul style="list-style-type: none">• Yes - Proceed to step 3• No - Proceed to step 4</td></tr></table>	Step 2	Step ID 1213b	SRT	<p>Electrical Checks</p> <p>Ensure that the ignition key/switch has been set to OFF before disconnecting related cables.</p> <p>Based on the fault message provided, confirm that the following electrical values are within specified ranges or limits:</p> <ul style="list-style-type: none">• Supply and signal voltages (12V).• Cable continuity (no opens or shorts). <p>Are measured electrical values outside of expected range or limits?</p> <ul style="list-style-type: none">• Yes - Proceed to step 3• No - Proceed to step 4		
Step 2	Step ID 1213b	SRT					
<p>Electrical Checks</p> <p>Ensure that the ignition key/switch has been set to OFF before disconnecting related cables.</p> <p>Based on the fault message provided, confirm that the following electrical values are within specified ranges or limits:</p> <ul style="list-style-type: none">• Supply and signal voltages (12V).• Cable continuity (no opens or shorts). <p>Are measured electrical values outside of expected range or limits?</p> <ul style="list-style-type: none">• Yes - Proceed to step 3• No - Proceed to step 4							
<table><tr><td>Step 3</td><td>Step ID 1213c</td><td>SRT</td></tr><tr><td colspan="3"><p>Repairs or component replacements appropriate component “Solenoid Valve Injector, Cylinder 6” and use DAVIE to re-check for the presence of active faults.</p><ul style="list-style-type: none">• Fault inactive – issue resolve• Fault active - Proceed to step 4</td></tr></table>	Step 3	Step ID 1213c	SRT	<p>Repairs or component replacements appropriate component “Solenoid Valve Injector, Cylinder 6” and use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">• Fault inactive – issue resolve• Fault active - Proceed to step 4			
Step 3	Step ID 1213c	SRT					
<p>Repairs or component replacements appropriate component “Solenoid Valve Injector, Cylinder 6” and use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">• Fault inactive – issue resolve• Fault active - Proceed to step 4							
<table><tr><td>Step 4</td><td>Step ID 1213d</td><td>SRT</td></tr><tr><td colspan="3">For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the Engine Support Call Center at 1-800-477-0251.</td></tr></table>	Step 4	Step ID 1213d	SRT	For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the Engine Support Call Center at 1-800-477-0251.			
Step 4	Step ID 1213d	SRT					
For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the Engine Support Call Center at 1-800-477-0251.							
Verification Drive Cycle	To validate repair, with the brakes set, turn the key to the ON position with the engine off, and allow 10 seconds for the system to initialize and run diagnostics.						
	Back to Index						


P1214

Code number	P1214
Fault code description	Injector Solenoid Valve Cylinder 6 – Short circuit between ECU D420 pin A7 and A8
Fault code information	<div>  <div> For further assistance: Contact the PACCAR Engine Support Call Center 1-800-477-0251 </div> </div> <p>Please Contact the Engine Support Center</p>
Description of component(s)	
Location of component(s)	
Diagnostic condition	
Set condition of fault code	
Reset condition of fault code	
Electrical diagram(s)	
Technical data	
Possible causes	
Additional information	
Diagnostic Step-by-Step	
Verification Drive Cycle	
	Back to Index


P1215

Code number	P1215
Fault code description	Injector Solenoid Valve Cylinder 6 – Voltage too low or Short circuit to ground on ECU D420 pin A8
Fault code information	<div>  <div> For further assistance: Contact the PACCAR Engine Support Call Center 1-800-477-0251 </div> </div> <p>Please Contact the Engine Support Center</p>
Description of component(s)	
Location of component(s)	
Diagnostic condition	
Set condition of fault code	
Reset condition of fault code	
Electrical diagram(s)	
Technical data	
Possible causes	
Additional information	
Diagnostic Step-by-Step	
Verification Drive Cycle	
	Back to Index


P1216

Code number	P1216
Fault code description	Injector solenoid valve cylinder 6 – Voltage too high or short circuit to supply on ECU D420 pin A8
Fault code information	<div>  <p>For further assistance: Contact the PACCAR Engine Support Call Center 1-800-477-0251</p> </div> <p>Please Contact the Engine Support Center</p>
Description of component(s)	
Location of component(s)	
Diagnostic condition	
Set condition of fault code	
Reset condition of fault code	
Electrical diagram(s)	
Technical data	
Possible causes	
Additional information	
Diagnostic Step-by-Step	
Verification Drive Cycle	
	Back to Index


P1217

Code number	P1217
Fault code description	Injector solenoid valve cylinder 2 – Current too low or open circuit on ECU D420 pin A9
Fault code information	<div>  <p>For further assistance: Contact the PACCAR Engine Support Call Center 1-800-477-0251</p> </div> <p>Please Contact the Engine Support Center</p>
Description of component(s)	
Location of component(s)	
Diagnostic condition	
Set condition of fault code	
Reset condition of fault code	
Electrical diagram(s)	
Technical data	
Possible causes	
Additional information	
Diagnostic Step-by-Step	
Verification Drive Cycle	
	Back to Index


P1218

Code number	P1218
Fault code description	Injector solenoid valve cylinder 2 – Short circuit between ECU D420 pin A10 and A9
Fault code information	
Description of component(s)	<div>  <p>For further assistance: Contact the PACCAR Engine Support Call Center 1-800-477-0251</p> </div> <p>Please contact Engine support center</p>
Location of component(s)	
Diagnostic condition	
Set condition of fault code	
Reset condition of fault code	
Electrical diagram(s)	
Technical data	
Possible causes	
Additional information	
Diagnostic Step-by-Step	
Verification Drive Cycle	
	Back to Index



P1219

Code number	P1219
Fault code description	Injector solenoid valve cylinder 2 – Voltage too low or short circuit to ground on ECU 420 pin A9
Fault code information	
Description of component(s)	<div>  <p>For further assistance: Contact the PACCAR Engine Support Call Center 1-800-477-0251</p> </div> <p>Please contact Engine support center</p>
Location of component(s)	
Diagnostic condition	
Set condition of fault code	
Reset condition of fault code	
Electrical diagram(s)	
Technical data	
Possible causes	
Additional information	
Diagnostic Step-by-Step	
Verification Drive Cycle	
	Back to Index


P1220

Code number	P1220
Fault code description	Injector solenoid valve cylinder 2 - Voltage too high or short circuit to supply on ECU D420 pin A9
Fault code information	1 trip MIL 3 drive cycle recovery Readiness group – None Freeze frame type - Comprehensive
Description of component(s)	<p>The fuel injector injects fuel into the combustion chamber. Control</p> <p>The amount of fuel injected depends on the duration of the injector solenoid activation in combination with the rail pressure. The longer the solenoid is activated by the PCI ECU at the same rail pressure, the more fuel is injected.</p> <p>Injector codes</p> <p>Every fuel injector is calibrated during production to compensate for any production tolerances. An injector calibration code is present on the housing and connector of the injector. These injector codes must be (re)programmed with DAVIE if one or more injectors have been replaced or fitted in another position, or if the PCI ECU is replaced.</p> <p>Not programming or incorrectly programmed injector codes can result in reduced engine performance or a warning to the driver.</p>
Location of component(s)	
Diagnostic condition	Diagnostic condition is set when Power stage hardware is active in less than one second.
Set condition of fault code	<ul style="list-style-type: none"> High side voltage on the injector (before injection) compared to battery voltage is greater than the threshold value 80.00% then the condition is set. Current through sense resistor on driver bank B is greater than the threshold value 25.00A then the condition is set.
Reset condition of fault code	This fault code will change to inactive immediately after the diagnostic runs and passes.

Electrical diagram(s)



Wiring harness connector D420.A front view



Wiring harness connector B460 & B461 front view

B460 connector cylinders 1-3

B461 connector cylinders 4-6

D420 PCI ECU

B421 solenoid valve injector cylinder 1

B422 solenoid valve injector cylinder 2

B423 solenoid valve injector cylinder 3



B424 solenoid valve injector cylinder 4

B425 solenoid valve injector cylinder 5

B426 solenoid valve injector cylinder 6


D420	B460	B421	B422	B423	Function
A1	7	2			Signal low, injector solenoid valve cylinder 1

	<table><tr><td>A2</td><td>1</td><td>1</td><td></td><td></td><td>Signal high, injector solenoid valve cylinder 1</td></tr><tr><td>A5</td><td>9</td><td></td><td>2</td><td></td><td>Signal low, injector solenoid valve cylinder 3</td></tr><tr><td>A6</td><td>3</td><td></td><td>1</td><td></td><td>Signal high, injector solenoid valve cylinder 3</td></tr><tr><td>A9</td><td>8</td><td></td><td></td><td>2</td><td>Signal low, injector solenoid valve cylinder 2</td></tr><tr><td>A10</td><td>2</td><td></td><td></td><td>1</td><td>Signal high, injector solenoid valve cylinder 2</td></tr><tr><td colspan="6"> </td></tr><tr><td>D420</td><td>B460</td><td>B424</td><td>B425</td><td>B426</td><td>Function</td></tr><tr><td>A3</td><td>2</td><td></td><td>1</td><td></td><td>Signal high, injector solenoid valve cylinder 5</td></tr><tr><td>A4</td><td>8</td><td></td><td>2</td><td></td><td>Signal low, injector solenoid valve cylinder 5</td></tr><tr><td>A7</td><td>3</td><td></td><td></td><td>1</td><td>Signal high, injector solenoid valve cylinder 6</td></tr><tr><td>A8</td><td>9</td><td></td><td></td><td>2</td><td>Signal low, injector solenoid valve cylinder 6</td></tr><tr><td>A11</td><td>1</td><td>1</td><td></td><td></td><td>Signal high, injector solenoid valve cylinder 4</td></tr><tr><td>A12</td><td>7</td><td>2</td><td></td><td></td><td>Signal low, injector solenoid valve cylinder 4</td></tr></table>					A2	1	1			Signal high, injector solenoid valve cylinder 1	A5	9		2		Signal low, injector solenoid valve cylinder 3	A6	3		1		Signal high, injector solenoid valve cylinder 3	A9	8			2	Signal low, injector solenoid valve cylinder 2	A10	2			1	Signal high, injector solenoid valve cylinder 2							D420	B460	B424	B425	B426	Function	A3	2		1		Signal high, injector solenoid valve cylinder 5	A4	8		2		Signal low, injector solenoid valve cylinder 5	A7	3			1	Signal high, injector solenoid valve cylinder 6	A8	9			2	Signal low, injector solenoid valve cylinder 6	A11	1	1			Signal high, injector solenoid valve cylinder 4	A12	7	2			Signal low, injector solenoid valve cylinder 4
A2	1	1			Signal high, injector solenoid valve cylinder 1																																																																														
A5	9		2		Signal low, injector solenoid valve cylinder 3																																																																														
A6	3		1		Signal high, injector solenoid valve cylinder 3																																																																														
A9	8			2	Signal low, injector solenoid valve cylinder 2																																																																														
A10	2			1	Signal high, injector solenoid valve cylinder 2																																																																														
D420	B460	B424	B425	B426	Function																																																																														
A3	2		1		Signal high, injector solenoid valve cylinder 5																																																																														
A4	8		2		Signal low, injector solenoid valve cylinder 5																																																																														
A7	3			1	Signal high, injector solenoid valve cylinder 6																																																																														
A8	9			2	Signal low, injector solenoid valve cylinder 6																																																																														
A11	1	1			Signal high, injector solenoid valve cylinder 4																																																																														
A12	7	2			Signal low, injector solenoid valve cylinder 4																																																																														
Technical data	<div>Component check, injector solenoid valve cylinder 1 (B421)</div> <div>Preparation<ul style="list-style-type: none">Key off the ignitionDisconnect connector B460Measure on wiring harness connector B460<table><thead><tr><th>Pin (+ probe)</th><th>Pin (- probe)</th><th>Value</th><th>Additional information</th></tr></thead><tbody><tr><td>1</td><td>7</td><td>$\pm 0.67 \Omega$</td><td>Resistance value at 20°C [68°F]</td></tr><tr><td></td><td></td><td>maximum 0.94 Ω</td><td>Resistance value at 120°C [248°F]</td></tr></tbody></table><div>Component check, injector solenoid valve cylinder 2 (B422)</div><div>Preparation<ul style="list-style-type: none">Key off the ignitionDisconnect connector B460Measure on wiring harness connector B460<table><thead><tr><th>Pin (+ probe)</th><th>Pin (- probe)</th><th>Value</th><th>Additional information</th></tr></thead><tbody><tr><td>2</td><td>8</td><td>$\pm 0.67 \Omega$</td><td>Resistance value at 20°C [68°F]</td></tr><tr><td></td><td></td><td>maximum 0.94 Ω</td><td>Resistance value at 120°C [248°F]</td></tr></tbody></table><div>Component check, injector solenoid valve cylinder 3 (B423)</div><div>Preparation<ul style="list-style-type: none">Key off the ignitionDisconnect connector B460Measure on wiring harness connector B460<table><thead><tr><th>Pin (+ probe)</th><th>Pin (- probe)</th><th>Value</th><th>Additional information</th></tr></thead><tbody><tr><td>3</td><td>9</td><td>$\pm 0.67 \Omega$</td><td>Resistance value at 20°C [68°F]</td></tr><tr><td></td><td></td><td>maximum 0.94 Ω</td><td>Resistance value at 120°C [248°F]</td></tr></tbody></table><div>Component check, injector solenoid valve cylinder 4 (B424)</div></div></div></div>					Pin (+ probe)	Pin (- probe)	Value	Additional information	1	7	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]			maximum 0.94 Ω	Resistance value at 120°C [248°F]	Pin (+ probe)	Pin (- probe)	Value	Additional information	2	8	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]			maximum 0.94 Ω	Resistance value at 120°C [248°F]	Pin (+ probe)	Pin (- probe)	Value	Additional information	3	9	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]			maximum 0.94 Ω	Resistance value at 120°C [248°F]																																										
Pin (+ probe)	Pin (- probe)	Value	Additional information																																																																																
1	7	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]																																																																																
		maximum 0.94 Ω	Resistance value at 120°C [248°F]																																																																																
Pin (+ probe)	Pin (- probe)	Value	Additional information																																																																																
2	8	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]																																																																																
		maximum 0.94 Ω	Resistance value at 120°C [248°F]																																																																																
Pin (+ probe)	Pin (- probe)	Value	Additional information																																																																																
3	9	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]																																																																																
		maximum 0.94 Ω	Resistance value at 120°C [248°F]																																																																																



	<p>Preparation</p> <ul style="list-style-type: none">• Key off the ignition• Disconnect connector B461• Measure on wiring harness connector B461 <table><tr><td>Pin (+ probe)</td><td>Pin (- probe)</td><td>Value</td><td>Additional information</td></tr><tr><td>1</td><td>7</td><td>$\pm 0.67 \Omega$ maximum 0.94Ω</td><td>Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]</td></tr></table> <p>Component check, injector solenoid valve cylinder 5 (B425)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key off the ignition• Disconnect connector B461• Measure on wiring harness connector B461 <table><tr><td>Pin (+ probe)</td><td>Pin (- probe)</td><td>Value</td><td>Additional information</td></tr><tr><td>2</td><td>8</td><td>$\pm 0.67 \Omega$ maximum 0.94Ω</td><td>Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]</td></tr></table> <p>Component check, injector solenoid valve cylinder 6 (B426)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key off the ignition• Disconnect connector B461• Measure on wiring harness connector B461 <table><tr><td>Pin (+ probe)</td><td>Pin (- probe)</td><td>Value</td><td>Additional information</td></tr><tr><td>3</td><td>9</td><td>$\pm 0.67 \Omega$ maximum 0.94Ω</td><td>Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]</td></tr></table>	Pin (+ probe)	Pin (- probe)	Value	Additional information	1	7	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]	Pin (+ probe)	Pin (- probe)	Value	Additional information	2	8	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]	Pin (+ probe)	Pin (- probe)	Value	Additional information	3	9	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]
Pin (+ probe)	Pin (- probe)	Value	Additional information																						
1	7	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]																						
Pin (+ probe)	Pin (- probe)	Value	Additional information																						
2	8	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]																						
Pin (+ probe)	Pin (- probe)	Value	Additional information																						
3	9	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]																						
Possible causes	No possible causes information available																								
Additional information	No additional information available																								
Diagnostic Step-by-Step	<div><p>Perform the troubleshooting steps below using the breakout harness, if necessary, to check electrical components, such as sensors, electrical control units, and harnesses. Back probing is not recommended, as it could damage the harness. The ignition should always be in the OFF position when connecting or disconnecting electrical components in order to reduce the likelihood of damage to electrical components.</p></div> <div><ul style="list-style-type: none">• Disconnecting the EAS connectors during the troubleshooting process will result in multiple errors.• For specific electrical component information and pinout locations, always refer to the technical data.• It is necessary to exit the fault code menu in DAVIE and run the diagnostic test again to identify a change in errors.• Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive fault codes. Refer to the 'possible causes' section.</div>																								

	<table><tr><td>Step 1</td><td>Step ID 1220a</td><td>SRT</td></tr><tr><td colspan="3">Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.</td></tr></table>	Step 1	Step ID 1220a	SRT	Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.		
	Step 1	Step ID 1220a	SRT				
	Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.						
	<table><tr><td>Step 2</td><td>Step ID 1220b</td><td>SRT</td></tr><tr><td colspan="3"><p>Electrical Checks</p><p>Ensure that the ignition key/switch has been set to OFF before disconnecting related cables.</p><p>Based on the fault message provided, confirm that the following electrical values are within specified ranges or limits:</p><ul style="list-style-type: none">• Supply and signal voltages (12V).• Cable continuity (no opens or shorts).<p>Are measured electrical values outside of expected range or limits?</p><ul style="list-style-type: none">• Yes - Proceed to step 3• No - Proceed to step 4</td></tr></table>	Step 2	Step ID 1220b	SRT	<p>Electrical Checks</p> <p>Ensure that the ignition key/switch has been set to OFF before disconnecting related cables.</p> <p>Based on the fault message provided, confirm that the following electrical values are within specified ranges or limits:</p> <ul style="list-style-type: none">• Supply and signal voltages (12V).• Cable continuity (no opens or shorts). <p>Are measured electrical values outside of expected range or limits?</p> <ul style="list-style-type: none">• Yes - Proceed to step 3• No - Proceed to step 4		
	Step 2	Step ID 1220b	SRT				
<p>Electrical Checks</p> <p>Ensure that the ignition key/switch has been set to OFF before disconnecting related cables.</p> <p>Based on the fault message provided, confirm that the following electrical values are within specified ranges or limits:</p> <ul style="list-style-type: none">• Supply and signal voltages (12V).• Cable continuity (no opens or shorts). <p>Are measured electrical values outside of expected range or limits?</p> <ul style="list-style-type: none">• Yes - Proceed to step 3• No - Proceed to step 4							
<table><tr><td>Step 3</td><td>Step ID 1220c</td><td>SRT</td></tr><tr><td colspan="3"><p>Make the appropriate repairs or component replacements and use DAVIE to re-check for the presence of active faults.</p><ul style="list-style-type: none">• Fault inactive – issue resolve• Fault active - Proceed to step 4</td></tr></table>	Step 3	Step ID 1220c	SRT	<p>Make the appropriate repairs or component replacements and use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">• Fault inactive – issue resolve• Fault active - Proceed to step 4			
Step 3	Step ID 1220c	SRT					
<p>Make the appropriate repairs or component replacements and use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">• Fault inactive – issue resolve• Fault active - Proceed to step 4							
<table><tr><td>Step 4</td><td>Step ID 1220d</td><td>SRT</td></tr><tr><td colspan="3"><p>Replace: Solenoid Valve Injector, Cylinder 2</p><p>Replace the identified faulty component and use DAVIE to re-check for the presence of active faults.</p><ul style="list-style-type: none">• Fault inactive – issue resolve• Fault active - Proceed to step 5</td></tr></table>	Step 4	Step ID 1220d	SRT	<p>Replace: Solenoid Valve Injector, Cylinder 2</p> <p>Replace the identified faulty component and use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">• Fault inactive – issue resolve• Fault active - Proceed to step 5			
Step 4	Step ID 1220d	SRT					
<p>Replace: Solenoid Valve Injector, Cylinder 2</p> <p>Replace the identified faulty component and use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">• Fault inactive – issue resolve• Fault active - Proceed to step 5							
<table><tr><td>Step 5</td><td>Step ID 1220e</td><td>SRT</td></tr><tr><td colspan="3">For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the Engine Support Call Center at 1-800-477-0251.</td></tr></table>	Step 5	Step ID 1220e	SRT	For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the Engine Support Call Center at 1-800-477-0251.			
Step 5	Step ID 1220e	SRT					
For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the Engine Support Call Center at 1-800-477-0251.							
Verification Drive Cycle	To validate repair, with the brakes set, turn the key to the ON position with the engine off, and allow 10 seconds for the system to initialize and run diagnostics.						
	Back to Index						


P1221

Code number	P1221
Fault code description	Injector solenoid valve cylinder 4 - Current too low or open circuit on ECU D420 pin A12
Fault code information	1 trip MIL 3 drive cycle recovery Readiness group – None Freeze frame type - Comprehensive
Description of component(s)	<p>The fuel injector injects fuel into the combustion chamber. Control</p> <p>The amount of fuel injected depends on the duration of the injector solenoid activation in combination with the rail pressure. The longer the solenoid is activated by the PCI ECU at the same rail pressure, the more fuel is injected.</p> <p>Injector codes</p> <p>Every fuel injector is calibrated during production to compensate for any production tolerances. An injector calibration code is present on the housing and connector of the injector. These injector codes must be (re)programmed with DAVIE if one or more injectors have been replaced or fitted in another position, or if the PCI ECU is replaced.</p> <p>Not programming or incorrectly programmed injector codes can result in reduced engine performance or a warning to the driver.</p>
Location of component(s)	
Diagnostic condition	Diagnostic condition is set when Power stage hardware is active in less than one second
Set condition of fault code	Current in Needle control valve is less than 4.50A
Reset condition of fault code	This fault code will change to inactive immediately after the diagnostic runs and passes.

Electrical diagram(s)



Wiring harness connector D420.A front view



Wiring harness connector B460 & B461 front view

B460 connector cylinders 1-3

B461 connector cylinders 4-6

D420 PCI ECU

B421 solenoid valve injector cylinder 1

B422 solenoid valve injector cylinder 2

B423 solenoid valve injector cylinder 3



B424 solenoid valve injector cylinder 4

B425 solenoid valve injector cylinder 5

B426 solenoid valve injector cylinder 6


D420	B460	B421	B422	B423	Function
A1	7	2			Signal low, injector solenoid valve cylinder 1

	A2	1	1		Signal high, injector solenoid valve cylinder 1																																																	
	A5	9		2	Signal low, injector solenoid valve cylinder 3																																																	
	A6	3		1	Signal high, injector solenoid valve cylinder 3																																																	
	A9	8		2	Signal low, injector solenoid valve cylinder 2																																																	
	A10	2		1	Signal high, injector solenoid valve cylinder 2																																																	
	D420	B460	B424	B425	B426	Function																																																
	A3	2		1		Signal high, injector solenoid valve cylinder 5																																																
	A4	8		2		Signal low, injector solenoid valve cylinder 5																																																
	A7	3			1	Signal high, injector solenoid valve cylinder 6																																																
	A8	9			2	Signal low, injector solenoid valve cylinder 6																																																
	A11	1	1			Signal high, injector solenoid valve cylinder 4																																																
	A12	7	2			Signal low, injector solenoid valve cylinder 4																																																
Technical data	Component check, injector solenoid valve cylinder 1 (B421) Preparation <ul style="list-style-type: none">• Key off the ignition• Disconnect connector B460• Measure on wiring harness connector B460 <table><tr><td>Pin</td><td>Pin</td><td></td><td></td></tr><tr><td>(+ probe)</td><td>(- probe)</td><td>Value</td><td>Additional information</td></tr><tr><td>1</td><td>7</td><td>± 0.67 Ω</td><td>Resistance value at 20°C [68°F]</td></tr><tr><td></td><td></td><td>maximum 0.94 Ω</td><td>Resistance value at 120°C [248°F]</td></tr></table> Component check, injector solenoid valve cylinder 2 (B422) Preparation <ul style="list-style-type: none">• Key off the ignition• Disconnect connector B460• Measure on wiring harness connector B460 <table><tr><td>Pin</td><td>Pin</td><td></td><td></td></tr><tr><td>(+ probe)</td><td>(- probe)</td><td>Value</td><td>Additional information</td></tr><tr><td>2</td><td>8</td><td>± 0.67 Ω</td><td>Resistance value at 20°C [68°F]</td></tr><tr><td></td><td></td><td>maximum 0.94 Ω</td><td>Resistance value at 120°C [248°F]</td></tr></table> Component check, injector solenoid valve cylinder 3 (B423) Preparation <ul style="list-style-type: none">• Key off the ignition• Disconnect connector B460• Measure on wiring harness connector B460 <table><tr><td>Pin</td><td>Pin</td><td></td><td></td></tr><tr><td>(+ probe)</td><td>(- probe)</td><td>Value</td><td>Additional information</td></tr><tr><td>3</td><td>9</td><td>± 0.67 Ω</td><td>Resistance value at 20°C [68°F]</td></tr><tr><td></td><td></td><td>maximum 0.94 Ω</td><td>Resistance value at 120°C [248°F]</td></tr></table> Component check, injector solenoid valve cylinder 4 (B424) Preparation <ul style="list-style-type: none">• Key off the ignition						Pin	Pin			(+ probe)	(- probe)	Value	Additional information	1	7	± 0.67 Ω	Resistance value at 20°C [68°F]			maximum 0.94 Ω	Resistance value at 120°C [248°F]	Pin	Pin			(+ probe)	(- probe)	Value	Additional information	2	8	± 0.67 Ω	Resistance value at 20°C [68°F]			maximum 0.94 Ω	Resistance value at 120°C [248°F]	Pin	Pin			(+ probe)	(- probe)	Value	Additional information	3	9	± 0.67 Ω	Resistance value at 20°C [68°F]			maximum 0.94 Ω	Resistance value at 120°C [248°F]
Pin	Pin																																																					
(+ probe)	(- probe)	Value	Additional information																																																			
1	7	± 0.67 Ω	Resistance value at 20°C [68°F]																																																			
		maximum 0.94 Ω	Resistance value at 120°C [248°F]																																																			
Pin	Pin																																																					
(+ probe)	(- probe)	Value	Additional information																																																			
2	8	± 0.67 Ω	Resistance value at 20°C [68°F]																																																			
		maximum 0.94 Ω	Resistance value at 120°C [248°F]																																																			
Pin	Pin																																																					
(+ probe)	(- probe)	Value	Additional information																																																			
3	9	± 0.67 Ω	Resistance value at 20°C [68°F]																																																			
		maximum 0.94 Ω	Resistance value at 120°C [248°F]																																																			



	<ul style="list-style-type: none">• Disconnect connector B461• Measure on wiring harness connector B461 <table><tr><th>Pin (+ probe)</th><th>Pin (- probe)</th><th>Value</th><th>Additional information</th></tr><tr><td>1</td><td>7</td><td>$\pm 0.67 \Omega$ maximum 0.94Ω</td><td>Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]</td></tr></table> <p>Component check, injector solenoid valve cylinder 5 (B425)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key off the ignition• Disconnect connector B461• Measure on wiring harness connector B461 <table><tr><th>Pin (+ probe)</th><th>Pin (- probe)</th><th>Value</th><th>Additional information</th></tr><tr><td>2</td><td>8</td><td>$\pm 0.67 \Omega$ maximum 0.94Ω</td><td>Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]</td></tr></table> <p>Component check, injector solenoid valve cylinder 6 (B426)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key off the ignition• Disconnect connector B461• Measure on wiring harness connector B461 <table><tr><th>Pin (+ probe)</th><th>Pin (- probe)</th><th>Value</th><th>Additional information</th></tr><tr><td>3</td><td>9</td><td>$\pm 0.67 \Omega$ maximum 0.94Ω</td><td>Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]</td></tr></table>	Pin (+ probe)	Pin (- probe)	Value	Additional information	1	7	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]	Pin (+ probe)	Pin (- probe)	Value	Additional information	2	8	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]	Pin (+ probe)	Pin (- probe)	Value	Additional information	3	9	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]
Pin (+ probe)	Pin (- probe)	Value	Additional information																						
1	7	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]																						
Pin (+ probe)	Pin (- probe)	Value	Additional information																						
2	8	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]																						
Pin (+ probe)	Pin (- probe)	Value	Additional information																						
3	9	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]																						
Possible causes	No possible causes information available																								
Additional information	No additional information available																								
Diagnostic Step-by-Step	<div></div> <p>Perform the troubleshooting steps below using the breakout harness, if necessary, to check electrical components, such as sensors, electrical control units, and harnesses. Back probing is not recommended, as it could damage the harness. The ignition should always be in the OFF position when connecting or disconnecting electrical components in order to reduce the likelihood of damage to electrical components.</p> <ul style="list-style-type: none">• Disconnecting the EAS connectors during the troubleshooting process will result in multiple errors.• For specific electrical component information and pinout locations, always refer to the technical data.• It is necessary to exit the fault code menu in DAVIE and run the diagnostic test again to identify a change in errors.• Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive fault codes. Refer to the 'possible causes' section. <table><tr><td>Step 1</td><td>Step ID 1221a</td><td>SRT</td></tr><tr><td colspan="3">Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.</td></tr></table>	Step 1	Step ID 1221a	SRT	Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.																				
Step 1	Step ID 1221a	SRT																							
Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.																									

	<table><tr><td>Step 2</td><td>Step ID 1221b</td><td>SRT</td></tr><tr><td colspan="3">Electrical Checks Ensure that the ignition key/switch has been set to OFF before disconnecting related cables. Based on the fault message provided, confirm that the following electrical values are within specified ranges or limits:<ul style="list-style-type: none">• Supply and signal voltages (12V).• Cable continuity (no opens or shorts).Are measured electrical values outside of expected range or limits?<ul style="list-style-type: none">• Yes - Proceed to step 3• No - Proceed to step 4</td></tr></table>	Step 2	Step ID 1221b	SRT	Electrical Checks Ensure that the ignition key/switch has been set to OFF before disconnecting related cables. Based on the fault message provided, confirm that the following electrical values are within specified ranges or limits: <ul style="list-style-type: none">• Supply and signal voltages (12V).• Cable continuity (no opens or shorts). Are measured electrical values outside of expected range or limits? <ul style="list-style-type: none">• Yes - Proceed to step 3• No - Proceed to step 4		
	Step 2	Step ID 1221b	SRT				
	Electrical Checks Ensure that the ignition key/switch has been set to OFF before disconnecting related cables. Based on the fault message provided, confirm that the following electrical values are within specified ranges or limits: <ul style="list-style-type: none">• Supply and signal voltages (12V).• Cable continuity (no opens or shorts). Are measured electrical values outside of expected range or limits? <ul style="list-style-type: none">• Yes - Proceed to step 3• No - Proceed to step 4						
	<table><tr><td>Step 3</td><td>Step ID 1221c</td><td>SRT</td></tr><tr><td colspan="3">Make the appropriate repairs or component replacements and use DAVIE to re-check for the presence of active faults.<ul style="list-style-type: none">• Fault inactive – issue resolve• Fault active - Proceed to step 4</td></tr></table>	Step 3	Step ID 1221c	SRT	Make the appropriate repairs or component replacements and use DAVIE to re-check for the presence of active faults. <ul style="list-style-type: none">• Fault inactive – issue resolve• Fault active - Proceed to step 4		
	Step 3	Step ID 1221c	SRT				
Make the appropriate repairs or component replacements and use DAVIE to re-check for the presence of active faults. <ul style="list-style-type: none">• Fault inactive – issue resolve• Fault active - Proceed to step 4							
<table><tr><td>Step 4</td><td>Step ID 1221d</td><td>SRT</td></tr><tr><td colspan="3">Replace: Solenoid Valve Injector, Cylinder 4 Replace the identified faulty component and use DAVIE to re-check for the presence of active faults.<ul style="list-style-type: none">• Fault inactive – issue resolve• Fault active - Proceed to step 5</td></tr></table>	Step 4	Step ID 1221d	SRT	Replace: Solenoid Valve Injector, Cylinder 4 Replace the identified faulty component and use DAVIE to re-check for the presence of active faults. <ul style="list-style-type: none">• Fault inactive – issue resolve• Fault active - Proceed to step 5			
Step 4	Step ID 1221d	SRT					
Replace: Solenoid Valve Injector, Cylinder 4 Replace the identified faulty component and use DAVIE to re-check for the presence of active faults. <ul style="list-style-type: none">• Fault inactive – issue resolve• Fault active - Proceed to step 5							
<table><tr><td>Step 5</td><td>Step ID 1221e</td><td>SRT</td></tr><tr><td colspan="3">For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the Engine Support Call Center at 1-800-477-0251.</td></tr></table>	Step 5	Step ID 1221e	SRT	For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the Engine Support Call Center at 1-800-477-0251.			
Step 5	Step ID 1221e	SRT					
For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the Engine Support Call Center at 1-800-477-0251.							
<table><tr><td colspan="3"></td></tr></table>							
Verification Drive Cycle	To validate repair, with the brakes set, turn the key to the ON position with the engine off, and allow 10 seconds for the system to initialize and run diagnostics.						
	Back to Index						


P1222

Code number	P1222
Fault code description	Injector solenoid valve cylinder 4– Short circuit between ECU D420 pin A11 and A12
Fault code information	<p>1 trip MIL</p> <p>3 drive cycle recovery</p> <p>Readiness group – None</p> <p>Freeze frame type – Comprehensive</p>
Description of component(s)	<p>The fuel injector injects fuel into the combustion chamber.</p> <p>Control</p> <p>The amount of fuel injected depends on the duration of the injector solenoid activation in combination with the rail pressure. The longer the solenoid is activated by the PCI ECU at the same rail pressure, the more fuel is injected.</p> <p>Injector codes</p> <p>Every fuel injector is calibrated during production to compensate for any production tolerances. An injector calibration code is present on the housing and connector of the injector. These injector codes must be (re)programmed with DAVIE if one or more injectors have been replaced or fitted in another position, or if the PCI ECU is replaced.</p> <p>Not programming or incorrectly programmed injector codes can result in reduced engine performance or a warning to the driver.</p>
Location of component(s)	
Diagnostic condition	The diagnostic runs when power stage hardware is active
Set condition of fault code	<p>This condition is set when</p> <ul style="list-style-type: none"> • High side voltage on the injector (before injection) compared to battery voltage is in between 20% to 80% of threshold value • Current through sense resistor on driver bank A is more than 25 A
Reset condition of fault code	This fault code will change to inactive immediately after the diagnostic runs and passes.

Electrical diagram(s)



Wiring harness connector D420.A front view



Wiring harness connector B460 & B461 front view

B460 connector cylinders 1-3

B461 connector cylinders 4-6

D420 PCI ECU

B421 solenoid valve injector cylinder 1

B422 solenoid valve injector cylinder 2

B423 solenoid valve injector cylinder 3



B424 solenoid valve injector cylinder 4

B425 solenoid valve injector cylinder 5

B426 solenoid valve injector cylinder 6


D420	B460	B421	B422	B423	Function
A1	7	2			Signal low, injector solenoid valve cylinder 1

	<table><tr><td>A2</td><td>1</td><td>1</td><td></td><td></td><td>Signal high, injector solenoid valve cylinder 1</td></tr><tr><td>A5</td><td>9</td><td></td><td>2</td><td></td><td>Signal low, injector solenoid valve cylinder 3</td></tr><tr><td>A6</td><td>3</td><td></td><td>1</td><td></td><td>Signal high, injector solenoid valve cylinder 3</td></tr><tr><td>A9</td><td>8</td><td></td><td></td><td>2</td><td>Signal low, injector solenoid valve cylinder 2</td></tr><tr><td>A10</td><td>2</td><td></td><td></td><td>1</td><td>Signal high, injector solenoid valve cylinder 2</td></tr><tr><td colspan="6"> </td></tr><tr><td>D420</td><td>B460</td><td>B424</td><td>B425</td><td>B426</td><td>Function</td></tr><tr><td>A3</td><td>2</td><td></td><td>1</td><td></td><td>Signal high, injector solenoid valve cylinder 5</td></tr><tr><td>A4</td><td>8</td><td></td><td>2</td><td></td><td>Signal low, injector solenoid valve cylinder 5</td></tr><tr><td>A7</td><td>3</td><td></td><td></td><td>1</td><td>Signal high, injector solenoid valve cylinder 6</td></tr><tr><td>A8</td><td>9</td><td></td><td></td><td>2</td><td>Signal low, injector solenoid valve cylinder 6</td></tr><tr><td>A11</td><td>1</td><td>1</td><td></td><td></td><td>Signal high, injector solenoid valve cylinder 4</td></tr><tr><td>A12</td><td>7</td><td>2</td><td></td><td></td><td>Signal low, injector solenoid valve cylinder 4</td></tr></table>	A2	1	1			Signal high, injector solenoid valve cylinder 1	A5	9		2		Signal low, injector solenoid valve cylinder 3	A6	3		1		Signal high, injector solenoid valve cylinder 3	A9	8			2	Signal low, injector solenoid valve cylinder 2	A10	2			1	Signal high, injector solenoid valve cylinder 2							D420	B460	B424	B425	B426	Function	A3	2		1		Signal high, injector solenoid valve cylinder 5	A4	8		2		Signal low, injector solenoid valve cylinder 5	A7	3			1	Signal high, injector solenoid valve cylinder 6	A8	9			2	Signal low, injector solenoid valve cylinder 6	A11	1	1			Signal high, injector solenoid valve cylinder 4	A12	7	2			Signal low, injector solenoid valve cylinder 4
A2	1	1			Signal high, injector solenoid valve cylinder 1																																																																										
A5	9		2		Signal low, injector solenoid valve cylinder 3																																																																										
A6	3		1		Signal high, injector solenoid valve cylinder 3																																																																										
A9	8			2	Signal low, injector solenoid valve cylinder 2																																																																										
A10	2			1	Signal high, injector solenoid valve cylinder 2																																																																										
D420	B460	B424	B425	B426	Function																																																																										
A3	2		1		Signal high, injector solenoid valve cylinder 5																																																																										
A4	8		2		Signal low, injector solenoid valve cylinder 5																																																																										
A7	3			1	Signal high, injector solenoid valve cylinder 6																																																																										
A8	9			2	Signal low, injector solenoid valve cylinder 6																																																																										
A11	1	1			Signal high, injector solenoid valve cylinder 4																																																																										
A12	7	2			Signal low, injector solenoid valve cylinder 4																																																																										
Technical data	<p>Component check, injector solenoid valve cylinder 1 (B421)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key off the ignition• Disconnect connector B460• Measure on wiring harness connector B460 <table><tr><td>Pin (+ probe)</td><td>Pin (- probe)</td><td>Value</td><td>Additional information</td></tr><tr><td>1</td><td>7</td><td>± 0.67 Ω</td><td>Resistance value at 20°C [68°F]</td></tr><tr><td></td><td></td><td>maximum 0.94 Ω</td><td>Resistance value at 120°C [248°F]</td></tr></table> <p>Component check, injector solenoid valve cylinder 2 (B422)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key off the ignition• Disconnect connector B460• Measure on wiring harness connector B460 <table><tr><td>Pin (+ probe)</td><td>Pin (- probe)</td><td>Value</td><td>Additional information</td></tr><tr><td>2</td><td>8</td><td>± 0.67 Ω</td><td>Resistance value at 20°C [68°F]</td></tr><tr><td></td><td></td><td>maximum 0.94 Ω</td><td>Resistance value at 120°C [248°F]</td></tr></table> <p>Component check, injector solenoid valve cylinder 3 (B423)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key off the ignition• Disconnect connector B460• Measure on wiring harness connector B460 <table><tr><td>Pin (+ probe)</td><td>Pin (- probe)</td><td>Value</td><td>Additional information</td></tr><tr><td>3</td><td>9</td><td>± 0.67 Ω</td><td>Resistance value at 20°C [68°F]</td></tr><tr><td></td><td></td><td>maximum 0.94 Ω</td><td>Resistance value at 120°C [248°F]</td></tr></table> <p>Component check, injector solenoid valve cylinder 4 (B424)</p>	Pin (+ probe)	Pin (- probe)	Value	Additional information	1	7	± 0.67 Ω	Resistance value at 20°C [68°F]			maximum 0.94 Ω	Resistance value at 120°C [248°F]	Pin (+ probe)	Pin (- probe)	Value	Additional information	2	8	± 0.67 Ω	Resistance value at 20°C [68°F]			maximum 0.94 Ω	Resistance value at 120°C [248°F]	Pin (+ probe)	Pin (- probe)	Value	Additional information	3	9	± 0.67 Ω	Resistance value at 20°C [68°F]			maximum 0.94 Ω	Resistance value at 120°C [248°F]																																										
Pin (+ probe)	Pin (- probe)	Value	Additional information																																																																												
1	7	± 0.67 Ω	Resistance value at 20°C [68°F]																																																																												
		maximum 0.94 Ω	Resistance value at 120°C [248°F]																																																																												
Pin (+ probe)	Pin (- probe)	Value	Additional information																																																																												
2	8	± 0.67 Ω	Resistance value at 20°C [68°F]																																																																												
		maximum 0.94 Ω	Resistance value at 120°C [248°F]																																																																												
Pin (+ probe)	Pin (- probe)	Value	Additional information																																																																												
3	9	± 0.67 Ω	Resistance value at 20°C [68°F]																																																																												
		maximum 0.94 Ω	Resistance value at 120°C [248°F]																																																																												



	<p>Preparation</p> <ul style="list-style-type: none">• Key off the ignition• Disconnect connector B461• Measure on wiring harness connector B461 <table><tr><th>Pin</th><th>Pin</th><th>Value</th><th>Additional information</th></tr><tr><td>(+ probe)</td><td>(- probe)</td><td></td><td></td></tr><tr><td>1</td><td>7</td><td>$\pm 0.67 \Omega$</td><td>Resistance value at 20°C [68°F]</td></tr><tr><td></td><td></td><td>maximum 0.94 Ω</td><td>Resistance value at 120°C [248°F]</td></tr></table> <p>Component check, injector solenoid valve cylinder 5 (B425)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key off the ignition• Disconnect connector B461• Measure on wiring harness connector B461 <table><tr><th>Pin</th><th>Pin</th><th>Value</th><th>Additional information</th></tr><tr><td>(+ probe)</td><td>(- probe)</td><td></td><td></td></tr><tr><td>2</td><td>8</td><td>$\pm 0.67 \Omega$</td><td>Resistance value at 20°C [68°F]</td></tr><tr><td></td><td></td><td>maximum 0.94 Ω</td><td>Resistance value at 120°C [248°F]</td></tr></table> <p>Component check, injector solenoid valve cylinder 6 (B426)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key off the ignition• Disconnect connector B461• Measure on wiring harness connector B461 <table><tr><th>Pin</th><th>Pin</th><th>Value</th><th>Additional information</th></tr><tr><td>(+ probe)</td><td>(- probe)</td><td></td><td></td></tr><tr><td>3</td><td>9</td><td>$\pm 0.67 \Omega$</td><td>Resistance value at 20°C [68°F]</td></tr><tr><td></td><td></td><td>maximum 0.94 Ω</td><td>Resistance value at 120°C [248°F]</td></tr></table>	Pin	Pin	Value	Additional information	(+ probe)	(- probe)			1	7	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]			maximum 0.94 Ω	Resistance value at 120°C [248°F]	Pin	Pin	Value	Additional information	(+ probe)	(- probe)			2	8	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]			maximum 0.94 Ω	Resistance value at 120°C [248°F]	Pin	Pin	Value	Additional information	(+ probe)	(- probe)			3	9	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]			maximum 0.94 Ω	Resistance value at 120°C [248°F]
Pin	Pin	Value	Additional information																																														
(+ probe)	(- probe)																																																
1	7	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]																																														
		maximum 0.94 Ω	Resistance value at 120°C [248°F]																																														
Pin	Pin	Value	Additional information																																														
(+ probe)	(- probe)																																																
2	8	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]																																														
		maximum 0.94 Ω	Resistance value at 120°C [248°F]																																														
Pin	Pin	Value	Additional information																																														
(+ probe)	(- probe)																																																
3	9	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]																																														
		maximum 0.94 Ω	Resistance value at 120°C [248°F]																																														
Possible causes	No possible causes available.																																																
Additional information	No additional information available.																																																
Diagnostic Step-by-Step	<div><p>Perform the troubleshooting steps below using the breakout harness, if necessary, to check electrical components, such as sensors, electrical control units, and harnesses. Back probing is not recommended, as it could damage the harness. The ignition should always be in the OFF position when connecting or disconnecting electrical components in order to reduce the likelihood of damage to electrical components.</p></div> <div><ul style="list-style-type: none">• Disconnecting the EAS connectors during the troubleshooting process will result in multiple errors.• For specific electrical component information and pinout locations, always refer to the technical data.• It is necessary to exit the fault code menu in DAVIE and run the diagnostic test again to identify a change in errors.• Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive fault codes. Refer to the 'possible causes' section.</div>																																																

	<table><tr><td>Step 1</td><td>Step ID 1222a</td><td>SRT</td></tr><tr><td colspan="3">Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.</td></tr></table>	Step 1	Step ID 1222a	SRT	Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.		
	Step 1	Step ID 1222a	SRT				
	Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.						
	<table><tr><td>Step 2</td><td>Step ID 1222b</td><td>SRT</td></tr><tr><td colspan="3"><p>Electrical Checks</p><p>Ensure that the ignition key/switch has been set to OFF before disconnecting related cables.</p><p>Based on the fault message provided, confirm that the following electrical values are within specified ranges or limits:</p><ul style="list-style-type: none">• Supply and signal voltages (12V).• Cable continuity (no opens or shorts).<p>Are measured electrical values outside of expected range or limits?</p><ul style="list-style-type: none">• Yes - Proceed to step 3• No - Proceed to step 4</td></tr></table>	Step 2	Step ID 1222b	SRT	<p>Electrical Checks</p> <p>Ensure that the ignition key/switch has been set to OFF before disconnecting related cables.</p> <p>Based on the fault message provided, confirm that the following electrical values are within specified ranges or limits:</p> <ul style="list-style-type: none">• Supply and signal voltages (12V).• Cable continuity (no opens or shorts). <p>Are measured electrical values outside of expected range or limits?</p> <ul style="list-style-type: none">• Yes - Proceed to step 3• No - Proceed to step 4		
Step 2	Step ID 1222b	SRT					
<p>Electrical Checks</p> <p>Ensure that the ignition key/switch has been set to OFF before disconnecting related cables.</p> <p>Based on the fault message provided, confirm that the following electrical values are within specified ranges or limits:</p> <ul style="list-style-type: none">• Supply and signal voltages (12V).• Cable continuity (no opens or shorts). <p>Are measured electrical values outside of expected range or limits?</p> <ul style="list-style-type: none">• Yes - Proceed to step 3• No - Proceed to step 4							
<table><tr><td>Step 3</td><td>Step ID 1222c</td><td>SRT</td></tr><tr><td colspan="3"><p>Repairs or component replacements appropriate component and use DAVIE to re-check for the presence of active faults.</p><ul style="list-style-type: none">• Fault inactive – issue resolve• Fault active - Proceed to step 4</td></tr></table>	Step 3	Step ID 1222c	SRT	<p>Repairs or component replacements appropriate component and use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">• Fault inactive – issue resolve• Fault active - Proceed to step 4			
Step 3	Step ID 1222c	SRT					
<p>Repairs or component replacements appropriate component and use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">• Fault inactive – issue resolve• Fault active - Proceed to step 4							
<table><tr><td>Step 4</td><td>Step ID 1222d</td><td>SRT</td></tr><tr><td colspan="3">For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the Engine Support Call Center at 1-800-477-0251.</td></tr></table>	Step 4	Step ID 1222d	SRT	For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the Engine Support Call Center at 1-800-477-0251.			
Step 4	Step ID 1222d	SRT					
For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the Engine Support Call Center at 1-800-477-0251.							
Verification Drive Cycle	To validate repair, with the brakes set, turn the key to the ON position with the engine off, and allow 10 seconds for the system to initialize and run diagnostics.						
	Back to Index						


P1223

Code number	P1223
Fault code description	Injector solenoid valve cylinder 4– Voltage too low or short circuit to ground on ECU D420 pin A12
Fault code information	1 trip MIL 3 drive cycle recovery Readiness group – None Freeze frame type – Comprehensive
Description of component(s)	<p>The fuel injector injects fuel into the combustion chamber. Control</p> <p>The amount of fuel injected depends on the duration of the injector solenoid activation in combination with the rail pressure. The longer the solenoid is activated by the PCI ECU at the same rail pressure, the more fuel is injected.</p> <p>Injector codes</p> <p>Every fuel injector is calibrated during production to compensate for any production tolerances. An injector calibration code is present on the housing and connector of the injector. These injector codes must be (re)programmed with DAVIE if one or more injectors have been replaced or fitted in another position, or if the PCI ECU is replaced.</p> <p>Not programming or incorrectly programmed injector codes can result in reduced engine performance or a warning to the driver.</p>
Location of component(s)	
Diagnostic condition	The diagnostic runs when power stage hardware is active
Set condition of fault code	<p>This condition is set when</p> <ul style="list-style-type: none"> • High side voltage on the injector (before injection) compared to battery voltage is less than 20% of threshold value • Current through sense resistor on driver bank B is less than 4.5 A
Reset condition of fault code	This fault code will change to inactive immediately after the diagnostic runs and passes.

Electrical diagram(s)



Wiring harness connector D420.A front view



Wiring harness connector B460 & B461 front view

B460 connector cylinders 1-3

B461 connector cylinders 4-6

D420 PCI ECU

B421 solenoid valve injector cylinder 1

B422 solenoid valve injector cylinder 2

B423 solenoid valve injector cylinder 3



B424 solenoid valve injector cylinder 4

B425 solenoid valve injector cylinder 5

B426 solenoid valve injector cylinder 6

D420	B460	B421	B422	B423	Function
A1	7	2			Signal low, injector solenoid valve cylinder 1

	<table><tr><td>A2</td><td>1</td><td>1</td><td></td><td></td><td>Signal high, injector solenoid valve cylinder 1</td></tr><tr><td>A5</td><td>9</td><td></td><td>2</td><td></td><td>Signal low, injector solenoid valve cylinder 3</td></tr><tr><td>A6</td><td>3</td><td></td><td>1</td><td></td><td>Signal high, injector solenoid valve cylinder 3</td></tr><tr><td>A9</td><td>8</td><td></td><td></td><td>2</td><td>Signal low, injector solenoid valve cylinder 2</td></tr><tr><td>A10</td><td>2</td><td></td><td></td><td>1</td><td>Signal high, injector solenoid valve cylinder 2</td></tr><tr><td colspan="6"> </td></tr><tr><td>D420</td><td>B460</td><td>B424</td><td>B425</td><td>B426</td><td>Function</td></tr><tr><td>A3</td><td>2</td><td></td><td>1</td><td></td><td>Signal high, injector solenoid valve cylinder 5</td></tr><tr><td>A4</td><td>8</td><td></td><td>2</td><td></td><td>Signal low, injector solenoid valve cylinder 5</td></tr><tr><td>A7</td><td>3</td><td></td><td></td><td>1</td><td>Signal high, injector solenoid valve cylinder 6</td></tr><tr><td>A8</td><td>9</td><td></td><td></td><td>2</td><td>Signal low, injector solenoid valve cylinder 6</td></tr><tr><td>A11</td><td>1</td><td>1</td><td></td><td></td><td>Signal high, injector solenoid valve cylinder 4</td></tr><tr><td>A12</td><td>7</td><td>2</td><td></td><td></td><td>Signal low, injector solenoid valve cylinder 4</td></tr></table>					A2	1	1			Signal high, injector solenoid valve cylinder 1	A5	9		2		Signal low, injector solenoid valve cylinder 3	A6	3		1		Signal high, injector solenoid valve cylinder 3	A9	8			2	Signal low, injector solenoid valve cylinder 2	A10	2			1	Signal high, injector solenoid valve cylinder 2							D420	B460	B424	B425	B426	Function	A3	2		1		Signal high, injector solenoid valve cylinder 5	A4	8		2		Signal low, injector solenoid valve cylinder 5	A7	3			1	Signal high, injector solenoid valve cylinder 6	A8	9			2	Signal low, injector solenoid valve cylinder 6	A11	1	1			Signal high, injector solenoid valve cylinder 4	A12	7	2			Signal low, injector solenoid valve cylinder 4
A2	1	1			Signal high, injector solenoid valve cylinder 1																																																																														
A5	9		2		Signal low, injector solenoid valve cylinder 3																																																																														
A6	3		1		Signal high, injector solenoid valve cylinder 3																																																																														
A9	8			2	Signal low, injector solenoid valve cylinder 2																																																																														
A10	2			1	Signal high, injector solenoid valve cylinder 2																																																																														
D420	B460	B424	B425	B426	Function																																																																														
A3	2		1		Signal high, injector solenoid valve cylinder 5																																																																														
A4	8		2		Signal low, injector solenoid valve cylinder 5																																																																														
A7	3			1	Signal high, injector solenoid valve cylinder 6																																																																														
A8	9			2	Signal low, injector solenoid valve cylinder 6																																																																														
A11	1	1			Signal high, injector solenoid valve cylinder 4																																																																														
A12	7	2			Signal low, injector solenoid valve cylinder 4																																																																														
Technical data	<div>Component check, injector solenoid valve cylinder 1 (B421)</div> <div>Preparation<ul style="list-style-type: none">Key off the ignitionDisconnect connector B460Measure on wiring harness connector B460<table><tr><td>Pin</td><td>Pin</td><td></td><td></td></tr><tr><td>(+ probe)</td><td>(- probe)</td><td>Value</td><td>Additional information</td></tr><tr><td>1</td><td>7</td><td>$\pm 0.67 \Omega$</td><td>Resistance value at 20°C [68°F]</td></tr><tr><td></td><td></td><td>maximum 0.94 Ω</td><td>Resistance value at 120°C [248°F]</td></tr></table></div> <div>Component check, injector solenoid valve cylinder 2 (B422)</div> <div>Preparation<ul style="list-style-type: none">Key off the ignitionDisconnect connector B460Measure on wiring harness connector B460<table><tr><td>Pin</td><td>Pin</td><td></td><td></td></tr><tr><td>(+ probe)</td><td>(- probe)</td><td>Value</td><td>Additional information</td></tr><tr><td>2</td><td>8</td><td>$\pm 0.67 \Omega$</td><td>Resistance value at 20°C [68°F]</td></tr><tr><td></td><td></td><td>maximum 0.94 Ω</td><td>Resistance value at 120°C [248°F]</td></tr></table></div> <div>Component check, injector solenoid valve cylinder 3 (B423)</div> <div>Preparation<ul style="list-style-type: none">Key off the ignitionDisconnect connector B460Measure on wiring harness connector B460<table><tr><td>Pin</td><td>Pin</td><td></td><td></td></tr><tr><td>(+ probe)</td><td>(- probe)</td><td>Value</td><td>Additional information</td></tr><tr><td>3</td><td>9</td><td>$\pm 0.67 \Omega$</td><td>Resistance value at 20°C [68°F]</td></tr><tr><td></td><td></td><td>maximum 0.94 Ω</td><td>Resistance value at 120°C [248°F]</td></tr></table></div> <div>Component check, injector solenoid valve cylinder 4 (B424)</div>					Pin	Pin			(+ probe)	(- probe)	Value	Additional information	1	7	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]			maximum 0.94 Ω	Resistance value at 120°C [248°F]	Pin	Pin			(+ probe)	(- probe)	Value	Additional information	2	8	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]			maximum 0.94 Ω	Resistance value at 120°C [248°F]	Pin	Pin			(+ probe)	(- probe)	Value	Additional information	3	9	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]			maximum 0.94 Ω	Resistance value at 120°C [248°F]																														
Pin	Pin																																																																																		
(+ probe)	(- probe)	Value	Additional information																																																																																
1	7	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]																																																																																
		maximum 0.94 Ω	Resistance value at 120°C [248°F]																																																																																
Pin	Pin																																																																																		
(+ probe)	(- probe)	Value	Additional information																																																																																
2	8	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]																																																																																
		maximum 0.94 Ω	Resistance value at 120°C [248°F]																																																																																
Pin	Pin																																																																																		
(+ probe)	(- probe)	Value	Additional information																																																																																
3	9	$\pm 0.67 \Omega$	Resistance value at 20°C [68°F]																																																																																
		maximum 0.94 Ω	Resistance value at 120°C [248°F]																																																																																

	<p>Preparation</p> <ul style="list-style-type: none">• Key off the ignition• Disconnect connector B461• Measure on wiring harness connector B461 <table><tr><th>Pin (+ probe)</th><th>Pin (- probe)</th><th>Value</th><th>Additional information</th></tr><tr><td>1</td><td>7</td><td>$\pm 0.67 \Omega$ maximum 0.94Ω</td><td>Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]</td></tr></table> <p>Component check, injector solenoid valve cylinder 5 (B425)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key off the ignition• Disconnect connector B461• Measure on wiring harness connector B461 <table><tr><th>Pin (+ probe)</th><th>Pin (- probe)</th><th>Value</th><th>Additional information</th></tr><tr><td>2</td><td>8</td><td>$\pm 0.67 \Omega$ maximum 0.94Ω</td><td>Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]</td></tr></table> <p>Component check, injector solenoid valve cylinder 6 (B426)</p> <p>Preparation</p> <ul style="list-style-type: none">• Key off the ignition• Disconnect connector B461• Measure on wiring harness connector B461 <table><tr><th>Pin (+ probe)</th><th>Pin (- probe)</th><th>Value</th><th>Additional information</th></tr><tr><td>3</td><td>9</td><td>$\pm 0.67 \Omega$ maximum 0.94Ω</td><td>Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]</td></tr></table>	Pin (+ probe)	Pin (- probe)	Value	Additional information	1	7	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]	Pin (+ probe)	Pin (- probe)	Value	Additional information	2	8	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]	Pin (+ probe)	Pin (- probe)	Value	Additional information	3	9	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]
Pin (+ probe)	Pin (- probe)	Value	Additional information																						
1	7	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]																						
Pin (+ probe)	Pin (- probe)	Value	Additional information																						
2	8	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]																						
Pin (+ probe)	Pin (- probe)	Value	Additional information																						
3	9	$\pm 0.67 \Omega$ maximum 0.94Ω	Resistance value at 20°C [68°F] Resistance value at 120°C [248°F]																						
Possible causes	No possible causes available.																								
Additional information	No additional information available.																								
Diagnostic Step-by-Step	<div><p>Perform the troubleshooting steps below using the breakout harness, if necessary, to check electrical components, such as sensors, electrical control units, and harnesses. Back probing is not recommended, as it could damage the harness. The ignition should always be in the OFF position when connecting or disconnecting electrical components in order to reduce the likelihood of damage to electrical components.</p></div> <div><ul style="list-style-type: none">• Disconnecting the EAS connectors during the troubleshooting process will result in multiple errors.• For specific electrical component information and pinout locations, always refer to the technical data.• It is necessary to exit the fault code menu in DAVIE and run the diagnostic test again to identify a change in errors.• Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive fault codes. Refer to the 'possible causes' section.</div>																								

	<table><tr><td>Step 1</td><td>Step ID 1223a</td><td>SRT</td></tr><tr><td colspan="3">Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.</td></tr></table>	Step 1	Step ID 1223a	SRT	Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.		
	Step 1	Step ID 1223a	SRT				
	Visually inspect all applicable connectors (bent, broken, corroded or loose pins) and harnesses for corrosion, damage, and rubbing during each step of the diagnostic procedure. Proceed to step 2.						
	<table><tr><td>Step 2</td><td>Step ID 1223b</td><td>SRT</td></tr><tr><td colspan="3"><p>Electrical Checks</p><p>Ensure that the ignition key/switch has been set to OFF before disconnecting related cables.</p><p>Based on the fault message provided, confirm that the following electrical values are within specified ranges or limits:</p><ul style="list-style-type: none">• Supply and signal voltages (12V).• Cable continuity (no opens or shorts).<p>Are measured electrical values outside of expected range or limits?</p><ul style="list-style-type: none">• Yes - Proceed to step 3• No - Proceed to step 4</td></tr></table>	Step 2	Step ID 1223b	SRT	<p>Electrical Checks</p> <p>Ensure that the ignition key/switch has been set to OFF before disconnecting related cables.</p> <p>Based on the fault message provided, confirm that the following electrical values are within specified ranges or limits:</p> <ul style="list-style-type: none">• Supply and signal voltages (12V).• Cable continuity (no opens or shorts). <p>Are measured electrical values outside of expected range or limits?</p> <ul style="list-style-type: none">• Yes - Proceed to step 3• No - Proceed to step 4		
	Step 2	Step ID 1223b	SRT				
<p>Electrical Checks</p> <p>Ensure that the ignition key/switch has been set to OFF before disconnecting related cables.</p> <p>Based on the fault message provided, confirm that the following electrical values are within specified ranges or limits:</p> <ul style="list-style-type: none">• Supply and signal voltages (12V).• Cable continuity (no opens or shorts). <p>Are measured electrical values outside of expected range or limits?</p> <ul style="list-style-type: none">• Yes - Proceed to step 3• No - Proceed to step 4							
<table><tr><td>Step 3</td><td>Step ID 1223c</td><td>SRT</td></tr><tr><td colspan="3"><p>Repairs or component replacements appropriate component and use DAVIE to re-check for the presence of active faults.</p><ul style="list-style-type: none">• Fault inactive – issue resolve• Fault active - Proceed to step 4</td></tr></table>	Step 3	Step ID 1223c	SRT	<p>Repairs or component replacements appropriate component and use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">• Fault inactive – issue resolve• Fault active - Proceed to step 4			
Step 3	Step ID 1223c	SRT					
<p>Repairs or component replacements appropriate component and use DAVIE to re-check for the presence of active faults.</p> <ul style="list-style-type: none">• Fault inactive – issue resolve• Fault active - Proceed to step 4							
<table><tr><td>Step 4</td><td>Step ID 1223d</td><td>SRT</td></tr><tr><td colspan="3">For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the Engine Support Call Center at 1-800-477-0251.</td></tr></table>	Step 4	Step ID 1223d	SRT	For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the Engine Support Call Center at 1-800-477-0251.			
Step 4	Step ID 1223d	SRT					
For further assistance in diagnosing this issue or for confirmation prior to the replacement of suspect components, contact the Engine Support Call Center at 1-800-477-0251.							
Verification Drive Cycle	To validate repair, with the brakes set, turn the key to the ON position with the engine off, and allow 10 seconds for the system to initialize and run diagnostics.						

[Back to Index](#)