

P1028

Fault code description

BPV initialisation - Malfunction

Possible cause

1. Valve not initialised (initialise valve with DAVIE)
2. Main switch was switched off immediately after ignition off (within 15 seconds)

Additional information

-

Set condition of fault code

-

Reset condition of fault code

-

M028261 - 07/22/2015 16:13:45

This information applies exclusively to the entered chassis number or the selected engine type. Please take into account that this information may change daily. Therefore the provided information is only valid on 12-13-2015. You cannot derive any rights from the information provided with respect to vehicles and/or components of another series, with another chassis number, and/or of another date. (/)

P1028, Diagnostic information

Technical data

["BPV actuator \(L020\)"](#)

Location of component(s)

["Location information, PMCI-2"](#)

Electrical diagram(s)

["PMCI-2"](#)

Description of component(s)

["BPV actuator \(L020\)"](#)

Block diagram

["PMCI-2"](#)

Step by step troubleshooting



Please perform the troubleshooting steps below by utilising the breakout harness if necessary to check electrical components such as sensors, electrical control units or harnesses. Back probing is not recommended as it could damage the harness. The ignition should always be in the **OFF** position when connecting or disconnecting electrical components to reduce the likelihood of damage to electrical components.



- This troubleshooting tree is based on the assumption that supply power and earth to the PMCI are functioning properly.
- Disconnecting the PMCI connectors during the troubleshooting process will result in multiple errors.
- For specific electrical component information and pin out locations, always refer to the technical data in Rapido.

- It is necessary to exit the 'active errors' screen in DAVIE and run the diagnostic test again to identify a change in errors.
- Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive codes. Refer to the 'possible causes' section in Rapido.

Step by step 1: Visual Inspections

Step 1A: Check connections and wiring

Troubleshooting steps

1. Visually inspect the component connections and wiring.

Are any issues found?

- **Yes** – Repair any issues found. Proceed to step 2A.
- **No** – Proceed to step 2A.

Step by step 2: Resistance

Step 2A: Check resistance of sensor and wiring

Troubleshooting steps

1. Check the resistance of the sensor and wires.

Is there any issue with resistance?

- **Yes** – Repair any issues found, proceed to step 3.
- **No** – Replace the BPV actuator. Proceed to step 3.

Step by step 3: Validate repair

Step 3A: Check if the fault code is active

Troubleshooting steps

1. Validate the repairs.

Does the fault code become active after validation?

- Yes – Proceed to step 4A.
- No – Troubleshooting completed.

Step by step 4: Contact PACCAR Engine Support Center

Step 4A: Assistance

Contact the PACCAR Engine Support Center for further assistance.

M046414 - 07/22/2015 19:18:07

This information applies exclusively to the entered chassis number or the selected engine type. Please take into account that this information may change daily. Therefore the provided information is only valid on 12-13-2015. You cannot derive any rights from the information provided with respect to vehicles and/or components of another series, with another chassis number, and/or of another date. (/)