

Model:0880027
Chapter


Serial number: 0880027

1876473

1876473 Stab.leg down detection

1876473 - 1876473 Stab.leg down detection

Pos	Part No	Description	Quantity
1	1877011	BALL SWITCH	2
2	1877020	SHIM RD.15X21X0.5	2



1876473 Stab.leg down detection - 1876473

Model:0880027
Chapter


Serial number: 0880027

1890115

1890115 Tilt indicator 2nd boom

1890115 - 1890115 Tilt indicator 2nd boom

Pos	Part No	Description	Quantity
1	3600866	TILT INDICATOR	1
2	9908242	WASHER	2
3	9902376	CH.SCREW	2



189-0115A


1890115 Tilt indicator 2nd boom - 1890115

Model:0880027
Chapter

Serial number: 0880027

1890131
1890131 Filters SPACE 4000

1890131 - 1890131 Filters SPACE 4000



Pos	Part No	Description	Quantity
1	9859942	FILTER	1
2	9821341	COUPLING	2
3	9821741	ANGLE COUPLING	2
4	9825011	PLUG	1
5	9991689	NIPPLE	1
6	9859934	FILTER	1
7	3585867	ANGLE NIPPLE	1
8	8163677	RETAINING RING 3/4	1
9	9814507	COUPLING	1
10	9968725	MEASURING NIPPLE	1
11	1803735	SUPPORT	1
12	9904131	SPRING WASHER	7
13	9924051	HEXAGON HEAD SCREW	7
14	9937587	HOSE CLAMP	2
15	9808213	COUPLING	2
16	9873694	HP HOSE	1
17	9836802	HP-HOSE	2

1890131 Filters SPACE 4000 - 1890131


Model:0880027
Chapter

Serial number: 0880027

1890280
1890280 Nipples 4+2F

1890280 - 1890280 Nipples 4+2F

Pos	Part No	Description	Quantity
1	9991638	ANGLE COUPLING	1
2	4978943	SWIVEL 3/4-16	6
3	9998438	COUPLING	6
4	9988092	COUPLING	1
5	9991662	NIPPLE 7/8-1/2	1
6	9904042	GS-WASHER	6



189-0280

1890280 Nipples 4+2F - 1890280

Model:0880027


Chapter

Serial number: 0880027

1890395

1890395 Tilttable stabilizer legs (3 degr.)

1890395 - 1890395 Tilttable stabilizer legs (3 degr.)



Pos	Part No	Description	Quantity
1	4939549	THREADED ROD M12 LG.50	2
2	1890701	EXTENDED ROD	2
3	9908480	NUT	2
4	9900535	HEXAGON HEAD SCREW	2
5	4933206	GUIDE	2
6	9904131	SPRING WASHER	4
7	9924086	HEXAGON HEAD BOLT	4
8	1885901	BUSH	2
9	3655857	WASHER	8
10	1890417	TILTING KIT	1
11	1911031	TILTINGPLATE (3)	1
12	9966986	FLANGE NUT	8
13	9924345	HEXAGON HEAD SCREW	4
14	9908498	SPRING WASHER	4
15	9812989	SCREW	2
16	4936116	DISK	2
17	1866621	PLATE	2
18	1890441	RING	2
19	1911023	TILTING PLATE (3)	1
20	1890425	TILTING KIT	1
21	9922903	SCREW	8
22	9922954	SCREW	8
23	1885871	GUIDE	2
24	1836714	SLIDE RAIL	2
25	3475727	SHIM	4
26	9877151	PT HEX NUT M14-A3P	8
27	3500691	CLAMP	4
28	3500721	LOCKING WIRE	2
29	1836684	SUPPORT LEG CPL.	2
30	4480538	HOSE CLAMP 113-121MM	4
31	9967940	SCREW	2

1890395 Tilttable stabilizer legs (3 degr.) - 1890395

Model:0880027
Chapter


Serial number: 0880027

1890433

1890433 Not stowed warning

1890433 - 1890433 Not stowed warning

Pos	Part No	Description	Quantity
1	3630722	TRANSDUCER	3
2	1891090	SUPPORT	1
3	9900489	HEX HEAD SCREW	1
4	9964347	LOCKING NUT	1
5	1867296	SUPPORT	1
6	1867300	SUPPORT	1
7	1890123	ELECTRONIC BOX	1



1890433 Not stowed warning - 1890433

Model:0880027
Chapter


Serial number: 0880027

1890450
1890450 Transport Kit

1890450 - 1890450 Transport Kit

Pos	Part No	Description	Quantity
1	9924655	HEXAGON HEAD SCREW	2
2	4971264	LIFTING EYE	2
3	9910565	WASHER	2
4	9964487	LOCKING NUT	2
5	9922628	SCREW	1
6	9924086	HEXAGON HEAD BOLT	2
7	9903861	WASHER	4
8	8912670	CLAMP	4
9	1890468	PIPE	1
10	9965823	LOCKING NUT	2
11	1890492	PALLET	1
12	9838317	SCREW	2
13	9800514	SQUARE NECK BOLT	2
14	3287572	WASHER	4
15	9908480	NUT	4


1890450 Transport Kit - 1890450



Model:0880027
Chapter

Serial number: 0880027

1890476
1890476 Spirit level

1890476 - 1890476 Spirit level		Pos	Part No	Description	Quantity
 189-0476		1	9852468	SPIRIT LEVEL	1
		2	1890557	PLATE	1

1890476 Spirit level - 1890476

Model:0880027
Chapter


Serial number: 0880027

1890506

1890506 Beam crane base 2300

1890506 - 1890506 Beam crane base 2300

Pos	Part No	Description	Quantity
1	1890506	BEAM	1



1890506 Beam crane base 2300 - 1890506

Model:0880027

Chapter


Serial number: 0880027

1890573

1890573 Slewing house mounted

1890573 - 1890573 Slewing house mounted

* Tightening torque M30 bolts
* 1500 Nm (4x)



Pos	Part No	Description	Quantity
1	9922695	SCREW	12
2	9836187	WASHER	12
3	1890352	SLEWING CYLINDER	2
4	7116672	SEAL RING	2
5	3549143	SLEWING PISTON	1
6	9933476	O-RING	2
7	1838555	SLEWING HOUSE MACHINE	1
8	3403904	RING	1
9	8495084	BUSHING	1
10	3477771	BEARING BUSHING	1
11	9820043	RETAINING RING	1
12	9921885	O-RING	1
13	9824391	SCREW	2
14	1811932	LEVEL SCALE	1
15	1830767	PROTECTION COVER	4
16	1805401	CH.TENSION SCREW M30X	2
17	1834819	PLATE	2
18	9939415	GS-WASHER	1
19	9900519	HEXAGON HEAD BOLT	1
20	9924329	HEXAGON HEAD SCREW	1
21	9908498	SPRING WASHER	1
22	1872974	HOSE GUIDE	1
23	1838563	PLATE, LOADERBODY HOU	2
24	1834801	NUT	4
25	1805614	GUIDE	1
26	9819622	PLUG	1
27	9924051	HEXAGON HEAD SCREW	6
28	1805649	SLEEVE	1
29	1805665	SEAL RING	1
30	3493539	SLIDE PAD	1
31	9900471	HEXAGON HEAD SCREW	1
32	9904140	SPRING WASHER	1
33	3154921	LOCKING WASHER	1
34	1806084	SECURING PIN	1
35	9921338	O-RING	1

1890573 Slewing house mounted - 1890573


Model:0880027
Chapter

Serial number: 0880027

1890581
1890581 3-Point bridge

1890581 - 1890581 3-Point bridge

Pos	Part No	Description	Quantity
1	1890590	THREE POINT BRIDGE	1
2	9928880	RETAININGS RING	1




1890581 3-Point bridge - 1890581

Model:0880027
Chapter

Serial number: 0880027

1890620
1890620 Hydr. stabilizer kit

1890620 - 1890620 Hydr. stabilizer kit



Pos	Part No	Description	Quantity
1	3567851	ROLLER	2
2	9998161	BALL BEARING	4
3	1824830	SHAFT	2
4	9904140	SPRING WASHER	8
5	9924191	HEXAGON HEAD SCREW	4
6	1806025	LOCKING PLATE	2
7	1866435	PLATE	1
8	9876421	SCREW	2
9	1811843	ROLL	2
10	9953523	LOCKING NUT	2
11	1867164	HOSE GUIDE	1
12	1890387	HYDR.CYLINDER	2
13	1867091	CAP	2
14	1867148	HOSE GUIDE	1
15	9924205	HEXAGON HEAD SCREW	4
16	1866630	BRACKET	2
17	9904131	SPRING WASHER	8
18	9900420	HEXAGON HEAD SCREW	8
19	9922504	SCREW	8
20	1866427	PLATE	1
21	9964347	LOCKING NUT	8
22	1811886	OUTRIGGER BEAM	2

1890620 Hydr. stabilizer kit - 1890620


Model:0880027
Chapter

Serial number: 0880027

1890638

1890638 Operating base 4+2F

1890638 - 1890638 Operating base 4+2F



Pos	Part No	Description	Quantity
1	4978994	COVER CPL.	1
2	4978340	CLAMPPROFILE 2-4 MM	1
3	1803743	CLAMPPROFILE 2-4 MM	2
4	3552527	SYMBOL SIGN	1
5	3552535	SYMBOL SIGN	1
6	3552543	SYMBOL SIGN	1
7	3552560	SYMBOL SIGN	1
8	3552594	SYMBOL SIGN	2
9	4474732	RIPP BOLT M12X20	4
10	1890646	CONSOLE	1
11	9964347	LOCKING NUT	3
12	9819851	HANDLE	1
13	9809945	HANDLE	5
14	1891499	LEVER	6
15	9914111	WASHER	3
16	9900497	HEXAGON HEAD SCREW	3

1890638 Operating base 4+2F - 1890638

Model:0880027


Chapter

Serial number: 0880027

1890727

1890727 Oil cooler mounted

1890727 - 1890727 Oil cooler mounted



Pos	Part No	Description	Quantity
1	9924213	HEXAGON HEAD SCREW	8
2	9914111	WASHER	2
3	9964347	LOCKING NUT	8
4	9906878	HEXAGON HEAD SCREW	3
5	9903861	WASHER	3
6	9821767	ANGLE COUPLING	1
7	9822615	L-COUPLING	1
8	9820469	COUPLING	1
9	1819135	HOLDERPLATE	1
10	1890719	OIL COOLER	1
11	9819789	ANGLE COUPLING	1
12	1890735	MOUNTING PLATE	1
13	9821848	ANGLE COUPLING	1
14	9904140	SPRING WASHER	6
15	1890751	SUPPORT	1
16	9861939	HP HOSE	2
17	9900420	HEXAGON HEAD SCREW	2
18	9904131	SPRING WASHER	2
19	9962484	WASHER	2


1890727 Oil cooler mounted - 1890727

Model:0880027
Chapter

Serial number: 0880027

1890786
1890786 (Storage) Box mounted

1890786 - 1890786 (Storage) Box mounted



Pos	Part No	Description	Quantity
1	1890794	BOX	1
2	9924205	HEXAGON HEAD SCREW	4
3	9904140	SPRING WASHER	4
4	1819453	RUBBER STRIP 10X3	1
5	9854649	COVERLOCK	1
6	9908242	WASHER	3
7	9988271	SCREW	3

1890786 (Storage) Box mounted - 1890786


Model:0880027
Chapter

Serial number: 0880027

1890875

1890875 Pipe kit base ext. 2F

1890875 - 1890875 Pipe kit base ext. 2F



Pos	Part No	Description	Quantity
1	9924159	HEXAGON HEAD BOLT	3
2	9924086	HEXAGON HEAD BOLT	1
3	9903861	WASHER	5
4	8912670	CLAMP	3
5	9965823	LOCKING NUT	4
6	1891316	HYDR.PIPE	1
7	1891324	HYDR.PIPE	1
8	9900438	HEXAGON HEAD SCREW	1
9	1891278	HYDR.PIPE	1
10	9819231	NIPPLE	2
11	9925228	HOSE CLAMP	1
12	1891294	HYDR.PIPE	1
13	1891260	HYDR.PIPE	1
14	9821368	COUPLING	2
15	1891286	HYDR.PIPE	1
16	9819223	COUPLING	2
17	9867996	SEQUENCE VALVE	2
18	4480201	NIPPLE 3/8	2
19	9988394	ANGLE COUPLING	1
20	9814507	COUPLING	1
21	9853227	CONTROL VALVE	1
22	9998438	COUPLING	4
23	9988092	COUPLING	1
24	1891308	HYDR.PIPE	1
25	1891251	HYDR.PIPE	1
26	1891243	HYDR.PIPE	1
27	1891227	HYDR.PIPE	1
28	1891235	HYDR.PIPE	1

1890875 Pipe kit base ext. 2F - 1890875

Model:0880027


Chapter

Serial number: 0880027

1890948

1890948 Column Box Compl.

1890948 - 1890948 Column Box Compl.



Pos	Part No	Description	Quantity
1	9903844	WASHER	4
2	9990631	SCREW	4
3	3805921	COLUMN BOX	1
4	9828061	CABLE SWIVEL NUT	1
5	9921290	O-RING	1
6	9827269	CONDUIT ENTRY	1
7	3724441	CABLE	1
8	3721370	PROTECTION HOSE ROUNI	1
9	3611043	CABLE	1
10	3610918	CABLE	1
11	3610926	CABLE	2
12	9827242	CONDUIT ENTRY	4
13	9921265	O-RING	4
14	9828010	CABLE SWIVEL NUT	4

1890948 Column Box Compl. - 1890948


Model:0880027
Chapter

Serial number: 0880027

1890956

1890956 Operating base extension

1890956 - 1890956 Operating base extension



189-0956A

Pos	Part No	Description	Quantity
1	9965823	LOCKING NUT	6
2	9903861	WASHER	6
3	9964347	LOCKING NUT	2
4	9924213	HEXAGON HEAD SCREW	2
5	9809945	HANDLE	2
6	9809856	CONTROL LEVER UNIT	2
7	3815358	SIGN	2
8	9924116	HEXAGON HEAD BOLT	6
9	1911007	PLATE	1
10	9952217	PIN	2
11	3010767	BOLT	4
12	1891456	PLATE	2
13	9949305	RETAINING RING	4
14	9810005	SECURING PLATE	2
15	9840460	CONTROL CABLE	2
16	1878646	PLATE	1
17	1911015	PLATE	1
18	9914111	WASHER	1
19	9924205	HEXAGON HEAD SCREW	1
20	9904140	SPRING WASHER	2
21	9924051	HEXAGON HEAD SCREW	2
22	1891359	PLATE	1

1890956 Operating base extension - 1890956


Model:0880027
Chapter

Serial number: 0880027

1890999

1890999 Pipe kit base 2300 (Page 1/2)

1890999 - 1890999 Pipe kit base 2300 (Page 1/2)



189-0999
Page 1/2

Page 2/2

Pos	Part No	Description	Quantity
1	9924086	HEXAGON HEAD BOLT	1
2	9903861	WASHER	9
3	8912670	CLAMP	5
4	9900438	HEXAGON HEAD SCREW	3
5	1891189	HOSE CHANNEL	1
6	9904131	SPRING WASHER	1
7	8932646	SCREW	2
8	9965823	LOCKING NUT	2
9	9875417	HP HOSE	4
10	1866591	LOCKING PLATE	1
11	9924078	HEXAGON HEAD BOLT	5
12	3197336	CLAMP	10
13	9819291	ANGLE COUPLING	2


1890999 Pipe kit base 2300 (Page 1/2) - 1890999

Model:0880027
Chapter

Serial number: 0880027

1891057
1891057 Mounting kit SPACE 4000

1891057 - 1891057 Mounting kit SPACE 4000



Pos	Part No	Description	Quantity
1	9984461	SCREW	3
2	9904115	SPRING WASHER	15
3	9907939	HEXAGON HEAD SCREW	12
4	9908242	WASHER	2
5	9801189	SCREW	2
6	9879561	SCREW	12

1891057 Mounting kit SPACE 4000 - 1891057


Model:0880027
Chapter

Serial number: 0880027

1891073
1891073 Parking support

1891073 - 1891073 Parking support

Pos	Part No	Description	Quantity
1	1890913	SUPPORT	1
2	4482301	SELF LOCKING HEX.BOLT 1	4



1891073 Parking support - 1891073

Model:0880027

Chapter



Serial number: 0880027

1891138

1891138 Frame connection

1891138 - 1891138 Frame connection

Tightening torque:
M30 bolts 1600 Nm
M27 bolts 1170 Nm



189-1138@1

Pos	Part No	Description	Quantity
1	9824481	LOCKING NUT	4
2	1855972	SQUARE WASHER	2
3	1891448	STUD BOLT M27 LG.550	2
4	9967931	LOCKING NUT	4
5	1855981	SQUARE WASHER	2
6	1890271	STUD BOLT M30 LG.580	2
7	1891472	SQUARE WASHER	2
8	1891430	SQUARE WASHER	2

1891138 Frame connection - 1891138


Model:0880027
Chapter

Serial number: 0880027

1891146
1891146 Hook storage

1891146 - 1891146 Hook storage

Pos	Part No	Description	Quantity
1	1804260	HOOKSUPPORT MOUNTED	1
2	3661865	LOAD HOOK	1
3	8567051	CLAMP	2
4	8182906	STEEL CABLE	1
5	1825658	SPRING COTTER RD.6.5	1
6	9915150	LOCKING PIN	1



1891146 Hook storage - 1891146


Model:0880027
Chapter

Serial number: 0880027

1891367
1891367 Sign kit 088 ATD-1

1891367 - 1891367 Sign kit 088 ATD-1

Pos	Part No	Description	Quantity
1	3455653	WARNING SIGN	2
2	1891065	STAB CONTROL SIGN	2
3	1890158	CAPACITY SIGN	1
4	9902813	RIVIT	4
5	8139041	MANUFACTURING SIGN	0
6	1890166	CAPACITY DIAGRAM	2
7	1890298	WARNING SIGN	1
8	1898001	CONTROL SIGN	1





1891367 Sign kit 088 ATD-1 - 1891367

Model:0880027
Chapter

Serial number: 0880027

1891405
1891405 Hydraulic Interface

1891405 - 1891405 Hydraulic Interface



Pos	Part No	Description	Quantity
1	1891502	HP.HOSE 1/2"X1240	1
2	1891537	HP.HOSE	1
3	1891545	HP.HOSE	1
4	9878475	TUBE END REDUCER	1

1891405 Hydraulic Interface - 1891405


Model:0880027
Chapter

Serial number: 0880027

1891464
1891464 2nd boom cpl.

1891464 - 1891464 2nd boom cpl.

Pos	Part No	Description	Quantity
1	9866183	BUSHING 75X70 LG.50	2
2	1891821	SPACING TUBE	1
3	1892916	2ND BOOM WELDED	1
4	9945768	GREASE NIPPLE	2



1891464 2nd boom cpl. - 1891464


Model:0880027
Chapter

Serial number: 0880027

1891642
1891642 Column cpl.

1891642 - 1891642 Column cpl.

Pos	Part No	Description	Quantity
1	1891651	COLUMN MACHINED	1
2	1891821	SPACING TUBE	1
3	9866183	BUSHING 75X70 LG.50	2
4	9945768	GREASE NIPPLE	1



1891642 Column cpl. - 1891642


Model:0880027
Chapter

Serial number: 0880027

1891839
1891839 1st boom cpl.

1891839 - 1891839 1st boom cpl.

Pos	Part No	Description	Quantity
1	1891847	FIRST BOOM MACHINED	1
2	1891936	SPACING TUBE	1
3	9866183	BUSHING 75X70 LG.50	2
4	9945768	GREASE NIPPLE	1



189-1839

1891839 1st boom cpl. - 1891839

Model:0880027
Chapter


Serial number: 0880027

1892002

1892002 1st boom cylinder mounting

1892002 - 1892002 1st boom cylinder mounting

Pos	Part No	Description	Quantity
1	1824554	SHAFT	1
2	1824546	LOCKINGPLATE	1
3	4482301	SELF LOCKING HEX.BOLT 1	1



189-2002

1892002 1st boom cylinder mounting - 1892002

Model:0880027
Chapter


Serial number: 0880027

1892011

1892011 1st boom/cylinder mounting

1892011 - 1892011 1st boom/cylinder mounting

Pos	Part No	Description	Quantity
1	9978119	LOCKING NUT	1
2	1891952	SHAFT	1
3	1824546	LOCKINGPLATE	2
4	4482301	SELF LOCKING HEX.BOLT	2
5	4964896	SCREW M10X25 ZELFB	1
6	1891979	SHAFT	1



1892011 1st boom/cylinder mounting - 1892011

Model:0880027
Chapter


Serial number: 0880027

1892029

1892029 2nd boom cylinder mounting

1892029 - 1892029 2nd boom cylinder mounting

Pos	Part No	Description	Quantity
1	1891979	SHAFT	1
2	1824546	LOCKINGPLATE	3
3	4482301	SELF LOCKING HEX.BOLT 1	5
4	9978119	LOCKING NUT	2
5	1891995	SHAFT	2
6	1892053	LINK GUIDE	2
7	1892037	LINK COMPLETE	2



1892029 2nd boom cylinder mounting - 1892029


Model:0880027
Chapter

Serial number: 0880027

1892061
1892061 2nd boom mounting

1892061 - 1892061 2nd boom mounting

Pos	Part No	Description	Quantity
1	1891987	SHAFT	1
2	1892347	LOCKING PLATE	1
3	4482301	SELF LOCKING HEX.BOLT M	4
4	9978119	LOCKING NUT	1
5	1891961	SHAFT	1
6	1824546	LOCKINGPLATE	1
7	9909176	REATAINING RING	1



189-2061


1892061 2nd boom mounting - 1892061

Model:0880027
Chapter

Serial number: 0880027

1892355
1892355 1st boom cylinder

1892355 - 1892355 1st boom cylinder



Pos	Part No	Description	Quantity
1	9858768	OVER CENTRE VALVE	1
2	9922369	CH. SCREW	4
3	9819223	COUPLING	4
4	9822151	COUPLING	1
5	9939342	GS-WASHER	2
6	9857826	PRESSURE SENSOR	2
7	9998438	STRAIGHT NIPPLE	1
8	1892363	HYDR.PIPE	1
9	1890301	FIRST BOOM CYLINDER	1
10	1860721	CONNECTION VALVE	1
11	9993746	PLUG	1

1892355 1st boom cylinder - 1892355


Model:0880027
Chapter

Serial number: 0880027

1892401
1892401 Pipe kit 1st boom

1892401 - 1892401 Pipe kit 1st boom

Pos	Part No	Description	Quantity
1	9924108	HEXAGON HEAD BOLT	1
2	9965823	LOCKING NUT	1
3	9924086	HEXAGON HEAD BOLT	1
4	9903861	WASHER	2
5	8912670	CLAMP	4
6	1892410	HYDR.PIPE	1
7	1892428	HYDR.PIPE	1




1892401 Pipe kit 1st boom - 1892401

Model:0880027
Chapter

Serial number: 0880027

1892436
1892436 2nd boom cylinder

1892436 - 1892436 2nd boom cylinder



Pos	Part No	Description	Quantity
1	1890328	SECONDBOOM CYL. 125/90	1
2	9925252	HOSE CLAMP	2
3	1892517	SUPPORT	1
4	9903861	WASHER	4
5	3922871	LOAD HOLDING VALVE	1
6	9819291	ANGLE COUPLING	1
7	9821821	ANGLE COUPLING	1
8	1892461	HYDR.PIPE	1
9	9924086	BOLT	2
10	9939342	SEALING WASHER	1
11	9819223	COUPLING	4
12	9857826	SENSOR	1
13	1892452	HYDR.PIPE	1
14	9998438	COUPLING	1


1892436 2nd boom cylinder - 1892436

Model:0880027
Chapter

Serial number: 0880027

1892487
1892487 Pipe kit extension 1

1892487 - 1892487 Pipe kit extension 1



Pos	Part No	Description	Quantity
1	9819975	ANGLE COUPLING	1
2	9819291	ANGLE COUPLING	5
3	1892495	HYDR.PIPE	1
4	8163014	PLATE	1
5	9908242	WASHER	2
6	9853791	LOAD HOLDING VALVE	1
7	9904107	SPRING WASHER	2
8	9923781	HEXAGON HEAD BOLT	2
9	1892576	HYDR.PIPE	1
10	9819223	COUPLING	1
11	9917799	HOSE CLAMP	4
12	3506495	SUPPORT	2
13	9820710	HP-HOSE	1
14	9838741	HP-HOSE	1
15	9924078	HEXAGON HEAD BOLT	1
16	9903861	WASHER	1
17	3197336	CLAMP	2

1892487 Pipe kit extension 1 - 1892487


Model:0880027
Chapter

Serial number: 0880027

1892584

1892584 Extension boom 1.2

1892584 - 1892584 Extension boom 1.2



Pos	Part No	Description	Quantity
1	1892606	EXTENSION ARM HOOK	1
2	9922521	SCREW	4
3	4962877	LOCKING PLATE	1
4	9964347	LOCKING NUT	4
5	9922571	SCREW	4
6	9836012	WASHER	4
7	3661679	WASHER	4
8	1890336	EXTENSION CYLINDER	1
9	9984941	SCREW	2
10	8424942	WASHER	2
11	8189137	SLIDE PAD	1
12	9965823	LOCKING NUT	2
13	8161691	SLIDE PAD	1
14	3634698	STOP	2
15	9973371	SCREW	6
16	1827651	SLIDE PAD	1


1892584 Extension boom 1.2 - 1892584

Model:0880027
Chapter

Serial number: 0880027

1892886
1892886 Hose kit

1892886 - 1892886 Hose kit




Pos	Part No	Description	Quantity
1	1892902	COVER MACHINED	1
2	1892339	MOUNTING PLATE	1
3	9924078	HEXAGON HEAD BOLT	2
4	1835467	CLAMPPROFILE 6-8 MM	1
5	9990631	SCREW	4
6	9858989	WASHER	4
7	9903861	WASHER	5
8	3628116	PIPE	1
9	9872264	HP HOSE	2
10	9873091	HP HOSE	2
11	3197336	CLAMP	10
12	9924167	HEXAGON HEAD BOLT	1
13	9904131	SPRING WASHER	2
14	9906878	HEXAGON HEAD SCREW	3
15	4971604	BRACE	1
16	9924086	HEXAGON HEAD BOLT	1
17	9875476	HP HOSE	2
18	9973371	SCREW	2
19	9965823	LOCKING NUT	2
20	1885979	CLAMPPROFILE	1

1892886 Hose kit - 1892886

Serial number: 0880027

3822851
3822851 XS-drive (Mil)

3822851 - 3822851 XS-drive (Mil)



Note:
Do not forget to order a (customized)
control sign if you order a new controller.

382-2851

Pos	Part No	Description	Quantity
1	3818021	XS-DRIVE CONTROLLER	1
2	3818039	XS-DRIVE RECEIVER	1
3	3822869	DUMMY BATTERY	1
4	3787117	NECK-BELT	1
5	3787125	WAIST-BELT	1
6	3700038	CONNECTOR	1
7	3818047	CABLE	1

3822851XS-drive (Mil) - 3822851


Model:0880027
Chapter

Serial number: 0880027

3952533
3952533 V80R control valve

3952533 - 3952533 V80R control valve

Pos	Part No	Description	Quantity
1	3952533	V80R 6F CONTROL VALVE	1



3952533 V80R control valve - 3952533

Model:0880027
Chapter


Serial number: 0880027

6001327

6001327 Shims for slide pads in boom systems


6001327 - 6001327 Shims for slide pads in boom systems

Pos	Part No	Description	Quantity
1	4913426	SHIM	1
2	4913418	SHIM	1
3	8163031	SHIM	1
4	8163022	SHIM	1
5	1921550	SHIM	1




Note:


The amount of shims and the type of shims used on a boom depends the boom system; therefore select type and amount yourself.



600-1327



Mounting example



6001327 Shims for slide pads in boom systems - 6001327