

16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
L															L
K															K
J															J
I															I
H															H
G															G
F															F
E															E
D															D
C															C
B															B
A															A

GENERAL NOTES:

1) USE ON T600 'B5' EXTENDED DAY CAB MODELS TO INSTALL ROOF FAIRING AND /OR SIDE EXTENDERS.

2) INNSTALL BEFORE CAB PAINT UNLESS OTHERWISE SPECIFIED.

3) FASTENER QUANTITIES SHOWN ARE FOR BOTH SIDES.

4) DRILL HOLES THRU FAIRING AND/OR ROOF ON ASSEMBLY. HOLES IN CAB ROOF ARE MEASURED TO TOP SURFACE OF CAB ROOF. DRILL NORMAL TO SURFACE. BRACKETS MAY BE LOCATED AND USED AS DRILL TEMPLATES.

5) TO BE INSTALLED AFTER PAINT

FOR SERVICE PARTS OR INVENTORY BALANCE ONLY

SUPERSEDED BY NONE

PROO	X
SERV	

		CORNER WINDOWS													
		SIDE OF CAB MTD EXHAUST													
		FLUSH MTD FLD LIGHTS - HIGH MTD													
		GRAB HNDL - FULL LENGTH, BOC													
		ROOF MTD MARKER LIGHTS													
		ROOF MTD AIR HORNS													
		CNTR MTD AM / FM RADIO ANT.													
		CNTR MTD 2-WAY RADIO ANT.													
		ROOF MTD BEACON LIGHTS													
		W/ SIDE EXTENDERS ONLY													
		W/ SIDE EXTENDERS AND ROOF FAIRING (W/O QUALCOMM ANTENNA MTD ON AIRSHIELD)													
		W/ SIDE TRIM TABS (BRACKETS ONLY)													
		W/ SIDE TRIM TABS (FACTORY INSTALLED / PAINTED)													
		W/ SIDE TRIM TABS (FACTORY INSTALLED / PAINTED)													
		W/ SIDE EXTENDERS AND ROOF FAIRING (W/O QUALCOMM ANTENNA MTD ON AIRSHIELD)													
		W/ SIDE TRIM TABS (FACTORY INSTALLED / PAINTED)													
		STANDARD WIDTH RUBBER EXTENDERS													
		WIDE WIDTH RUBBER EXTENDERS													
R97-1172-1	N	N	Y	N	Y	Y	Y	Y	Y	Y					
R97-1172-2	N	N	N	N	N	N	N	N	N	N	Y	N	N	Y	N
R97-1172-3	N	N	N	N	N	N	N	N	N	N	N	Y	N	Y	N
R97-1172-4	N	N	N	N	N	N	N	N	N	N	N	Y	Y	Y	N
R97-1172-5	N	N	Y	N	Y	Y	Y	Y	Y	Y	N	N	N	N	Y
R97-1172-6	N	N	N	N	N	N	N	N	N	N	Y	N	N	N	Y
R97-1172-7	N	N	N	N	N	N	N	N	N	N	N	Y	N	N	Y
R97-1172-8	N	N	N	N	N	N	N	N	N	N	N	Y	N	N	Y

R97-1172-8	2	2	2	2	-	-	-	-	30	R33-1056-1673	EXTRUSION - DEFLECTOR
R97-1172-7	1	-	-	-	1	-	-	-	29	R33-1054-002	FAIRING KIT - ROOF
R97-1172-6	18	18	18	18	18	18	18	18	28	W01-10-02P55L020N	SCRW - PSD, PAN HD, SST, M5
R97-1172-5	28	28	28	28	28	28	28	28	27	W01-10-02C55L016N	SCRW - PSD, PAN, SST, W / W, M5
R97-1172-4	12	12	12	12	12	12	12	12	26	W01-10-01P57L012Z	SCREW - PSD, PAN HD M6
R97-1172-3	18	1	18	1	18	18	18	18	25	W01-10-01C55L016Z	SCREW - PSD, PAN W / W, M
R97-1172-2	AR	AR	AR	AR	AR	AR	AR	AR	24	V762-1	PVC TAPE - 1 / 16" X 1"
R97-1172-1	32	32	32	32	32	32	32	32	23	K363-340-2-190	WASHER - FLAT, SST
	6	6	6	-	6	6	6	-	22	K363-338-3-250	WASHER - FLAT, STL, M6
	12	12	12	12	12	12	12	12	21	K363-338-2-375	WASHER - FLAT, STL, M10
	12	12	12	12	12	12	12	12	20	K363-338-1-250	WASHER - FLAT, STL, M6
	4	4	4	4	4	4	4	4	19	K363-475	WASHER - NYLON, 190D, 6.3ID
	-	-	-	4	-	-	-	4	18	K221-4172	SPACER - CAB EXTENDER
	6	6	6	-	6	6	6	-	17	K220-520	COLLAR - STEEL, 1 / 4"
	2	2	2	2	2	2	2	2	16	K196-1123	RETAINER - DEFLECTOR
	2	2	2	2	2	2	2	2	15	K169-202-5-50	NUT - SELF RTNG, STL, M5
	14	14	14	14	14	14	14	14	14	K169-201-5	NUT - HEX, SST, M5
	6	6	6	6	6	6	6	6	13	K169-173-10-130	NUT - SELF RTNG, STL, M10
	-	-	-	-	2	2	2	2	12	K126-450-1673	EXTRUSION - DEFLECTOR
	12	12	12	12	12	12	12	12	11	K041-830-40CA	BOLT - HEX HD, LKNG, STL, M10
	6	6	6	-	6	6	6	-	10	K041-75L2N	BOLT - SWGD, STL, 1 / 4"
	2	2	2	2	2	2	2	2	9	R11-1222	BRACKET - SPACER, SIDE EXTENDER
	1	1	1	-	1	1	1	-	8	R11-1212	BRACKET KIT - FAIRING
	-	-	-	2	-	-	-	2	7	R42-1059	SEAL - FAIRING BRKT
	1	1	-	-	1	1	-	-	6	R33-1046	FAIRING KIT - SIDE EXTENDERS
	-	1	-	-	-	1	-	-	5	R33-1054-001	FAIRING KIT - ROOF
	1	1	1	1	1	1	1	1	4	R33-1044R	FAIRING - TRANSITION, SIDE EXT.
	1	1	1	1	1	1	1	1	3	R33-1044	FAIRING - TRANSITION, SIDE EXT.
	1	1	1	1	1	1	1	1	2	R33-1055-002R	FAIRING - SIDE EXTENDER ASSY
	1	1	1	1	1	1	1	1	1	R33-1055-002	FAIRING - SIDE EXTENDER ASSY

16

15

14

13

12

11

10

9

8

7

6

5

4

3

2

1

A

DWG

SIZE

A0





