



Basic codes

Basic code	Description	Location on vehicle	Location in diagram	Variants
B131	Solenoid valve, pump unit, cyl. 1	-	8K	
B132	Solenoid valve, pump unit, cyl. 2	-	9K	
B133	Solenoid valve, pump unit, cyl. 3	-	10K	
B134	Solenoid valve, pump unit, cyl. 4	-	10K	
B135	Solenoid valve, pump unit, cyl. 5	-	11K	
B136	Solenoid valve, pump unit, cyl. 6	-	12K	
B411	MX Engine Brake solenoid valve cylinder 1	-	4J	
B412	MX Engine Brake solenoid valve cylinder 2	-	4K	
B413	MX Engine Brake solenoid valve cylinder 3	-	4K	
B414	MX Engine Brake solenoid valve cylinder 4	-	7J	
B415	MX Engine Brake solenoid valve cylinder 5	-	7K	
B416	MX Engine Brake solenoid valve cylinder 6	-	7K	
B421	Injector solenoid valve cylinder 1 1	-	2J	
B422	Injector solenoid valve cylinder 1 2	-	2K	
B423	Injector solenoid valve cylinder 1 3	-	2K	
B424	Injector solenoid valve cylinder 1 4	-	6J	
B425	Injector solenoid valve cylinder 1 5	-	6K	
B426	Injector solenoid valve cylinder 1 6	-	6K	
B460	Connector cylinders 1-3	-	1J	
B461	Connector cylinders 4-6	-	5J	
D365	ECU, PMCI-2	-	1E	
F552	Crankshaft sensor	-	5B	
F558	Camshaft sensor	-	6B	
F801	Fuel pressure sensor	-	2B	
F802	Boost pressure sensor	-	3B	
F803	Fuel temperature sensor	-	7B	
F804	Boost temperature sensor	-	8B	





Basic codes

Basic code	Description	Location on vehicle	Location in diagram	Variants
A141	Connector, application power	-	4K	
A142	Connector, application signal	-	12K	
B335	Electronic controlled fan clutch	-	7K	
D365	ECU, PMCI-2	-	6E	
F566	Coolant temperature sensor	-	9B	
F683	Turbo speed sensor	-	11B	
F749	EGR temperature sensor	-	7B	
F750	Intercooler temperature sensor	-	8B	
F751	sensor, EGR pressure difference	-	6B	
F772	Sensor, coolant level low	-	10B	
F805	Coolant pump speed sensor	-	8K	
F808	Oil temperature sensor	-	12B	
F810	Oil pressure sensor	-	9B	
MX_EPA10				
F811	Sensor, position BPV	-	11K	Not MX-EPA04
MX_EPA10				
F823	Sensor, pressure after back pressure valve	-	5B	Not MX-EPA04
F826	Pressure sensor before turbine	-	4B	
MX_EPA10				
F834	Lambda sensor	-	10K	Not MX-EPA04
F852	sensor, humidity	-	1J	
MX_EPA10				
F853	Temperature sensor after BPV	-	13B	Not MX-EPA04
MX_EPA10				
L020	Actuator, BPV	-	6K	Not MX-EPA04
L033	Valve sensor, EGR	-	8K	
L037	actuator, rotary speed	-	2K	
L073	Dosing module, fuel	-	5I	



This information applies exclusively to the entered chassis number or the selected engine type. Please take into account that this information may change daily. Therefore the provided information is only valid on 12-12-2015. You cannot derive any rights from the information provided with respect to vehicles and/or components of another series, with another chassis number, and/or of another date. (/)