

Sensor, DEF temperature/level (F851)

The DEF temperature/level sensor is located in the DEF tank and measures the DEF level and the DEF temperature inside the tank.



Refer to the OEM service manual for more information.

Effect of the output signal on the system:

- Activation of the tank heater valve

Effect of the output signal on the system:

- Also see the control function 'Driver warnings and inducements'
- Refer to the OEM service manual for more information.

M027015 - 02.23.2010

This information applies exclusively to the entered chassis number or the selected engine type. Please take into account that this information may change daily. Therefore the provided information is only valid on 12-16-2015. You cannot derive any rights from the information provided with respect to vehicles and/or components of another series, with another chassis number, and/or of another date. (/)