

P0513

Fault code description

Immobiliser communication failure - Not released between immobiliser ECU and the engine management system

Possible cause

1. Key without transponder used
2. Key with wrong transponder used
3. Damaged transponder
4. Damaged immobiliser

Additional information

-

Set condition of fault code

-

Reset condition of fault code

-

M028204 - 07/22/2015 17:07:17

This information applies exclusively to the entered chassis number or the selected engine type. Please take into account that this information may change daily. Therefore the provided information is only valid on 12-13-2015. You cannot derive any rights from the information provided with respect to vehicles and/or components of another series, with another chassis number, and/or of another date. (/)

P0513, Diagnostic information

Technical data

Refer to the OEM service manual for more information.

Location of component(s)

Refer to the OEM service manual for more information.

Electrical diagram(s)

["PMCI-2"](#)

Description of component(s)

Refer to the OEM service manual for more information.

Block diagram

["PMCI-2"](#)

M046372 - 07/22/2015 16:07:37

This information applies exclusively to the entered chassis number or the selected engine type. Please take into account that this information may change daily. Therefore the provided information is only valid on 12-13-2015. You cannot derive any rights from the information provided with respect to vehicles and/or components of another series, with another chassis number, and/or of another date. (/)