

P1526

Fault code description

CAN communication - Message (CM1) data error, Requested Percent Fan Speed from vehicle control system

Possible cause

1. Check cabin ECU for faults

Additional information

-

Set condition of fault code

-

Reset condition of fault code

-

M028614 - 07/22/2015 18:12:37

This information applies exclusively to the entered chassis number or the selected engine type. Please take into account that this information may change daily. Therefore the provided information is only valid on 12-13-2015. You cannot derive any rights from the information provided with respect to vehicles and/or components of another series, with another chassis number, and/or of another date. (/)

P1526, Diagnostic information

Technical data

Refer to the OEM service manual for more information.

Location of component(s)

Refer to the OEM service manual for more information.

Electrical diagram(s)

["PMCI-2"](#)

Description of component(s)

Refer to the OEM service manual for more information.

Block diagram

["PMCI-2"](#)

Step by step troubleshooting



Please perform the troubleshooting steps below by utilising the breakout harness if necessary to check electrical components such as sensors, electronic control units or harnesses. Back probing is not recommended as it could damage the harness. The ignition should always be in the **OFF** position when connecting or disconnecting electrical components to reduce the likelihood of damage to electrical components.



- This troubleshooting tree is based on the assumption that supply power and earth to the PMCI are functioning properly.
- Disconnecting the PMCI connectors during the troubleshooting process will result in multiple errors.
- For specific electrical component information and pin out locations, always refer to the technical data in Rapido.

- It is necessary to exit the 'active errors' screen in DAVIE and run the diagnostic test again to identify a change in errors.
- Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive codes. Refer to the 'possible causes' section in Rapido.

Step 1: Check for fault codes

Troubleshooting steps

1. Turn the key switch ON.
2. Use DAVIE to check whether the fault code is present as an active or inactive fault code.

Is this fault code present as an active or inactive fault code?

- Yes – Proceed to step 2.
- No – Proceed to any other fault codes present.

Step 2: Make sure the software is up to date

Troubleshooting steps

1. Make sure the software is up to date.

Is this software up to date?

- Yes – Proceed to step 3.
- No – Update the software. Proceed to step 3.

Step 3: Check connectors at electronic control units

Troubleshooting steps

1. Inspect the connectors at the electronic control units (check for loose/damaged pins/terminals/seals in connector), and check for any broken/damaged wiring to the electronic control units.

2. Check the pin and terminal integrity on system components (electronic control units, sensors and harness).
3. Check for corroded/damaged pins and spread terminals.
4. Check for damaged connector shell, loose connector, missing seal, and moisture in connector.

Was an issue found?

- **Yes** – Resolve issue found. Proceed to step 8.
- **No** – Proceed to step 4.

Step 4: Pin out and check for damage

Troubleshooting steps

1. Visual inspection of harness for severe pinching, crushing or any other potential damage.
2. Check the following resistances:
 - Disconnect the PMCI ECU and CECU and verify that the resistance is 120 Ω ($\pm 12 \Omega$).
 - Check for 60 Ω ($\pm 6 \Omega$) for all branches off the VCAN.

Does the electrical system pass all these tests?

- **Yes** – Proceed to step 5.
- **No** – Resolve the electrical issues. Proceed to step 8.

Step 5: Isolate each component

Troubleshooting steps

1. Turn the key switch OFF
2. Disconnect the PMCI ECU.
3. Turn the key switch ON.
4. Check with DAVIE to see if the fault code becomes inactive.

5. Reconnect the PMCI.
6. Repeat this step for all other components on the CAN bus.

Has the fault code become inactive while any of the components were isolated?

- **Yes** – Solve the fault code for this component. Proceed to step 8.
- **No** – Proceed to step 6.

Step 6: Check the CECU

Troubleshooting steps

1. Check to see if the CECU fuses are blown.
2. Check to see if there is power at the CECU.
3. Check to see if the CECU connectors are in good working order.
4. Connect to the CECU using ESA and make sure that the software is up to date.
5. Using ESA go the program page and make sure that the engine fan override is enabled
6. 6. Using ESA go to the monitor page and make sure that the engine fan override switch is being read by the CECU correctly

Is the CECU and engine fan override are working correctly?

- **Yes** – Proceed to step 7.
- **No** – Resolve any issues and proceed to step 7. If issues cannot be resolved, contact the Engine Support Center.

Step 7: Perform wiggle test if issue is intermittent

Troubleshooting steps

1. If the issue is intermittent, perform a wiggle test on the aftertreatment harness

and all connectors to recreate the fault code.

Does the wiggle test result in fault codes or intermittent connection to any electronic control units?

- Yes – Proceed to step 8.
- No – Proceed to step 8.

Step 8: Verify all campaigns have been performed

Troubleshooting steps

1. Verify that all campaigns have been performed on the truck.

Have all campaigns been performed?

- Yes – Proceed to step 9.
- No – Perform campaigns. Proceed to step 9.

Step by step 9: Check to see if the fault has been resolved

Troubleshooting steps

1. Warm the truck to operating temperature.
2. Use DAVIE to see whether the fault code has been resolved.

Has the fault code been resolved?

- Yes – Release the truck.
- No – Contact the Engine Support Center for further assistance.

M046525 - 07/22/2015 15:13:45

This information applies exclusively to the entered chassis number or the selected engine type. Please take into account that this information may change daily. Therefore the provided information is only valid on 12-13-2015. You cannot derive any rights from the information provided with respect to vehicles and/or components of another series, with another chassis number, and/or of another date. (/)