

## P3985

### Fault code description

Pump module - Unable to prime

### Possible cause

1. -

### Additional information

This fault code is not used and therefore will not be set.

### Set condition of fault code

-

### Reset condition of fault code

-

M029233 - 07/22/2015 16:15:27

This information applies exclusively to the entered chassis number or the selected engine type. Please take into account that this information may change daily. Therefore the provided information is only valid on 12-19-2015. You cannot derive any rights from the information provided with respect to vehicles and/or components of another series, with another chassis number, and/or of another date. ( / )

## P3985, Diagnostic information

### Technical data

-

### Location of component(s)

["Location information, EAS-3"](#)

### Electrical diagram(s)

Refer to the OEM service manual for more information.

### Description of component(s)

-

### Block diagram

["Block diagram EAS-3"](#)

M046932 - 07/22/2015 16:13:31

This information applies exclusively to the entered chassis number or the selected engine type. Please take into account that this information may change daily. Therefore the provided information is only valid on 12-19-2015. You cannot derive any rights from the information provided with respect to vehicles and/or components of another series, with another chassis number, and/or of another date. ( / )