


Valve, Tank Heater (L076)



A	Electronic unit connection point				
B	Description of connection point				
C	Reading at connection point (Ubat = battery voltage)				
D	Measuring unit				
E	Explanatory notes (if applicable)				
F	The 'X' indicates that additional information is available in 'Technical Data.'				
A	B	C	D	E	F
A08	Supply, tank heater valve	Ubat	VDC		
A85	Signal, tank heater valve		%	Ground-controlled duty cycle	X

Defrost heating

On
Off
Duty cycle

tank temperature below 23°F (-5°C)
tank temperature above 32°F (0°C)
98%

Maintenance heating

On
Off
Duty cycle

tank temperature below 32°F (0°C)
tank temperature above 41°F (5°C)
98%

Refer to the OEM service manual for more



information.

M026992 - 08.12.2010

This information applies exclusively to the entered chassis number or the selected engine type. Please take into account that this information may change daily. Therefore the provided information is only valid on 12-16-2015. You cannot derive any rights from the information provided with respect to vehicles and/or components of another series, with another chassis number, and/or of another date. (/)