CORRECTOR 2.6.2

Lesson 2.4.3

What happens when one of these indicators remains on?

ANSWER CHOICES: Only one correct answer X
Several possible answers

A) Parking brakes will apply in a certain time to avoid a break on the braking systems

B) The ABS brake system has a failure. The service brakes still work but without ABS.

C) The ABS brake system is functional.

D) ABS brake systems have a failure and there is no more braking possible

Refer to: Lesson 2.4.3 Student Notebook.




QUESTION 2: Identify all gauges showing an anomaly 10 15 km/h ANSWER CHOICE: Only one answer possible Several possible answers X A) The primary air gauge X B) The secondary air gauge X C) The brake application gauge X D) The battery voltage gauge Refer to: Lesson 2.4.2 Student notebook.



QUESTION 3:

Which of these gauges indicate the minimum efficiency of the compressor?




ANSWER CHOICE: Only one possible answer **X**Several possible answers

A) The gauge indicating 90 psi	X
B) The gauge indicating 120 psi	
C) The gauge indicating 80 psi	
D) The gauge indicating 70 psi	

Feedback if wrong answer: Air gauges should never drop below the compressor efficiency of 90 psi. Lesson 2.4.1 from the student's workbook.

QUESTION 4:

Which gauge indicates the minimum starting pressure of the compressor?



ANSWER CHOICE: Only one possible answer X
Several possible answers

A) The gauge indicating 90 psi


B) The gauge indicating 120 psi

C) The gauge indicating 70 psi

D) The indicating 80 psi

Feedback if wrong answer: The compressor must start at a minimum of 80 psi Ref: Lesson 2.4.1 of the student's workbook.

QUESTION 5: This is an illustration of a dual brake receiver. Associate each letter in the diagram with the parts named below.



Parts Answers (letter) 1 Spring brake cylinder A 2 Slack adjuster B 3 Returning springs E 4 Push rod C 5 Diaphragm D

Feedback if wrong answer: Lesson 2.4.2 Student notebook. Lesson 2.4.3




QUESTION 6:

What would be the best way to save your brakes in a steep do	wnhill?
ANSWER CHOICE: Only one possible answer X Several possible answers	
A) Anticipate and slow down	
B) Anticipate, slow down and use the engine brake	
C) Anticipate, slow down, downshift and use the engine brake	x
D) Slow down and use the engine brake	
Refer to if wrong answer: Lesson 2.4.3 Student workbook.	



QUESTION: 7

Of the following actions below, which one will allow air to move into the brake booster chamber and compress the parking brake spring.



ANSWER CHOICE: Only one possible answer X
Several possible answers

A) By pulling this command

B) By pressing the brake pedal

C) By pushing this command

X

D) None of these answers

Refer to if wrong answer: Lesson 2.4.2 Student notebook.



QUESTION: 8 Which of the following statements apply to the illustration above	ve?
ANSWER CHOICE: Only one answer possible Several possible answers X	
A) The service brake is applied	X
B) The parking brake is applied	
C) The parking brake is released	X
D) The service brake is released	
Refer to if wrong answer: Lesson 2.4.2 Student notebook.	



QUESTION: 9	
Emergency brakes apply when the air pressure (PSI) in the pneumatic system is no longer sufficient to compress the parking spring	
TRUE	Х
FALSE	
. Refer to if wrong answer: Lesson 2.4.2 Student notebook.	



Lesson 2.4.2 QUESTION 10








A B C


Associate illustrations A, B and C above with the following images of dual brake receivers:



<u>C</u>



A



A AND B

Answers: Corresponding letters: C; A; A et B
Refer to if wrong answer: Lesson 2.4.2 Student workbook



\cap	IEST	\cup	J٠	1	1	

The following pictograms and warning lights are all connected to the air brake system.







TRUE	X
FALSE	
Refer to if wrong answer: Lesson 2.4.2 Student workbook.	

Lesson: 2.4.2

QUESTION: 12



Which one of the following statements applies to the illustration above?

ANSWER CHOICE: Only one possible answer **X**Several possible answers

A) 30 PSI (psi) is applied by the service brake.	X
B) 30 PSI (psi) is the volume of air available in the supply tank	
C) 30 PSI (psi) is the volume of air in the suspension	
D) None of these answers.	
Refer to if wrong answer: Lesson 2.4.2 Student workbook.	



QUESTION: 13		
What are the proper procedures when approaching a traffic light in an urban environment?		
ANSWER CHOICE: Only one answer possible Several possible answers X		
A) Accelerate to try to pass on the green light to avoid making a stop and use fuel when the vehicle is restarted.		
B) Anticipate traffic and if the light turns green, try not to stop the vehicle.	X	
C) Anticipate traffic lights to avoid unnecessary stops	X	
D) Use the engine brake as much as possible.		
Refer to if wrong answer: Lesson 2.4.3 Student Notebook.		

Lesson : 2.4.3

QUESTION: 14	
What must you do to check the effectiveness of the electric braking system of a trailer?	
ANSWER CHOICE: Only one possible answer X Several possible answers	
A) Put the vehicle in motion and the vehicle does not stop.	
B) Move the vehicle and brake. The vehicle comes to a stop quickly.	Х
C) Look at the trailer lights.	
D) Disconnect the electrical cable and listen for the leak.	
Refer to if wrong answer: DHV page 414.	



QUESTION: 15	
It's major defect if, the brake pedal descends to the floor in less than 10 seconds during the hydraulic brake system test.	
True	X
False	
Refer to if wrong answer: Page 417 DHV	

Lesson: 2.4.1

QUESTION: 16	
The air compressor efficiency test consist of the air compressor achieve or maintain an air pressure of at least 380 kPa (55 psi)	or ability to
ANSWER CHOICES:	
True	
False	X
Refer to if wrong answer: DHV page 421.	



QUESTION: 17	
It's a minor defect if, the compressor starts up at a pressure less than or equal to 550 kPa (80 psi).	
ANSWER CHOICES:	
True	X
False	
Refer to if wrong answer: DHV page 423	

Lesson: 2.2.6

QUESTION: 18	
What are the uses of the auxiliary brake system (retarder)?	
ANSWER CHOICE: Only one answer possible Several possible answers X	
A) Additional braking capacity	X
B) Serves to slow us down a steep upward slope	
C) Allows you to change gears more slowly	
D) Downhill speed control.	X
Refer to if wrong answer: Lesson 2.2.6 Student workbook.	



QUESTION: 19	
How can the auxiliary brake be cancelled?	
ANSWER CHOICE: Only one answer possible Several possible answers X	
A) Through the switches	X
B) By pressing the clutch release (or clutch) pedal	X
C) By pressing the accelerator pedal	X
D) Through the brake pedal	
Refer to if wrong answer: Lesson 2.2.6 Student workbook.	

Lesson : 2.2.6

QUESTION: 20	
There are no restrictions on using auxiliary brakes on icy pavement.	
TRUE	
FALSE	Х
Refer to if wrong answer: Lesson 2.2.6 Student Notebook.	



QUESTION: 21

From the following illustrations, identify the air compressor.

ANSWER CHOICE: Only one possible answer **X**Several possible answers

A) B)

C)

D)









Refer to if wrong answer: Lesson 2.4.1 of the student workbook.

QUESTION: 22

Identify the part that start and stop the air compressor.

ANSWER CHOICE: Only one possible answer **X**Several possible answers

A)

B)

C)

D)










Refer to if wrong answer: Lesson 2.4.1 of the student workbook.

QUESTION: 23

Identify the part that contains the parking spring.


ANSWER CHOICE: Only one possible answer **X**Several possible answers





Refer to if wrong answer: Lesson 2.4.1 from the student's workbook.

Lesson: 2.4.1





Lesson	2	4	1
LC22011	∠.	4	. 1

QUESTION: 25	
This control releases the tractor's parking brake when pressed.	RAILER SUPPLY FOR PARKING Bendity
TRUE	
FALSE	X
Refer to if wrong answer: Lesson 2.4.1 of the student workbook.	
Lesson : 2.4.1	
QUESTION: 26	
The supply tank stores the compressed air from the compresupplies the primary and secondary service tanks.	essor and then
TRUE	Х
FALSE	
Refer to if wrong answer: Lesson 2.4.1 of the student workbook.	



_esson : 2.4.1	
QUESTION: 27	
The parking brake is also the emergency brake and works mechanically.	
:	
True	X
False	
Refer to if wrong answer: Lesson 2.4.1 of the student workbook	
_esson : 2.4.1	
QUESTION: 28	
The parking brake must be applied for the air leak test.	
True	
False	X
Refer to if wrong answer: Lesson 2.4.1 of the student workbook.	•
_esson : 2.4.1	
QUESTION: 29 When the vehicle speed is doubled, the braking distance is twice a	as long.
True	

Refer to if wrong answer: Lesson 2.4.1 from the student workbook, DHV 108.




X

False

QUESTION: 30 Using the diagram below, identify the green part of the circuits? ANSWER CHOICE: Only one possible answer X Several possible answers A) The service brake part X B) The parking brake part C) The service and parking brake part D) The compressor part Refer to if wrong answer: Lesson 2.4.1 of the student workbook.







QUESTION: 32	
How can tire wear be determined?	
ANSWER CHOICE: Only one possible answer X Several possible answers	
A) By looking at the tire	
B) With the wear indicator on the tread	X
C) With a pressure gauge	
D) With a \$0.10 coin	
Refer to if wrong answer: Lesson 2.5.2 from the student's workbook.	·

33- Explain in your own words what the term pyrolysis means.

Pyrolysis is the invisible decomposition of a tire, which can lead to a tire blowout.

Refer to if wrong answer: **Lesson 2.5.2 from the student workbook.**

34- Identify at least two situations that could cause the pyrolysis of a tire.

Overheating of the brakes;

Driving long distances with underinflated tires;

Overload

Refer to if wrong answer: Lesson 2.5.2 from the student workbook.

35- Explain in your own words, why the inflation pressure of 11R22.5 truck tires can be different from one company to another.

Because this pressure reflects the value of the loads transported by the different companies.

Refer to if wrong answer: **Lesson 2.5.2 from the student workbook.**



36- On a wideband tyre with dimensions 445 / 50 R 22.5, what does the number 445 represent?

The width of the tread.

Refer to if wrong answer: **Lesson 2.5.2 of the student workbook.**

37- Say in your words, what is the visual difference between the tires #1: 445 / 50 R 22.5, and tire #2: 455 / 55 R 22.5.

Tire #2 is wider and higher.

Refer to if wrong answer: Lesson 2.5.2 from the student workbook.

QUESTION: 38 The maximum inflation pressure of a tire is indicated on the manufacturer.	sidewall by the
TRUE	X
FALSE	
Refer to if wrong answer: The maximum inflation pressure of a tire is indicated on the sidewall by the manufacturer. This indication can also be found in the door frame of the truck. Lesson 2.5.2 from the student's workbook.	



QUESTION: 39	
Identify the most reliable way to find the load capacity of a tire?	
ANSWER CHOICE: Only one possible answer X Several possible answers	
A) Check in the vehicle door frame.	
B) Check the tire manufacturer's book	
C) Using a hammer or light mass	
D) Check on the Internet	
E) Check on the sidewall of the tire	X
Refer to if wrong answer: Lesson 2.5.2 from the student's workbook.	

QUESTION 40: From the following actions below, which one should you do to power steering system.	safeguard the
ANSWER CHOICE: Only one possible answer X Several possible answers	
A) Avoid turning the steering wheel when the truck is stationary.	
B) Ensure proper lubrication of the fifth wheel.	
C) Avoid turning the steering wheel to the maximum on either side and holding it, thus forcing it into position.	
D) All of the above	X
Refer to if wrong answer: Lesson 2.5.1 from the student's workbook.	



QUESTION 41: What is the colour of a typical power steering oil in heavy vehicles?		
ANSWER CHOICE: Only one possible answer X Several possible answers		
A) Red	X	
B) Blue		
C) Golden		
D) None of these answers		
Refer to if wrong answer: Lesson 2.5.1 from the student's workbook.		


Lesson : 2.5.3

QUESTION 42: What is the manufacturer's recommended torque for a disc wheel nut?	
ANSWER CHOICE: Only one possible answer X Several possible answers	
A) 250 lb/po	
B) 300 à 350 lb/pi	
C) 350 à 400 lb/pi	
D) 450 à 500 lb/pi	X
Refer to if wrong answer: Lesson 2.5.3 in the Student Notebook.	



QUESTION: 43

This label is attached to the yellow brake button of a vehicle.





What is it?

Answer:

Two wheels have just been installed on this vehicle. The driver is responsible for tightening these two wheels before 100 km.

Refer to if wrong answer: Lesson 2.5.3 from the student workbook.

Lesson: 2.1.2

Question 44: When a yellow warning light comes on in the dashboard, you must stop driving with the vehicle as soon as possible.	
TRUE	
FALSE	Х
Refer to if wrong answer: Lesson 2.1.2 from the student's workbook.	

