

P3898

Fault code description

EAS-3 actuator ECU - Voltage too high on ECU (D375) pin (B6) or pin (B7) or pin (B8)

Possible cause

1. Battery voltage too high.
2. A damaged alternator causing a high voltage
3. Improperly connected batteries.

Additional information

There are four battery inputs into the connectors that provide un-switched battery supply to the EAS-3 actuator. To reduce the possibility of damaging a new ECU, all other active fault codes must be investigated prior to replacing the ECU.

DEF injection into the SCR system is disabled.

Set condition of fault code

This diagnostic runs continuously.

EAS-3 supply voltage is above the maximum system voltage level.

Reset condition of fault code

This fault code will change to inactive immediately after the diagnostic runs and passes.

M027986 - 07/23/2015 02:11:17

This information applies exclusively to the entered chassis number or the selected engine type. Please take into account that this information may change daily. Therefore the provided information is only valid on 12-19-2015. You cannot derive any rights from the information provided with respect to vehicles and/or components of another series, with another chassis number, and/or of another date. (/)

P3898, Diagnostic information

Technical data

["Power supply and earth of EAS-3 actuator \(D375\)"](#)

["CAN connection. EAS-3 actuator \(D375\)"](#)

Location of component(s)

["Location information. EAS-3"](#)

Electrical diagram(s)

Refer to the OEM service manual for more information.

Description of component(s)

-

Block diagram

["Block diagram EAS-3"](#)

Step by step troubleshooting



Please perform the troubleshooting steps below by utilising the breakout harness if necessary to check electrical components such as sensors, electrical control units or harnesses. Back probing is not recommended as it could damage the harness. The ignition should always be in the OFF position when connecting or disconnecting electrical components to reduce the likelihood of damage to electrical components.



- Disconnecting the EAS connectors during the troubleshooting process will result in multiple errors.
- For specific electrical component information and pin out locations, always refer to the technical data.
- It is necessary to exit the fault

code menu in DAVIE and run the diagnostic test again to identify a change in errors.

- Remember that the truck's operational or mechanical issues may be the root cause of both active and inactive fault codes. Refer to the 'possible causes' section.

Step by step 1: Check fault codes

Step 1A: Check for fault codes

Troubleshooting steps

1. Turn the key switch ON.
2. Use DAVIE to check for fault codes.

Is fault code P3898 active?

- Yes – Proceed to step 2A
- No – Proceed to step 4A

Step by step 2: Check the EAS-3 actuator and the harness

Step 2A: Inspect the EAS-3 actuator and the harness connector pins

Troubleshooting steps

1. Turn the key switch OFF.
2. Disconnect the EAS-3 actuator from the harness.
3. Inspect the harness and EAS-3 actuator connector for:
 1. corroded or dirty pins
 2. damaged pins
 3. pushed back or expanded pins
 4. loose connector
 5. moisture in or on the connector
 6. connector shell damaged
 7. missing or damaged connector seals

8. wire insulation damage

Dirty or damaged pins/connector?

- **Yes** – A dirty or damaged connection has been detected. Clean, repair or replace the damaged connection or harness if possible
- Proceed to step 4A
- **No** – Proceed to step 2B

Step 2B: Check the voltage to the EAS-3 actuator

Troubleshooting steps

1. Turn the key switch OFF.
2. Disconnect the EAS-3 actuator from the harness.
3. Check the power supply and return circuit to the EAS-3 actuator.
4. Measure the voltage between the EAS-3 actuator battery supply circuit and return circuit at the EAS-3 connector.



Check the voltage at key ON, while cranking the engine and with the engine running at idle.

Is the voltage less than 18 VDC?

- **Yes** – Proceed to step 4A
- **No** – Proceed to step 3A

Step by step 3: Check the alternator

Step 3A: Check the alternator

Troubleshooting steps

1. Turn the key switch OFF.
2. Use an ammeter to measure the charging amperes.
3. Start the engine and check the alternator charging rate.



Check the charging rate according to the OEM specifications

Is the alternator charging within the specifications?

- **Yes** – Proceed to step 4A
- **No** – Repair or replace the alternator/regulator. Refer to the OEM manual. Proceed to step 4A

Step by step 4: Clear the fault code

Step 4A: Disable the fault code

Troubleshooting steps

1. Connect all components.
2. Operate the system within the 'reset condition of the fault code' found in the fault code information.
3. Use DAVIE to verify if the fault codes are inactive.

Is fault code P3898 inactive?

- **Yes** – Proceed to step 4B
- **No** – Return to the troubleshooting steps. Proceed to step 1A

If all the steps have been completed and checked again, contact the Engine Support Center for further instructions.

Step 4B: Clear the inactive fault codes

Troubleshooting steps

1. Connect all components
2. Turn the key switch ON.
3. Use DAVIE to clear the inactive fault codes.

Have all the fault codes been cleared?

- **Yes** – Repair complete
- **No** – Troubleshoot any remaining active fault codes

M046845 - 07/23/2015 02:16:49

may change daily. Therefore the provided information is only valid on 12-19-2015. You cannot derive any rights from the information provided with respect to vehicles and/or components of another series, with another chassis number, and/or of another date. (/)