

P1707

Fault code description

Lambda - Data valid but too high

Possible cause

1. Faulty lambda sensor (F834)
2. Faulty NOx sensor (F844)

Additional information

Monitoring of the difference between the air/fuel ratio sensor signal and the air/fuel ratio derived from the NOx sensor

Set condition of fault code

This diagnostic starts when the coolant temperature is above 122°F (50°C) and it runs continuously.

Reset condition of fault code

This fault code will change to inactive immediately after the diagnostic runs and passes.

M027741 - 07/22/2015 19:18:37

This information applies exclusively to the entered chassis number or the selected engine type. Please take into account that this information may change daily. Therefore the provided information is only valid on 12-14-2015. You cannot derive any rights from the information provided with respect to vehicles and/or components of another series, with another chassis number, and/or of another date. (/)

P1707, Diagnostic information

Technical data

["Sensor, lambda \(F834\)"](#)

["Sensor, NOx before catalyst \(F844\)"](#)

Location of component(s)

["Location information, PMCI-2"](#)

Electrical diagram(s)

["PMCI-2"](#)

Description of component(s)

["Lambda sensor \(F834\)"](#)

["Sensor, NOx before catalyst \(F844\)"](#)

Block diagram

["PMCI-2"](#)

M046570 - 07/22/2015 16:07:08

This information applies exclusively to the entered chassis number or the selected engine type. Please take into account that this information may change daily. Therefore the provided information is only valid on 12-14-2015. You cannot derive any rights from the information provided with respect to vehicles and/or components of another series, with another chassis number, and/or of another date. (/)